

# FUJIFILM

## Frontier DX400 Series User's Guide



**3rd Edition**

DX400EUN23JUNEN

## Caution

- Unauthorized transfer or duplication of all or any part of the content of this manual is strictly prohibited.
- The contents of this manual are subject to change without prior notice.
- If you have any concerns, in regard to unclear points, errors, or printing omissions, etc. in this manual, please contact FUJIFILM.
- Notwithstanding the preceding paragraph, please note that we cannot bear liability in regard to the effects of operational results.
- Please note that we cannot bear liability for damages, etc. which are generated due to the product being handled without the contents in this manual being followed, it being used inappropriately, it being repaired or modified, etc. by FUJIFILM, or third parties other than those who are specified by FUJIFILM.

## FUJIFILM recommends genuine ink supply units.

FUJIFILM recommends using genuine FUJIFILM ink supply units in order to fully exercise the printer's performance. If products other than genuine products are used, the printer unit and print quality may be adversely affected, etc., and the printer may not be able to exercise its performance. FUJIFILM cannot guarantee the quality and reliability of products other than genuine products. There will be charges for repairs for damages and malfunctions of the main unit which are generated due to the usage of non-genuine products even if they occur within the warranty period.

## Meaning of Symbols

### Safety Marking

This manual uses the following symbols to warn you of dangerous operations or handling cautions to prevent injury to people and damage to properties. Make sure you have a good understanding of these symbols before reading on.



### **WARNING**

**Warnings must be followed to avoid serious bodily injury.**



### **CAUTION**

**Cautions must be followed to avoid damage to this product or bodily injury.**

## Labels Regarding General Information




### **Important**

Important must be followed to avoid damage to this product.

### **Note:**

Notes contain important information on the operation of this product.

 Indicates the reference pages for the related contents.

**Settings** The character strings displayed on the computer screen are enclosed in [ ].

## Screens

- The screenshots in this document may be slightly different from the actual screens. Also note that a different screen may be displayed due to different operating systems or operating environment.
- The Windows screen captures used in this document are based on Windows 10 unless otherwise specified.

## Trademarks

Microsoft® and Windows® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe, Photoshop, Photoshop Elements, Illustrator, Acrobat Reader are registered trademarks of Adobe Inc.

Other company names or product names are registered trademarks or trademarks of each company.

## Copyrights

Permission from the copyright holders is required for reproducing copyrighted works such as photographs, books, maps, drawings, paintings, prints, music, movies, programs, etc., except for personal usage (within a scope which is restricted to conforming to anything other than this at home).

## For the customers in Europe

### WEEE symbol

The crossed dustbin symbol on the device means that it should not be disposed of with other household wastes at the end of its working life. Instead, the device should be taken to the waste collection centres for activation of the treatment, collection, recycling and disposal procedure.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of the wastes and recycle it responsibly to promote the sustainable reuse of the material resources.

Household users should contact either the retailer where they purchased this product or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the term and conditions of the purchase contract.

This product should not be mixed with other commercial wastes for disposal.



## Information of electromagnetic interference

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## Information for traceability in Europe

### Manufacturer: FUJIFILM Corporation

7-3, Akasaka 9-Chome, Minato-ku, Tokyo  
Japan

### Authorized representative in Europe: FUJIFILM Europe GmbH

Balcke-Duerr-Allee 6, 40882 Ratingen  
Germany

### EU Importer: FUJIFILM Europe B.V.

Oudenstaart 1, 5047 TK Tilburg  
The Netherlands

### UK Importer: FUJIFILM UK Limited

Fujifilm House, Whitbread Way, Bedford,  
Bedfordshire, MK42 0ZE  
United Kingdom

## For the customers in Turkey

EEE Yöemeliğine Uygunudur.

## For the customers in Taiwan

警告

為避免電磁干擾，本產品不應安裝或使用於住宅環境。

商品名稱：噴墨列印機

FUJIFILM

型號：FrontierDX400W

電壓：100-240V 電流：1.4A

頻率：50-60Hz

進口商：恆昶實業股份有限公司

地址：台北市民權東路6段38號

電話：(02) 2791-1188

生產國別：菲律賓

製造年份：2024



R33950  
RoHS

設備名稱：噴墨列印機/ Piezoelectric inkjet system，型號（型式）： DX400 ，Frontier DX400W Equipment Type designation (Type)						
單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols					
	鉛Lead (Pb)	汞Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr <sup>+6</sup> )	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominate d diphenyl ethers (PBDE)
機箱, 塑料外殼 (Chassis, Plastic shell)	○	○	○	○	○	○
列印配線板, 電路板 (Printing wiring board, Circuit board)	—	○	○	○	○	○
電源線, 電線 (Power cord, Wire)	○	○	○	○	○	○
內部組件 (Internal components)	—	○	○	○	○	○
金屬組件 (Metal components)	—	○	○	○	○	○
<p>備考1. “超出0.1 wt %”及“超出0.01 wt %”係指限用物質之百分比含量超出百分比含量基準值。  Note 1 : “Exceeding 0.1 wt %” and “exceeding 0.01 wt %” indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.</p> <p>備考2. “○”係指該項限用物質之百分比含量未超出百分比含量基準值。  Note 2 : “○” indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.</p> <p>備考3. “—”係指該項限用物質為排除項目。  Note 3 : The “—” indicates that the restricted substance corresponds to the exemption.</p>						

# Table of Contents

Caution .....	2	Basic Operations .....	24
FUJIFILM recommends genuine ink supply units...	2	Notes When Loading/Replacing Paper .....	24
Meaning of Symbols .....	2	Notes when Loading Roll Paper.....	24
Safety Marking .....	2	How to Replace Roll Paper .....	25
Labels Regarding General Information .....	2	Preparing to Replace Paper .....	25
Screens .....	2	Removing the Spindle Unit.....	25
Trademarks .....	3	Removing the Roll Paper .....	26
Copyrights .....	3	Attaching the Roll Paper.....	26
For the customers in Europe .....	3	Installing the Spindle Unit.....	28
WEEE symbol .....	3	How to Load Sheet Paper .....	31
Information of electromagnetic interference .....	3	Loading in the Paper Feed Unit.....	31
Information for traceability in Europe.....	3	When Paper is Loaded in the Sheet Feeder ..	32
For the customers in Turkey.....	3	Loading in the Sheet Feeder (Option).....	32
For the customers in Taiwan.....	3		
		<b>Basic Printing Methods (Windows).....</b>	<b>35</b>
<b>Before Use.....</b>	<b>7</b>	How to Print from Photoshop .....	35
Difference between DX400 and DX400W and		How to Cancel Printing (from the Computer) .....	38
how to identify .....	7	How to Cancel Printing (from the Printer).....	39
Printer Parts .....	7		
Front .....	7	<b>Printing Using Various Print Functions .....</b>	<b>40</b>
Rear.....	9	Color Management.....	40
Feeding Unit.....	10	Color Management Settings.....	40
Platen Area.....	11	Setting Colors Manually .....	40
Spindle Unit.....	12	Color Management from the Application	
Control Panel.....	13	(No Color Management).....	42
Understanding and Operating the Display .....	14	Color Management from the Printer Driver	
Home Screen .....	14	(ICM) (Windows) .....	43
Text Input Screen .....	15	Borderless Printing on All Sides .....	44
Notes on Usage.....	16	Types of Borderless Printing Methods.....	44
Notes when Handling the Main Unit.....	16	Setting Procedure.....	45
Notes on Paper .....	16	Printing on Paper of Non-Standard Sizes .....	46
Notes on Handling.....	16	Settings on Windows.....	46
Paper that cannot be used .....	17	Double-Sided Printing .....	47
Notes before Loading Paper .....	17	Settings on Windows.....	47
Notes on storage .....	18		
Notes on Printing.....	18	<b>Maintenance .....</b>	<b>48</b>
Storing and displaying printouts .....	18	List of Maintenance Items .....	48
Notes on Handling Ink Supply Units.....	18	Disposal of Used Consumables .....	49
Introducing the Software .....	19	Precautions Regarding Maintenance .....	49
Wired LAN connection.....	20	Replacing Ink Supply Units .....	50
Installing Printer Driver and Maintenance Tool ...	21	Replacing Maintenance Cartridge .....	52
Installing the Printer Driver .....	21	Emptying the Scrap Paper Box .....	53
Installing the Maintenance Tool .....	21	Cleaning Airflow Vents.....	54
Printer Driver Functions.....	22	Cleaning the Platen and Roll Paper Unit.....	54
Firmware update .....	22	How to Clean the Platen.....	54
Uninstalling Software.....	23	How to Clean the Roll Paper Unit.....	55
Windows.....	23	Cleaning and Replacing the Rollers in the	
		Sheet Feeder (Option).....	56
		Notes on Handling Rollers.....	56
		Replacing Feed Rollers .....	56
		Cleaning the Feed Rollers and Transfer	
		Rollers .....	59
		Maintenance Functions That Can Be Executed	
		from the Printer.....	62
		Print Head Nozzle Check and Cleaning .....	62
		Powerful Cleaning .....	63

<b>Using the Maintenance Tool (Windows) ...</b>	<b>64</b>	<b>Appendix.....</b>	<b>109</b>
Summary of the Maintenance Tool.....	64	Optional Accessories and Consumables.....	109
Starting and Closing.....	64	Optional Accessories.....	109
Explanation of the Main Screen.....	65	Consumables.....	109
Explanation of the Printer settings.....	67	Moving and Transporting the Printer.....	111
Explanation of the System Environment		Moving the Printer.....	111
Settings Screen.....	71	Transport.....	112
Printer Maintenance.....	72	System Requirements.....	113
Maintenance Operations.....	72	Printer Driver.....	113
Nozzle Check Methods.....	72	Maintenance Tool.....	113
Print Nozzle Check Pattern Method.....	73	Specifications Table.....	114
Print Head Cleaning Method.....	74	Basic specifications.....	114
Print Head Alignment Method.....	75	Electrical Specifications.....	114
Paper Feed Adjustment Method.....	76	Interface Specifications.....	114
		Roll paper unit Specifications.....	114
		Paper feed unit Specifications.....	115
		Output tray Specifications.....	115
		Ink Specifications.....	115
		General Specifications.....	115
		Sheet feeder Specifications.....	116
		Necessary Space.....	116
		<b>FUJIFILM END USER SOFTWARE LICENSE</b>	
		<b>AGREEMENT.....</b>	<b>117</b>
		<b>OPEN SOURCE SOFTWARE LICENSE</b>	
		<b>TERMS.....</b>	<b>121</b>
		Boost Software License - Version 1.0 -	
		August 17th, 2003.....	121
		Inno Setup License.....	121
		7-Zip Command line version.....	122
		GNU LESSER GENERAL PUBLIC	
		LICENSE Version 2.1, February 1999.....	122
		PDFsharp License.....	128
		HTML-Renderer / LICENSE.....	129
		AdobeRGB.....	129
		libpng-LICENSE.....	131
		Zlib.....	133
<b>Adding Paper Information from Custom</b>			
<b>Settings (Windows Only).....</b>	<b>78</b>		
<b>Control Panel Menu.....</b>	<b>80</b>		
Menu List.....	80		
Settings.....	80		
Details of the Menu.....	82		
<b>Problem Solver.....</b>	<b>85</b>		
When a Message Is Displayed.....	85		
Messages Displayed on the Printer.....	85		
Maintenance Tool Error Codes and			
Messages.....	88		
Error Messages (Windows).....	91		
Troubleshooting.....	92		
When Paper Jams.....	92		
You Cannot Print			
(Because the Printer Does Not Work).....	105		
The Printer Sounds Like It Is Printing, but			
Nothing Prints.....	105		
Cannot Do Borderless Printing.....	106		
The Prints Are Not What You Expected.....	106		
Trouble when Printing from a Cassette.....	107		
Troubles when Cutting Roll Paper.....	108		
Others.....	108		
If Troubles Are Not Resolved.....	108		


## Before Use

### Difference between DX400 and DX400W and how to identify

The DX400 has a USB 2.0 interface, while the DX400W had both USB 2.0 and network LAN interfaces. To identify the model, please refer to the rating plate located at the rear of the printer.

### Printer Parts


#### Front



When the optional sheet feeder is installed



While the scrap paper box is removed and the ink supply unit cover is open



#### ① Printer cover

Remove when doing maintenance or removing paper jams.

#### ② Rear paper feed slot cover

Open this cover when loading sheet paper to print from the rear paper feed slot.

#### ③ Status display light

This light indicates when the printer's status is normal or if an error has occurred.

#### 4 Ink supply unit cover (left)

Open to replace ink supply unit.

 [“Replacing Ink Supply Units” \(Page 50\)](#)

#### 5 Security slot

Located alongside the ink supply unit cover.

Insert a commercially available security cable and lock to prevent theft of the printer and to lock the ink supply unit cover.

#### 6 Scrap paper box

Scraps cut from roll paper while printing are collected here. Be sure to dispose of scrap paper when you replace the roll paper. Also, remove it when loading or removing roll paper.

 [“Emptying the Scrap Paper Box” \(Page 53\)](#)

#### 7 Output tray

The output tray is integrated with the scrap paper box.

Printed paper is collected on the output tray. To use it, pull it out toward you and raise the front end.

See the following for how many sheets of paper can accumulate on the tray.

 [“Specifications Table” \(Page 114\)](#)

Also, until paper that has been printed on has sufficiently dried, do not leave it stacked up for a long time. If paper that has not dried is left stacked up for a long time, the colors in the parts that overlap could change. See the following for more details.

 [“Notes on Paper” \(Page 16\)](#)

#### 8 Ink supply unit cover (right)

Open to replace the ink supply unit and maintenance cartridge.

 [“Replacing Ink Supply Units” \(Page 50\)](#)

 [“Replacing Maintenance Cartridge” \(Page 52\)](#)

#### 9 Control panel

 [“Control Panel” \(Page 13\)](#)

#### 10 Ink supply unit

For loading 6 colors of ink supply units.

 [“Replacing Ink Supply Units” \(Page 50\)](#)

#### 11 Ink supply unit tray

The colors on the labels indicate which ink supply unit is installed. Load all of the ink supply unit trays in the printer.

The ink supply unit trays are common parts, so they can be used the same with any color ink.

#### 12 Roll paper unit


Pull this out toward you to remove the spindle.

If the back side of printed roll paper is dirty, clean the roll paper unit.

 [“Cleaning the Platen and Roll Paper Unit” \(Page 54\)](#)

#### 13 Maintenance cartridge

Container that holds the waste ink fluid.


 [“Replacing Maintenance Cartridge” \(Page 52\)](#)

#### 14 Cassette

For loading sheet paper.



## Rear



### 1 Airflow vents

Air passes through these to adjust the temperature of the inside of the printer. There are multiple airflow vents. Do not obstruct any of the airflow vents.

### 2 AC inlet

Connects the power cord to the printer.

### 3 LAN port \*Only available on DX400W

Connects the LAN cable.

Note\* The LAN Port on the DX400 is inactive and cannot be activated even with firmware upgrades.

### 4 USB port

Connect the USB cable here.

### 5 Paper feed unit

Open this cover to load sheet paper into the rear paper feed slot. Close this cover when not using the rear paper feed slot. Remove when doing maintenance or removing paper jams.

### 6 Lock lever

This lever releases the lock for removing the paper feed unit.

### 7 Rear cover

Open when doing maintenance or removing paper jams.

### 8 Lock lever

This lever releases the lock for opening the rear cover.

### 9 Feed rollers

The sheet paper that are loaded in the cassette are fed via these rollers. When assembling the sheet feeder, install the feed rollers before using the machine.

The feed rollers need to be replaced according to the type of sheet paper being used. Also, if paper feeding problems occur repeatedly, clean and wipe any dirt from the surface of the rollers.

See the following for more details.

 [“Cleaning and Replacing the Rollers in the Sheet Feeder \(Option\)” \(Page 56\)](#)


### 10 Transfer rollers

Sheet paper that are fed from the cassette are transferred to the platen via these rollers. If paper feeding problems occur repeatedly, clean and wipe any dirt from the surface of the rollers. See the following for more details.


 “Cleaning and Replacing the Rollers in the Sheet Feeder (Option)” (Page 56)

## Feeding Unit


Roll paper unit



Paper feed unit



Cassette  
(when the optional sheet feeder is installed)



### 1 Spindle unit

For loading roll paper.

### 2 Handle

Turn this to rewind roll paper to the spindle unit.

### 3 Edge guide

Align them with the edges of the paper when loading paper.

### 4 Paper slot

Insert the leading edge of the roll paper to load it.

## Platen Area



### ❶ Print head unit


The print head prints by moving left and right while emitting ink. Do not move the print head unit manually with too much force. Otherwise, it may break down.

### ❷ Platen

Clean the platen if the back of printed paper is dirty.

👉 [“Cleaning the Platen and Roll Paper Unit” \(Page 54\)](#)

## Spindle Unit



### ❶ Media edge guide

Insert into the roll paper's left and right ends to secure it. The media edge guides are the same on the left and right.


### ❷ Knob

Secures/releases the media edge guides, which are mounted on the spindle.

### ❸ Spindle

Insert into the roll core of the roll paper. When loading onto the printer, engage the gear on the right side so the rotation can be controlled from the printer.

## Control Panel



### ❶ ⏻ button (power button), ⏻ light (power light)

This is normally on (the light is lit) during use. If an emergency occurs, or when the printer is not going to be used for an extended period, turn this off (the light turns off). The light flashes while the printer is operating.

### ❷ 📄 button (take-up button)

Press to replace the roll paper. The roll paper is wound back to the replacement position.

### ❸ 🏠 button (home button)

Press this, such as when a settings menu is displayed, to return to the Home screen.

### ❹ Screen

Displays the printer's status, menus, and error messages.

### ❺ ↶ button (back button)

Press to go back up one level in the displayed settings menu.

### ❻ ▲/▼/◀/▶ buttons (arrow buttons)

Press when selecting items or entering text in settings menus.

### ❼ OK button


Press to execute functions, and to apply selections and inputs.

### ❽ 🛑 button (stop button)

Press to stop operations.

## Understanding and Operating the Display

### Home Screen



#### 1 Ink information

The statuses and estimates of ink levels are shown by horizontal bar displays. As the amount of ink runs low, the bar display becomes shorter.

The code to the left of the bar display indicates the ink color.

K : Black

C : Cyan

P : Pink

SB : Sky Blue

M : Magenta

Y : Yellow

Icons are displayed as notification of the following statuses.

⚠ : Ink is running low.

✖ : Ink Level is below the minimum value. Replace the ink supply unit with a new one.

👉 [“Replacing Ink Supply Units” \(Page 50\)](#)

#### 2 Settings menu

Set the printer and execute maintenance functions.

Press the [OK] button to go to the next screen.

👉 [“Control Panel Menu” \(Page 80\)](#)

#### 3 Operation Button Guide

Buttons that can be operated appear as icons. This example shows you can go to a selected menu by using the [OK] button.

#### 4 Maintenance cartridge information

The status and estimate of the approximate amount of space in the maintenance cartridge are shown by a vertical bar display. As the amount of available space decreases, the bar display becomes shorter.

Icons are displayed as notification of the following statuses.

⚠ : Available space is running low.

✖ : There is no available space in the maintenance cartridge. Replace the maintenance cartridge with a new one.

👉 [“Replacing Maintenance Cartridge” \(Page 52\)](#)

#### 5 Network Status **\*Only available on DX400W**


The network connection statuses are shown by icons.

🔌 : Wired LAN is not connected, network is not set.

🌐 : Wired LAN is connected

## Text Input Screen

To enter characters and symbols for network settings from the control panel, use the ▲/▼/◀/▶ buttons and the software keyboard on the screen. Press the ▲/▼/◀/▶ button to select a character or function button on the keyboard, and then press the [OK] button. When you have finished entering characters, select [OK], and then press the [OK] button.



- ◀ ▶ : Moves the cursor to the left or right.
- A1# : Switches the character type. You can enter alphanumerics or symbols.
- ␣ : Enters a space.
- ✖ : Deletes a character to the left (backspace).
- OK : Enters the selected characters.

**The initial administrator password is the serial number. We request that you be sure to change the administrator password at the time of installation.**

## Notes on Usage

### Notes when Handling the Main Unit

- Do not suddenly change the temperature in the room where the printer is installed. If the temperature changes suddenly, drops of water (condensation) could occur inside the printer which may have an adverse effect on operations.
- Use the printer in an environment with a temperature of 10 to 35 °C, and a humidity of 20 to 80%. When the printer is placed on a system rack, make sure the environment of the rack is within these ranges. Even when the conditions above are met, you may not be able to print properly if the environmental conditions are not suitable for the paper. Be sure to use the printer in an environment where the paper's requirements are met. Also, when operating in dry areas, air conditioned environment, or under direct sunlight, maintain the appropriate humidity.
- Do not place any containers containing water, such as vases or cups, on the printer. If water enters the printer, it may break down. Also, do not put any heavy objects on the printer.
- The printer is equipped with several airflow vents. The airflow vents allow air to go in and out of the printer. Do not block these airflow vents by placing any objects near them, or by covering them with film sheets or paper.
- Do not use accessories designed for this printer with any other products.
- If the printer's covers are opened during printing, a safety mechanism is activated and printing is stopped automatically. Do not turn off the printer in this condition. This could cause the print head nozzles to dry and print quality to decline.
- Depending on the performance of the computer being used, the printer stops printing temporarily; however, this is not a malfunction.
- If the printer is not used for an extended period of time, make sure you leave the ink supply units and maintenance cartridge installed.
- Do not leave the printer for more than three days in a state in which the power was not turned off correctly, such as due to a power outage. Roll paper may curl which could cause a decline in printer performance.

### Notes on Paper

Note the following points when handling and storing the paper. If the paper is not in good condition, print quality may decline.

Check the documentation supplied with each paper.

### Notes on Handling

Use paper recommended by our company.





Note the following points when handling paper.

- Use special media under normal room conditions (temperature: 15 to 25 °C, humidity: 40 to 60%).
- Do not fold the paper or scratch the surface of the paper.
- Avoid touching the printable surface of the paper with your bare hands. Moisture and oil from hands can have an adverse effect on the print quality.
- Handle paper by the edges of the paper. We recommend wearing cotton gloves.
- Do not throw away the paper packaging as you can use it for storing the paper.
- If roll paper is left loaded on the printer, the leading edge of the paper may curl and print quality may decline. We recommend removing roll paper from the printer when it is not in use.



## Paper that cannot be used

Do not load paper as described below. Doing so could cause paper jams and dirty printouts.

<ul style="list-style-type: none"> <li>• Paper that is wavy</li> <li>• Paper that is torn</li> <li>• Paper that is cut</li> <li>• Paper that is too thick</li> <li>• Paper that is too thin</li> <li>• Paper that is hard</li> </ul>	
<ul style="list-style-type: none"> <li>• Paper that has folded corners</li> <li>• Paper that is creased</li> </ul>	
<ul style="list-style-type: none"> <li>• Paper that has been rolled up</li> <li>• Paper that has been folded</li> </ul>	
<ul style="list-style-type: none"> <li>• Paper on which stickers, etc., have been stuck</li> <li>• Paper that is damp</li> </ul>	

## Notes before Loading Paper

When using the sheet feeder (option), before loading paper in the cassette, carefully riffle the stack of paper so the sheets do not stick together, and then align all four edges.

How to riffle  [“Loading in the Sheet Feeder \(Option\)” \(Page 32\)](#)

## Notes on storage

- Do not throw away the paper packaging as you can use it for storing the paper.
- Avoid locations that are subject to direct sunlight, excessive heat, or humidity.
- Keep sheet paper in their original package after opening, and keep them in a flat place.
- Remove roll paper that is not in use from the spindle unit. Rewind it correctly and then store it in the original packaging that came with the roll paper. If you leave the roll paper in the printer for a long time, its quality may decline.
- We recommend removing roll paper from the printer if you are continuously using sheet paper. The back side of the roll paper may become dirty due to the increased amount of ink mist inside the printer, which sticks to the back of the roll paper. However, if [Auto Nozzle Check Settings] is set to [High quality], then leave the roll paper loaded. In this case, it will not become sheet paper dirty because check patterns are periodically printed on the roll paper.

## Notes on Printing

Make sure that the leading edge of the paper is perpendicular to the long side and cut completely straight.

## Storing and displaying printouts




- Make sure you do not rub or scratch the printed side.
- Make sure the print outs are completely dry before folding or stacking; otherwise, the color may change where they touch (leaves a mark). These marks will disappear if they are separated immediately and dried; however, they will remain if not separated.
- Do not use a dryer to dry the print outs.
- Avoid locations that are subject to high temperature, humidity, and direct sunlight, and store in a dark place.
- Avoid displaying print outs outdoors or in direct sunlight. This may accelerate the fading.
- When displaying print outs indoors, we recommend placing them in glass frames and so on. This allows you to display your print outs for a long time without them fading.

## Notes on Handling Ink Supply Units

- Store the ink supply units away from direct sunlight at room temperature.
- To ensure print quality, we recommend using all the ink before the earlier of the following dates:
  - Recommended use-by-date printed on the package of the ink supply unit
  - Within one year after installing the ink supply unit to the printer.
- If ink supply units have been stored in a cold place for a long time, leave them at room temperature for more than 3 hours before use.
- The ink level and other data are stored in the IC chip, allowing ink supply units to be used after being removed and replaced.
- Store ink supply units that are removed before all the ink has been used so that dust does not get on the ink supply ports. The ink supply port has a valve in it so it does not need to be capped.
- Removed ink supply units may have ink around the ink supply port, so be careful not to get any ink on the surrounding area.
- Do not touch the IC chip of the ink supply unit. Doing so may prevent normal operation and printing.
- Do not subject ink supply units to extreme shock, such as by dropping them. Ink may leak from the ink supply units.
- Even while nothing is printed, the printer uses ink from all ink supply units during head cleaning and other maintenance operations to keep the print head in good condition.
- Although the ink supply units may contain recycled materials, this does not affect printer function or performance.
- Do not leave the printer without ink supply units installed. The ink in the printer may dry and the printer will not print correctly. When you are not using the printer, make sure there is an ink supply unit installed in each slot.
- Load all colors of ink supply units. You cannot print unless all the colors are loaded.
- To maintain the quality of the head, the printer stops printing before the ink supply units are completely expended; therefore, some ink is left in used ink supply units.
- Do not dismantle or modify ink supply units. You may not be able to print properly.

## Introducing the Software

Install the printer driver and Maintenance Tool on your computer to use the printer.

Software Name	Summary
Printer Driver	<p>This software is for printing from the printer according to print commands from application software.</p> <p> <a href="#">"Printer Driver Functions" (Page 22)</a></p>
Maintenance Tool	<p>This software can execute maintenance functions, such as checking the printer's status, making settings, and doing Print Head Cleaning.</p> <p>Also, the Maintenance Tool must be installed in the following cases, so install Maintenance Tool on your computer.</p> <ul style="list-style-type: none"> <li>• To use the automatic print head nozzle check.</li> <li>• To add types of paper to be used on the printer.</li> </ul> <p>Maintenance Tool is not installed automatically if you are using Windows. See the following to install it.</p> <p> <a href="#">"Installing the Maintenance Tool" (Page 21)</a></p> <p>See the following for more details on Maintenance Tool.</p> <p> <a href="#">"Using the Maintenance Tool (Windows)" (Page 64)</a></p>
Firmware Updater*1	<p>This software is for updating firmware. It uses EFU format files for firmware updates to update the printer firmware.</p>

\*1: This is not installed automatically.

## Wired LAN connection

Note;

Support DX400W. DX400 cannot be used with the wired LAN.

### 1. Confirm configuration information for network connection in advance.


Classification	Item	Remarks
Device Connection	Wired LAN	The wired LAN connects to the switching hub.
LAN Connection Information	<ul style="list-style-type: none"> <li>• IP address</li> <li>• Subnet mask</li> <li>• Default gate Way</li> </ul>	<p>Determine the IP address to be assigned to the printer.</p> <p>When assigning an IP address statically, values for all items are required. When dynamically assigning an IP address using the DHCP function, information on the LAN connection is not required as it is set automatically.</p>
DNS Server Information	<ul style="list-style-type: none"> <li>• Primary DNS IP address</li> <li>• Secondary DNS IP address</li> </ul>	<p>This is required when static IP address are assigned to printers. Secondary DNS is set if the system is configured for redundancy and has a secondary DNS server. If you have a small network and have not built a DNS server, set the IP address of the router.</p>
Proxy Server Information	Proxy Server Name	In the network environment where a proxy server is used to connect from an intranet to the Internet, set this option if you want to use the printer's ability to access the Internet directly.

### 2. connect to the network via the DX400 control panel.


#### <IP Address Settings>

Set basic IP addresses such as the host address, subnet mask, and default gateway. This section explains how to set a fixed IP address.


- (1) Turn on the printer.
- (2) Press [Settings] on the home screen of the operation panel.
- (3) Select [Network Settings] - [Advanced Setup] – [TCP/IP] in that order.



- (4) Select [Manual].  
Select Auto if you want to use the DHCP function for automatic configuration.




- (5) Enter the IP address.



- (6) Similarly, set the Subnet Mask and Default Gateway. When the settings are complete, return to the Advanced Setup screen.
- (7) Select DNS Server.
- (8) Select [Auto] or [Manual].  
If you cannot automatically obtain the DNS server address, select [Manual] and proceed to the next step to enter the DNS server address.
- (9) Enter the primary DNS address.
- (10) Set up a secondary DNS server.  
If you do not have a secondary DNS, set it to "0.0.0.0". Once the settings are complete, you will return to the Advanced Setup screen.

### 3. Connect to the wired LAN.

- (1) Connect the DX400 printer and the switching hub with a LAN cable.
- (2) Select [Settings] on the home screen.
- (3) Select [Network Settings] - [Connection Check].  
The connection diagnosis results are displayed.  
Confirm that the connection is normal.
- (4) Finish the settings. Press the [OK] button to print the diagnosis results.




## Installing Printer Driver and Maintenance Tool


### Installing the Printer Driver

1. Run the exe file located in “PrinterDriver\Installer\WW”.


Note: Select the exe file from the “x64” or “x86” folder according to your PC.



2. Follow the on-screen instructions to install the printer driver.




3. Select either network connection or USB connection.




4. Follow the instructions on the screen to configure the settings.

5. When the following dialog box appears, installation is complete.




### Installing the Maintenance Tool

1. Run the “Systemsoft\Windows\SystemSoft\DX400Inst.exe”.



2. Follow the on-screen instructions to install the system software.



#### Note:

- The printer driver name is registered as “FUJIFILM DX400”. Specify this name when printing from an application.
- When installing the printer driver on a second printer, the name is “FUJIFILM DX400 (copy 1)”.

See the following for more details on Maintenance Tool.

 [“Using the Maintenance Tool \(Windows\)”](#)  
(Page 64)


## Printer Driver Functions

The printer driver coordinates print instructions from other applications to print on the printer. The main functions of the printer driver are described below.


- Converts print data received from applications into printable data and sends it to the printer.
- Set print conditions, such as the paper type and paper size, on the printer driver's settings screen.
- Windows only ;
  - Start Maintenance Tool and you can perform adjustment and maintenance operations, such as checking the printer's status, making settings, and performing head cleaning, from your computer.
    - ☞ ["Using the Maintenance Tool \(Windows\)" \(Page 64\)](#)
  - Start up Paper Type Additional Tool to be able to add paper information to the printer and printer driver.
    - ☞ ["Adding Paper Information from Custom Settings \(Windows Only\)" \(Page 78\)](#)

## Firmware update

### 1. Run the Printer firmware data.



### 2. Follow the on-screen instructions to install the printer firmware.



#### Note:

Please contact your distributor for the latest printer firmware.

## Uninstalling Software


### Windows

The printer driver and Maintenance Tool need to be deleted individually.

#### Important

- You must log in as an Administrator.
- If the password or confirmation of an administrator is requested, enter the password and then continue with the operation.

1. Open the Control Panel, and then click [Apps] - [Apps & features].




2. Select the software to delete, and then click [Uninstall] - [Uninstall].

#### To Delete the Printer Driver

Select [FUJIFILM DX400 Printer Uninstall].


#### To Delete Maintenance Tool

Select [FUJIFILM DX400 Software].



To delete the printer driver, go to step 3.  
To delete Maintenance Tool, go to step 4.

3. Select the target printer icon, and then click [OK].



4. Follow the on-screen instructions to continue.

When the delete confirmation message appears, click [Yes].

Restart the computer if you are reinstalling the printer driver.

## Basic Operations

### Notes When Loading/ Replacing Paper





#### CAUTION

- Do not rub the edges of the printing paper with your hand. The edges of the paper are thin and sharp and could cause an injury.
- When opening and closing the covers, do not place your hands near the points where the main unit and the cover join. If your fingers or hands are trapped, an injury could occur.
- When moving the roll paper unit in or out, grip the handle. If you place your hands into any other sections, either side of your hand or fingers could be injured.

### Notes when Loading Roll Paper

#### Do not load roll paper if the left and right edges are uneven

Loading roll paper whose left and right edges are uneven, will cause paper feeding problems. Align the edges before using it or use a roll of paper that has no such issues.



Repeatedly winding and unwinding the same roll paper on the spindle unit may tend to make the left and right ends uneven.

When removing roll paper, do not allow the paper to become loose, and when loading it, keep the left and right edges even.

#### Do not load roll paper if the leading edge is ragged.

If the leading edge of the roll paper is ragged, cut it straight with a pair of scissors, or something, and then load it.



## How to Replace Roll Paper

This section explains how to remove paper from the roll paper unit, and then load new paper.

### Preparing to Replace Paper


Prepare the following items.

Item Prepared	Explanation
New roll paper to be loaded	-
Cloth or vinyl rug	Spread it out where the roll paper will be loaded/removed from the spindle unit so that the roll paper does not get dirty.
Soft cloth	Clean the edges of the roll paper before installing the roll paper.
Gloves	Wear when handling the roll paper so that the paper does not get dirty.

Replace the roll paper in the following order. Follow the steps for each procedure.

- “Removing the Spindle Unit” (Page 25)
- “Removing the Roll Paper” (Page 26)
- “Attaching the Roll Paper” (Page 26)
- “Installing the Spindle Unit” (Page 28)

### Removing the Spindle Unit

1. Confirm that the power is on.
2. Press the  button to rewind roll paper to the spindle.
3. Store the output tray.




4. Remove the scrap paper box, and dispose of the scraps.



5. Pull out the roll paper unit.



6. Remove the spindle unit.




Do not lift the spindle unit by the knobs when removing it. The roll paper could fall.




## Removing the Roll Paper

1. Raise the knob and remove the left-side media edge guide.



2. Raise the knob and remove the right-side media edge guide and the spindle.




## Attaching the Roll Paper

Attach the roll paper so it is in the center of the spindle unit. Follow the steps below to attach it.


1. Remove the new roll paper from its packaging, and stand it on end on a flat surface. Next, wipe the end of the roll paper with a soft cloth several times to remove any dirt, such as paper dust.

Place the roll paper so the leading edge is facing as shown in the illustration below.



2. Raise the knob on the media edge guide and place it on the roll paper.



Press it in until there is no gap between the media edge guide and the roll paper. If the spindle is inserted into the media edge guide, first remove the spindle and then press the media edge guide in to securely attach it to the roll paper.




- 3. Insert the spindle into the media edge guide until the position of the width of the paper being loaded.**

Insert the end of the spindle that has no gear first.

The illustration shows an example of alignment with A4.



- 4. Lower the knob, and secure the media edge guide.**




When doing this, confirm that there are no gaps between the media edge guides and the roll paper.


**OK**



- 5. Insert the media edge guide into the side opposite to the shaft of the spindle unit, and firmly clamp the roll paper between the media edge guides.**



6. Confirm that there are no gaps between the media edge guide and the roll paper, lower the knob, and then secure the media edge guide.





## Installing the Spindle Unit


1. Load the spindle unit into the roll paper unit.

Position the gear on the end of the spindle on the right side.


Check that the shaft of the spindle unit fits into the bearing and that the gears engage.







2. Insert the leading edge of the roll paper into the paper slot until you hear a beep.



**3. Align the edge guides to the width of the roll paper.**



At this time, confirm that the position of the edge of the roll paper matches the label showing the paper size, and that there are no gaps between the left and right edge guides and the edges of the roll paper.



If the labels do not match or there are gaps at the left or right edge guides, then the position in which the roll paper is loaded is not aligned with the spindle unit. Reload the roll paper in the correct position.


**4. Push the roll paper unit all the way in.**



**5. Attach the scrap paper box.**




Please attach it so that the hook of the scrap paper box fits into the insertion slot of the main body.



Paper feed starts after it is attached. When paper feed stops, the control panel screen displays the paper type settings.

**6. Set the paper type on the control panel screen.**

Press [OK] if the type of paper displayed matches the type of roll paper inserted. If it is not, select [Change] and choose the correct type.




**7. Extend the output tray.**

Lift it up toward you and push it slightly in to secure it.



Pull the second stage out toward you and raise the front edge part.



## How to Load Sheet Paper


This section explains the procedure to load sheet paper in the paper feed unit and the optional cassette.

When printing on sheet paper from the paper feed unit, be sure to rewind the roll paper before starting the printing operation.


### Loading in the Paper Feed Unit

First start printing to transmit the print data to the printer, and then load sheet paper into the paper feed unit.


1. Open the rear paper feed slot cover.




2. Spread apart the edge guides.



3. Load the paper in the center between the edge guides with the printable side facing you.




4. Align the edge guides to the width of the paper.



5. Push the paper about 5 cm into the paper slot.


At this time, push the paper gradually in as you press on the left and right edge guide so the paper does not skew. You can load the paper correctly and prevent it from skewing.




## When Paper is Loaded in the Sheet Feeder

When using the optional sheet feeder for the first time, do the following settings.


1. Open the Control Panel, and click [Hardware and Sound] - [Devices and Printers], in this order.
2. Right-click the target printer icon, and select [Printer properties].



3. Select [Optional Settings], select [Acquire from Printer], and then click [Get].



4. Confirm that [Cassette] is displayed in [Optional Paper Sources] for [Current Printer Information], and then click [OK].



## Loading in the Sheet Feeder (Option)




Confirm in advance that the feed rollers that are installed are suitable for the type of paper that is loaded.

☞ [“Cleaning and Replacing the Rollers in the Sheet Feeder \(Option\)” \(Page 56\)](#)

1. Pull the cassette out toward you.



2. Spread apart the left, right, and front edge guides all the way. Pinch the levers as you move them.







### 3. Riffle the paper to be loaded.

Static electricity may cause sheets of paper in a stack to stick to each other. Loading paper like that into the cassette could cause paper feeding problems, so follow the procedure below to riffle the paper. Riffling paper forces air between the sheets, which causes them to separate.

Riffle the short edges of the paper two times each. For square paper, riffle whichever two opposing sides.


(1) Riffle the short edges of the paper as shown in the illustration.

- Hold the paper lightly, without gripping it too tightly. If you grip too tightly, air cannot get into the edges of the paper to separate the sheets that are stuck together.
- When riffling large sheets of paper, support the stack of paper against your arm as shown in the illustration.



(2) Riffle the other short edges two times in the same way.

(3) Align all four edges of the paper.




### 4. Load the paper with the printable side facing down.

The number of sheets that can be loaded is either 100 sheets or up to the limit line on the edge guide, whichever is fewer.

See the following for the number of sheets of genuine Fujifilm paper that can be loaded.

“(3) Sheet Papers” (Page 110)




### 5. Align the left, right, and front edge guides to the paper.


Pinch the levers as you move them.

If there are gaps between the edge guides and the paper, the paper may skew during printing, so align them accurately.



Also, confirm that the top of the paper does not exceed the upper limit line on the left and right edge guides.



**6. Close the cassette.**



After closing it, set the paper size and paper type on the control panel screen.  
Press [OK] if the type of paper displayed matches the type of paper inserted.  
If it is not, select [Change] and choose the correct type.



## Basic Printing Methods (Windows)

This section explains how to print and how to cancel printing.

Printing is executed from application software on a computer connected to the printer.

See the following for more details on stopping printing.

☞ “How to Cancel Printing (from the Computer)” (Page 38)

## How to Print from Photoshop

This section uses Adobe Photoshop 2021 as an example of how to print image data.

Operations may differ depending on the application software being used. See the manual supplied with the application for more details.


### 1. Turn on the printer, and load the paper to be used.

☞ “Basic Operations” (Page 24)


#### When paper is loaded in the sheet feeder

When using the optional sheet feeder for the first time, do the following settings.


- Open the Control Panel, and click [Hardware and Sound] - [Devices and Printers], in this order.
- Right-click the target printer icon, and select [Printer properties].



- Select [Optional Settings], select [Acquire from Printer], and then click [Get].




- Confirm that [Cassette] is displayed in [Optional Paper Sources] for [Current Printer Information], and then click [OK].



- Start Adobe Photoshop 2021, and open an image.

- Click [Image] - [Image Size], in this order. The [Image Size] screen is displayed.




**4. Set the Image Size and Resolution, and then click [OK].**

Select [Original Size] for [Fit To], and then match the [Width] and [Height] to the size of the paper being printed.

Set the [Resolution].

Setting the [Width] or [Height] changes [Fit To] to [Custom].



**Note:**


We recommend [Resolution] normally be set to 360 dpi.

However, if all the following printing preferences are met, setting 720 dpi can produce very clear printouts.

- When [Finest Detail] is selected in the printer driver.
- When a setting other than [Draft] is set for [Print Quality] in the printer driver.
- When the paper length is less than 305 mm


**5. Click [File] - [Print] in this order.**

The [Photoshop Print Settings] screen is displayed.



**6. Select the printer in [Printer], and then click [Print Settings].**

The Main screen of the printer driver is displayed.




**7. Set the various items in [Print Settings].**

- **Media Type**  
Select the type of paper that is loaded in the printer.
- **Print Quality**  
The print qualities that you can select vary depending on the type of paper that was selected.

Normally, set [Standard]. If you want to print with an emphasis on quality, set [High Quality].

If you want to print quickly, set [Draft]. When [Draft] is set, the printing speed is quicker, however the print quality may decline a little.




To do advanced settings according to your preferences for color management and color modes, click [Advanced].

☞ [“Color Management” \(Page 40\)](#)

**8. Set the various items in [Paper Source Settings].**

- **Paper Source**  
Settings depend on the type of paper that was selected.  
To print from the sheet feeder, select [Cassette].
- **Paper Size**  
Select a size to print. Make sure this is the same as the image size you set in step 4.




To print without borders (margins), select [Borderless].


☞ [“Borderless Printing on All Sides” \(Page 44\)](#)

**9. To do double-sided printing on sheet paper, click [Page Layout], and set the binding position in [Double-Sided Printing].**

☞ [“Double-Sided Printing” \(Page 47\)](#)

**10. Click [OK].**

- Set each item, such as color management and print position, while checking the image displayed on the [Photoshop Print Settings] screen.



**Note:**

- When the printer driver's [Color Adjustment] is set to [Color Controls], select [Printer Manages Colors] in [Color Handling] in [Color Management].
- When performing detailed color management using the Photoshop functions, set [Color Management] according to the conditions.


See the following for more details on color adjustment.

☞ "Color Management" (Page 40)

- Click [Print].

**Note:**

If the image size is larger than the print size, the following screen is displayed. Click [Proceed]. If you click [Cancel], printing is canceled and you are returned to the application's screen.



Print data is sent to the printer and printing starts.

## How to Cancel Printing (from the Computer)

When the computer has finished sending data to the printer, you cannot cancel the print job from the computer. Cancel on the printer.


☞ "How to Cancel Printing (from the Printer)" (Page 39)

- Click the printer icon on the taskbar.




Whether or not an icon is displayed depends on the settings selected for Windows.

- Select the job you want to cancel, and then select [Cancel] from the [Document] menu. To cancel all jobs, click [Cancel All Documents] in the [Printer] menu.



If the job has been sent to the printer, print data is not displayed on the above screen.

## How to Cancel Printing (from the Printer)

Press the  button (stop button) on the control panel.

The print job is canceled even in the middle of printing. After cancelling, it may take a while before the printer returns to the ready status.

**Note:**

You cannot delete print jobs which are in the print queue on the computer using the above operation. See [“How to Cancel Printing \(from the Computer\)” \(Page 38\)](#) in the previous section to delete print jobs from the print queue.

# Printing Using Various Print Functions

## Color Management

### Color Management Settings

When printing on the printer, you can select from the following color correction methods.

Choose the best method according to the application you are using, the operating system environment, and the aim of the printout.


#### Setting colors manually

Manually adjust the color space and color tone settings used for printing. Use this option when the application in use does not have a color correction function.

 ["Setting Colors Manually" \(Page 40\)](#)


#### Color management from the application (no color management)

This method is for printing from applications that support color management. All color management processes are carried out by the application's color management system. This method is used when you want to obtain the same color management results using a common application among different operating system environments.

 ["Color Management from the Application \(No Color Management\)" \(Page 42\)](#)

#### Color management from the printer driver

The printer driver uses the operating system's color management system and carries out all color management processes. This is used when you want to produce similar print results from different applications under the same operating systems. However, to do this, you also need an application that supports color management.

 ["Color Management from the Printer Driver \(ICM\) \(Windows\)" \(Page 43\)](#)

### Setting Colors Manually

You can select one of the following color correction modes. In addition, you can fine tune the brightness, contrast, saturation, and color balance, while looking at a preview image.

- sRGB: Optimizes the sRGB space and corrects the color. This should normally be selected.
- Adobe RGB: Optimizes the Adobe RGB space and corrects the color. Select when printing image data using the Adobe RGB color space information.

### Settings on Windows

#### 1. When using applications featuring a color management function, specify how to adjust colors from these applications.

When using applications without a color management function, start from step 2. When using the following applications, select the [Printer Manages Colors] color management option.

- Adobe Photoshop CS6 or later
- Adobe Photoshop Elements 11 or later
- Adobe Photoshop Lightroom 5 or later

In other applications, set [No Color Management].


#### Note:

For information on supported platforms, see the website for the application in question.




### Example of Adobe Photoshop 2021


The [Photoshop Print Settings] screen opens. Select [Color Management], then select [Printer Manages Colors] in [Color Handling].



2. Display the printer driver's [Main] screen. When using Adobe Photoshop 2021, click [Print Settings] to display the printer driver's [Main] screen.



3. Click [Advanced] in [Color Adjustment].




4. Select [Color Controls] in [Color Management].

The setting items are displayed on the [Color Correction] screen.

5. Select [Color Mode].


- sRGB  
Manages colors using sRGB. Prints at the optimum color tones. This should normally be selected.
- Adobe RGB  
Manages colors based on the larger Adobe RGB color space. Select when printing image data using the Adobe RGB color space information.



6. Set the various items, and then click [OK].

- Color Adjustment Method  
Select the color adjustment method. By selecting [Color Circle], you can click on the color circle to adjust the colors and move the density slide bar to adjust the density. By selecting [Slide Bar], you can move the slide bar of each color to adjust the colors.
- Brightness  
Adjusts the brightness of the image.
- Contrast  
Adjusts the contrast (difference between light and dark) of the image. When the contrast is raised, bright sections become brighter, and dark sections become darker. When the contrast is lowered, the difference between light and dark sections decreases.

- Saturation  
Adjusts the saturation (color clarity) of the image.  
When the saturation is raised, colors become vivid. When the saturation is lowered, the colors become dull until they are close to gray.



**Note:**  
You can adjust the colors while checking the sample image on the right side of the screen.

**7. Set other items if necessary, and then print.**


## Color Management from the Application (No Color Management)

Print using applications with a color management function. Enable the color management settings in the application and disable the printer driver's color adjustment function.

**1. Make the settings for color adjustment using the application.**

**Example of Adobe Photoshop 2021**


The [Photoshop Print Settings] screen opens. Select [Color Management], then select [Photoshop Manages Colors] in [Color Handling], and then select [Printer Profile] and [Rendering Intent].



**Note:**  
If you are not using an original printer profile, select a profile for the paper type being used from [Printer Profile].


**2. Display the printer driver's settings screen (Windows).**

When using Adobe Photoshop 2021, click [Print Settings] to display the various screens.




**3. Set color management to off. For Windows**

(1) Click [Advanced] in [Color Adjustment] in the [Main] screen.



(2) In [Color Management], select [No Color Adjustment], and then click [OK].



**4. Set other items if necessary, and then print.**

**Color Management from the Printer Driver (ICM) (Windows)**

Performs color management from the printer driver. An ICC profile that supports the paper type set in the printer driver is automatically selected for doing color adjustment.

**1. When using applications featuring a color management function, specify how to adjust colors from these applications.**

When using applications without a color management function, start from step 2. When using the following applications, select the [Printer Manages Colors] color management option.


- Adobe Photoshop CS6 or later
- Adobe Photoshop Elements 11 or later
- Adobe Photoshop Lightroom 5 or later

In other applications, set [No Color Management].


**Note:**  
For information on supported platforms, see the website for the application in question.

**Example of Adobe Photoshop 2021**


The [Photoshop Print Settings] screen opens. Select [Color Management], then select [Printer Manages Colors] in [Color Handling].




2. **Display the printer driver's [Main] screen.**  
When using Adobe Photoshop 2021, click [Print Settings] to display the printer driver's [Main] screen.



3. **Click [Advanced] in [Color Adjustment].**



4. **In [Color Management], select [ICM], and then click [OK].**



5. **Set other items if necessary, and then print.**

## Borderless Printing on All Sides

You can print your data without margins on the paper.

### Types of Borderless Printing Methods


You can perform borderless printing using the following two methods: Auto Expand or Retain Size. For simple borderless printing, we recommend Auto Expand. To prevent the printer driver from enlarging your image, we recommend Retain Size.

#### Auto Expand

The printer driver enlarges the print data to a size slightly larger than the paper size and prints the enlarged image. The sections which are beyond the paper edges are not printed; therefore, resulting in borderless printing.

Use settings such as Page Layout in the applications to set the size of the image data as follows.


- Match the paper size and page setting for the print data.
- If the application has margin settings, set the margins to 0 mm.
- Make the image data as large as the paper size.



#### Retain Size

Create the print data larger than the paper size in the applications to produce borderless output. The printer driver does not enlarge the image data. Use settings such as Page Layout in the applications to set the size of the image data as follows.


- Set the page layout to extend 2.3 mm beyond the actual paper size on all four edges.
- If the application has margin settings, set the margins to 0 mm.
- Make the image data as large as the paper size.




## Setting Procedure


### Settings on Windows

1. A Open the printer driver's [Main] screen, and set the various settings required for printing, such as [Media Type], [Print Quality], [Paper Source], and [Paper Size]. See the following for how to display the [Main] screen.

 "Basic Printing Methods (Windows)" (Page 35)




2. Select [Borderless], and then click [Settings].



3. Select [Auto Expand] or [Retain Size] as the [Method of Enlargement], and then click [OK].

When [Auto Expand] is selected, set the slider to set the amount of enlargement.



**Note:**

Moving the slider towards [Med] or [Min] decreases the image enlargement ratio. Therefore, some margins may appear at the edges of the paper depending on the paper and printing environment.

4. Set other items if necessary, and then print.

## Printing on Paper of Non-Standard Sizes

You can print on paper sizes not included in the printer driver.

The paper sizes you can set are shown below.

### Roll Paper

Width	89.0, 101.6, 127.0, 152.4, 203.2, 210.0 mm
Length	50 to 1,000 mm

### Sheet paper

Width	Printing with margins: 89 to 210 mm Borderless printing: 89.0, 100.0, 101.6, 127.0, 152.4, 203.2, 210.0 mm
Length	Single-sided printing: 148 to 1000 mm Double-sided printing: 148 to 297 mm

### Important


Output sizes may be restricted by the application being used for printing.

## Settings on Windows


1. Open the printer driver's [Main] screen, and then select [Media Type] and [Paper Source].

See the following for how to display the [Main] screen.


 [“Basic Printing Methods \(Windows\)” \(Page 35\)](#)



2. Select [User-Defined] for [Paper Size].



3. On the [User-Defined Paper Size] screen, enter [Paper Size Name], set a paper size to use, and then click [Save].



### Note:

- To change the information you saved, click the Paper Size Name in the list on the left side of the screen.
- To delete a paper you saved, select the Paper Size Name in the list on the left side of the screen, and then click [Delete].
- You can save up to 30 paper sizes.

4. Click [OK].

You can now select the saved paper size from [Paper Size] in the [Main] screen.

You can now print as normal.

## Double-Sided Printing


You can print on both sides of sheet paper. Double-sided printing is automatic, so that after the front side is printed the back side is printed automatically.

**Note:**


- Double-sided printing cannot be done on roll paper.
- Paper jams may occur if you load thick sheet paper in landscape orientation.

### Settings on Windows


1. Load the paper to be used in the paper feed unit or the optional sheet feeder.  
 ☞ “How to Load Sheet Paper” (Page 31)
2. Open the printer driver’s [Main] screen, and then set the paper type for the sheet paper that you loaded in step 1 in [Media Type]. See the following for how to display the [Main] screen.  
 ☞ “Basic Printing Methods (Windows)” (Page 35)



3. Do the settings needed for printing, such as [Print Quality] and [Paper Size], and then select [Rear Paper Feed Slot] or [Cassette] for the [Paper Source].




4. Select [Page Layout], and then select the binding position in [Double-Sided Printing].



**Note:**

If you notice scratching or the transfer of ink to the back side of other sheets of paper in the print results, click [Settings] and set additional drying time.












5. Set other items if necessary, and then print.

# Maintenance

## List of Maintenance Items

See the following table for details on maintenance.

Contents	When to perform	Reference
Replacing ink supply units Replacing Maintenance Cartridge	When a Remaining Alert is displayed on the control panel screen	 <a href="#">“Replacing Ink Supply Units” (Page 50)</a>  <a href="#">“Replacing Maintenance Cartridge” (Page 52)</a>
Emptying the Scrap Paper Box	When Replacing Roll Paper	 <a href="#">“Emptying the Scrap Paper Box” (Page 53)</a>
Cleaning airflow vents	Once every 3 months	 <a href="#">“Cleaning Airflow Vents” (Page 54)</a>
Cleaning the platen and roll paper unit	When the Back of Printed Paper is Dirty	 <a href="#">“Cleaning the Platen and Roll Paper Unit” (Page 54)</a>
Cleaning Feed Rollers and Transfer Rollers in the Sheet Feeder (Option)	When paper feed trouble repeatedly occurs	 <a href="#">“Cleaning and Replacing the Rollers in the Sheet Feeder (Option)” (Page 56)</a>
Replacing feed rollers in the sheet feeder (option)	<ul style="list-style-type: none"> <li>• When the type of paper that is loaded in the cassette is changed.</li> <li>• When paper feed trouble repeatedly occurs even after doing the following               <ul style="list-style-type: none"> <li>• Is the paper loaded correctly in the cassette?</li> <li>• Are you using the feed roller that is appropriate for the type of paper?</li> <li>• Have the feed rollers and transfer rollers been cleaned?</li> </ul> </li> </ul>	 <a href="#">“Cleaning and Replacing the Rollers in the Sheet Feeder (Option)” (Page 56)</a>
Doing a Print Head Nozzle Check	<ul style="list-style-type: none"> <li>• When checking if nozzles are clogged</li> <li>• When checking which colors are clogged</li> <li>• Horizontal stripes or tint unevenness (banding) have appeared</li> </ul>	 <a href="#">“Print Head Nozzle Check and Cleaning” (Page 62)</a>
Cleaning the print head	When a clogged nozzle is found	 <a href="#">“Print Head Nozzle Check and Cleaning” (Page 62)</a>

The printer has other maintenance functions, that can be executed from the maintenance tool, than those mentioned above. See the following for more details.

 [“Using the Maintenance Tool \(Windows\)” \(Page 64\)](#)



## Disposal of Used Consumables

Dispose of consumables and optional parts in accordance with your local laws and statutes, such as by entrusting them to an industrial waste disposal company. In such cases, submit the "Safety data sheet" to the industrial waste disposal company.

Please contact your sales company or retailer for safety data sheets.

## Precautions Regarding Maintenance



### CAUTION

- Do not disassemble ink supply units or maintenance cartridges.  
Failure to observe this precaution could result in ink getting in your eyes or on your skin.
- Do not shake the ink supply units too hard.  
Ink may leak from the ink supply unit if you shake it or swing it around too hard.
- Keep ink supply units and maintenance cartridges out of reach of children.
- If ink gets in the eyes or mouth, or stains the skin, treat the area as follows.
  - If ink adheres to your skin, immediately wash it off using soapy water.
  - If ink enters your eyes, rinse immediately with water. Failure to observe this precaution could result in bloodshot eyes or mild inflammation. If you notice any abnormalities, consult a physician immediately.
  - If ink enters your mouth, consult a physician immediately.
- Do not touch any areas inside the printer except for those indicated in the manual. An electric shock or burn could occur.
- Do not disassemble anything except when indicated to do so in the manual.
- When opening and closing the covers, do not place your hands near the points where the main unit and the cover join. If your fingers or hands are trapped, an injury could occur.
- When moving the roll paper unit in or out, grip the handle. If you place your hands into any other sections, either side of your hand or fingers could be injured.


## Replacing Ink Supply Units

### Important

- If you do not have a new ink supply unit for installation, leave the expended ink supply unit in the printer until the new one is ready. If the printer is left without an ink supply unit, it may malfunction.
- When the ink supply unit being used falls below the limit, replace it with a new ink supply unit as soon as possible.
- Do not leave the printer without ink supply units installed. The inks inside the printer may dry and you may not be able to print. When you are not using the printer, make sure there is an ink supply unit installed in each slot.

#### 1. Check that the power light is lit.

If the power light is flashing, the printer is operating. Wait until all operations have stopped.




#### 2. On the control panel, check which ink supply units need to be replaced.

#### 3. Open the ink supply unit cover on the side to be replaced.




When the cover is opened, the status light lights.

#### 4. Push in the ink supply unit tray to pull it out.




#### 5. Remove the ink supply unit.

Lift up the handle and then remove it.




6. Remove the new ink supply unit from the box.



**!** Important

Do not touch the chip on the ink supply unit. You may not be able to print properly.



7. Confirm the color of the label, and then put the ink supply unit tray back into the printer.



8. Close the ink supply unit cover.



9. Confirm that the status light is off.

## Replacing Maintenance Cartridge


The maintenance cartridge is to absorb ink consumed when Print Head Cleaning is executed. If a replace the maintenance cartridge message appears, follow the steps below to replace it.

### Important

After removing the maintenance cartridge, replace it immediately, do not leave the ink supply unit cover open.

#### 1. Check that the power light is lit.

If the power light is flashing, the printer is operating. Wait until all operations have stopped.



#### 2. Open the ink supply unit cover on the right side.

A warning buzzer sounds when you open the cover.




#### 3. Remove the maintenance cartridge slowly without tilting it.

Push up, and then pull it out.

See the following for more information on disposing of the maintenance cartridge.

 ["Disposal of Used Consumables" \(Page 49\)](#)




#### 4. Prepare a new maintenance cartridge.


### Important

Do not touch the chip on the maintenance cartridge.

Doing so may prevent normal operation and printing.



**5. Insert the new maintenance cartridge.**



**6. Close the ink supply unit cover.**



**7. Check that the power light has lit.**

This completes this section.


## Emptying the Scrap Paper Box

Scraps of paper cut during printing accumulate in the scrap paper box. You need to empty out the paper scraps before the box is full.

Check visually how much scrap paper has accumulated in the box. Be sure to dispose of scrap paper when you replace the roll paper.

**1. Check that the power light on the printer is lit.**

When the power light is flashing, the printer is operating. Wait until all operations have stopped.



**2. Remove the scrap paper box.**



When the scrap paper box is removed, the status light lights.

3. **Empty out the scrap paper.**  
Turn over the scrap paper box to throw away the scrap paper that has collected in the box.
4. **Attach the scrap paper box.**



5. **Confirm that the status light is off.**

## Cleaning Airflow Vents

Clean the airflow vent filter with a vacuum cleaner once every 3 months.



## Cleaning the Platen and Roll Paper Unit

If the back of printed paper is dirty, paper dust (white dust) has accumulated on the platen and roll paper unit, making them dirty. Clean the platen and roll paper unit according to the procedure in the next section.

If you are using roll paper, clean the platen and the roll paper unit. If you are using sheet paper, clean the platen. Execute cleaning with the power on.

If you are using roll paper, remove the roll paper from the roll paper unit in advance.

☞ [“Removing the Spindle Unit” \(Page 25\)](#)

### ! Important

Do not touch the rollers inside the printer. This could cause print outs to be soiled and so on.

## How to Clean the Platen

### ! Important

Do not touch any part of the platen except where instructed to clean. Otherwise, it may break down or reduce print quality.



**1. Remove the printer cover**


(1) Open the rear paper feed slot cover.




(2) Slide the printer cover backwards, and then remove it.






**2. Wipe off any dirt, such as paper dust, on the areas other than the ink absorbing material on the platen (the areas surrounded by the blue line in Figure A) with commercially available cotton swabs.**

When doing so, also wipe off any dirt adhering to the ribs (convex parts) within the area. Dirt left on the ribs may stain the back side of the printed paper. For each rib, wipe off its surface and surrounding area (the area indicated by  in Figure B).

A





B



**3. Wipe off any dirt, such as paper dust, that has accumulated on the ink absorbing areas (the area outlined in blue in the illustration below) with a commercially available cotton swab.**

Be careful as you wipe the ink off the ink absorbing area so that the ink does not spread to any other areas.




**4. Install the printer cover in the reverse order of step 1.**


**How to Clean the Roll Paper Unit**

**1. Open the front plate inside the roll paper unit.**


Place your finger in the hole at the bottom and lift to open.




2. Use a vacuum cleaner to remove dirt, such as paper dust, that has collected in the locations shown in the illustration.



Use a vacuum cleaner that has a nozzle type head with no brush.



3. Replace the plate.  
Press down until you hear it click into place.



4. Reload the roll paper.  
☞ "Installing the Spindle Unit" (Page 28)

## Cleaning and Replacing the Rollers in the Sheet Feeder (Option)

The feed rollers and transfer rollers in the sheet feeder need the following maintenance depending on the state of the printer.

- Feed rollers: Clean or replace
- Transfer rollers: Clean

If they are not appropriately cleaned and replaced, paper feed trouble may occur. Follow the instructions below to do this.

### Install the feed rollers when assembling the sheet feeder

The feed rollers are not installed when the sheet feeder is assembled. See the following to install the feed rollers before using the machine.

☞ "Replacing Feed Rollers" (Page 56)

### Notes on Handling Rollers

Do not touch the roller surfaces of the paper feed rollers or transfer rollers.

Oil from your skin could stick to them and make printed materials dirty.




## Replacing Feed Rollers


### Types of Feed Rollers

The following A and B feed rollers are installed in the sheet feeder.

A




B






Also, there are 2 types of A feed roller, one for photo paper and one for card stock. See the following table to replace and use them according to the type of paper being used.

For photo paper



For card stock



## When to replace

Replace the feed rollers at the following times.

### When the type of paper being used is changed

If the A feed roller is not installed correctly, then paper feed problems and scratches on the back side of the paper may occur. Replace the feed rollers as appropriate, according to the table of compatibility of paper types and feed rollers. The B feed rollers do not need to be replaced.

When using paper other than Fujifilm Special Media, paper feed problems may occur because of the paper, even if you follow the guidelines in the table of compatibility of paper types and feed rollers. Because of this, we recommend first printing some paper to confirm whether it feeds. If paper feed problems occur, install and use the other feed rollers.

Compatibility of paper types and feed rollers

☞ [“Types of Feed Rollers” \(Page 56\)](#)

### When feed rollers reach the end of their service life

Faulty paper feeding, such as paper not feeding from the cassette, may occur when the feed rollers reach the end of their service life. If faulty paper feeding occurs repeatedly, even after doing the following, then replace both A and B feed rollers with new ones.

- Is the paper loaded correctly in the cassette?
- Are you using the feed roller that is appropriate for the type of paper?
- Have the feed rollers and transfer rollers been cleaned?

How to Load Paper in the Cassette ☞ [“How to Load Sheet Paper” \(Page 31\)](#)


How to Clean the Feed Rollers and Transfer Rollers ☞ [“Cleaning the Feed Rollers and Transfer Rollers” \(Page 59\)](#)

## How to Replace

1. Turn off the printer.
2. Move to the back, and open the cover of the sheet feeder.




3. Press on both sides of the A feed roller to remove it.




If you are replacing only the A feed roller, proceed to step 7.




- 4. Press in the button shown in the illustration.**  
The B feed roller comes out toward you.



- 5. Remove the B feed roller.**





- 6. Orient the new feed roller as shown in the illustration, and insert it until it stops.**  
When you press it all the way in, the button you pressed in comes back out.



7. Align the triangle on top of the cover with the triangle on the printer and then insert the A feed roller and press on its lower part to install it.

Install a new feed roller if you are replacing the feed roller at the end of its service life.



8. Close the cover of the sheet feeder.



9. Move to the front, and turn on the printer.

10. If you are replacing it at the end of its service life, then, in the control panel screen, select [Settings] - [Maintenance], and execute [Reset Counter].

The amount that has been fed from the cassette is reset. You can confirm the amount that has been fed from the cassette in Maintenance Tool.

## Cleaning the Feed Rollers and Transfer Rollers

### When to clean

Clean the feed rollers and transfer rollers together at the following times.

When paper feed trouble repeatedly occurs and one of the following messages is displayed on the control panel screen

- Paper jammed in Inside. Remove the jammed paper.
- Paper jammed in Cassette. Remove it.

The paper feed trouble described above may occur if the feed rollers or transfer rollers are dirty, such as with paper dust. Clean the rollers according to the next section.


See the following for details on troubleshooting paper feed trouble.


 ["When Paper Jams" \(Page 92\)](#)

### Item Prepared


Use a soft commercially available cloth to clean the rollers. Prepare this in advance. We recommend using a cloth that is low-lint and anti-static.

## How to Clean the Feed Rollers


- 1. Remove the A and B feed rollers.**  
See the following for the removal procedure.  
 [“Replacing Feed Rollers” \(Page 56\)](#)
- 2. Use a soft cloth that has been dipped in water and carefully wrung out to wipe any dirt, such as paper dust, off of the feed rollers.**

 **Important**  
Do not wipe the rollers with a dry cloth.  
This could scratch the surface of the rollers.


**A: feed roller**  
Wipe off any dirt stuck to the surface of the roller in the illustration.






**B: feed roller**  
Wipe off any dirt stuck to the surfaces of the rollers **1** and **2** in the illustration.  
The **3** roller does not need to be wiped.




Rotate both rollers **1** and **2** to wipe their entire surfaces. Rotating the part shown in the illustration rotates the rollers.



The **1** roller has a combination of different cross-sectional shapes. Wipe off the surfaces that protrude, indicated by  in the illustration. The places that do not protrude do not contact the paper when feeding, so they do not need to be wiped.



- 3. Leave the A and B feed rollers for a short time so their surfaces dry, and then install them in the sheet feeder.**  
See the following for the installation procedure.  
 [“Replacing Feed Rollers” \(Page 56\)](#)

Continue to the next section to clean the transfer rollers.


## How to clean the transfer rollers

1. Confirm that the printer's power is turned off and the cover of the sheet feeder is open.
2. Use a soft cloth that has been dipped in water and carefully wrung out to wipe any dirt, such as paper dust, off of the transfer rollers.


### Important

Do not wipe the rollers with a dry cloth. This could scratch the surface of the rollers.

- Wipe the surface of all 16 rollers shown in the image.



- Rotate the metal shafts of the rollers to spin the rollers to wipe their entire surfaces.



- Besides paper dust, dirt that is difficult to check visually, such as the residue of paper coatings, could be stuck to the surface of the rollers. Do not just wipe off the paper dust, carefully wipe the entire circumference of the rollers. Also, always wipe with a clean part of the cloth.

3. Leave the rollers alone for a short time so their surfaces dry, and then close the cover of the sheet feeder.



## Maintenance Functions That Can Be Executed from the Printer

### Print Head Nozzle Check and Cleaning

If the nozzles are clogged, the printouts become faint, or banding may appear. The printer has an auto nozzle check function that automatically detects clogged nozzles and does Print Head Cleaning or prints by using normal nozzles to compensate for clogged nozzles. Because of this, you do not need to regularly do manual cleaning or Print Head Nozzle Check.

The auto nozzle check function is set from Maintenance Tool.

 [“Using the Maintenance Tool \(Windows\)” \(Page 64\)](#)

If you do not use the auto nozzle check function, follow the procedure below to execute a Print Head Nozzle Check if there are problems with print quality or when you want to check for clogged nozzles. If the nozzles are clogged, clean the print head.

#### Note:

- When ink is low, you may not be able to do cleaning.
- If the clogs are not cleared after repeating Print Head Cleaning about three times, then execute Powerful Cleaning.

 [“Powerful Cleaning” \(Page 63\)](#)

If the clogs are not cleared after doing Powerful Cleaning, contact your sales company or retailer.

- 1. Load paper in the location set in [Printer Setup] - [Paper Source Settings] - [Paper path for maintenance printing].**


 [“Basic Operations” \(Page 24\)](#)

- 2. Select [Settings] - [Maintenance] on the home screen.**

To select an item, move the focus to the item using the ▲/▼/◀/▶ buttons, and then press the [OK] button.

- 3. Select [Print Head Nozzle Check].**

- 4. Follow the on-screen instructions to print a nozzle check pattern.**
- 5. Look at the printed pattern to check for print head nozzles that are clogged.**



- Same as A:  
All lines are printed. Select [No]. No further steps are needed.
- Close to B:  
Some nozzles are clogged. Select [Yes], check the messages, and then select [Cleaning].
- Close to C:  
If most lines are missing or not printed, this indicates most nozzles are clogged. Select [Yes], press the [OK] button to proceed to the next screen, and then select [Powerful Cleaning].

- 6. Follow the on-screen instructions to execute Print Head Cleaning or Powerful Cleaning.**

- 7. When cleaning is finished, the nozzle check pattern is printed again. Repeat checking and cleaning until all the lines in the nozzle check pattern are printed.**


## Powerful Cleaning

Executing Powerful Cleaning may improve quality in the following cases.

- When most nozzles are clogged.
- Clogs are not cleared even after doing Print Head Cleaning three times

**Note:**

Powerful Cleaning consumes more ink than normal cleaning.

- 1. Load paper in the location set in [Printer Setup] - [Paper Source Settings] - [Paper path for maintenance printing].**  
 [“Basic Operations” \(Page 24\)](#)
- 2. Select [Settings] - [Maintenance] on the home screen.**
- 3. Select [Powerful Cleaning].**
- 4. When cleaning is finished, the nozzle check pattern is printed again. Check whether all of the lines in the nozzle check pattern were printed correctly.**

## Using the Maintenance Tool (Windows)

This section explains how to use Maintenance Tool by starting it from the computer connected to the printer.

### Summary of the Maintenance Tool


From your computer you can perform adjustment and maintenance operations such as checking the printer's status, making settings, performing head cleaning and so on.

When multiple printers are connected to a single computer, you can operate multiple printers at one time.

### Starting and Closing

#### Starting

On the computer, click [Start] - Applications List - [FUJIFILM] - [FUJIFILM DX400 Maintenance Tool] in this order.



**Note:**

You can also start it by clicking [Maintenance Tool] in the [Maintenance] tab of the printer driver screen.


#### Closing






Click [Close] at the bottom-right of the screen.



## Explanation of the Main Screen

The following main screen appears when you start Maintenance Tool.  
The configuration and functions of the main screen are shown below.
















	Item	Functions
①	Printer list area	Displays a list of printers that are connected to the computer.
	Status	Displays the printer's status.
		Displays the ink level for each color. The following is shown for each color of ink.  : No problems with ink levels.  : New ink supply unit needs to be prepared because remaining ink level is low.  : Remaining ink level is below the minimum value. Replace with a new ink supply unit. Or, an error has occurred. Check the printer history (⑤) and clear the error.
	Printer Name	Displays the printer name.
	Paper Remaining/Paper Type	The paper sources are shown by the following icons.  : Roll Paper Information about the paper that is currently loaded is shown to the right of the icon. For roll paper, the remaining amount of paper is shown to the left of the icon.

	Item	Functions
②	Printer maintenance	The following maintenance functions can be executed for the printer selected in the printer list area ( ① ).
	Diagnostic Cleaning	Detects clogged nozzles and automatically performs cleaning. ☞ <a href="#">“Diagnostic Cleaning” (Page 74)</a>
	Forced Cleaning	Performs manual cleaning. ☞ <a href="#">“Forced Cleaning” (Page 75)</a>
	Nozzle Check	Checks for clogged nozzles. A nozzle check pattern can also be printed. ☞ <a href="#">“Nozzle Check Methods” (Page 72)</a> ☞ <a href="#">“Print Nozzle Check Pattern Method” (Page 73)</a>
③	Printer settings button	A screen for setting printer operations, Auto Nozzle Check Settings, and adjusting the printer is displayed. ☞ <a href="#">“Explanation of the Printer settings” (Page 67)</a>
④	System Environment Settings button	A screen for saving log files and status sheets is displayed. ☞ <a href="#">“Explanation of the System Environment Settings Screen” (Page 71)</a>
⑤	Printer history	Shows a history of settings and maintenance executed from Maintenance Tool and information about errors that occur on printers that are connected to the computer. This operation history is not retained at the next startup, it is deleted automatically when you exit Maintenance Tool.

## Explanation of the Printer settings


Clicking on [Printer settings] in the main screen displays the following Printer settings screen. The configuration and functions of the Printer settings screen are shown below.



	Item	Functions
①	Printer list area	Displays a list of printers that are connected to the computer. The settings of the items indicated by the following icons can be changed in the Printer settings tab.  ,  ,  ,  ,  ☞ “Printer settings tab” (Page 68)
	Printer Name	Displays the printer name.
	Status	Displays the printer’s status.
		Indicates the state of the warning buzzer settings.
		Indicates the sleep mode threshold.
		Indicates the state of Quick Print Mode settings.
		Indicates the state of Remaining Paper Management settings.
		Indicates the state of Heater setting.
	Serial number	Displays the printer’s serial number.
Paper information	The paper sources are shown by the following icons.  : Roll Paper  : Sheet Feeder Information about the paper that is currently loaded is shown to the right of the icon. For roll paper, the remaining amount of paper is shown to the right of the paper information.	
②	Tabs and information display area	The following three types of tabs are displayed.
	Printer settings tab	You can set the printer’s various operations. ☞ “Printer settings tab” (Page 68)
	Auto Nozzle Check Settings tab	You can set the various settings related to auto nozzle checks. ☞ “Auto Nozzle Check Settings tab” (Page 69)
	Paper Setting tab	You can adjust the printer, such as [Print Head Alignment] and [Paper Feed Adjustment]. ☞ “Paper Settings tab” (Page 70)

## Printer settings tab

The configuration and functions of the [Printer settings] tab in the Printer settings screen are shown below.



After changing the settings in items ② to ⑦, the changes are applied for each item by clicking Set.

	Item	Functions
①	Apply to all printers	By selecting this, the results of settings changed in ② to ⑦ are batch applied to all printers displayed in the printer list area at the top of the screen. Select this and then change the settings in ② to ⑦, and then click [Set] for each item.
②	Buzzer	Set volume of and whether to sound the warning buzzer.
③	Sleep Mode Threshold	Set the time before switching to Sleep Mode. If an error has not occurred on the printer and no print jobs have been received for the specified length of time, the printer automatically switches to Sleep Mode.
④	Quick Print Mode	Set whether to enable/disable Quick Print Mode. Quick Print Mode is a mode that increases print speed by shortening the drying time when printing one sheet at a time. We recommend using this when printing one sheet at a time such as for an event. Be sure to note the following points. <ul style="list-style-type: none"> <li>• Do not stack printouts as the drying time is shorter.</li> <li>• Depending on the paper type, color may be uneven or ink may be smudged. If this occurs, set Quick Print Mode to [Off].</li> </ul>
⑤	Remaining Paper Management	Set whether to enable/disable Remaining Paper Management. When this is [On], information, such as the paper type and remaining paper, is printed as a barcode on the leading edge of the roll paper.
⑥	Heater setting	This setting determines whether to print with the printer's built-in heater turned on or not. When set to [On], the built-in heater is turned on when printing on either roll or sheet paper. Printing time may be longer due to the additional drying time required by the heater. When duplex printing is performed on sheet photo paper and the printed sheets are stacked on top of each other, if the darker side and the lighter side overlap, one side may look uneven due to the difference in ink drying conditions. If you are concerned about this kind of unevenness, set the printer to [On]. When set to Auto, the built-in heater is turned on when printing on roll paper, but is turned off when printing on sheet paper. If the printer is used in one of the following environments, the built-in heater will be turned off regardless of the setting of this item. <ul style="list-style-type: none"> <li>• When the temperature exceeds 27°C</li> <li>• When the humidity is 20% or less</li> </ul>
⑦	Horizontal Centered	Enables/disables horizontal centered. When set to [On], print data is corrected so that it is printed centered horizontally on the paper.

## Auto Nozzle Check Settings tab

In this section you can do advanced settings for auto nozzle check to confirm the state of the nozzles when the printer is turned on and at specified times so that the nozzles are automatically cleaned if they clog. The configuration and functions of the [Auto Nozzle Check Settings] tab in the Printer settings screen are shown below.

The screenshot shows the 'Auto Nozzle Check Settings' tab selected. The settings are as follows:

- 1.  Apply to all printers
- 2. Auto Nozzle Check Settings: Normal
- 3. Nozzle Check before printing: Auto
- 4. Periodic Check: Off (slider), 100, 25
- 5. Nozzle Compensation: High quality
- 6. Auto Cleaning: 1
- 7. Action when printing trouble is detected: Stop Immediately
- 8. Set button


After changing the settings in items ② to ⑦, the changes are applied by clicking Set.

	Item	Functions
①	Apply to all printers	By selecting this, the results of settings changed in ② to ⑦ are batch applied to all printers displayed in the printer list area at the top of the screen. Select this and then change the settings in ② to ⑦, and then click [Set].
②	Auto Nozzle Check Settings	<p>Set the conditions in which an automatic nozzle check is done. Select one of the following.</p> <ul style="list-style-type: none"> <li>• High quality Prints a check pattern on roll paper and automatically checks the state of the nozzles. Nozzles are checked in the same way as when the printer is turned on too. Roll paper must always be loaded on the printer.</li> <li>• Normal When printing on roll paper, prints a check pattern on roll paper and automatically checks the state of the nozzles. When printing on sheet paper, does not print a check pattern and automatically checks the state of the nozzles. When roll paper is loaded, nozzles are checked in the same way as when the printer is turned on too.</li> <li>• Saving Ink Does not print a check pattern and automatically checks the state of the nozzles, whether roll paper or sheet paper are loaded on the printer. Nozzles are checked in the same way as when the printer is turned on too.</li> <li>• Off Nozzles are not checked automatically. Select his when you want to visually confirm the printed check pattern to confirm the state of the nozzles.</li> <li>• Default Returns all the settings ( ② to ⑦ ) in the [ Auto Nozzle Check Settings] tab to the manufacturer's settings.</li> </ul>
③	Nozzle Check before printing	<p>Set whether to execute auto nozzle check before printing.</p> <p>When set to [Auto], auto Nozzle Check is executed according to the state of the printer, such as after changing the auto nozzle check settings, or after executing nozzle cleaning.</p> <p>When set to [Every time], auto nozzle check is executed for each print job.</p>

	Item	Functions
④	Periodic Check	Set the time to execute auto nozzle check according to the number of sheets printed. If the number of sheets being printed for a single job exceeds the number of printed sheets set for this item, then the number of sheets for that job is printed, after which auto nozzle check is executed.
⑤	Nozzle Compensation	Set the print quality for when normal nozzles compensate for the ink that could not be ejected by clogged nozzles.
⑥	Auto Cleaning	Sets the number of times to do auto cleaning when clogged nozzles are detected.
⑦	Action when printing trouble is detected	Sets whether to stop printing when clogged nozzles are detected. When set to [Stop Immediately], printing is stopped when clogged nozzles are detected. When set to [Ignore], printing is continued even if clogged nozzles are detected.
⑧	Set button	Clicking this reflects the changes to each item ② to ⑦ .

### Paper Settings tab

The configuration and functions of the [Paper Settings] tab in the Printer settings screen are shown below.




	Item	Functions
①	Paper Source	Select the paper source for doing Print Head Alignment and Paper Feed Adjustment.
②	Paper Type	The set paper is displayed.
③	Print Head Alignment	Corrects print head misalignments when printing. See the following for details on Print Head Alignment. <a href="#">☞ “Print Head Alignment Method” (Page 75)</a>
④	Paper Feed Adjustment	Adjusts the amount of paper feed. See the following for details on Paper Feed Adjustment. <a href="#">☞ “Paper Feed Adjustment Method” (Page 76)</a>

## Explanation of the System Environment Settings Screen

Clicking on [System Environment Settings] in the main screen displays the following System Environment Settings screen.

The configuration and functions of the System Environment Settings screen are shown below.



	Item	Functions
①	Collect Logs	Clicking [Save] saves log files saved on the printer to the desktop of the computer. The following shows the file name. FUJIFILM DX400_<saved date>.zip
②	Save Status Sheet	Select a printer in [Printer Name], and then click [Save] to save a status sheet of the selected printer to a PDF file. You can change the file name and where the file is stored.

## Printer Maintenance

You need to perform print head maintenance if there are problems in the printed results, such as streaks in the printouts or if printed colors are different from usual.

### Maintenance Operations

Maintenance Tool has the following functions to keep the print head in good condition and to get the best print results.

Carry out appropriate maintenance depending on the print results and situation.

#### Auto Nozzle Check

By enabling this setting, you can confirm the state of the nozzles when the printer is turned on and at specified times so that the nozzles are automatically cleaned if they clog.

You can change the conditions to execute a nozzle check and the timing for nozzle checks in Auto Nozzle Check. You can also disable this setting so nozzles are not checked automatically.

 [“Auto Nozzle Check Settings tab” \(Page 69\)](#)

#### Manual Nozzle Check

Executes a nozzle check to check for clogged nozzles, such as when auto nozzle check is disabled, if you have not used the printer for an extended period, or before printing an important job. The printer automatically detects clogged nozzles.

 [“Nozzle Check Methods” \(Page 72\)](#)

#### Print Nozzle Check Pattern


Print a nozzle check pattern when you want to confirm whether clogged nozzles have been cleared after cleaning the print head or when you want to confirm the condition of nozzles visually with a printed nozzle check pattern.

 [“Print Nozzle Check Pattern Method” \(Page 73\)](#)

#### Print Head Cleaning


Do this if there are streaks in the printouts or if printed colors are different from usual. This function clears clogged nozzles.

There are two types, [Forced Cleaning], which is cleaning the print head manually, and [Diagnostic Cleaning], which detects clogged nozzles and cleans the print head automatically.

 [“Print Head Cleaning Method” \(Page 74\)](#)

#### Print Head Alignment

If the print results appear grainy or out of focus, perform Print Head Alignment. The Print Head Alignment function corrects print head misalignments when printing.

 [“Print Head Alignment Method” \(Page 75\)](#)

#### Paper Feed Adjustment

Execute this when streaks and unevenness that occur in print results are not improved even though print head cleaning was executed.

 [“Paper Feed Adjustment Method” \(Page 76\)](#)

#### Nozzle Check Methods

There are two types of nozzle checks, [Normal] and [Saving Ink].

[Normal] prints a check pattern on roll paper and automatically checks the status of the nozzles. Roll paper must be loaded on the printer.

[Saving Ink] does not print a check pattern and automatically checks the state of the nozzles.


#### 1. Select a printer, in the printer list area on the main screen, on which to execute a nozzle check.

When you select multiple printers, press and hold [Ctrl] as you select the targeted printers. See the following for more details on the main screen.

 [“Explanation of the Main Screen” \(Page 65\)](#)



2. In [Printer maintenance] - [Nozzle Check], select [Normal] or [Saving Ink], and then click [Execute].




Nozzle check is executed.

3. Check the results of nozzle checks in the message displayed in [Printer history]. When "<Printer name>-Nozzle Check is complete." is displayed, the work is complete. When "Clogged nozzles detected. Perform [Forced Cleaning]." is displayed, execute [Forced Cleaning].
- ["Forced Cleaning" \(Page 75\)](#)
- Perform [Print Check Pattern] to check the condition of the nozzles.
- ["Print Nozzle Check Pattern Method" \(Page 73\)](#)

## Print Nozzle Check Pattern Method


1. Load paper to print a nozzle check pattern.
- ["Basic Operations" \(Page 24\)](#)
2. Select a printer, in the printer list area on the main screen, on which to print a nozzle check pattern.
- When you select multiple printers, press and hold [Ctrl] as you select the targeted printers. See the following for more details on the main screen.
- ["Explanation of the Main Screen" \(Page 65\)](#)
3. In [Printer maintenance] - [Nozzle Check], select [Print Check Pattern].

4. Select the paper source for the paper loaded in step 1, and then click [Execute].




The check pattern is printed.

5. Review the printed check pattern while referring to the following section. **Example of clean nozzles**



If none of the check pattern is missing, then the print head nozzles are not clogged.

### Example of clogged nozzles



If part of the pattern is missing, then the print head nozzles are clogged. The print head needs to be cleaned.

["Print Head Cleaning Method" \(Page 74\)](#)

## Print Head Cleaning Method

### Types of Cleaning and Order of Implementation

There are two types of cleaning, [Forced Cleaning], which is cleaning the print head manually, and [Diagnostic Cleaning], which detects clogged nozzles and cleans the print head automatically.

First, implement [Diagnostic Cleaning].

After doing that, when “Clogged nozzles detected. Perform [Forced Cleaning].” is displayed in [Printer history] on the main screen, implement [Diagnostic Cleaning].

If the clogged nozzles are not cleared after repeating [Diagnostic Cleaning] three times, then do [Forced Cleaning] set to [Power].

### Diagnostic Cleaning

#### 1. Select a printer, in the printer list area on the main screen, on which to execute cleaning.

When you select multiple printers, press and hold [Ctrl] as you select the targeted printers. See the following for more details on the main screen.


 [“Explanation of the Main Screen” \(Page 65\)](#)

If an error is displayed for the printer you want to select, clear the error before selecting it.

#### 2. In [Printer maintenance] - [Diagnostic Cleaning], select [Normal] or [Saving Ink], and then click [Execute].

[Normal] prints a check pattern on roll paper and automatically checks the status of the nozzles. Roll paper must be loaded on the printer.

[Saving Ink] does not print a check pattern and automatically checks the state of the nozzles.



The nozzle check starts and cleaning is executed if necessary.

The time needed for cleaning varies according to the status of the nozzles.

#### 3. Check the results of Diagnostic Cleaning in the message displayed in [Printer history].

When “Clogged nozzles detected. Perform [Forced Cleaning].” is displayed, execute [Diagnostic Cleaning] again.

If “Auto Nozzle Check has failed.” is displayed, contact service support.

If the clogged nozzles are not cleared after repeating [Diagnostic Cleaning] three times, then execute [Forced Cleaning] set to [Power].

 [“Forced Cleaning” \(Page 75\)](#)

## Forced Cleaning

### 1. Select a printer, in the printer list area on the main screen, on which to execute cleaning.

When you select multiple printers, press and hold [Ctrl] as you select the targeted printers. See the following for more details on the main screen.


 [“Explanation of the Main Screen” \(Page 65\)](#)

If an error is displayed for the printer you want to select, clear the error before selecting it.

### 2. In [Printer maintenance] - [Forced Cleaning], select [Normal] or [Power], and then click [Execute].

Select [Normal] to clean the surface of the print head and to clear clogged nozzles.

[Power] cleans more powerfully than [Normal]. Use this setting if the nozzles are still clogged even after repeating [Normal] cleaning several times. [Power] consumes more ink than [Normal] cleaning. If a message is displayed informing you that there is not enough ink remaining, replace the ink supply unit before continuing.





Cleaning is executed.

Cleaning may take some time depending on the selected cleaning level.

When cleaning is complete, the results are displayed in [Printer history].

### 3. Check the results of Forced Cleaning.

There are the following two ways to check the cleaning results.

- Execute a nozzle check to check for clogged nozzles.  
 [“Nozzle Check Methods” \(Page 72\)](#)
- Print a nozzle check pattern to check for clogged nozzles.  
 [“Print Nozzle Check Pattern Method” \(Page 73\)](#)

If the clogged nozzles are not cleared by executing [Normal] cleaning, execute [Normal] cleaning again. If the clogged nozzles are not cleared even by repeating this several times, execute [Power] cleaning.

If the clogged nozzles are not cleared even by executing [Power] cleaning, contact service support.

## Print Head Alignment Method

If the print results appear grainy or out of focus, perform Print Head Alignment. The Print Head Alignment function corrects print head misalignments when printing.

### 1. Load paper to print an adjustment pattern.

 [“Basic Operations” \(Page 24\)](#)

### 2. Click [Printer settings] on the main screen.

See the following for more details on the main screen.

 [“Explanation of the Main Screen” \(Page 65\)](#)


### 3. Select a printer, in the printer list area on the top of the Printer settings screen, on which to execute Print Head Alignment, and then select [Paper Settings].

You cannot select multiple printers.


See the following for more details on the printer settings screen.

 [“Explanation of the Printer settings” \(Page 67\)](#)

- In [Paper Source], select the paper source in which you loaded paper in step 1.




- Click [Print] in [Print Head Alignment].




Adjustment patterns are printed.

- Check the printed adjustment pattern. Two groups of adjustment patterns, #1 and #2, are printed. Confirm which of the print pattern numbers has no gaps between the nozzles in each group.



- Select the number of the print pattern you confirmed, and then click [Set]. Select the number of the print pattern you confirmed individually for both [#1] and [#2].




The adjustment values are applied.


## Paper Feed Adjustment Method

Execute this when streaks and unevenness that occur in print results are not improved even though print head cleaning was executed.

- Load paper to print an adjustment pattern. [“Basic Operations” \(Page 24\)](#)
- Click [Printer settings] on the main screen. See the following for more details on the main screen. [“Explanation of the Main Screen” \(Page 65\)](#)
- Select a printer, in the printer list area on the top of the Printer settings screen, on which to execute Paper Feed Adjustment, and then select [Paper Settings]. You cannot select multiple printers. See the following for more details on the printer settings screen. [“Explanation of the Printer settings” \(Page 67\)](#)
- In [Paper Source], select the paper source in which you loaded paper in step 1.




- Click [Print] in [Paper Feed Adjustment].



Adjustment patterns are printed.

## 6. Check the printed adjustment pattern.


Two groups of adjustment patterns, #1 and #2, are printed. Confirm the number of the print pattern with the least amount of overlapping or gaps for each group.



If all of the adjustment patterns contain overlaps or gaps, and you cannot narrow it down to one, select the pattern with the least overlap or gap.

## 7. Select the number of the print pattern you confirmed, and then click [Set].

Select the number of the print pattern you confirmed individually for both [#1] and [#2].




The adjustment values are applied.


# Adding Paper Information from Custom Settings (Windows Only)

If you cannot acquire the Paper Type File for the paper you want to use, or when using commercially available paper, add paper information by adjusting the color density of paper information that has already been set.

1. Open the Control Panel, and click [Devices] - [Devices and printers], in this order.
2. Right-click your printer icon, and select [Printing preferences].




3. Select [Maintenance], and click [Paper Type Additional Tool]. Start Paper Type Additional Tool.




4. Click [Custom Settings], and select [Media Type].

Choose a paper type that is the closest match to the paper to be used.




5. Input a name in [Name], then set the [Color Density] to match the paper, and then click [Add].



**Note:**  
The added paper information appears in [Media Type] on the control panel screen and in the printer driver using the name you input in [Name].

- 6. Confirm that the paper information you added in step 5 is selected, and then click [Set].**



Follow the on-screen instructions to continue. When the settings are complete, the paper information appears in [Media Type] on the control panel screen and in the printer driver.


# Control Panel Menu

## Menu List

The following items and parameters can be set and executed in the Menu. See the reference pages for more details on each item.

\*Note. some menu items are only available on DX400W

## Settings

For more information on these items, see  [“Details of the Menu” \(Page 82\)](#).



Item	Parameter
<b>Printer Status</b>	
Supply Status	–
Message List	–
Firmware Version	–
<b>Paper Settings</b>	
Roll Paper	–
Paper information	–
Remaining Amount management	–
Remaining Amount setting	ON, OFF (Default: ON)
Remaining Amount	Enter the setting value
Remaining Alert	Enter the setting value
Paper Type	Display compatible paper types
Cassette	
Paper Size	Display compatible paper sizes
Paper Type	Display compatible paper types
<b>Maintenance</b>	
Print Head Nozzle Check	–
Print Head Cleaning	–
Powerful Cleaning	–
Replace Ink Supply Unit	–
Replace Maintenance Box	–
Reset Counter	–
<b>Printer Setup</b>	
<b>Paper Source Settings</b>	
Paper path for maintenance printing	Roll paper, Cassette, Rear paper feed slot
<b>Error Notice</b>	
Paper Size Notice	ON, OFF (Default: OFF)
Paper Type Notice	ON, OFF (Default: OFF)
Paper Setup Auto Display	ON, OFF (Default: OFF)
<b>Sound</b>	
Mute	ON, OFF (Default: OFF)
Button Press	OFF, Low, Medium, High (Default: High)
Error Tone	OFF, Low, Medium, High (Default: High)
Thick Paper	ON, OFF (Default: OFF)
Horizontal Centered	ON, OFF (Default: OFF)
Power Off Timer	OFF, 30min, 1h, 2h, 4h, 8h, 12h (Default: OFF)



Item	Parameter
<b>Date/Time Settings</b>	
Date/Time	
Date Format	yyyy.mm.dd / mm.dd.yyyy / dd.mm.yyyy
Time Format	12h, 24h (Default: 12h)
Daylight Saving Time	ON, OFF (Default: OFF)
Time Difference	-12:45 to +13:45
Language	English, other languages
Keyboard	QWERTY, AZERTY, QWERTZ, ABC
Sleep Timer	Enter the setting value
PC Connection via USB	Enable, Disable (Default: Enable)
Length Unit	mm, inch (Default: mm)
<b>Network Settings *Only available on DX400W</b>	
Print Status Sheet	
Connection Check	–
<b>Advanced Setup</b>	
Device Name	–
TCP/IP	Auto, Manual
DNS Server	Auto, Manual
Proxy Server	Do Not Use, Use
IPv6 Address	Enable, Disable (Default: Enable)
Link Speed & Duplex	Auto, 10BASE-T Half, 10BASE-T Full, 100BASE-TX Half, 100BASE-TX Full
Redirect HTTP to HTTPS	Enable, Disable (Default: Enable)
Disable IPsec/IP Filtering	–
Disable IEEE802.1X	–
Print Network Status Sheet	–
Print Counter	–
<b>Reports</b>	
Network	–
<b>Security Settings</b>	
<b>Admin Settings</b>	
Admin Password	
Change	–
Restore Default Settings	–
Lock Setting	ON, OFF (Default: OFF)
Password Encryption	ON, OFF (Default: OFF)
<b>Restore Default Settings</b>	
Network Settings	–
Clear All Data and Settings	–

## Details of the Menu

\* indicates default settings.

Item	Parameter	Explanation
Printer Status		
Supply Status	-	You can confirm an estimate of the amount of ink remaining and the free space in the maintenance cartridge. The  mark indicates that the ink levels or the free space in the maintenance cartridge are low. The  mark indicates that the ink level is below the minimum value or that there is no free space in the maintenance cartridge, so the ink supply unit or maintenance cartridge should be replaced.
Message List	-	The printer's current status and description of unresolved errors are displayed in a list.
Firmware Version	-	Displays the firmware version of the printer.
Paper Settings		
Roll Paper		
Paper information		Displays paper type that is currently set.
Remaining Amount Management	-	When [Remaining Amount Setting] is [On], information about the remaining amount of paper is printed as a barcode when printing ends, so that the next time that roll of paper is loaded, the information about the remaining amount can be scanned.
Remaining amount setting	<b>ON, OFF</b>	This is useful because the remaining amounts of roll paper can be managed automatically. In addition to bar codes, the following information is printed as text that can be read visually.
Remaining Amount	Enter the setting value	<ul style="list-style-type: none"> <li>• Time and date barcode printed</li> <li>• Model name</li> <li>• Paper Type</li> <li>• Remaining Amount</li> </ul>
Remaining Alert	Enter the setting value	When loading roll paper for the first time, set the remaining amount from [Paper Remaining]. When the remaining amount reaches the level set in [Remaining Alert], a warning message appears in the control panel screen.
Paper Type	Displays the supported paper types	Set the type of roll paper being loaded.
Cassette		
Paper Size	Displays the supported paper sizes	Set the type and size of sheet paper loaded in the cassette of the sheet feeder (option).
Paper Type	Displays the supported paper types	

Item	Parameter	Explanation
<b>Maintenance</b>		
Print Head Nozzle Check	-	Print a check pattern to check whether nozzles (holes that eject ink) in the print head are clogged.
Print Head Cleaning	-	Clean the print head nozzles to clear the clogs.
Powerful Cleaning	-	This is powerful cleaning that is executed when clogged nozzles are not cleared by doing Print Head Cleaning.
Replace Ink Supply Unit	-	Execute this when replacing ink supply units so you can watch the explanation displayed on the screen.
Replace Maintenance Box	-	Execute this when replacing the maintenance box to watch an explanation shown on screen while you replace the parts.
Reset Counter	-	Execute this to reset the amount of paper that has been fed from the cassette of the sheet feeder. Be sure to execute this when you replace feed rollers at the end of their service life.
<b>Printer Setup</b>		
<b>Paper Source Settings</b>		
Paper path for maintenance printing	<b>Roll Paper</b>	When printing the nozzle check pattern or network connection diagnosis report, set where the set paper will be used.
	Cassette	
	Rear Paper Feed Slot	
Error Notice		When turned [On], error messages are displayed when the paper type and size set in Print Settings does not match the fed Paper Setting.
Paper Size Notice	ON, OFF	
Paper Type Notice	ON, OFF	
Paper Setup Auto Display	ON, OFF	Select On to display the Paper Setting screen when loading paper in the cassette of Sheet Feeder (Option).
Sound		Sets volume of sounds produced by the printer. When [Mute] is [On], all sounds are muted.
Mute	ON, OFF	
Button Press	OFF, Low, Medium, High	
Error Tone	OFF, Low, Medium, High	
Thick Paper	ON, OFF	Normally, leave this [Off]. Set this to [On] to widen the gap between the print head and paper to reduce rubbing if the print head and paper rub together causing print results to be dirty.
Horizontal Centered	ON, OFF	Set this function when the paper is skewed during printing.
Power Off Timer	OFF, 30min, 1h, 2h, 4h, 8h, 12h	Set the time until the power automatically turns off when the printer has continuously not been operated.
<b>Date/Time Settings</b>		
Date/Time		Set the current date and time and their display format.
Date Format	yyyy.mm.dd / mm.dd.yyyy / dd.mm.yyyy	
Time Format	12h, 24h	
Time Difference	-12:45 to +13:45	Set the time difference with coordinated universal time (UTC).
Language	English, other languages	You can select the language displayed on the screens.
Keyboard	QWERTY, AZERTY, QWERTZ, ABC	Select the keyboard layout used in the control panel screens.






Item	Parameter	Explanation
Sleep Timer	Enter the setting value	Set the time until the printer automatically goes into sleep (energy saving) mode when the printer has continuously not been operated. When the set time is exceeded, the screen becomes dark.
PC Connection via USB	<b>Enable</b> , Disable	When [Enable] is set, access is allowed from computers connected via USB.
Length Unit	<b>mm</b> , inch	Set the units of length to be displayed and input on the control panel.
<b>Network Settings</b> *Only available on DX400W		
Print Status Sheet	-	Prints the network status sheet.
Connection Check	-	Checks the status of the printer's network connection and prints a network connection diagnosis report. If there is a problem with the connection, use the results of the diagnosis to resolve it.
<b>Advanced Setup</b>		Set various items related to the network.
Device Name	-	
TCP/IP	<b>Auto</b> , Manual	
DNS Server	<b>Auto</b> , Manual	
Proxy Server	<b>Do Not Use</b> , Use	
IPv6 Address	<b>Enable</b> , Disable	
Link Speed & Duplex	<b>Auto</b> , 10BASE-T Half, 10BASE-T Full, 100BASE-TX Half, 100BASE-TX Full	
Redirect HTTP to HTTPS	<b>Enable</b> , Disable	
Disable IPsec/IP Filtering	-	
Disable IEEE802.1X	-	
Print Network Status Sheet	-	Prints the network status sheet.
Print Counter	-	Displays the total number of pages printed from the start of use to the present, converted to 102 x 152 mm (4 x 6 inch) pages.
<b>Reports</b>		Checks the status of the printer's network connection and prints a network connection diagnosis report. If there is a problem with the connection, use the results of the diagnosis to resolve it.
Network	-	
<b>Security Settings</b>		
<b>Admin Settings</b>		Sets, changes, and initializes the administrator's password. The initial value for the administrator's password is the product's serial number. Confirm the product serial number printed on a label on the printer.
<b>Admin Password</b>		
Change	-	
Restore Default Settings	-	
Lock Setting	<b>ON</b> , <b>OFF</b>	Uses the [Admin Password] to lock the control panel so it cannot be used.
Password Encryption	<b>ON</b> , <b>OFF</b>	Select [On] to encrypt the password, and then restart the printer. If the power is cut off during a restart, the password data could be damaged and the printer's settings initialized. If this happens, reset the password information.
<b>Restore Default Settings</b>		
Network Settings	-	Return network related settings to factory defaults.
Clear All Data and Settings	-	Returns all settings to their defaults. However, "time", "language" and "each counter" will not be initialized.







# Problem Solver

## When a Message Is Displayed

### Messages Displayed on the Printer

If one of the following messages is displayed, read and follow the instructions below.

Message	What to do
There may be foreign material inside the printer. Check and remove it.	Some protective tape or protective materials may have been left inside the printer. Remove all the protective tape and protective materials, and then turn the power on again.
Paper that is not a standard size has been loaded. Reload or replace it.	<ul style="list-style-type: none"> <li>A size of roll paper that the printer cannot use may have been loaded. Correctly load a supported standard size of roll paper.  <a href="#">“How to Replace Roll Paper” (Page 25)</a></li> <li>The ends of the roll paper could have become uneven. Even up the ends of the roll paper, and then reload it onto the spindle unit. Or, use a new roll of paper.  <a href="#">“Notes when Loading Roll Paper” (Page 24)</a>  <a href="#">“How to Replace Roll Paper” (Page 25)</a></li> </ul>
Print head may require maintenance. Perform a Print Head Nozzle Check.	Nozzles may be clogged because the print head unit was stopped for a long period outside the specified position. We recommend doing a nozzle check to check for clogged nozzles, and then to clean the heads if necessary.  <a href="#">“Print Head Nozzle Check and Cleaning” (Page 62)</a>
Printing may have been done while the nozzles were clogged. Check the print results.	The print head’s auto nozzle check function detected clogged nozzles. Check the print results and clean the print head if needed, and then start printing again.  <a href="#">“Print Head Nozzle Check and Cleaning” (Page 62)</a>
Parts are nearing the end of their service life. XXXXXXXX	The part number appears in XXXXXXXXXXXX. A part used in the printer is nearing its replacement time. The printer can be used until the replacement notice appears, but you will need to request repairs to do the replacement.
It is time to replace a printer part. XXXXXXXX	The part number appears in XXXXXXXXXXXX. It is time to replace a part in the printer. Contact your sales company or retailer. Be sure to tell them the part number when you contact them.
Cannot check nozzle clogging or read barcodes.	Could not read the barcode of the Remaining Amount Management function or the check pattern of the Auto Nozzle Check function. Turn the printer’s power off and then on again to use it.  If you turn the power off and on several times and the same error occurs, then a sensor may be malfunctioning. Contact your sales company or retailer.
Cannot check nozzle clogging. For details, see your documentation.	Could not read the check pattern of the Auto Nozzle Check function. If necessary, stop printing and do a nozzle check.  If you repeat this and the same error occurs, then a sensor may be malfunctioning. Contact your sales company or retailer.

Message	What to do
<p>Could not read the barcode correctly. Set paper type and remaining paper.</p>	<p>Could not read the barcode of the Remaining Amount Management function on the loaded roll paper. Reset the remaining amount, and then use the printer. Remove the printer cover to check the remaining amount, which is printed in text on the leading edge of the roll paper.</p> <p>If you repeat this and the same error occurs, then a sensor may be malfunctioning. Contact your sales company or retailer.</p>
<p>Printer error. Turn power off and on again. See documentation. XXXXXXX</p>	<p>A code number appears in XXXXXXXXXX according to the content of the error. Turn off the printer, disconnect the power cable from the outlet and from the AC inlet on the printer, and then reconnect it. Turn on the printer again multiple times. If the same code number appears again, contact your sales company or retailer. Be sure to tell them the code number when you contact them.</p>
<p>Adjustment canceled. There is a problem with the print head nozzles. For details, see documentation.</p>	<p>Clogs are not cleared even by repeatedly alternating nozzle checks and head cleaning. After leaving the printer alone and not printing for more than 12 hours, execute a nozzle check and head cleaning again. We recommend turning off the power and leaving the printer alone. If the situation does not improve, try doing power cleaning. If the clogs are not cleared even after executing power cleaning, then after not printing for more than 12 hours, print a nozzle check pattern. Then, depending on the condition of the printed pattern, execute cleaning or power cleaning again. If the situation is still not improved, then repairs are needed. Contact your sales company or retailer.</p>
<p>Ink low.</p>	<p>The ink is low. Prepare a new ink supply unit. You can continue printing until the replacement notice appears.  <a href="#">“Optional Accessories and Consumables” (Page 109)</a></p>
<p>Cannot recognize Ink Supply Unit. Try installing again.</p>	<ul style="list-style-type: none"> <li>• Reinstall the ink supply unit. If the same error occurs even after reinstalling the ink supply unit, then replace it with a new one (do not install a faulty ink supply unit).  <a href="#">“Replacing Ink Supply Units” (Page 50)</a></li> <li>• Condensation may have formed. Leave it for more than 3 hours at room temperature, and then reinstall it.  <a href="#">“Notes on Handling Ink Supply Units” (Page 18)</a></li> </ul>
<p>The Maintenance Cartridge is nearing the end of its service life. You can continue printing until replacement is required.</p>	<p>There is little available space in the maintenance cartridge. Prepare a new maintenance cartridge. You can continue printing until the replacement notice appears.  <a href="#">“Optional Accessories and Consumables” (Page 109)</a></p>
<p>Cannot recognize the Maintenance Cartridge.</p>	<p>Reinstall the maintenance cartridge. If the same error occurs even after reinstalling the maintenance cartridge, then replace it with a new one (do not install a faulty maintenance cartridge).  <a href="#">“Replacing Maintenance Cartridge” (Page 52)</a></p>
<p>Cannot start cleaning because the Maintenance Cartridge is near full.</p>	<p>Cleaning cannot be executed because there is not enough available space in the maintenance cartridge for the waste ink that is ejected during print head cleaning. To execute cleaning, replace the maintenance cartridge with a new one. The maintenance cartridge that was removed can be reinstalled and used again after cleaning is complete.  <a href="#">“Replacing Maintenance Cartridge” (Page 52)</a></p>


### Message Codes Displayed on the Screen

Message codes are displayed in the upper right part of the screen when there are notices or errors on the printer. Message codes are categorized as shown in the following table, and the various message codes appear when the printer is in the following conditions. When a message is displayed on screen, resolve the problem according to the message that appears.

Category	Message code	Status
Hardware related error at printer	E-01	Printer fatal error
	W-01	Paper jam error
Ink related error	W-11	Ink supply unit not installed error
	W-12	Ink supply unit recognition error
Sensor related error	W-41	Nozzle detection error
	W-42	
	W-43	
	W-44	Sensor module error
	W-45	
	W-46	
	W-47	
Image quality abnormality in sensor detection results	W-51	Abnormality during analysis
	W-52	
	W-53	
Sensor related error	W-61	Error at nozzles or circuit board
	W-62	
	W-63	
	W-64	
	W-65	
Hardware related warning at printer	I-01	Temperature warning at nozzle clog detection not covered by warranty
Sensor related warning	I-41	Sensor module warning











## Maintenance Tool Error Codes and Messages






The Maintenance Tool printer history lists the error codes and messages for errors generated by printers connected to the computer. Should an error occur, check the notification in the display and take the action described below. The messages in the table below can be viewed by mousing over the error code as shown.



Error code	Message	Action
I-1311	The scrap paper box is full.	Check the scrap paper box and empty it if necessary. ☞ <a href="#">“Emptying the Scrap Paper Box” (Page 53)</a>
I-1313	Paper low	The printer is running out of roll paper. Ready a new roll. You can continue printing until prompted to replace the roll.
I-2101	Maintenance required.	One or more of the printer’s internal parts is nearing the end of its service life. You can continue printing until prompted to replace the part but servicing will be required to replace it.
I-2201	Ink is low	One or more colors of ink is running low. Check the ink level in the printer control panel screen and ready a replacement ink supply unit. You can continue printing until prompted to replace the unit.
I-2307	Cannot check nozzle for clogging or read barcodes.	The printer was unable to read the Remaining Amount Management bar code or the check pattern generated by the auto nozzle check feature. Turn the printer off and then on again. If the error persists even after the printer has been turned on and off several times, the sensor may be malfunctioning. Contact your sales company or retailer.
I-2310	Cleaning the print head or charging ink.	Wait until the print head cleaning or ink filling are complete.
I-2401	Maintenance cartridge is nearing the end of its service life.	The maintenance cartridge is almost full. Ready a replacement cartridge. You can continue printing until prompted to replace the Maintenance cartridge.
I-5201	Amount of data in print jobs sent to printer nearly at maximum limit.	The print job is too large. Delete all existing print jobs and split the large job into several smaller jobs.
W-1101	Paper jam	Check the location of the jam in the message and illustration displayed in the printer control panel screen and remove the jammed paper as described in the following section. ☞ <a href="#">“When Paper Jams” (Page 92)</a>
W-1103	Paper skew	Reload the paper after checking that none remains in the inside the printer. ☞ <a href="#">“When Paper Jams” (Page 92)</a> ☞ <a href="#">“Basic Operations” (Page 24)</a>
W-1104	Load the paper.	
W-1105 W-1106	Paper out or incorrect loading	
W-1114	Paper out or incorrect loading	Reload the paper after checking that none remains in the inside the printer. ☞ <a href="#">“When Paper Jams” (Page 92)</a> ☞ <a href="#">“How to Replace Roll Paper” (Page 25)</a>
W-1301	Scrap paper box is not attached correctly.	Attach the scrap paper box correctly as described in the following section. ☞ <a href="#">“Emptying the Scrap Paper Box” (Page 53)</a>



Error code	Message	Action
W-1302	Ink supply unit cover is open	Close the ink supply unit cover.  <a href="#">"Front" (Page 7)</a>
W-1304	Printer cover open	Close the printer cover.  <a href="#">"Front" (Page 7)</a>
W-1307	The paper feed slot cover is open.	Close the rear paper feed slot cover.  <a href="#">"Front" (Page 7)</a>
W-2202	Replace Ink supply unit(s)	Replace the ink supply unit listed in the printer control panel screen.  <a href="#">"Replacing Ink Supply Units" (Page 50)</a>
W-2203 W-2204	Ink supply unit cannot be recognized	<ul style="list-style-type: none"> <li>Remove and reinsert the ink supply unit listed in the printer control panel screen. If the error persists, remove the malfunctioning unit and replace it with a new one (do not continue to use malfunctioning units).  <a href="#">"Replacing Ink Supply Units" (Page 50)</a></li> <li>Condensation may have formed in or on the ink supply unit. Remove the unit and leave it at room temperature for at least three hours before reinserting it.  <a href="#">"Notes on Handling Ink Supply Units" (Page 18)</a></li> </ul>
W-2205	Power Cleaning cannot be completed.	Power Cleaning cannot be performed due to insufficient levels of one or more colors of ink. Replace the ink supply units for the colors listed as low in printer control panel screen. Once cleaning is complete, you can reinsert the original ink supply units and continue using them until the level of ink falls below the minimum value.  <a href="#">"Replacing Ink Supply Units" (Page 50)</a>
W-2208	Ink levels are not enough for initialization.	Initial charging cannot be performed due to insufficient levels of one or more colors of ink. Replace the ink supply units for the colors in question with units that have sufficient levels of ink. Once charging is complete, you can reinsert the original ink supply units and continue using them until the level of ink falls below the minimum value.  <a href="#">"Replacing Ink Supply Units" (Page 50)</a>
W-2301 W-2302 W-2303 W-2305 W-2306 W-2307	W-2325 W-2326 W-2327 W-2349 Cannot check nozzle for clogging.	The printer was unable to read the check pattern generated by the auto nozzle check feature. Stop printing and perform a nozzle check if necessary. If the error persists, the sensor may be malfunctioning. Contact your sales company or retailer.
W-2328 W-2329 W-2350	Could not read the barcode correctly.	The printer was unable to read the Remaining Amount Management bar code or the check pattern generated by the auto nozzle check feature. Turn the printer off and then on again. If the error persists even after the printer has been turned on and off several times, the sensor may be malfunctioning. Contact your sales company or retailer.
W-2360 W-2361 W-2362	Nozzle check is recommended.	The print head's auto nozzle check feature has detected clogged nozzles. Resume printing after checking the print results and performing head cleaning if necessary.  <a href="#">"Print Head Nozzle Check and Cleaning" (Page 62)</a>
W-2401	Maintenance cartridge not installed	Reattach the maintenance cartridge. If the error persists, replace the malfunctioning box with a new one (do not continue to use malfunctioning maintenance cartridges).  <a href="#">"Replacing Maintenance Cartridge" (Page 52)</a>

Error code	Message	Action
W-2402	Maintenance cartridge is at the end of its service life	Replace the maintenance cartridge after checking the part number in the printer control panel screen.  <a href="#">"Replacing Maintenance Cartridge" (Page 52)</a>
W-2403	Maintenance cartridge cannot be recognized	Reattach the maintenance cartridge. If the error persists, replace the malfunctioning box with a new one (do not continue to use malfunctioning maintenance cartridges).  <a href="#">"Replacing Maintenance Cartridge" (Page 52)</a>
W-2404	Power Cleaning cannot be completed.	Print head cleaning cannot be performed because it will generate more waste ink than can currently be contained in the maintenance cartridge. Replace the maintenance cartridge before performing cleaning. You can reattach the original maintenance cartridge and continue using it once cleaning is complete.  <a href="#">"Replacing Maintenance Cartridge" (Page 52)</a>
W-5202	Amount of data in print jobs sent to printer is at maximum limit.	The print job is too large. Delete all existing print jobs and split the large job into several smaller jobs.
W-5207	Paper out or incorrect loading	Reload the paper after checking that none remains in the inside the printer.  <a href="#">"When Paper Jams" (Page 92)</a>  <a href="#">"Basic Operations" (Page 24)</a>
W-5208	Print job error	An attempt has been made to print using an incompatible printer driver. <ul style="list-style-type: none"> <li>• Use the printer driver described in the printer manual.</li> <li>• Check the printer port as follows: Click the [Ports] tab in the "Printer Properties" dialog and check that there is a port selected next to the printer name. If the printer is not listed, the driver has not been installed correctly. Delete and reinstall the printer driver.</li> </ul>
W-5209	Paper Size is different to the paper loaded	The paper type selected in the printer driver is not the same as that chosen via the printer control panel. Follow the instructions displayed in the printer control panel screen.
W-5210	Mismatch between the paper size settings on your computer and printer.	
W-5211	Mismatch between the paper type settings on your computer and printer.	
W-5212	Mismatch between the print settings on your computer and printer.	
E-2101	It is time to replace a printer part.	Replace the parts according to the instructions displayed on the printer's LCD screen.
E-5101	-	Check that the printer and computer are connected via cable and turn the printer off and then on again. If the error persists, contact your sales company or retailer.
E-9901 E-9902	-	Turn the printer off, disconnect the power cable from both the printer and the outlet, and then reconnect the cable. Turn the printer off and then on again a few times. If this error occurs again, contact your sales company or retailer with the number displayed in the printer control panel screen.

## Error Messages (Windows)

When an error occurs while printing, you can check error messages on the computer that is connected to the printer.

To check error messages on the computer, open FUJIFILM DX400 Printer Window.


Click the utility icon in the Windows taskbar, and then click the printer's name - [FUJIFILM DX400 Printer Window], in this order, to start FUJIFILM DX400 Printer Window.



### FUJIFILM DX400 Printer Window

Error messages are displayed at the top of the screen. When an error message is displayed, check the solution on the screen and take the required measures.



Check the printer's status, such as the remaining amount of ink, also.



## Registering the printer window icon

If the following confirmation screen appears when printing, select either option according to your purpose.

- : A printer window icon will be added to the taskbar. Double-click the icon to display information about the printer, such as the ink level.
- : The icon for calling up the printer window will not be registered in the taskbar.



Even if you select “No”, Printer Window can be displayed from the printer driver. You can also place the icon in the taskbar by following the steps below from the printer driver .

1. Click the “Utility” tab of the printer driver.
2. Click “Monitoring Preferences”.
3. Check “Place the icon in the taskbar”.

## Troubleshooting

### When Paper Jams

This section explains how to clear paper jammed in the printer.



#### CAUTION



- Do not touch any areas inside the printer except for those indicated in the manual. An electric shock or burn could occur.
- When opening and closing the covers, do not place your hands near the points where the main unit and the cover join. If your fingers or hands are trapped, an injury could occur.
- When moving the roll paper unit in or out, grip the handle. If you place your hands into any other sections, either side of your hand or fingers could be injured.




### Screen Display When Paper Jams



When a paper jams, messages and illustrations are displayed on the screen of the control panel. The displayed information varies, as shown in the following table, according to the location of the jam and the type of paper being printed. Follow the steps described in the following section to implement the removal procedure according to the information shown.

The illustrations in the following table are displayed by pressing the ▼ button in the screen in which the message is displayed.




#### When printing on roll paper




<b>Message</b>	Roll paper jammed. Remove it.
<b>Illustration</b>	
<b>Removal procedure to implement</b>	 "Paper is Jammed in the Roll Paper Unit" (Page 93)



<b>Message</b>	Roll paper jammed. Remove it.	
<b>Illustration</b>		When sheet feeder is installed 
<b>Removal procedure to implement</b>	 "Paper is Jammed in the Paper Feed Unit" (Page 95)	

<b>Message</b>	Roll paper jammed. Remove it.	
<b>Illustration</b>		
<b>Removal procedure to implement</b>	 "Paper Jammed Between the Paper Feed Unit and Platen" (Page 99)	

#### When printing on sheet paper



<b>Message</b>	Paper jammed in Rear Paper Feed Slot. Remove it.	
<b>Illustration</b>		When sheet feeder is installed 
<b>Removal procedure to implement</b>	 "Paper is Jammed in the Paper Feed Unit" (Page 95)	

<b>Message</b>	Paper jammed in Inside. Remove the jammed paper.	
<b>Illustration</b>		When sheet feeder is installed 
<b>Removal procedure to implement</b>	 "Paper Jammed Between the Paper Feed Unit and Platen" (Page 99)	

<b>Message</b>	Paper jammed in Cassette. Remove it.	
<b>Illustration</b>		When sheet feeder is installed 
<b>Removal procedure to implement</b>	☞ “Paper Jammed Between the Rear Cover and the Paper Feed Unit” (Page 104)	

If paper is jammed when the power is turned on, the following message appears.

If this happens, the location in which paper is jammed is not identified. Implement all of the removal procedures to remove any paper that is jammed.

<b>Message</b>	Paper jammed in Inside. Remove the jammed paper.	
<b>Illustration</b>		When sheet feeder is installed 

**! Important**

- If a printer system error occurs, turn off the power for a moment, and then turn it on again to confirm whether the error persists, and then check if a paper jam has occurred.
- Do not remove paper forcibly when clearing paper jams. Otherwise, the printer could be damaged.
- If paper is jammed inside the printer where you cannot reach it with your hands, do not try to forcibly extract it yourself, contact your sales company or retailer.

## Paper is Jammed in the Roll Paper Unit

Follow the steps below to solve the problem.

### 1. Remove the scrap paper box.



### 2. Pull out the roll paper unit.




**! Important**

If you cannot pull out the roll paper unit, do not forcibly pull it out. Paper may be jammed inside. Refer to the next section to check for paper jams in the platen and paper feed unit, and remove any jammed paper.

- 3. Turn the handle on the left side of the roll paper unit in the direction of the arrow to rewind the roll paper.**


Rewind the roll paper until the leading edge appears at the paper slot.




If it does not rewind, use scissors or something to cut the roll paper near the paper slot.

- 4. If the leading edge of the roll paper is ragged, cut it in a straight line with a pair of scissors or something.**



Cut the paper as straight as possible.



- 5. Remove the spindle unit.**




- 6. Open the internal rear plate.**




- 7. Check that there is no paper or scraps at the back of the inside of the printer.**


If there is a jam, remove the paper slowly.




- 8. Open the front plate.**  
Place your finger in the hole at the bottom and lift to open.




- 9. Check that there is no paper or scraps of paper inside the printer.**  
If there is a jam, remove the paper slowly.



- 10. Replace the front and rear plates.**  
Press down until you hear it click into place.




- 11. On the control panel screen, press the OK button.**  
The error is canceled and the home screen is displayed.
- 12. If there is a print job, press the ⏏ button to cancel the job.**
- 13. Reload the roll paper.**  
See the following for the procedure to load the roll paper.  
 ["How to Replace Roll Paper" \(Page 25\)](#)
- 14. Confirm that the status light is off.**

### Paper is Jammed in the Paper Feed Unit

Follow the steps below to solve the problem.

#### Checking for jammed paper

- 1. Remove the paper feed unit.**




- 2. Check for jammed paper and paper scraps.**

### Checking for jammed paper (The sheet feeder is installed)

1. If the sheetfeeder is installed, open the rear cover.



2. Remove the paper feed unit.



3. Check for jammed paper and paper scraps.

### Removing jammed paper (roll paper)

1. Cut the jammed paper with scissors or something.



2. Remove paper from the top side. Remove it slowly.



**!** Important

After cutting the paper, do not pull paper at the rear side out through the upper side. Follow the steps below to remove paper from the rear side.



3. Move to the front, and remove the scrap paper box.




4. Pull out the roll paper unit.




5. Turn the handle on the left side of the roll paper unit in the direction of the arrow to rewind the paper.

Rewind the paper until the leading edge appears at the paper slot.



If it does not rewind, use scissors or something to cut the roll paper near the paper slot.

6. Move to the rear side, and install the paper feed unit.





7. If the sheet feeder is installed, close the rear cover.



8. Move to the front, and on the control panel screen, press the OK button.


The error is canceled and the home screen is displayed.

**9.** If there is a print job, press the  button to cancel the job.

**10.** Reload the roll paper.  
See the following for the procedure to load the roll paper.  
 [“How to Replace Roll Paper” \(Page 25\)](#)

**11.** Confirm that the status light is off.

**4.** Move to the front, and on the control panel screen, press the [OK] button.  
The error is canceled and the home screen is displayed.

**5.** Reload the sheet paper.  
See the following for the procedure to load the sheet paper.  
 [“How to Replace Roll Paper” \(Page 25\)](#)


**6.** Confirm that the status light is off.

### Removing jammed paper (sheet paper)

**1.** Remove jammed paper.  
Remove it slowly.



**2.** Install the paper feed unit.



**3.** If the sheet feeder is installed, close the rear cover.



## Paper Jammed Between the Paper Feed Unit and Platen


Follow the steps below to solve the problem.

### Checking for jammed paper

1. If the sheet feeder is installed, open the rear cover.



2. Remove the paper feed unit.





3. Remove the printer cover. Slide the printer cover backwards, and then remove it.



4. Check for jammed paper and paper scraps.


## Removing jammed paper (roll paper)

1. If a lot of paper has been ejected from the front of the printer, cut the paper in front of the jam with a pair of scissors or something.



**2. Slowly pull out, towards the rear, the remaining paper jammed at the top side.**

If you have pulled out the paper, go to step 4.  
If the paper is under the print head and cannot be easily removed, go to the next step.




**3. Move the print head unit manually, and remove the paper towards the rear.**

Move the print head unit to the left or right to the edge of the paper.



**! Important**

- If you cannot move the print head unit, do not try to force it to move, contact your sales company or retailer. Otherwise, the print head unit could be damaged.
- When removing the paper, do not touch the ink absorbing areas. Otherwise, the platen may get dirty which could make the back of the paper dirty.



- Do not touch the parts around the platen. Otherwise, it may break down or reduce print quality.



4. Cut the paper you have pulled out with scissors or something.



**! Important**

After cutting the paper, do not pull paper at the rear side out through the upper side. Follow the steps below to remove paper from the rear side.

5. Move to the front, and remove the scrap paper box.




6. Pull out the roll paper unit.



7. Turn the handle on the left side of the roll paper unit in the direction of the arrow to rewind the paper.

Rewind the paper until the leading edge appears at the paper slot.




If it does not rewind, use scissors or something to cut the roll paper near the paper slot.

8. Move to the rear side, and install the printer cover.



**9. Install the paper feed unit.**




**10. If the sheet feeder is installed, close the rear cover.**



**11. Move to the front, and on the control panel screen, press the OK button.**

The error is canceled and the home screen is displayed.

**12. If there is a print job, press the  button to cancel the job.**

**13. Reload the roll paper.**

See the following for the procedure to load the roll paper.

 [“How to Replace Roll Paper” \(Page 25\)](#)

**14. Confirm that the status light is off.**

**Removing jammed paper (sheet paper)**

**1. Remove jammed paper.**

Remove it slowly to the rear.

If you have pulled out the paper, go to step 3.  
If the paper is under the print head and cannot be easily removed, go to the next step.




**2. Move the print head unit manually, and remove the paper towards the rear.**

Move the print head unit to the left or right to the edge of the paper.



**! Important**

- If you cannot move the print head unit, do not try to force it to move, contact your sales company or retailer. Otherwise, the print head unit could be damaged.
- When removing the paper, do not touch the ink absorbing areas. Otherwise, the platen may get dirty which could make the back of the paper dirty.




- Do not touch the parts around the platen. Otherwise, it may break down or reduce print quality.



**3. Install the printer cover.**



**4. Install the paper feed unit.**



**5. If the sheet feeder is installed, close the rear cover.**



**6. Move to the front, and on the control panel screen, press the [OK] button.**

The error is canceled and the home screen is displayed.

**7. Reload the sheet paper.**

See the following for the procedure to load the sheet paper.

["How to Load Sheet Paper" \(Page 31\)](#)

**8. Confirm that the status light is off.**


## Paper Jammed Between the Rear Cover and the Paper Feed Unit

Follow the steps below to solve the problem.

1. Open the rear cover of the sheet feeder.




2. Remove the paper feed unit.



3. Check for jammed paper and paper scraps. Remove the jammed paper slowly.




4. Install the paper feed unit.



5. Close the rear cover.



6. Move to the front, and on the control panel screen, press the [OK] button.  
The error is canceled and the home screen is displayed.
7. Reload the sheet paper.  
See the following for the procedure to load the sheet paper.  
 ["How to Load Sheet Paper" \(Page 31\)](#)
8. Confirm that the status light is off.



## You Cannot Print (Because the Printer Does Not Work)

### The printer driver is not installed properly (Windows).

#### ■ Is the icon for this printer displayed in the Devices and Printers folder?

- Yes

The printer driver is installed. See the following item, “The printer is not connected correctly to the computer”.

- No (An icon is displayed under “Unspecified”)
 

Do the following:

  - (1) Open the Control Panel, and click [Hardware and Sound] - [Device Manager] - [Other devices], in this order.
  - (2) Right-click [FUJIFILM DX400], and then click [Update Driver Software].
  - (3) Click Search automatically for updated driver software.
  - (4) After the driver software is updated, click Close.


If the printer driver is still not installed even after taking the above measures, install the printer driver again.

#### ■ Does the printer port setting match the printer connection port?

Check the printer port.

Click the [Port] tab on the printer’s Properties screen, and check if the printer name’s port is set. If it is not indicated, the printer driver is not installed correctly.

Delete and reinstall the printer driver.

 [“Uninstalling Software” \(Page 23\)](#)

### The printer is not communicating with the computer.

#### ■ Is the cable plugged in properly?

Confirm that the interface cable is securely connected to both the printer port and the computer. Also, make sure the cable is not broken nor bent. If you have a spare cable, try connecting with the spare cable.

### The printer has an error.

#### ■ View the message displayed in the control panel.

 [“Control Panel” \(Page 13\)](#)

 [“When a Message Is Displayed” \(Page 85\)](#)

### The printer stops printing.

#### ■ Is the status of print queue Pause? (Windows)

If you stop printing or the printer stops printing because of an error, the print queue enters a [Pause] status. You cannot print in this status.

Double-click the printer icon in the [Devices and Printers] folder; if printing is paused, open the [Printer] menu and clear the [Pause] check box.

### The printer is offline.

#### ■ Has the computer entered sleep mode?

Do not allow the computer to enter sleep mode. When the computer enters sleep mode, the printer may go offline.



If the printer goes offline, reboot your computer. If the printer is still offline even after rebooting your computer, turn the printer off and then on again.

## The Printer Sounds Like It Is Printing, but Nothing Prints

### The print head moves, but nothing prints.

#### ■ Confirm the printer operation.

Print a nozzle check pattern, and then check the printer’s operations and print conditions.



- When printing from the printer
  -  [“Print Head Nozzle Check and Cleaning” \(Page 62\)](#)
- When printing from Maintenance Tool (Windows)
  -  [“Print Nozzle Check Pattern Method” \(Page 73\)](#)

Check the next section if the nozzle check pattern is not printed correctly.

### The nozzle check pattern is not printed correctly.

#### ■ Perform head cleaning.

The nozzles may be clogged. Print a nozzle check pattern again after performing head cleaning.

- When executing cleaning from the printer
  -  [“Print Head Nozzle Check and Cleaning” \(Page 62\)](#)
- When executing cleaning from Maintenance Tool (Windows)
  -  [“Diagnostic Cleaning” \(Page 74\)](#)

## Cannot Do Borderless Printing

### ■ Is the paper loaded correctly?

Follow the procedures below to load the paper in the correct position. Borderless printing cannot be done if paper is loaded in the wrong position.

 [“Attaching the Roll Paper” \(Page 26\)](#)

 [“Installing the Spindle Unit” \(Page 28\)](#)

### ■ Are you using paper that supports borderless printing?

Borderless printing can only be done on the printer with supported paper. See the following and use paper that supports borderless printing.

## The Prints Are Not What You Expected

### Print quality is poor, uneven, too light, or too dark.

#### ■ Are the print head nozzles clogged?

If the nozzles are clogged, specific nozzles do not fire ink and the print quality declines. Try doing a nozzle check.

- For Windows

 [“Nozzle Check Methods” \(Page 72\)](#)

#### ■ Are the Media Type settings correct?

Print quality can be affected if the media settings in the printer driver/on the printer and the actual paper do not match. Be sure to match the media type setting with the paper that is loaded in the printer.


#### ■ Are you using a recommended (genuine) ink supply unit?

This printer is developed for use with genuine ink supply units.

If you use non-genuine products, the prints may smear, or the color of the printed image may be changed because the remaining ink level is not correctly detected. Be sure to use the correct ink supply units.

#### ■ Are you using an old ink supply unit?

The print quality declines when an old ink supply unit is used. Replace the ink supply unit with a new one. We recommend using ink supply units before the expiry date printed on the package.

 [“Replacing Ink Supply Units” \(Page 50\)](#)

#### ■ Have you compared the printing result with the image on the display monitor?

Since monitors and printers produce colors differently, printed colors will not always match on-screen colors perfectly.

### The color is not exactly the same as another printer.

#### ■ Colors vary depending on the printer type due to each printer's characteristics.

Because inks, printer drivers, and printer profiles are developed for each printer model, the colors printed by different printer models are not exactly the same.

### The print is not positioned properly on the media.

#### ■ Have you specified the print area?

Check the print area in the settings of the application and the printer.

#### ■ Are the Paper Size settings correct?

If the [Paper Size] in the printer driver and the paper size (width) loaded in the printer do not match, the print position may misalign or some of the data may not be printed. In this case, check the print settings.

### The printed surface is scuffed or soiled.

#### ■ Is the paper too thick or too thin?

Check that the paper specifications are compatible with this printer.

### The reverse side of the printed paper is soiled.

#### ■ Has paper dust collected on the platen?

Clean the platen and roll paper unit.

 [“Cleaning the Platen and Roll Paper Unit” \(Page 54\)](#)

### The paper is creased.

#### ■ Are you using the printer at normal room temperature?

The printer should be used at normal room temperature (temperature: 15 to 25 °C, humidity: 40 to 60%). For information about paper, such as thin paper from other manufacturers that requires special handling, see the documentation supplied with the paper.

## Margins appear in borderless printing.

### ■ Are the settings for the print data in the application correct?

Make sure that the paper settings in the application are correct as well as in the printer driver.

 [“Borderless Printing on All Sides” \(Page 44\)](#)

## Trouble when Printing from a Cassette

### Scratch-like marks appear on the back side of two-sided photo paper during printing.

#### ■ Are you using the correct feed rollers?

Scratch-like marks may appear on the back side of two-sided photo paper during printing if you are using the feed rollers for card stock. Install the feed rollers for photo paper, and then print.

 [“Cleaning and Replacing the Rollers in the Sheet Feeder \(Option\)” \(Page 56\)](#)

#### ■ Are you using the printer within its environmental conditions?

High humidity in the printer’s operating environment is very likely to cause these marks. Check whether the humidity is within the environmental conditions, and lower the humidity as necessary to use the printer.

 [“Specifications Table” \(Page 114\)](#)

#### ■ Did you riffle the paper before loading it in the cassette?

Marks may appear if sheets of paper are stuck to each other in the stacks of paper loaded in the cassette. Before loading the paper, riffle it to unstick it.

 [“Loading in the Sheet Feeder \(Option\)” \(Page 32\)](#)

#### ■ Increase the number of sheets of paper in the cassette.

Depending on the type of paper being used, the marks may appear if there is too little paper in the cassette. Before printing, increase the number of sheets of paper in the cassette to about 50 sheets.

 [“Loading in the Sheet Feeder \(Option\)” \(Page 32\)](#)

## Paper does not feed.

### ■ Is the paper loaded correctly?

- Load paper that can be used on the printer.
- Follow the notes on handling paper.
- Do not load more than the allowable amount of paper.
- Match the paper size and paper type settings on the machine to the paper that is actually loaded.

 [“Consumables” \(Page 109\)](#)

 [“Notes on Paper” \(Page 16\)](#)

 [“How to Load Sheet Paper” \(Page 31\)](#)

### ■ Are you using the correct feed rollers?

Card stock may not feed correctly during printing if you are using the feed rollers for photo paper. Install the feed rollers for card stock, and then print.

 [“Cleaning and Replacing the Rollers in the Sheet Feeder \(Option\)” \(Page 56\)](#)

### ■ Clean the feed rollers and transfer rollers.

The paper feed trouble may occur if the feed rollers or transfer rollers are dirty, such as with paper dust. Clean the surfaces of the rollers.

 [“Cleaning the Feed Rollers and Transfer Rollers” \(Page 59\)](#)

### ■ The feed rollers need to be replaced with new ones.

If paper does not feed even after doing the following, then replace the feed rollers with new ones.

- Is the paper loaded correctly in the cassette?
- Are you using the feed roller that is appropriate for the type of paper?
- Have the feed rollers and transfer rollers been cleaned?

 [“Optional Accessories and Consumables” \(Page 109\)](#)

 [“Replacing Feed Rollers” \(Page 56\)](#)

## Troubles when Cutting Roll Paper

**The cut is crooked, the cut edge is frayed or turned up, or the coating is cracked.**

■ **The cutter needs to be replaced.**

Contact your sales company or retailer to replace the cutter.

## Others

**The administrator password has been lost.**

■ **Contact your sales company or retailer.**

The initial value for the administrator's password is the product's serial number. If you forget the password after it was changed from the product serial number, contact your sales company or retailer.

If the [Lock Setting] is [Off], then you can execute [Clear All Data and Settings] without inputting the admin password. Doing this returns all the settings, including the admin password, to their initial values.

 ["Control Panel Menu" \(Page 80\)](#)

## If Troubles Are Not Resolved

If you cannot resolve a problem after taking the measures described in the "Troubleshooting" section, contact your sales company or retailer.

## Appendix

### Optional Accessories and Consumables

The following consumable products and optional items are available for use with your printer.

#### Optional Accessories

Product name	Explanation
SPINDLE UNIT DX400	Spool (2pcs) and Flange(2pcs), Fixing Parts(1psc)
MAINTENANCE CARTRIDGE DX400	Waste ink cartridge
SHEET FEEDER DX400	Sheet Feeder(1pcs), Feed roller for photo paper(1psc), Feed roller for card stock(1psc)
FEED ROLLERS FOR PHOTO PAPER	Replacement parts in the paper feed section of sheet paper (for use other than postcards)
FEED ROLLERS FOR CARD STOCK	Replacement parts in the paper feed section of sheet paper (for postcards)

#### Consumables

##### (1) Ink

Product name	Explanation
DX400 INK SUPPLY UNIT (C )	250ml Dye-based Ink pack (Exclusive for DX400/400W)
DX400 INK SUPPLY UNIT(M)	
DX400 INK SUPPLY UNIT(Y)	
DX400 INK SUPPLY UNIT(BK)	
DX400 INK SUPPLY UNIT(SB)	
DX400 INK SUPPLY UNIT(P)	

##### (2) Roll Papers

###### Standard Roll Paper

Paper Weight	Paper Size	Surface		Explanation
		Glossy	Luster	
250 gsm	89mm×65m	✓	✓	(Country of origin: Japan)
	102mm×65m	✓	✓	
	127mm×65m	✓	✓	
	152mm×65m	✓	✓	
	203mm×65m	✓	✓	
	210mm×65m	✓	✓	

**(3) Sheet Papers****Standard Double-sided Sheet Paper**

Paper Weight	Paper Size	Surface	Explanation
		Luster	
225 gsm	102 x 152 mm	✓	(Country of origin: Japan)
	127 x 178 mm	✓	
	203 x 254 mm	✓	
	210 x 297 mm	✓	

**Thinner Double-sided Sheet Paper**

Paper Weight	Paper Size	Surface	Explanation
		Luster	
190 gsm	102 x 152 mm	✓	(Country of origin: Japan)
	127 x 178 mm	✓	
	203 x 254 mm	✓	
	210 x 297 mm	✓	

## Moving and Transporting the Printer

This section describes how to move and transport the product.



### CAUTION

- When lifting this printer, make sure you use the correct posture.
- When lifting the product, place your hands in from the front of the printer as shown in the manual. If you hold any other areas, the printer may fall or your fingers could be trapped and damaged when placing the printer.
- Do not tilt the product more than 10 degrees forward, back, left, or right while moving it. Failure to observe this precaution could result in the printer falling over, causing accidents.



### Important

- Only hold the required area. Otherwise, it may breakdown.
- Move the printer while the ink supply units are installed. If the ink supply units are removed, the nozzles may clog so printing is not possible or ink may leak.
- Do not tilt the product when moving or transporting it. Ink could leak out.

## Moving the Printer

This section explains how to move the printer over short distances, such as to a different location within the same building.

### Preparing to Move


Make the following preparations in advance before moving the printer.

- Remove all paper from the printer.
- Close all the printer's covers and store the output tray.
- Turn off the printer and remove all cables.

## How to carry the printer

When lifting the printer to move it, place your hands at the points indicated in the illustration. Also, place your hands so the front of the printer is facing your body, so the scrap paper box does not accidentally fall out.

When sheet feeder (option) is installed



## Operations after Moving

After moving, make sure that the print head is not clogged before use.

 ["Print Head Nozzle Check and Cleaning"](#) (Page 62)

## Transport

If you plan to move the printer long distances, such as sending it back for repairs, please contact your sales company or retailer.



## System Requirements

Software for this printer can be used in the following environments. (As of December, 2023)

Supported OS and other elements may change.


For the latest information, please contact your sales company or retailer.

### Printer Driver

#### Windows

Operating system	Windows 10 / Windows 10 x64 / Windows 11
CPU	Intel Core2 Duo 3.0 GHz or better
Available memory space	1 GB or more
Hard disk (Available volume to install)	2 GB or more
Display resolution	SXGA (1280×1080) or better
Connection method with the printer*	USB connection, or wired LAN connection

\* For details on the connection methods (interface specifications), see the following.


 [“Specifications Table” \(Page 114\)](#)

### Maintenance Tool

#### Windows

Operating system	Windows 10 / Windows 10 x64 / Windows 11
CPU	Intel Core2 Duo 3.0 GHz or better
Available memory space	1 GB or more
Hard disk (Available volume to install)	2 GB or more
Display resolution	SXGA (1280×1080) or better
Connection method with the printer*	USB connection, or wired LAN connection

\* For details on the connection methods (interface specifications), see the following.

 [“Specifications Table” \(Page 114\)](#)

## Specifications Table

### Basic specifications

Printing method	On-demand ink jet
Nozzle configuration	180 nozzles for each color
Highest resolution	1440 x 720 dpi
Paper feed method	Friction feed



#### Important

Use this printer at an altitude of up to 2000 m.



#### WARNING

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### Electrical Specifications

Rated voltage	AC 100 V – 120 V, AC 220 V – 240 V
Rated frequency range	50/60 Hz
Power consumption	Operating: Approximately 80 W

### Interface Specifications

USB port	USB 2.0 (Hi-Speed USB)
Wired LAN compliance standard	10BASE-T (IEEE802.3i) 100BASE-TX (IEEE802.3u) Energy Efficient Ethernet (IEEE802.3az)* <sup>1</sup>

\*1 The connected device must comply with IEEE802.3az standards.

### Roll paper unit Specifications

Loadable sizes	3-inch roll core Outside diameter of 170 mm or less One roll can be loaded
Roll paper width	89 mm (3.5 inches), 102 mm (4 inches), 127 mm (5 inches), 152 mm (6 inches), 203 mm (8 inches), 210 mm (A4)
Roll paper thickness	0.22 to 0.25 mm

## Paper feed unit Specifications

Paper Width	89 to 210 mm
Paper Height	148 to 1000 mm
Paper Thickness	0.20 to 0.50 mm

## Output tray Specifications

Capacity	<p>Roll Paper:            10×15 cm (4 x 6 in) 50 sheets            Length 203 mm (8 in) or less 50 sheets            Length 203.1 mm (8.1 in) to 305 mm (12 in) 20 sheets</p> <p>Sheet paper:            Length 305 mm (12 in) or less 20 sheets</p>
Paper Size	<p>Standard size:            A4 (210×297 mm) or less</p> <p>Non-standard size:            Width 89 mm (3.5 in) to 210 mm (A4), length: 50 mm (1.9 in) to 305 mm (12 in)</p>


## Ink Specifications

Type	Ink supply unit
Ink type	Six color water-based dye (C/M/Y/K/SB/P)
Use by date	Three years after manufacture
Storage temperature	<p>Stored in packaging: -20 to 40 °C (4 days or less at -20 °C, 1 month or less at 40 °C)</p> <p>Installed in printer: -20 to 40 °C (4 days or less at -20 °C, 1 month or less at 40 °C)</p> <p>Transported in packaging: -20 to 60 °C (4 days or less at -20 °C, 1 month or less at 40 °C, 72 hours or less at 60 °C)</p>
Capacity	250 ml
Dimensions	81 (W) x 263.3 (D) x 32.3 (H) mm

### Important

- The ink freezes if left at below -10 °C for a long time. If it does freeze, leave it at room temperature (25 °C) for at least three hours until it has defrosted (without condensation).
- Do not disassemble ink supply units or refill them with ink.

## General Specifications

Temperature	<p>Operating: 10 to 35 °C</p> <p>Storage (before unpacking): -20 to 60 °C (within 120 hours at 60 °C, one month at 40 °C)</p> <p>Storage (after unpacking): -20 to 40 °C (within one month at 40 °C)</p>
Humidity	<p>Operating: 20 to 80% (without condensation)</p> <p>Storage (before unpacking): 5 to 85% (without condensation)</p> <p>Storage (after unpacking): 5 to 85% (without condensation)</p>
Weight	Main unit: 17.6 kg (ink not included)
Dimensions	<p>Main unit: 460 (W) x 374 (D) x 343 (H) mm</p> <p> "Necessary Space" (Page 116)</p>

## Sheet feeder Specifications


Paper Width	89 to 210 mm
Paper Height	148 to 297 mm
Paper Thickness	0.20 to 0.265 mm
Weight	4.9 kg
Dimensions	460 (W) x 428 (D) x 365 (H) mm



### WARNING

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

## Necessary Space



\*1 51 to 180 mm is needed to load sheet paper in the rear paper feed slot. (180 mm for A4 paper)

\*2 Needed to open the rear cover.

## FUJIFILM END USER SOFTWARE LICENSE AGREEMENT

### NOTICE TO USER: PLEASE READ THIS AGREEMENT CAREFULLY BEFORE INSTALLING OR USING THIS PRODUCT.

This is a legal agreement (“Agreement”) between you (an individual or entity, referred to hereinafter as “you”) and Fujifilm Corporation (including its affiliates, “Fujifilm”) for the enclosed software programs, including any related documentation, firmware, or updates (collectively referred to hereinafter as the “Software”). The Software is provided by Fujifilm and its suppliers for use only with the corresponding Fujifilm brand computer peripheral product (the “Fujifilm Hardware”). BEFORE INSTALLING, COPYING OR OTHERWISE USING THE SOFTWARE, YOU NEED TO REVIEW AND AGREE TO THE TERMS AND CONDITIONS OF THIS AGREEMENT INCLUDING THE FUJIFILM PRIVACY POLICY stated in Section 17. If you agree, click on the Agree (“ACCEPT”, “OK” or any similar representation of agreement) on the Software.

If you do not agree with the terms and conditions of this Agreement, return the Software, along with the packaging and related materials, to the place of purchase for a full refund.

1. **Grant of License.** Fujifilm grants you a limited, nonexclusive license to (i) download, install and use the Software for your personal and internal business use on hard disks or other computer storage devices, or in the case of a software application (also referred to as “Software”), on the smartphone, tablet, or other mobile device (collectively, “Device”), provided that the Software is used (i) **only** in a single location (e.g., a home or office or place of business), or in the case of a mobile device, on a Device owned or otherwise controlled by you, and (ii) **only** in connection with Fujifilm Hardware owned by you. You may allow other users of the Fujifilm Hardware connected to your network to use the Software, provided that you shall ensure that such users use the Software only in accordance with this Agreement. You agree to be responsible for and indemnify Fujifilm for liabilities incurred as a consequence of use by such users. You may make backup copies of the Software, as necessary, provided the backup is only used to support your use of the Fujifilm Hardware.
2. **Upgrades and Updates.** If you acquire an upgrade, updated version, modified version, or additions to or for the Software from Fujifilm, the upgrade, updated version, modified version, or addition, shall be included in the defined term Software and governed by this Agreement. You acknowledge that Fujifilm has no obligation to provide you with any Updates (as defined below in this Section 2) to the Software. Fujifilm may, however, from time to time, issue updated versions of the Software and the Software may automatically connect to Fujifilm or third-party servers via the Internet to check for available updates to the Software, such as bug fixes, patches, upgrades, additional or enhanced functions, plug-ins and new versions (collectively, “Updates”) and may either (a) automatically electronically update the version of the Software that you are using on your personal device or (b) give you the option of manually downloading applicable Updates.
3. **Other Rights and Limitations.** You agree not to modify, adapt or translate the Software and further agree not to attempt to reverse engineer, decompile, disassemble or otherwise attempt to discover the source code of the Software. You may not rent, lease, distribute, lend the Software to third parties or incorporate the Software into a revenue generating product or service. You may, however, transfer all of your rights to use the Software to another person or legal entity, provided that the recipient also agrees to the terms of this Agreement and you transfer the Software, including all copies, updates and prior versions, and the Fujifilm Hardware, to such person or entity. The Software is licensed as a single unit, and its component programs may not be separated for some other use. Further, you agree not to place the Software onto or into a shared environment accessible via a public network such as the Internet or otherwise accessible by others outside the single location referred to in Section 1 above.
4. **Ownership.** Title, ownership rights, and intellectual property rights in and to the Software shall remain with Fujifilm or its licensors and suppliers. The Software is protected by United States Copyright Law, copyright laws of Japan and international copyright treaties, as well as other intellectual property laws and treaties. There is no transfer to you of any title to or ownership of the Software and this License shall not be construed as a sale of any rights in the Software. You agree not to remove or alter any copyright, trademark, registered mark and other proprietary notices on any copies of the Software. Fujifilm and/or its licensors and suppliers reserve all rights not granted. The Software may also contain images, illustrations, designs and

photos (“Materials”), and the copyright of such material belongs to Fujifilm and/or its licensors and suppliers, protected by national and/or international intellectual property laws, conventions and treaties. For clarity, (1) the Materials shall be used for non-commercial purposes only, (2) the Materials shall be edited, adjusted and copied only in the manner designated by the Software, and (3) you may use the Materials only for lawful personal use, home use or as otherwise legally permitted.

**5. Open Source and Other Third-Party Components.** Notwithstanding the foregoing license grant, you acknowledge that certain components of the Software may be covered by third-party licenses, including so-called “open source” software licenses, which means any software licenses approved as open source licenses by the Open Source Initiative or any substantially similar licenses, including without limitation any license that, as a condition of distribution of the software licensed under such license, requires that the distributor make the software available in source code format (such third-party components, “Third-Party Components”). A list of Third-Party Components, and associated license terms (as required), for particular versions of the Software is indicated at the end of this Agreement, relevant user manual/CD, or the license information displayed on your Device/in Software. To the extent required by the licenses covering Third-Party Components, the terms of such licenses will apply in lieu of the terms of this Agreement. To the extent the terms of the licenses applicable to Third-Party Components prohibit any of the restrictions in this Agreement with respect to such Third-Party Components, such restrictions will not apply to such Third-Party Component.

**6. Multiple Versions of Software.** You may receive or obtain the Software in more than one version (e.g. for different operating environments; two or more language translation versions; on a CD-ROM), however, regardless of the type or number of copies you receive, you still may use only the media or version appropriate for the license granted in Section 1 above.

**7. Disclaimer of Warranty and Remedy.** If you obtained the Software by media from Fujifilm or a dealer, Fujifilm warrants that the media on which the Software is recorded will be free from defects in workmanship and materials under normal use for a period of 90 days from the date of delivery to you. If the media is returned to Fujifilm or the dealer from which the media was obtained within 90 days of the date of delivery to you, and if Fujifilm determines the media to be defective and provided the media was not subject to misuse, abuse, misapplication or use in defective equipment, Fujifilm will replace the media, upon your return to Fujifilm of the Software, including all copies of any portions thereof. You acknowledge and agree that the use of the Software is at your sole risk. THE SOFTWARE IS PROVIDED "AS IS" AND WITHOUT ANY WARRANTY OF ANY KIND. FUJIFILM AND ITS SUPPLIERS DO NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE. Fujifilm does not warrant that the operation of the Software will be uninterrupted, error free, free from viruses or other harmful components or vulnerabilities, or that the functions of the Software will meet your needs or requirements. Fujifilm’s sole and exclusive liability and your exclusive remedy for breach of warranty shall be limited to either, at Fujifilm’s option, the replacement of the media for the Software or to refund your money upon returning the Software and Fujifilm Hardware. Any replacement Software will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer. If the above remedy fails for any reason, Fujifilm’s entire liability for a breach of warranty shall be limited to a refund of the price paid for the Fujifilm Hardware. Fujifilm is not liable for performance delays or for nonperformance due to causes beyond its reasonable control. This Limited Warranty is void if failure of the Software resulted from accident, abuse, or misapplication. THE STATED LIMITED WARRANTIES AND REMEDY ARE EXCLUSIVE AND IN LIEU OF ALL OTHERS. FUJIFILM DISCLAIMS ALL OTHER WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ALL WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE. SOME JURISDICTIONS, HOWEVER, DO NOT ALLOW EXCLUSIONS OR LIMITATIONS OF IMPLIED WARRANTIES, AND IN SUCH JURISDICTIONS, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

**8. Limitation of Liability.** TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT WILL FUJIFILM OR ITS SUPPLIERS BE LIABLE FOR ANY DAMAGES, WHATSOEVER, WHETHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER ARISING UNDER CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY, BREACH OF WARRANTY, MISREPRESENTATION, OR OTHERWISE, INCLUDING WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR OTHER PECUNIARY LOSS, ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE, OR ARISING OUT OF THIS AGREEMENT, EVEN IF FUJIFILM OR ITS REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR

LIMITATION OF DAMAGES IN CERTAIN TRANSACTIONS, AND IN SUCH JURISDICTIONS , THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY.

9. **U.S. Government Acquisition of the Software.** This Section applies to all acquisitions of the Software by or for the U.S. Government (“Government”), or by any prime contractor or subcontractor (at any tier) under any contract, grant, cooperative agreement, “other transaction” (“OT”), or other activity with the Government. By accepting delivery of the Software, the Government, any prime contractor, and any subcontractor agree that the Software qualifies as “commercial” computer software within the meaning of FAR Part 12, paragraph (b) of FAR Subpart 27.405, or DFARS Subpart 227.7202, as applicable, and that no other regulation, or FAR or DFARS data rights clause, applies to the delivery of this Software to the Government. Accordingly, the terms and conditions of this Agreement govern the Government’s (and the prime contractor and subcontractor’s) use and disclosure of the Software, and supersede any conflicting terms and conditions of the contract, grant, cooperative agreement, OT, or other activity pursuant to which the Software is delivered to the Government. If this Software fails to meet the Government’s needs, if this Agreement is inconsistent in any respect with Federal law, or if the above cited FAR and DFARS provisions do not govern, the Government agrees to return the Software, unused, to Fujifilm.

10. **Export Restriction.** You agree that the Software will not be shipped, transferred or exported into any country or used in any manner prohibited by the United States Export Administration Act or any other export laws, restrictions or regulations.

11. **Entire Agreement.** This Agreement is the entire agreement between the parties related to the Software and supersedes any purchase order, communication, advertisement, or representation concerning the Software.

12. **Binding Agreement; Assignees.** This Agreement shall be binding upon, and inure to the benefit of, the parties hereto and their respective successors, assigns and legal representatives.

13. **Severability; Modifications.** If any provision herein is found void or unenforceable by a court of competent jurisdiction, it will not affect the validity of the balance of the Agreement, which shall remain valid and enforceable according to its terms. This Agreement may only be modified in writing signed by an authorized representative of Fujifilm.

14. **Indemnification.** You agree that you will indemnify and hold harmless, and upon Fujifilm’s request, defend Fujifilm and its directors, officers, shareholders, employees and agents from and against any and all losses, liabilities, damages, costs, expenses (including reasonable attorneys’ fees), actions, suits, and claims arising from (i) any breach of any of your obligations in this Agreement or (ii) any use of the Software or the Fujifilm Hardware. If Fujifilm asks you to defend any such action, suit or claim, Fujifilm will have the right, at its own expense, to participate in the defense thereof with counsel of its choice. You will not settle any third-party claims for which Fujifilm is entitled to indemnification without the prior written approval of Fujifilm.

15. **Termination.** Without prejudice to any other rights Fujifilm has, your license rights under Section 1 above and your warranty rights under Section 7 above, shall automatically terminate upon failure by you to comply with this Agreement. Upon termination of such rights, you agree that the Software, and all copies thereof, will be immediately destroyed.

16. **Capacity and Authority to Contract.** You represent that you are of the legal age of majority in your state or jurisdiction of residence and have all necessary authority to enter into this Agreement, including, if applicable, due authorization by your employer to enter into this Agreement.

17. **Privacy, Information Processing.** The Software may have the ability to connect over the Internet to transmit data to and from your Device. For example, if you install the Software, the Software may cause your Device to send information about your Fujifilm Hardware such as model and serial number, country identifier, language code, operating system information, and Fujifilm Hardware usage information to an Fujifilm Internet site which may return promotional or service information to your Device for display. Any processing of information provided through the Software, shall be according to applicable data protection laws and the Fujifilm Privacy Policy located at <https://www.fujifilm.com/jp/en/privacy>. To the extent permitted by applicable laws, by agreeing to the terms of this Agreement and by installing the Software, you consent to the processing and storage of your information in and/or outside your country of residence. If there is a specific privacy policy

incorporated into the Software and/or displayed when you use the Software (for example, in the case of certain software application software), such specific privacy policy shall prevail over the Fujifilm Privacy Policy stated above.

**18. Third Party Websites.** You may, through hypertext or other computer links from the Software, gain access to websites and use certain services that are not under the control of or operated by Fujifilm, but rather are controlled by third parties. You acknowledge and agree that Fujifilm is not responsible for such third party sites or services, including their accuracy, completeness, timeliness, validity, copyright compliance, legality, decency, quality, or any other aspect thereof. These third party websites/services are subject to different terms and conditions and when you access and use third party websites/services, you will be legally bound by the terms and conditions of those websites/services. If there is a conflict between this Agreement and terms and conditions of third party websites/services, the third party websites'/services' terms and conditions will govern with respect to your access and use of those websites/services. Although Fujifilm may provide a link to a third party website/service from the Software, such a link is not an authorization, endorsement, sponsorship or affiliation by Fujifilm with respect to such website/services, its content, its owners or its providers. Fujifilm provides such links for your reference and convenience only. Accordingly, Fujifilm makes no representations whatsoever concerning such websites/services and does not provide any support related to such third party sites or services. Fujifilm has not tested any information, products or software found on such websites/ services and therefore cannot make any representations whatsoever with respect thereto. You agree that Fujifilm is not responsible for the content or operation of such websites/services, and it is up to you to take precautions to ensure that whatever you select is free of items such as viruses, worms, Trojan horses and other items of a destructive nature. You are solely responsible for determining the extent to which you may use any content at any other websites/services to which you link from this Software.



## OPEN SOURCE SOFTWARE LICENSE TERMS

This product uses open source software as well as software for which Fujifilm owns the rights. Information related to open source software used by the product is shown below.

### Boost Software License - Version 1.0 - August 17th, 2003

Permission is hereby granted, free of charge, to any person or organization obtaining a copy of the software and accompanying documentation covered by this license (the "Software") to use, reproduce, display, distribute, execute, and transmit the Software, and to prepare derivative works of the Software, and to permit third-parties to whom the Software is furnished to do so, all subject to the following:

The copyright notices in the Software and this entire statement, including the above license grant, this restriction and the following disclaimer, must be included in all copies of the Software, in whole or in part, and all derivative works of the Software, unless such copies or derivative works are solely in the form of machine-executable object code generated by a source language processor.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT. IN NO EVENT SHALL THE COPYRIGHT HOLDERS OR ANYONE DISTRIBUTING THE SOFTWARE BE LIABLE FOR ANY DAMAGES OR OTHER LIABILITY, WHETHER IN CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

### Inno Setup License

Except where otherwise noted, all of the documentation and software included in the Inno Setup package is copyrighted by Jordan Russell.

Copyright (C) 1997-2021 Jordan Russell. All rights reserved.

Portions Copyright (C) 2000-2021 Martijn Laan. All rights reserved.

This software is provided "as-is," without any express or implied warranty. In no event shall the author be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter and redistribute it, provided that the following conditions are met:

1. All redistributions of source code files must retain all copyright notices that are currently in place, and this list of conditions without modification.
2. All redistributions in binary form must retain all occurrences of the above copyright notice and web site addresses that are currently in place (for example, in the About boxes).
3. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software to distribute a product, an acknowledgment in the product documentation would be appreciated but is not required.
4. Modified versions in source or binary form must be plainly marked as such, and must not be misrepresented as being the original software.

Jordan Russell

jr-2020 AT jrsoftware.org

<https://jrsoftware.org/>

## 7-Zip Command line version

### License for use and distribution

7-Zip Copyright (C) 1999-2010 Igor Pavlov.

7za.exe is distributed under the GNU LGPL license

Notes:

You can use 7-Zip on any computer, including a computer in a commercial organization. You don't need to register or pay for 7-Zip.

### GNU LGPL information

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You can receive a copy of the GNU Lesser General Public License from <http://www.gnu.org/>

## GNU LESSER GENERAL PUBLIC LICENSE Version 2.1, February 1999

Copyright (C) 1991, 1999 Free Software Foundation, Inc.

51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public Licenses are intended to guarantee your freedom to share and change free software--to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages--typically libraries--of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish); that you receive source code or can get it if you want it; that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can relink them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser license provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries. In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the difference between a "work based on the library" and a "work that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

## TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executables.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law: that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful.

(For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must be optional: if the application does not supply it, the square root function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. (If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish.) Do not make any other change in these notices.

Once this change is made in a given copy, it is irreversible for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange.

If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.

5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to be true is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under Section 6.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging such modifications.

You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

a) Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above);

and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)

b) Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.

c) Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.

d) If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.

e) Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:

a) Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.

b) Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.

8. You may not copy, modify, sublicense, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all. For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Library under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED

INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

## END OF TERMS AND CONDITIONS

### How to Apply These Terms to Your New Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary General Public License).

To apply these terms, attach the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and an idea of what it does.>

Copyright (C) <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the library, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the library `Frob' (a library for tweaking knobs) written by James Random Hacker.

<signature of Ty Coon>, 1 April 1990

Ty Coon, President of Vice

That's all there is to it!

## PDFsharp License

PDFsharp is published under the MIT License.

Copyright (c) 2005-2014 empira Software GmbH, Troisdorf (Germany)

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.



THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

PDFsharp is Open Source.

You can copy, modify and integrate the source code of PDFsharp in your application without restrictions at all.

This also applies to commercial products (both open source and closed source).

## HTML-Renderer / LICENSE

Copyright (c) 2009, José Manuel Menéndez Poo

Copyright (c) 2013, Arthur Teplitzki

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

Neither the name of the menendezpoo.com, ArthurHub nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES

(INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## AdobeRGB

NOTICE TO USER: PLEASE READ THIS CONTRACT CAREFULLY. BY USING ALL OR ANY PORTION OF THE SOFTWARE YOU ACCEPT ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT. YOU AGREE THAT THIS AGREEMENT IS ENFORCEABLE LIKE ANY WRITTEN NEGOTIATED AGREEMENT SIGNED BY YOU. IF YOU DO NOT AGREE WITH THE TERMS OF THIS AGREEMENT, DO NOT USE THE SOFTWARE.

DEFINITIONS. In this Agreement, "Adobe" means Adobe Systems Incorporated, a Delaware corporation, located at 345 Park Avenue, San Jose, California 95110. "Software" means the software and related items with which this Agreement is provided, as listed in Exhibit A.

LICENSE. Subject to the terms of this Agreement, Adobe hereby grants you the worldwide, non-exclusive, nontransferable, royalty-free license to use, reproduce and publicly display the Software. Adobe also grants you the rights to distribute the Software: (a) on a standalone basis (b) as embedded within digital image files. (c) as embedded within hardware products that author digital images, where there is no End User access to the Software, and (d) as bundled with your own application software, provided that you comply with all the

distribution requirements in Section 3 below. No other distribution of the Software is allowed. All individual profiles must be referenced by their ICC Profile description string. YOU MAY NOT MODIFY THE SOFTWARE. Adobe is under no obligation to provide any support under this Agreement, including upgrades or future versions of the Software or other items. No title to the intellectual property in the Software is transferred to you under the terms of this Agreement. You do not acquire any rights to the Software except as expressly set forth in this Agreement. Notwithstanding the above, if you are bundling with Linux or Unix software products, you may (a) add shortcut or menu items within your software that point to the Software, but may not change the name or iconography of the Software, (b) repackage the RPM or Gzip versions of the Software for distribution purposes, and (c) create a graphical user interface as otherwise specifically allowed by instructions found at [www.adobe.com](http://www.adobe.com) or <http://partners.adobe.com> (e.g., installation of additional plug-in and help files) but may not add, delete, or modify any components of the Software without the explicit written permission of Adobe.

**DISTRIBUTION.** If you choose to distribute the Software, you do so with the understanding that you agree to defend, indemnify and hold harmless Adobe against any losses, damages or costs arising from any claims, lawsuits or other legal actions arising out of such distribution, including, without limitation, product liability and other claims by consumers and your failure to comply with this Section 3. If you distribute the Software on a standalone or bundled basis, you will do so by first obtaining the agreement of the end user under the terms of either the Adobe End User License Agreement ("Adobe EULA"), attached as Exhibit B, or your own license agreement which (a) complies with the terms and conditions of this Agreement; (b) effectively disclaims all warranties and conditions, express or implied, on behalf of Adobe; (c) effectively excludes all liability for damages on behalf of Adobe; (d) substantially states that any provisions that differ from this Agreement are offered by you alone and not Adobe; and (e) substantially states that the Software is available from you or Adobe and informs licensees how to obtain it in a reasonable manner on or through a medium customarily used for software exchange. Any distributed Software will include the Adobe copyright notices as included in the Software provided to you by Adobe.

**DISCLAIMER OF WARRANTY.** Adobe licenses the Software to you on an "AS IS" basis. Adobe makes no representation as to the adequacy of the Software for any particular purpose or to produce any particular result. Adobe shall not be liable for loss or damage arising out of this Agreement or from the distribution or use of the Software or any other materials. ADOBE AND ITS SUPPLIERS DO NOT AND CANNOT WARRANT THE PERFORMANCE OR RESULTS YOU MAY OBTAIN BY USING THE SOFTWARE, EXCEPT FOR ANY WARRANTY, CONDITION, REPRESENTATION OR TERM TO THE EXTENT TO WHICH THE SAME CANNOT OR MAY NOT BE EXCLUDED OR LIMITED BY LAW APPLICABLE TO YOU IN YOUR JURISDICTION, ADOBE AND ITS SUPPLIERS MAKE NO WARRANTIES, CONDITIONS, REPRESENTATIONS OR TERMS, EXPRESS OR IMPLIED, WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE AS TO ANY OTHER MATTERS, INCLUDING BUT NOT LIMITED TO NON-INFRINGEMENT OF THIRD PARTY RIGHTS, INTEGRATION, SATISFACTORY QUALITY OR FITNESS FOR ANY PARTICULAR PURPOSE. YOU MAY HAVE ADDITIONAL RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION. The provisions of Sections 4 and 5 shall survive the termination of this Agreement, howsoever caused, but this shall not imply or create any continued right to use the Software after termination of this Agreement.

**LIMITATION OF LIABILITY.** IN NO EVENT WILL ADOBE OR ITS SUPPLIERS BE LIABLE TO YOU FOR ANY DAMAGES, CLAIMS OR COSTS WHATSOEVER OR ANY CONSEQUENTIAL, INDIRECT, INCIDENTAL DAMAGES, OR ANY LOST PROFITS OR LOST SAVINGS, EVEN IF AN ADOBE REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSS, DAMAGES, CLAIMS OR COSTS OR FOR ANY CLAIM BY ANY THIRD PARTY. THE FOREGOING LIMITATIONS AND EXCLUSIONS APPLY TO THE EXTENT PERMITTED BY APPLICABLE LAW IN YOUR JURISDICTION. ADOBE'S AGGREGATE LIABILITY AND THAT OF ITS SUPPLIERS UNDER OR IN CONNECTION WITH THIS AGREEMENT SHALL BE LIMITED TO THE AMOUNT PAID FOR THE SOFTWARE. Nothing contained in this Agreement limits Adobe's liability to you in the event of death or personal injury resulting from Adobe's negligence or for the tort of deceit (fraud). Adobe is acting on behalf of its suppliers for the purpose of disclaiming, excluding and/or limiting obligations, warranties and liability as provided in this Agreement, but in no other respects and for no other purpose.

**TRADEMARKS.** Adobe grants you a worldwide, nonexclusive, nontransferable, personal right to use the "Adobe" word trademark (the "Trademark") solely to identify Adobe as the source of the Adobe RGB (1998) product or Adobe RGB technology, so long as such use complies with the terms of this Agreement, the trademark guidelines available at the "Permissions and trademarks" pages of the Adobe web site ([www.adobe.com](http://www.adobe.com)) and the "Adobe Trademark Guidelines for third parties who license, use or refer to Adobe trademarks," also available from the Adobe web site. You acknowledge the validity of the Trademark and Adobe's ownership of the Trademark. Nothing in this Agreement shall give you any right, title or interest in the Trademark, other than the license rights granted in this Agreement. You recognize the value of the goodwill associated with the

Trademark and acknowledge that such goodwill exclusively inures to the benefit of and belongs to Adobe. Adobe and the Adobe logo are either registered trademarks or trademarks of Adobe in the United States and/or other countries. With the exception of referential use and the rights granted in this Agreement, you will not use such trademarks or any other Adobe trademark or logo without separate prior written permission from Adobe. TERM. This Agreement is effective until terminated. Adobe has the right to terminate this Agreement immediately if you fail to comply with any term hereof. Upon any such termination, you must return to Adobe all full and partial copies of the Software in your possession or control.

GOVERNMENT REGULATIONS. If any part of the Software is identified as an export controlled item under the United States Export Administration Act or any other export law, restriction or regulation (the "Export Laws"), you represent and warrant that you are not a citizen, or otherwise located within, an embargoed nation (including without limitation Iran, Iraq, Syria, Sudan, Libya, Cuba, North Korea, and Serbia) and that you are not otherwise prohibited under the Export Laws from receiving the Software. All rights to use the Software are granted on condition that such rights are forfeited if you fail to comply with the terms of this Agreement.

GOVERNING LAW. This Agreement will be governed by and construed in accordance with the substantive laws in force in the State of California as such laws are applied to agreements entered into and to be performed entirely within California between California residents. This Agreement will not be governed by the conflict of law rules of any jurisdiction or the United Nations Convention on Contracts for the International Sale of Goods, the application of which is expressly excluded. All disputes arising out of, under or related to this Agreement will be brought exclusively in the state Santa Clara County, California, USA.

GENERAL. You may not assign your rights or obligations granted under this Agreement without the prior written consent of Adobe. None of the provisions of this Agreement shall be deemed to have been waived by any act or acquiescence on the part of Adobe, its agents, or employees, but only by an instrument in writing signed by an authorized signatory of Adobe. When conflicting language exists between this Agreement and any other agreement included in the Software, the terms of such included agreement shall apply. If either you or Adobe employs attorneys to enforce any rights arising out of or relating to this Agreement, the prevailing party shall be entitled to recover reasonable attorneys' fees. You acknowledge that you have read this Agreement, understand it, and that it is the complete and exclusive statement of your agreement with Adobe which supersedes any prior agreement, oral or written, between Adobe and you with respect to the licensing to you of the Software. No variation of the terms of this Agreement will be enforceable against Adobe unless Adobe gives its express consent, in writing, signed by an authorized signatory of Adobe.

## libpng-LICENSE

This copy of the libpng notices is provided for your convenience. In case of any discrepancy between this copy and the notices in the file png.h that is included in the libpng distribution, the latter shall prevail.

COPYRIGHT NOTICE, DISCLAIMER, and LICENSE:

If you modify libpng you may insert additional notices immediately following this sentence.

This code is released under the libpng license.

libpng versions 1.2.6, August 15, 2004, through 1.5.5, September 22, 2011, are Copyright (c) 2004, 2006-2011 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-1.2.5 with the following individual added to the list of Contributing Authors

Cosmin Truta

libpng versions 1.0.7, July 1, 2000, through 1.2.5 - October 3, 2002, are Copyright (c) 2000-2002 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-1.0.6 with the following individuals added to the list of Contributing Authors

Simon-Pierre Cadieux  
Eric S. Raymond  
Gilles Vollant

and with the following additions to the disclaimer:

There is no warranty against interference with your enjoyment of the library or against infringement. There is no warranty that our efforts or the library will fulfill any of your particular purposes or needs. This library is provided with all faults, and the entire risk of satisfactory quality, performance, accuracy, and effort is with the user.

libpng versions 0.97, January 1998, through 1.0.6, March 20, 2000, are Copyright (c) 1998, 1999 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-0.96, with the following individuals added to the list of Contributing Authors:

Tom Lane  
Glenn Randers-Pehrson  
Willem van Schaik

libpng versions 0.89, June 1996, through 0.96, May 1997, are Copyright (c) 1996, 1997 Andreas Dilger  
Distributed according to the same disclaimer and license as libpng-0.88, with the following individuals added to the list of Contributing Authors:

John Bowler  
Kevin Bracey  
Sam Bushell  
Magnus Holmgren  
Greg Roelofs  
Tom Tanner

libpng versions 0.5, May 1995, through 0.88, January 1996, are Copyright (c) 1995, 1996 Guy Eric Schalnat, Group 42, Inc.

For the purposes of this copyright and license, "Contributing Authors" is defined as the following set of individuals:

Andreas Dilger  
Dave Martindale  
Guy Eric Schalnat  
Paul Schmidt  
Tim Wegner

The PNG Reference Library is supplied "AS IS". The Contributing Authors and Group 42, Inc. disclaim all warranties, expressed or implied, including, without limitation, the warranties of merchantability and of fitness for any purpose. The Contributing Authors and Group 42, Inc. assume no liability for direct, indirect, incidental, special, exemplary, or consequential damages, which may result from the use of the PNG Reference Library, even if advised of the possibility of such damage.

Permission is hereby granted to use, copy, modify, and distribute this source code, or portions hereof, for any purpose, without fee, subject to the following restrictions:

1. The origin of this source code must not be misrepresented.
2. Altered versions must be plainly marked as such and must not be misrepresented as being the original source.

3. This Copyright notice may not be removed or altered from any source or altered source distribution.

The Contributing Authors and Group 42, Inc. specifically permit, without fee, and encourage the use of this source code as a component to supporting the PNG file format in commercial products. If you use this source code in a product, acknowledgment is not required but would be appreciated.

A "png\_get\_copyright" function is available, for convenient use in "about" boxes and the like:

```
printf("%s",png_get_copyright(NULL));
```

Also, the PNG logo (in PNG format, of course) is supplied in the files "pngbar.png" and "pngbar.jpg (88x31) and "pngnow.png" (98x31).

Libpng is OSI Certified Open Source Software. OSI Certified Open Source is a certification mark of the Open Source Initiative.

Glenn Randers-Pehrson  
glennrp at users.sourceforge.net  
September 22, 2011

## Zlib

Copyright (C) 1995-2012 Jean-loup Gailly and Mark Adler

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

**FUJIFILM**