DX 400 Quick Reference Guide

Emptying the Scrap Paper Box







Check that the power light is lit.

If the power light is flashing, the printer is operating. Wait until all operations have stopped.

2 | ^F

Remove the scrap paper box.

When the scrap paper box is removed, the status light lights.

3

Empty the scrap paper.

Turn over the scrap paper box to throw away the scrap paper that has collected in the box.





Attach the scrap paper box.

5

Confirm that the status light is off.

4