FUJIFILM

DRIVER SETTINGS FOR EPSON STYLUS PRO 4900 USING FUJIFILM PROFILES FOR FUJIFILM MEDIA

Epson UltraChrome HDR - Photo Black

Note: These profiles are for use with PC and Mac

Note: On the printer display select "No Paper Selected' under paper Setup/Paper Type

Media Name	Media Setting	Profile name
Fine Art Fibre Baryte Gloss 310gsm	Premium Luster Photo Paper (260) 1440dpi Level 4	FF_4900_Fine Art Fibre Baryte Gloss 310gsm.icc
EZ Gloss Paper 240gsm Sheet	Premium Luster Photo Paper (260) 1440dpi Level 4	FF_4900_EZGloss 240gsm.icc
EZ Satin Paper 240gsm Sheet	Premium Luster Photo Paper (260) 1440dpi Level 4	FF_4900_EZSatin 240gsm.icc

DRIVER SETTINGS FOR EPSON STYLUS PRO 4900 USING FUJIFILM PROFILES FOR FUJIFILM MEDIA

Epson UltraChrome HDR - Matt Black

Note: These profiles are for use with PC and Mac

Note: On the printer display select "No Paper Selected' under paper Setup/Paper Type

Media Name	Media Setting	Profile name
Artist Canvas 340gsm	Ultra Smooth Fine Art Paper Level 4, 1440dpi	FF_4900_Artist Canvas 340gsm.icc
Fine Art Photo Rag Paper 300gsm	Ultra Smooth Fine Art Paper Level 4, 1440dpi	FF_4900_Fine Art Photo Rag Paper 300gsm.icc
Fine Art Etch Paper 300gsm	Ultra Smooth Fine Art Paper Level 4, 1440dpi	FF_4900_Fine Art Etch Paper 300gsm.icc