

DX 400
Quick Reference Guide

Emptying the Scrap Paper Box



1 Check that the power light is lit.

If the power light is flashing, the printer is operating. Wait until all operations have stopped.

2 Remove the scrap paper box.

When the scrap paper box is removed, the status light lights.

3 Empty the scrap paper.

Turn over the scrap paper box to throw away the scrap paper that has collected in the box.



4 Attach the scrap paper box.

5 Confirm that the status light is off.

