

Universal Frontier P2 Bleach Fix Start Up Kit For Processing Fujicolor Papers and Equivalent Papers in Frontier Minilabs

Catalog Number: 600012438 to make CP48 and CP49 Solutions
See *below for CP48* and reverse for CP49

DESCRIPTION

This product is designed for mixing fresh P2 Bleach Fix working tank solution for Fuji Frontier 330, 350, 370 & 390 minilab processors.

SAFE HANDLING INSTRUCTIONS

Please refer to Material Safety Data Sheets (MSDS) for specific chemical details. For emergencies, please contact CHEMTREC at 1-800-424-9300. You can obtain an MSDS by calling the FUJIFILM Technical Hotline at 1-800-526-0851 Ext. 10.

HMS INFORMATION

Hazardous Materials Identification System. Please refer to Section 3 in the MSDS for further information.

	Concentrate		Working Tank
	Part A	Part B	
Health	2	2	1
Flammability	1	1	0
Reactivity	0	0	0
Personal Protection	C	C	C

SPECS & RECOMMENDATIONS CP48

Temperature	All CP48 Frontiers	38.0° ± 0.3° C 100.4° ± 3.6° F
Replenishment Rate	All CP48 Frontiers	31.1mls/m ²
Processing Time	All CP48 Frontiers	P2 = 45"

Refer to bulletin 600005482 for additional specifications and recommendations

SHELF LIFE

	Concentrate		Working Tank
	Part A	Part B	
Time	U = 24 Months O = 2 Weeks	U = 24 Months O = 2 Weeks	1 Week
Color	Red, Brown	Clear, Colorless	Red, Brown
Odor	No Odor	Slight Ammonia Odor	Slight Ammonia Odor

U = Unopened, O = Opened

MIXING INSTRUCTIONS

To Make CP48 Working Tank Solution

P2W	Water	Concentrate		
		Part A	Part B	
Working Tank	Pour 2.540 Liters of Water (30-40° C) into measuring bottle	Add 1 Bottle P2A to the measuring bottle	Add 1 Bottle P2B to the measuring bottle	Pour Solution into Sub Tank Circulation Filter

Frontier 330

Repeat the above instructions 2 times and top Sub Tank with an additional 2 Liters of water.

Frontier 350

Repeat the above instructions 3 times and top Sub Tank with an additional 1.6 Liters of water.

Frontier 370

Repeat the above instructions 4 times and top Sub Tank with an additional 1.5 Liters of water.

Frontier 390

Repeat the above instructions 12 times and top Sub Tank with an additional 10.1 Liters of water.

Universal Frontier P2 Developer Start Up Kit For Processing Fujicolor Papers and Equivalent Papers in Frontier Minilabs

Catalog Number: 600012438 to make CP48 and CP49 solutions
See **below for CP49** and reverse for CP48

DESCRIPTION

This product is designed for mixing fresh P2 Bleach Fix working tank solution for Fuji Frontier 340, 500, 550, 570, 590, 710, 750, 770 & 790

SAFE HANDLING INSTRUCTIONS

See reverse

HMIS INFORMATION

See reverse

SPECS & RECOMMENDATIONS CP49

Temperature	340 / 710 / 750 / 770 & 790	40° C ± 0.03°C (104° F)
	500 / 550 / 570 & 590	43° C ± 0.3° C (109.4° F)
Replenishment Rate	All CP49 Frontiers	31.1ml/m ²
Processing Time	340	25"
	500 / 550 / 570 & 590	19"
	710	27"
	750	28"
	770	22"
	790	20"

Refer to bulletin **600004889** for additional specifications and recommendations

SHELF LIFE

See reverse

MIXING INSTRUCTIONS

To Make **CP49** Working Tank Solution

P2W	Water	Concentrate		Top Off With Water
		Part A	Part B	
Working Tank	Pour 2 Liters of Water (30-40° C) into measuring bottle	Add 1 Bottle P2A to the measuring bottle	Add 1 Bottle P2B to the measuring bottle	Add 540mls water to make a total of 3.7L of solution. Pour mix into Sub Tank.

Frontier 340

Repeat the above instructions 2 times.

Frontier 500

Repeat the above instructions 2 times and discard remaining from final mix.

Frontier 550, 570 & 590

Repeat the above instructions 3 times.

Frontier 710

Repeat the above instructions 3 times and discard remaining from final mix.

Frontier 750 & 790

Repeat the above instructions 4 times and discard remaining from final mix.

Frontier 770

Repeat the above instructions 5 times and discard remaining from final mix.