

TECHMARK™

Fujifilm Formulation Guide

Version 2.0 SMS Base Colors

TechMark TM

Fujifilm Formulation Guide

This booklet furnishes the necessary formulas to simulate all the colors in the PANTONE® Color Guide. The formulations used in this guide are predictive simulations of the PANTONE®* references using TechMark TM Series colors.

Each formula was printed through a 255 monofilament screen with a 75 durometer sharp edge squeegee, thinned 15% with TM-TH. All formulas are presented by weight. However, due to variations in ink film thickness, screen mesh, and other variables, some formulas may need adjustments.

Each Base Color has been carefully selected for its cleanliness of tone, resistance to fading, and suitability for intermixing.

Although every care is taken in producing these formulations, variations in substrates and printing conditions may affect the color achieved. Fujifilm assumes no responsibility for actual color achieved versus the Pantone standard print. For this reason, all formulations must be proofed prior to a production run to ensure color accuracy.

All formulations are percentages by weight using the following Techmark TM Series colors:

DESCRIPTION	
TM-100 Primrose Yellow	TM-190 Process Blue
TM-110 Lemon Yellow	TM-200 Peacock Blue
TM-120 Medium Yellow	TM-205 Reflex Blue
TM-130 Brilliant Orange	TM-210 Ultra Blue
TM-140 Fire Red	TM-215 Green
TM-150 Scarlet Red	TM-220 Emerald Green
TM-155 Rubine Red	TM-295 Transparent Purple
TM-160 Rhodamine Red	TM-SB Shading Black
TM-175 Purple	TM-TW Tinting White
TM-180 Warm Red	TM-MX Mixing Clear
TM-185 Yellow	

Fujifilm's color mixing ink formulations for screen process printing produce only simulations of PANTONE Colors in this color reproduction method due to differences in ink film, opacity and pigment selection. The selection used in blending inks may cause metamerism. Pantone, Inc. assumes no responsibility for formula accuracy.

*PANTONE® is the property of Pantone Inc.

Techmark TM

Starting Point	Formula
Yellow C	
TM-MX 58.00	
TM-185 42.00	

Starting Point	Formula
Yellow 012 C	
TM-110 84.47	
TM-TW 11.16	
TM-100 4.37	

Starting Point	Formula
Orange 021 C	
TM-MX 42.00	
TM-185 37.00	
TM-180 21.00	

Starting Point	Formula
Warm Red C	
TM-MX 56.00	
TM-180 40.00	
TM-185 4.00	

Starting Point	Formula
Red 032 C	
TM-180 81.70	
TM-MX 13.00	
TM-160 5.30	

Starting Point	Formula
Rubine Red C	
TM-155 100.00	

Starting Point	Formula
Rhodamine Red C	
TM-160 70.00	
TM-MX 30.00	

Starting Point	Formula
Purple C	
TM-175 100.00	

Starting Point	Formula
Violet C	
TM-295 57.10	
TM-MX 42.90	

Starting Point	Formula
Blue 072 C	
TM-205 50.00	
TM-MX 30.00	
TM-160 20.00	

Starting Point	Formula
Reflex Blue C	
TM-205 100.00	

Starting Point	Formula
Process Blue C	
TM-190 62.50	
TM-MX 37.50	

Starting Point	Formula
Green C	
TM-215 62.50	
TM-MX 32.50	
TM-190 5.00	

Starting Point	Formula
Black C	
TM-SB 100.00	

Starting Point	Formula
100 C	
TM-TW 91.00	
TM-185 9.00	

Starting Point	Formula
101 C	
TM-TW 73.00	
TM-185 27.00	

Techmark TM

Starting Point	Formula
102 C	
TM-TW 50.00	
TM-185 50.00	

Starting Point	Formula
103 C	
TM-185 97.00	
TM-SB 3.00	

Starting Point	Formula
104 C	
TM-185 94.00	
TM-SB 6.00	

Starting Point	Formula
105 C	
TM-185 80.00	
TM-SB 20.00	

Starting Point	Formula
106 C	
TM-TW 87.50	
TM-185 10.70	
TM-MX 1.77	
TM-180 0.03	

Starting Point	Formula
107 C	
TM-TW 75.00	
TM-185 18.60	
TM-MX 6.30	
TM-180 0.10	

Starting Point	Formula
108 C	
TM-TW 50.00	
TM-185 32.00	
TM-MX 17.70	
TM-180 0.03	

Starting Point	Formula
109 C	
TM-185 55.00	
TM-MX 44.00	
TM-180 1.00	

Starting Point	Formula
110 C	
TM-185 53.75	
TM-MX 43.00	
TM-SB 2.28	
TM-180 0.97	

Starting Point	Formula
111 C	
TM-185 50.00	
TM-MX 40.00	
TM-SB 9.10	
TM-180 0.90	

Starting Point	Formula
112 C	
TM-185 45.00	
TM-MX 36.00	
TM-SB 18.20	
TM-180 0.80	

Starting Point	Formula
113 C	
TM-TW 88.00	
TM-185 10.92	
TM-MX 1.00	
TM-180 0.08	

Starting Point	Formula
114 C	
TM-TW 76.60	
TM-185 19.42	
TM-MX 3.70	
TM-180 0.28	

Starting Point	Formula
115 C	
TM-TW 50.00	
TM-185 38.10	
TM-MX 11.07	
TM-180 0.83	

Starting Point	Formula
116 C	
TM-185 80.00	
TM-MX 37.50	
TM-180 2.50	

Starting Point	Formula
117 C	
TM-185 53.00	
TM-MX 40.50	
TM-SB 3.60	
TM-180 2.90	

Techmark TM

Starting Point	Formula
118 C	
TM-185	51.00
TM-MX	38.90
TM-SB	7.30
TM-180	2.80

Starting Point	Formula
119 C	
TM-185	44.00
TM-MX	33.60
TM-SB	20.00
TM-180	2.40

Starting Point	Formula
120 C	
TM-TW	87.50
TM-185	15.80
TM-MX	4.25
TM-180	0.35

Starting Point	Formula
121 C	
TM-TW	75.00
TM-185	15.80
TM-MX	8.50
TM-180	0.70

Starting Point	Formula
122 C	
TM-TW	50.00
TM-185	31.50
TM-MX	17.10
TM-180	1.40

Starting Point	Formula
123 C	
TM-185	48.00
TM-MX	48.00
TM-180	4.00

Starting Point	Formula
124 C	
TM-185	46.60
TM-MX	46.50
TM-180	4.90
TM-SB	2.00

Starting Point	Formula
125 C	
TM-185	44.00
TM-MX	44.00
TM-SB	8.30
TM-180	3.70

Starting Point	Formula
126 C	
TM-185	42.24
TM-MX	42.24
TM-SB	12.00
TM-180	3.52

Starting Point	Formula
1205 C	
TM-TW	91.67
TM-110	7.85
TM-130	0.47

Starting Point	Formula
1215 C	
TM-TW	86.90
TM-110	12.40
TM-130	0.70

Starting Point	Formula
1225 C	
TM-TW	53.17
TM-110	44.91
TM-130	1.93

Starting Point	Formula
1235 C	
TM-110	54.80
TM-TW	41.95
TM-130	3.25

Starting Point	Formula
1245 C	
TM-MX	62.78
TM-110	27.70
TM-SB	6.13
TM-130	3.39

Starting Point	Formula
1255 C	
TM-MX	55.89
TM-110	28.74
TM-SB	3.48
TM-130	3.48

Starting Point	Formula
1265 C	
TM-MX	51.40
TM-SB	22.78
TM-110	22.34
TM-130	3.48

Techmark TM

Starting Point	Formula
127 C	
TM-TW 89.80	
TM-185 7.05	
TM-MX 2.90	
TM-155 0.50	

Starting Point	Formula
128 C	
TM-TW 79.60	
TM-185 14.10	
TM-MX 5.80	
TM-155 0.50	

Starting Point	Formula
129 C	
TM-TW 50.00	
TM-185 26.80	
TM-MX 21.40	
TM-155 1.80	

Starting Point	Formula
130 C	
TM-MX 60.00	
TM-185 35.00	
TM-155 5.00	

Starting Point	Formula
131 C	
TM-MX 49.80	
TM-185 42.00	
TM-155 6.00	
TM-SB 2.20	

Starting Point	Formula
132 C	
TM-MX 46.60	
TM-185 37.90	
TM-SB 10.60	
TM-155 4.90	

Starting Point	Formula
133 C	
TM-MX 40.00	
TM-185 31.70	
TM-SB 25.00	
TM-155 3.30	

Starting Point	Formula
134 C	
TM-TW 88.50	
TM-185 7.00	
TM-MX 3.80	
TM-180 0.70	

Starting Point	Formula
135 C	
TM-TW 68.80	
TM-185 16.90	
TM-MX 12.30	
TM-180 2.20	

Starting Point	Formula
136 C	
TM-TW 46.20	
TM-185 28.90	
TM-MX 21.20	
TM-180 3.70	

Starting Point	Formula
137 C	
TM-185 46.00	
TM-MX 46.00	
TM-180 8.00	

Starting Point	Formula
138 C	
TM-185 44.90	
TM-MX 44.80	
TM-180 7.80	
TM-SB 2.50	

Starting Point	Formula
139 C	
TM-185 46.00	
TM-MX 36.00	
TM-180 10.00	
TM-SB 8.00	

Starting Point	Formula
140 C	
TM-185 36.80	
TM-MX 36.80	
TM-SB 8.00	
TM-180 6.40	

Starting Point	Formula
1345 C	
TM-TW 78.40	
TM-185 10.20	
TM-MX 9.40	
TM-180 2.00	

Starting Point	Formula
1355 C	
TM-MX 70.30	
TM-185 15.20	
TM-MX 11.70	
TM-180 2.80	

Techmark TM

Starting Point	Formula
1365 C	
TM-TW 57.20	
TM-185 36.70	
TM-180 6.10	

Starting Point	Formula
1375 C	
TM-185 56.50	
TM-MX 32.60	
TM-180 10.90	

Starting Point	Formula
1385 C	
TM-185 68.40	
TM-MX 15.80	
TM-180 13.20	
TM-SB 2.60	

Starting Point	Formula
1395 C	
TM-185 65.80	
TM-SB 17.50	
TM-180 16.50	

Starting Point	Formula
1405 C	
TM-185 45.50	
TM-SB 28.10	
TM-180 16.00	
TM-MX 10.40	

Starting Point	Formula
141 C	
TM-TW 82.00	
TM-185 10.70	
TM-MX 5.30	
TM-155 2.00	

Starting Point	Formula
142 C	
TM-TW 67.20	
TM-185 19.40	
TM-MX 9.70	
TM-155 3.70	

Starting Point	Formula
143 C	
TM-TW 50.00	
TM-185 30.40	
TM-MX 15.30	
TM-155 4.30	

Starting Point	Formula
144 C	
TM-185 45.00	
TM-MX 43.00	
TM-155 12.00	

Starting Point	Formula
145 C	
TM-185 43.30	
TM-MX 41.40	
TM-155 12.60	
TM-SB 2.70	

Starting Point	Formula
146 C	
TM-185 40.00	
TM-MX 40.00	
TM-155 12.00	
TM-SB 8.00	

Starting Point	Formula
147 C	
TM-185 31.50	
TM-MX 30.10	
TM-SB 30.00	
TM-155 8.40	

Starting Point	Formula
148 C	
TM-TW 89.80	
TM-185 5.80	
TM-MX 2.80	
TM-180 1.60	

Starting Point	Formula
149 C	
TM-TW 84.30	
TM-185 8.90	
TM-MX 4.30	
TM-180 2.50	

Starting Point	Formula
150 C	
TM-TW 50.00	
TM-185 29.10	
TM-MX 13.90	
TM-180 7.00	

Starting Point	Formula
151 C	
TM-185 50.00	
TM-MX 33.30	
TM-180 16.70	

Techmark TM

Starting Point	Formula
152 C	
TM-185	47.60
TM-MX	31.00
TM-180	19.00
TM-SB	2.40

Starting Point	Formula
153 C	
TM-185	45.60
TM-MX	30.40
TM-180	16.70
TM-SB	7.30

Starting Point	Formula
154 C	
TM-185	41.30
TM-MX	27.40
TM-180	16.70
TM-SB	14.60

Starting Point	Formula
1485 C	
TM-TW	72.88
TM-185	22.52
TM-180	4.60

Starting Point	Formula
1495 C	
TM-185	54.88
TM-TW	36.86
TM-180	8.26

Starting Point	Formula
1505 C	
TM-185	86.89
TM-180	13.11

Starting Point	Formula
1525 C	
TM-185	63.73
TM-180	20.16
TM-SB	8.86
TM-TW	7.25

Starting Point	Formula
1535 C	
TM-185	55.11
TM-SB	23.32
TM-180	16.64
TM-TW	4.93

Starting Point	Formula
1545 C	
TM-SB	50.66
TM-185	41.09
TM-180	8.25

Starting Point	Formula
155 C	
TM-TW	96.70
TM-185	2.00
TM-155	0.70
TM-MX	0.60

Starting Point	Formula
156 C	
TM-TW	86.60
TM-185	8.20
TM-180	2.90
TM-MX	2.30

Starting Point	Formula
157 C	
TM-TW	57.10
TM-185	25.00
TM-180	9.70
TM-MX	8.20

Starting Point	Formula
158 C	
TM-185	50.00
TM-155	27.00
TM-MX	23.00

Starting Point	Formula
159 C	
TM-185	48.60
TM-180	26.30
TM-MX	22.40
TM-SB	2.70

Starting Point	Formula
160 C	
TM-185	45.40
TM-180	24.50
MT-MX	20.90
TM-SB	2.70

Starting Point	Formula
161 C	
TM-185	35.00
TM-SB	30.00
TM-180	18.90
TM-MX	16.10

Techmark TM

Starting Point	Formula
1555 C	
TM-TW 88.40	
TM-185 6.30	
TM-180 5.30	

Starting Point	Formula
1565 C	
TM-TW 57.70	
TM-MX 21.30	
TM-185 13.70	
TM-180 7.30	

Starting Point	Formula
1575 C	
TM-TW 33.70	
TM-185 28.10	
TM-MX 24.70	
TM-180 13.50	

Starting Point	Formula
1585 C	
TM-MX 42.30	
TM-185 34.30	
TM-180 23.40	

Starting Point	Formula
1595 C	
TM-185 45.30	
TM-MX 25.90	
TM-180 25.80	
TM-SB 3.00	

Starting Point	Formula
1605 C	
TM-185 44.30	
TM-MX 24.80	
TM-180 22.00	
TM-SB 8.90	

Starting Point	Formula
1615 C	
TM-185 37.20	
TM-180 28.20	
TM-MX 17.90	
TM-SB 16.70	

Starting Point	Formula
162 C	
TM-TW 92.20	
TM-180 3.10	
TM-MX 2.40	
TM-185 2.30	

Starting Point	Formula
163 C	
TM-TW 74.80	
TM-MX 8.90	
TM-185 8.30	
TM-180 8.00	

Starting Point	Formula
164 C	
TM-TW 47.60	
TM-MX 20.00	
TM-185 18.60	
TM-180 13.80	

Starting Point	Formula
165 C	
TM-MX 42.00	
TM-185 29.00	
TM-180 29.00	

Starting Point	Formula
166 C	
TM-MX 38.00	
TM-185 30.00	
TM-180 30.00	
TM-SB 2.00	

Starting Point	Formula
167 C	
TM-MX 38.10	
TM-180 27.60	
TM-185 26.30	
TM-SB 8.00	

Starting Point	Formula
168 C	
TM-MX 29.20	
TM-SB 26.10	
TM-180 24.50	
TM-185 20.20	

Starting Point	Formula
1625 C	
TM-TW 63.00	
TM-MX 23.10	
TM-180 8.40	
TM-185 5.50	

Starting Point	Formula
1635 C	
TM-TW 59.10	
TM-180 16.60	
TM-MX 129.00	
TM-185 11.40	

Techmark TM

Starting Point	Formula
1645 C	
TM-MX 35.60	
TM-TW 23.80	
TM-185 21.40	
TM-180 19.20	

Starting Point	Formula
1655 C	
TM-MX 38.70	
TM-180 32.30	
TM-185 29.00	

Starting Point	Formula
1665 C	
TM-185 44.80	
TM-180 44.80	
TM-MX 9.00	
TM-SB 1.40	

Starting Point	Formula
1675 C	
TM-185 40.80	
TM-180 37.00	
TM-MX 14.80	
TM-SB 7.40	

Starting Point	Formula
1685 C	
TM-180 41.80	
TM-185 32.80	
TM-SB 16.40	
TM-MX 9.00	

Starting Point	Formula
169 C	
TM-TW 90.00	
TM-MX 4.50	
TM-180 4.50	
TM-185 1.00	

Starting Point	Formula
170 C	
TM-TW 77.70	
TM-180 12.00	
TM-MX 6.50	
TM-185 3.80	

Starting Point	Formula
171 C	
TM-TW 38.40	
TM-180 26.90	
TM-MX 21.20	
TM-185 13.50	

Starting Point	Formula
172 C	
TM-180 50.00	
TM-185 25.00	
TM-MX 25.00	

Starting Point	Formula
173 C	
TM-180 45.50	
TM-MX 28.20	
TM-185 22.70	
TM-SB 3.60	

Starting Point	Formula
174 C	
TM-180 42.90	
TM-185 21.40	
TM-MX 21.40	
TM-SB 14.30	

Starting Point	Formula
175 C	
TM-180 60.70	
TM-SB 14.30	
TM-185 12.50	
TM-MX 12.50	

Starting Point	Formula
176 C	
TM-TW 92.00	
TM-MX 4.50	
TM-180 2.80	
TM-160 0.70	

Starting Point	Formula
177 C	
TM-TW 70.00	
TM-MX 19.00	
TM-180 10.00	
TM-160 1.00	

Starting Point	Formula
178 C	
TM-TW 50.00	
TM-MX 28.00	
TM-180 20.00	
TM-185 2.00	

Starting Point	Formula
179 C	
TM-MX 52.60	
TM-180 45.80	
TM-SB 1.60	

Techmark TM

Starting Point	Formula
180 C	
TM-MX	52.70
TM-180	37.64
TM-SB	5.90
TM-185	3.76

Starting Point	Formula
181 C	
TM-MX	44.80
TM-180	32.00
TM-SB	20.00
TM-185	3.20

Starting Point	Formula
1765 C	
TM-TW	63.30
TM-MX	28.70
TM-180	5.70
TM-155	2.30

Starting Point	Formula
1775 C	
TM-TW	52.00
TM-MX	30.40
TM-180	12.60
TM-155	5.00

Starting Point	Formula
1785 C	
TM-MX	39.90
TM-TW	30.80
TM-180	21.70
TM-155	7.60

Starting Point	Formula
1788 C	
TM-MX	44.44
TM-180	41.67
TM-155	13.89

Starting Point	Formula
1795 C	
TM-180	49.30
TM-MX	32.90
TM-155	16.50
TM-SB	1.30

Starting Point	Formula
1805 C	
TM-180	48.90
TM-MX	29.30
TM-155	16.30
TM-SB	5.50

Starting Point	Formula
1815 C	
TM-180	60.50
TM-155	20.10
TM-SB	19.40

Starting Point	Formula
1767 C	
TM-TW	93.54
TM-180	3.94
TM-160	2.52

Starting Point	Formula
1777 C	
TM-TW	70.65
TM-180	17.90
TM-160	11.45

Starting Point	Formula
1787 C	
TM-TW	51.25
TM-180	36.24
TM-160	12.50

Starting Point	Formula
1797 C	
TM-180	60.77
TM-TW	34.88
TM-SB	4.35

Starting Point	Formula
1807 C	
TM-180	55.17
TM-TW	16.26
TM-160	15.22
TM-SB	13.35

Starting Point	Formula
1817 C	
TM-SB	43.20
TM-180	41.08
TM-TW	15.73

Starting Point	Formula
182 C	
TM-TW	93.20
TM-180	3.20
TM-155	2.10
TM-MX	1.50

Techmark TM

Starting Point	Formula
183 C	
TM-TW 74.00	
TM-155 10.64	
TM-180 9.60	
TM-MX 5.76	

Starting Point	Formula
184 C	
TM-TW 50.00	
TM-180 20.00	
TM-155 18.00	
TM-MX 12.00	

Starting Point	Formula
185 C	
TM-180 60.00	
TM-155 40.00	

Starting Point	Formula
186 C	
TM-180 51.70	
TM-155 46.60	
TM-SB 1.70	

Starting Point	Formula
187 C	
TM-180 49.50	
TM-155 44.20	
TM-SB 6.30	

Starting Point	Formula
188 C	
TM-180 41.50	
TM-155 35.40	
TM-SB 23.10	

Starting Point	Formula
189 C	
TM-TW 90.90	
TM-155 5.50	
TM-180 2.70	
TM-MX 0.90	

Starting Point	Formula
190 C	
TM-TW 78.20	
TM-155 13.10	
TM-180 6.50	
TM-MX 2.20	

Starting Point	Formula
191 C	
TM-TW 50.00	
TM-155 30.00	
TM-180 15.00	
TM-MX 5.00	

Starting Point	Formula
192 C	
TM-155 60.00	
TM-180 30.00	
TM-MX 10.00	

Starting Point	Formula
193 C	
MT-155 57.90	
TM-180 28.90	
TM-MX 9.60	
TM-SB 3.60	

Starting Point	Formula
194 C	
TM-155 52.80	
TM-180 26.40	
TM-SB 12.00	
TM-MX 8.80	

Starting Point	Formula
195 C	
TM-155 42.00	
TM-SB 30.00	
TM-180 21.00	
TM-MX 7.00	

Starting Point	Formula
1895 C	
TM-TW 95.60	
TM-155 3.92	
TM-180 0.49	

Starting Point	Formula
1905 C	
TM-MX 88.87	
TM-155 8.41	
TM-TW 2.72	

Starting Point	Formula
1915 C	
TM-MX 50.00	
TM-155 23.73	
TM-TW 21.69	
TM-180 4.58	

Techmark TM

Starting Point	Formula
1925 C	
TM-MX 50.00	
TM-155 33.09	
TM-180 16.65	
TM-TW 0.26	

Starting Point	Formula
1935 C	
TM-155 55.35	
TM-180 27.07	
TM-TW 15.38	
TM-MX 2.20	

Starting Point	Formula
1945 C	
MT-MX 44.01	
TM-155 28.47	
TM-180 19.48	
TM-SB 8.03	

Starting Point	Formula
1955 C	
TM-155 31.07	
TM-MX 27.45	
TM-180 22.93	
TM-SB 18.56	

Starting Point	Formula
196 C	
TM-TW 94.00	
TM-155 4.80	
TM-185 1.20	

Starting Point	Formula
197 C	
TM-TW 79.10	
TM-155 16.70	
TM-185 4.20	

Starting Point	Formula
198 C	
TM-TW 50.00	
TM-155 40.00	
TM-185 10.00	

Starting Point	Formula
199 C	
TM-155 80.00	
TM-185 20.00	

Starting Point	Formula
200 C	
TM-155 78.50	
TM-185 19.60	
TM-SB 1.90	

Starting Point	Formula
201 C	
TM-155 74.00	
TM-185 18.50	
TM-SB 7.50	

Starting Point	Formula
202 C	
TM-155 68.00	
TM-185 17.00	
TM-SB 15.00	

Starting Point	Formula
203 C	
TM-TW 93.74	
TM-155 5.10	
TM-185 0.78	
TM-MX 0.38	

Starting Point	Formula
204 C	
TM-TW 75.00	
TM-155 20.37	
TM-185 3.13	
TM-MX 1.50	

Starting Point	Formula
205 C	
TM-TW 50.00	
TM-155 40.75	
TM-185 6.25	
TM-MX 3.00	

Starting Point	Formula
206 C	
TM-155 81.50	
TM-185 12.50	
TM-MX 6.00	

Starting Point	Formula
207 C	
TM-155 77.60	
TM-185 9.70	
TM-MX 9.70	
TM-SB 3.00	

Techmark TM

Starting Point	Formula
208 C	
TM-155 72.00	
TM-SB 10.00	
TM-185 9.00	
TM-MX 9.00	

Starting Point	Formula
209 C	
TM-155 64.00	
TM-SB 20.00	
TM-185 8.00	
TM-MX 8.00	

Starting Point	Formula
210 C	
TM-TW 87.50	
TM-160 7.40	
TM-MX 3.10	
TM-180 2.00	

Starting Point	Formula
211 C	
TM-TW 75.00	
TM-160 14.80	
TM-MX 6.20	
TM-180 4.00	

Starting Point	Formula
212 C	
TM-TW 50.00	
TM-160 29.50	
TM-MX 12.50	
TM-180 8.00	

Starting Point	Formula
213 C	
TM-180 59.00	
TM-MX 25.00	
TM-180 16.00	

Starting Point	Formula
214 C	
TM-160 57.20	
TM-MX 24.20	
TM-180 16.70	
TM-SB 1.90	

Starting Point	Formula
215 C	
TM-160 51.80	
TM-MX 22.00	
TM-180 18.60	
TM-SB 7.60	

Starting Point	Formula
216 C	
TM-160 39.30	
TM-180 23.20	
TM-SB 20.80	
TM-MX 16.70	

Starting Point	Formula
217 C	
TM-TW 96.40	
TM-155 3.60	

Starting Point	Formula
218 C	
TM-TW 82.00	
TM-155 18.00	

Starting Point	Formula
219 C	
TM-TW 50.00	
TM-155 50.00	

Starting Point	Formula
220 C	
TM-155 97.00	
TM-SB 3.00	

Starting Point	Formula
221 C	
TM-155 94.00	
TM-SB 6.00	

Starting Point	Formula
222 C	
TM-160 47.20	
TM-MX 20.00	
TM-SB 20.00	
TM-180 12.80	

Starting Point	Formula
223 C	
TM-TW 82.10	
TM-160 7.70	
TM-MX 7.40	
TM-155 2.80	

Techmark TM

Starting Point	Formula
224 C	
TM-TW 64.20	
TM-160 15.30	
TM-MX 14.90	
TM-155 5.60	

Starting Point	Formula
225 C	
TM-TW 35.70	
TM-160 27.50	
TM-MX 26.80	
TM-155 10.00	

Starting Point	Formula
226 C	
TM-160 55.00	
TM-MX 25.00	
TM-155 20.00	

Starting Point	Formula
227 C	
TM-160 49.70	
TM-155 24.80	
TM-MX 22.60	
TM-SB 2.90	

Starting Point	Formula
228 C	
TM-155 39.20	
TM-160 33.80	
TM-MX 15.40	
TM-SB 11.60	

Starting Point	Formula
229 C	
TM-155 73.00	
TM-SB 27.00	

Starting Point	Formula
230 C	
TM-TW 56.70	
TM-MX 37.90	
TM-160 5.40	

Starting Point	Formula
231 C	
TM-TW 47.40	
TM-MX 36.30	
TM-160 16.30	

Starting Point	Formula
232 C	
TM-TW 35.00	
TM-MX 33.50	
TM-160 31.50	

Starting Point	Formula
233 C	
TM-160 56.00	
TM-MX 33.30	
TM-155 9.00	
TM-SB 1.70	

Starting Point	Formula
234 C	
TM-160 50.00	
TM-155 36.00	
TM-MX 7.00	
TM-SB 7.00	

Starting Point	Formula
235 C	
TM-155 43.00	
TM-160 29.00	
TM-MX 14.00	
TM-SN 14.00	

Starting Point	Formula
236 C	
TM-TW 86.40	
TM-160 7.50	
TM-MX 5.10	
TM-175 1.00	

Starting Point	Formula
237 C	
TM-TW 72.80	
TM-160 15.00	
TM-MX 10.20	
TM-175 2.00	

Starting Point	Formula
238 C	
TM-TW 45.50	
TM-160 30.00	
TM-MX 20.40	
TM-175 4.10	

Starting Point	Formula
239 C	
TM-160 46.00	
TM-MX 45.00	
TM-175 9.00	

Techmark TM

Starting Point	Formula
240 C	
TM-160	44.60
TM-MX	43.70
TM-175	8.70
TM-SB	3.00

Starting Point	Formula
241 C	
TM-160	43.20
TM-MX	42.30
TM-175	8.50
TM-SB	6.00

Starting Point	Formula
242 C	
TM-155	58.40
TM-SB	23.10
TM-160	12.70
TM-MX	5.80

Starting Point	Formula
2365 C	
TM-160	96.38
TM-160	3.54
TM-295	0.08

Starting Point	Formula
2375 C	
TM-TW	41.38
TM-MX	40.00
TM-160	17.38
TM-295	1.24

Starting Point	Formula
2385 C	
TM-MX	40.00
TM-160	36.33
TM-TW	21.75
TM-295	1.92

Starting Point	Formula
2395 C	
TM-160	65.58
TM-MX	20.00
TM-TW	12.75
TM-295	1.67

Starting Point	Formula
2405 C	
TM-160	58.65
TM-MX	37.03
TM-295	4.32

Starting Point	Formula
2415 C	
TM-160	87.40
TM-MX	6.92
TM-295	5.86

Starting Point	Formula
2425 C	
TM-160	86.32
TM-SB	12.24
TM-295	1.45

Starting Point	Formula
243 C	
TM-TW	90.00
TM-MX	5.25
TM-160	2.75
TM-175	2.00

Starting Point	Formula
244 C	
TM-TW	80.00
TM-MX	10.50
TM-160	5.50
TM-175	4.00

Starting Point	Formula
245 C	
TM-TW	75.00
TM-160	10.30
TM-175	8.30
TM-MX	6.40

Starting Point	Formula
246 C	
TM-160	36.00
MT-175	36.00
TM-MX	28.00

Starting Point	Formula
247 C	
TM-160	35.30
TM-175	35.30
TM-MX	27.40
TM-SB	2.00

Starting Point	Formula
248 C	
TM-160	33.10
TM-175	33.10
TM-MX	25.80
TM-SB	8.00

Techmark TM

Starting Point	Formula
249 C	
TM-160	28.80
TM-175	28.80
TM-MX	22.40
TM-SB	20.00

Starting Point	Formula
250 C	
TM-TW	96.00
TM-175	1.87
TM-MX	1.25
TM-160	0.88

Starting Point	Formula
251 C	
TM-TW	84.00
TM-175	7.50
TM-MX	5.00
TM-160	3.50

Starting Point	Formula
252 C	
TM-TW	50.00
TM-175	26.80
TM-MX	17.90
TM-160	5.30

Starting Point	Formula
253 C	
TM-175	97.50
TM-MX	1.80
TM-SB	0.70

Starting Point	Formula
254 C	
TM-175	90.00
TM-MX	7.20
TM-SB	2.80

Starting Point	Formula
255 C	
TM-175	60.00
TM-MX	29.00
TM-SB	11.00

Starting Point	Formula
256 C	
TM-TW	96.00
TM-155	3.35
TM-205	0.40
TM-215	0.25

Starting Point	Formula
257 C	
TM-TW	90.50
TM-155	7.43
TM-215	1.20
TM-205	0.87

Starting Point	Formula
258 C	
TM-TW	54.54
TM-155	36.64
TM-205	4.55
TM-215	2.27

Starting Point	Formula
259 C	
TM-155	85.00
TM-205	10.00
TM-215	5.00

Starting Point	Formula
260 C	
TM-155	80.75
TM-205	9.50
TM-SB	5.00
TM-215	4.75

Starting Point	Formula
261 C	
TM-155	77.35
TM-205	9.10
TM-SB	9.00
TM-215	4.55

Starting Point	Formula
262 C	
TM-155	68.00
TM-SB	20.00
TM-205	8.00
TM-215	4.00

Starting Point	Formula
2562 C	
TM-MX	83.31
TM-TW	13.01
TM-295	2.82
TM-155	0.87

Starting Point	Formula
2572 C	
TM-MX	57.65
TM-TW	37.25
TM-295	3.54
TM-155	1.55

Techmark TM

Starting Point	Formula
2582 C	
TM-MX 84.74	
TM-295 12.90	
TM-155 2.63	

Starting Point	Formula
2592 C	
TM-MX 77.90	
TM-295 12.36	
TM-155 9.74	

Starting Point	Formula
2602 C	
TM-MX 68.88	
TM-295 18.45	
TM-155 12.68	

Starting Point	Formula
2612 C	
TM-155 48.79	
TM-MX 40.00	
TM-205 10.80	
TM-TW 0.41	

Starting Point	Formula
2622 C	
TM-155 79.70	
TM-205 9.39	
TM-TW 6.57	
TM-215 4.33	

Starting Point	Formula
2563 C	
TM-TW 53.50	
TM-MX 39.50	
TM-295 3.50	
TM-155 3.50	

Starting Point	Formula
2573 C	
TM-MX 44.50	
TM-TW 37.90	
TM-155 9.40	
TM-295 8.20	

Starting Point	Formula
2583 C	
TM-MX 52.30	
TM-TW 18.20	
TM-155 15.90	
TM-295 13.60	

Starting Point	Formula
2593 C	
TM-155 35.00	
TM-MX 35.00	
TM-295 30.00	

Starting Point	Formula
2603 C	
TM-155 38.00	
TM-295 32.60	
TM-MX 29.40	

Starting Point	Formula
2613 C	
TM-155 40.70	
TM-295 34.90	
TM-MX 24.40	

Starting Point	Formula
2623 C	
TM-155 60.50	
TM-295 39.50	

Starting Point	Formula
2567 C	
TM-TW 55.40	
TM-MX 37.90	
TM-295 5.50	
TM-155 1.20	

Starting Point	Formula
2577 C	
TM-MX 42.90	
TM-TW 42.70	
TM-295 11.10	
TM-155 3.30	

Starting Point	Formula
2587 C	
TM-MX 49.80	
TM-TW 22.30	
TM-295 21.60	
TM-155 6.30	

Starting Point	Formula
2597 C	
TM-295 46.51	
TM-MX 39.53	
TM-155 13.96	

Techmark TM

Starting Point	Formula
2607 C	
TM-295	54.10
TM-155	24.30
TM-MX	21.60

Starting Point	Formula
2617 C	
TM-295	51.74
TM-155	25.87
TM-MX	22.39

Starting Point	Formula
2627 C	
TM-295	61.20
TM-155	38.80

Starting Point	Formula
263 C	
TM-TW	91.85
TM-175	5.66
TM-160	1.55
TM-205	0.94

Starting Point	Formula
264 C	
TM-TW	89.54
TM-175	7.73
TM-160	1.45
TM-205	1.28

Starting Point	Formula
265 C	
TM-TW	60.60
TM-175	32.20
TM-205	5.32
TM-160	1.88

Starting Point	Formula
266 C	
TM-175	83.00
TM-205	17.00

Starting Point	Formula
267 C	
TM-175	79.10
TM-205	15.40
TM-SB	4.10
TM-MX	1.40

Starting Point	Formula
268 C	
TM-175	67.50
TM-SB	16.50
TM-205	10.50
TM-MX	5.50

Starting Point	Formula
269 C	
TM-175	54.90
TM-SB	30.00
TM-MX	10.00
TM-205	5.10

Starting Point	Formula
2635 C	
TM-TW	56.50
TM-MX	40.30
TM-295	2.60
TM-205	0.60

Starting Point	Formula
2645 C	
TM-MX	47.60
TM-TW	45.20
TM-295	6.00
TM-205	1.20

Starting Point	Formula
2655 C	
TM-MX	45.90
TM-TW	40.00
TM-295	11.80
TM-205	2.30

Starting Point	Formula
2665 C	
TM-MX	38.50
TM-TW	33.30
TM-295	25.60
TM-205	2.60

Starting Point	Formula
2685 C	
TM-295	65.20
TM-MX	34.80

Starting Point	Formula
2695 C	
TM-295	87.00
TM-SB	13.00

Techmark TM

Starting Point	Formula
270 C	
TM-TW 87.80	
TM-155 6.70	
TM-205 5.50	

Starting Point	Formula
271 C	
TM-TW 81.10	
TM-155 10.40	
TM-205 8.50	

Starting Point	Formula
272 C	
TM-TW 58.30	
TM-155 22.90	
TM-205 18.80	

Starting Point	Formula
273 C	
TM-155 55.00	
TM-205 45.00	

Starting Point	Formula
274 C	
TM-155 49.50	
TM-205 40.50	
TM-SB 10.00	

Starting Point	Formula
275 C	
TM-155 45.00	
TM-205 36.80	
TM-SB 18.20	

Starting Point	Formula
276 C	
TM-155 40.00	
TM-205 32.70	
TM-SB 27.30	

Starting Point	Formula
2705 C	
TM-TW 58.40	
TM-MX 38.20	
TM-295 3.40	
TM-205 2.00	

Starting Point	Formula
2715 C	
TM-TW 44.50	
TM-MX 42.00	
TM-295 8.60	
TM-205 4.90	

Starting Point	Formula
2725 C	
TM-MX 38.50	
TM-TW 33.30	
TM-295 17.90	
TM-205 10.30	

Starting Point	Formula
2735 C	
TM-295 41.70	
TM-MX 41.70	
TM-205 16.60	

Starting Point	Formula
2745 C	
TM-295 52.60	
TM-MX 26.40	
TM-205 21.00	

Starting Point	Formula
2755 C	
TM-295 71.40	
TM-205 28.60	

Starting Point	Formula
2765 C	
TM-295 66.70	
TM-205 26.60	
TM-SB 6.70	

Starting Point	Formula
2706 C	
TM-TW 98.45	
TM-205 0.88	
TM-295 0.67	

Starting Point	Formula
2716 C	
TM-TW 94.28	
TM-205 3.14	
TM-295 2.57	

Techmark TM

Starting Point	Formula
2726 C	
TM-TW 54.88	
TM-MX 20.00	
TM-205 13.42	
TM-295 11.71	

Starting Point	Formula
2736 C	
TM-MX 57.84	
TM-210 42.16	

Starting Point	Formula
2746 C	
TM-MX 55.09	
TM-295 21.42	
TM-205 15.01	
TM-155 8.48	

Starting Point	Formula
2756 C	
TM-MX 52.47	
TM-SB 21.01	
TM-295 20.01	
TM-205 6.51	

Starting Point	Formula
2766 C	
TM-SB 38.61	
TM-MX 35.77	
TM-295 22.32	
TM-205 3.30	

Starting Point	Formula
2707 C	
TM-TW 98.41	
TM-205 1.17	
TM-295 0.43	

Starting Point	Formula
2717 C	
TM-TW 26.73	
TM-205 2.49	
TM-295 0.77	

Starting Point	Formula
2727 C	
TM-TW 61.63	
TM-MX 20.00	
TM-205 15.39	
TM-295 2.99	

Starting Point	Formula
2747 C	
TM-205 70.84	
TM-295 29.16	

Starting Point	Formula
2757 C	
TM-205 51.56	
TM-295 33.85	
TM-SB 13.35	
TM-MX 1.25	

Starting Point	Formula
2767 C	
TM-SB 54.70	
TM-205 45.30	

Starting Point	Formula
2708 C	
TM-TW 97.47	
TM-205 1.91	
TM-295 0.62	

Starting Point	Formula
2718 C	
TM-TW 83.38	
TM-205 12.66	
TM-295 3.97	

Starting Point	Formula
2728 C	
TM-205 52.63	
TM-TW 26.32	
TM-MX 21.05	

Starting Point	Formula
2738 C	
TM-MX 55.28	
TM-210 44.72	

Starting Point	Formula
2748 C	
TM-205 47.82	
TM-295 44.11	
TM-MX 8.07	

Techmark TM

Starting Point	Formula
2758 C	
TM-MX	37.98
TM-295	35.66
TM-SB	20.34
TM-205	6.03

Starting Point	Formula
2768 C	
TM-SB	38.09
TM-MX	30.73
TM-295	29.05
TM-205	2.13

Starting Point	Formula
277 C	
TM-TW	97.40
TM-205	2.00
TM-160	0.60

Starting Point	Formula
278 C	
TM-TW	97.40
TM-205	4.05
TM-160	1.25

Starting Point	Formula
279 C	
TM-TW	82.50
TM-205	16.50
TM-160	1.00

Starting Point	Formula
280 C	
TM-205	89.00
TM-SB	11.00

Starting Point	Formula
281 C	
TM-205	81.20
TM-SB	18.80

Starting Point	Formula
282 C	
TM-205	62.50
TM-SB	37.50

Starting Point	Formula
283 C	
TM-TW	94.50
TM-205	4.10
TM-155	0.90
TM-MX	0.50

Starting Point	Formula
284 C	
TM-TW	88.90
TM-205	9.20
TM-MX	1.00
TM-155	0.90

Starting Point	Formula
285 C	
TM-TW	50.00
TM-205	37.50
TM-190	8.30
TM-MX	4.20

Starting Point	Formula
286 C	
TM-205	90.00
TM-MX	10.00

Starting Point	Formula
287 C	
TM-205	82.00
TM-MX	9.10
TM-SB	5.90
TM-190	3.00

Starting Point	Formula
288 C	
TM-205	74.10
TM-SB	11.80
TM-MX	8.20
TM-190	5.90

Starting Point	Formula
289 C	
TM-205	49.00
TM-SB	36.40
TM-190	9.10
TM-MX	5.50

Starting Point	Formula
290 C	
TM-TW	97.90
TM-205	1.70
TM-190	0.30
TM-155	0.10

Techmark TM

Starting Point	Formula
291 C	
TM-TW 92.20	
TM-205 4.70	
TM-190 2.40	
TM-155 0.70	

Starting Point	Formula
292 C	
TM-TW 82.30	
MT-205 10.30	
TM-190 7.40	

Starting Point	Formula
293 C	
TM-205 50.00	
TM-190 50.00	

Starting Point	Formula
294 C	
TM-190 47.80	
TM-205 45.00	
TM-SB 7.20	

Starting Point	Formula
295 C	
TM-190 45.70	
TM-205 40.00	
TM-SB 14.30	

Starting Point	Formula
296 C	
TM-190 39.30	
TM-SB 35.70	
TM-205 25.00	

Starting Point	Formula
2905 C	
TM-TW 95.16	
TM-190 2.49	
TM-205 2.35	

Starting Point	Formula
2915 C	
TM-TW 90.44	
TM-190 5.29	
TM-205 4.26	

Starting Point	Formula
2925 C	
TM-MX 67.47	
TM-TW 15.80	
TM-190 8.54	
TM-205 7.92	

Starting Point	Formula
2935 C	
TM-MX 55.71	
TM-190 28.29	
TM-210 16.00	

Starting Point	Formula
2945 C	
TM-200 71.90	
TM-190 25.21	
TM-205 2.89	

Starting Point	Formula
2955 C	
TM-MX 50.82	
TM-SB 23.35	
TM-205 18.54	
TM-210 7.29	

Starting Point	Formula
2965 C	
TM-SB 48.74	
TM-200 25.71	
TM-205 25.51	

Starting Point	Formula
297 C	
TM-TW 90.00	
TM-MX 4.60	
TM-190 2.90	
TM-205 2.50	

Starting Point	Formula
298 C	
TM-TW 75.00	
TM-190 15.90	
TM-MX 5.40	
TM-205 3.70	

Starting Point	Formula
299 C	
TM-TW 50.00	
TM-190 38.10	
TM-205 8.90	
TM-MX 3.00	

Techmark TM

Starting Point	Formula
300 C	
TM-190	66.70
TM-205	25.00
TM-MX	8.30

Starting Point	Formula
301 C	
TM-190	63.10
TM-205	25.00
TM-MX	6.70
TM-SB	5.20

Starting Point	Formula
302 C	
TM-190	65.20
TM-SB	18.20
TM-205	12.50
TM-MX	4.10

Starting Point	Formula
303 C	
TM-190	63.60
TM-SB	36.40

Starting Point	Formula
2975 C	
TM-TW	76.63
TM-MX	19.10
TM-190	4.02
TM-205	0.25

Starting Point	Formula
2985 C	
TM-TW	57.40
TM-MX	23.20
MT-190	18.90
TM-205	0.50

Starting Point	Formula
2995 C	
TM-190	43.50
TM-TW	17.40
TM-MX	17.40

Starting Point	Formula
3005 C	
TM-190	80.60
TM-MX	17.20
TM-205	2.20

Starting Point	Formula
3015 C	
TM-205	94.40
TM-215	2.80
TM-SB	2.80

Starting Point	Formula
3025 C	
TM-190	83.00
TM-MX	10.80
TM-215	6.20

Starting Point	Formula
3035 C	
TM-190	64.10
TM-MX	24.40
TM-215	11.50

Starting Point	Formula
304 C	
TM-TW	96.80
TM-190	3.07
TM-215	0.13

Starting Point	Formula
305 C	
TM-TW	87.10
TM-190	12.40
TM-215	0.50

Starting Point	Formula
306 C	
TM-TW	74.20
TM-190	24.80
TM-215	1.00

Starting Point	Formula
307 C	
TM-190	95.30
TM-SB	2.90
TM-215	1.80

Starting Point	Formula
308 C	
TM-190	81.20
TM-SB	11.70
TM-215	7.10

Techmark TM

Starting Point	Formula
309 C	
TM-190 50.00	
TM-SB 31.20	
TM-215 18.80	

Starting Point	Formula
310 C	
TM-TW 88.20	
TM-190 7.70	
TM-MX 2.80	
TM-215 1.30	

Starting Point	Formula
311 C	
TM-TW 78.60	
TM-190 14.00	
TM-MX 5.10	
TM-215 2.30	

Starting Point	Formula
312 C	
TM-TW 50.00	
TM-190 39.20	
TM-215 6.50	
TM-MX 4.30	

Starting Point	Formula
313 C	
TM-190 78.30	
TM-215 13.00	
TM-MX 8.70	

Starting Point	Formula
314 C	
TM-190 75.50	
TM-215 13.40	
TM-MX 8.40	
TM-SB 2.70	

Starting Point	Formula
315 C	
TM-190 67.30	
TM-215 14.50	
TM-SB 10.70	
TM-MX 7.50	

Starting Point	Formula
316 C	
TM-190 39.20	
TM-SB 33.30	
TM-215 23.20	
TM-MX 4.30	

Starting Point	Formula
3105 C	
TM-TW 73.10	
TM-MX 18.30	
TM-190 6.00	
TM-215 2.60	

Starting Point	Formula
3115 C	
TM-TW 64.20	
TM-MX 18.70	
TM-190 12.00	
TM-215 5.10	

Starting Point	Formula
3125 C	
TM-TW 51.30	
TM-190 24.30	
TM-MX 14.90	
TM-215 9.50	

Starting Point	Formula
3135 C	
TM-MX 47.40	
TM-190 40.80	
TM-215 11.80	

Starting Point	Formula
3145 C	
TM-190 64.40	
TM-215 26.20	
TM-SB 7.50	
TM-MX 1.90	

Starting Point	Formula
3155 C	
TM-190 57.30	
TM-215 25.70	
TM-MX 10.00	
TM-SB 7.00	

Starting Point	Formula
3165 C	
TM-190 48.50	
TM-215 27.80	
TM-SB 15.50	
TM-MX 8.20	

Starting Point	Formula
317 C	
TM-TW 96.50	
TM-215 1.66	
TM-190 1.49	
TM-MX 0.35	

Techmark TM

Starting Point	Formula
318 C	
TM-TW 90.00	
TM-190 4.95	
TM-215 3.85	
TM-MX 1.20	

Starting Point	Formula
319 C	
TM-TW 80.00	
TM-190 9.90	
TM-215 7.70	
TM-MX 2.40	

Starting Point	Formula
320 C	
TM-190 57.40	
TM-215 28.70	
TM-MX 13.90	

Starting Point	Formula
321 C	
TM-190 51.80	
TM-215 33.20	
TM-MX 12.50	
TM-SB 2.50	

Starting Point	Formula
322 C	
TM-190 51.00	
TM-215 29.00	
TM-MX 12.30	
TM-SB 7.70	

Starting Point	Formula
323 C	
TM-190 40.70	
TM-215 32.80	
TM-SB 16.70	
TM-MX 9.80	

Starting Point	Formula
324 C	
TM-TW 95.00	
TM-190 2.40	
TM-215 1.60	
TM-MX 0.80	
TM-185 0.20	

Starting Point	Formula
325 C	
TM-TW 75.00	
TM-190 12.00	
TM-215 7.80	
TM-MX 3.80	
TM-185 1.00	

Starting Point	Formula
326 C	
TM-TW 50.00	
TM-190 24.80	
TM-215 15.70	
TM-MX 7.60	
TM-185 1.90	

Starting Point	Formula
327 C	
TM-190 49.60	
TM-215 31.40	
TM-MX 15.20	
TM-185 3.80	

Starting Point	Formula
328 C	
TM-190 44.70	
TM-215 30.80	
TM-MX 13.50	
TM-SB 7.50	
TM-185 3.50	

Starting Point	Formula
329 C	
TM-190 39.70	
TM-215 30.70	
TM-SB 15.00	
TM-MX 12.10	
TM-185 3.10	

Starting Point	Formula
330 C	
TM-SB 30.00	
TM-190 29.80	
TM-215 28.80	
TM-MX 9.10	
TM-185 2.30	

Starting Point	Formula
3242 C	
TM-TW 67.30	
TM-MX 25.40	
TM-215 5.30	
TM-190 2.00	

Starting Point	Formula
3252 C	
TM-TW 62.90	
TM-MX 22.00	
TM-215 9.80	
TM-190 5.30	

Starting Point	Formula
3262 C	
TM-TW 51.80	
TM-215 19.20	
TM-MX 18.30	
TM-190 10.70	

Techmark TM

Starting Point	Formula
3272 C	
TM-MX 47.00	
TM-215 33.70	
TM-190 19.30	

Starting Point	Formula
3282 C	
TM-215 43.60	
TM-MX 28.60	
TM-190 25.00	
TM-SB 2.80	

Starting Point	Formula
3292 C	
TM-215 51.80	
TM-190 17.90	
TM-SB 17.50	
TM-MX 12.80	

Starting Point	Formula
3302 C	
TM-215 65.20	
TM-SB 34.80	

Starting Point	Formula
3245 C	
TM-TW 57.90	
TM-MX 34.00	
TM-215 6.80	
TM-190 1.30	

Starting Point	Formula
3255 C	
TM-TW 56.30	
TM-MX 28.20	
TM-215 12.70	
TM-190 2.80	

Starting Point	Formula
3265 C	
TM-TW 44.30	
TM-215 28.00	
TM-MX 21.40	
TM-190 6.30	

Starting Point	Formula
3275 C	
TM-MX 58.80	
TM-215 31.30	
TM-190 9.90	

Starting Point	Formula
3285 C	
TM-215 43.20	
TM-MX 41.80	
TM-190 13.90	
TM-SB 1.10	

Starting Point	Formula
3295 C	
TM-215 52.50	
TM-MX 29.30	
TM-190 11.40	
TM-SB 6.80	

Starting Point	Formula
3305 C	
TM-215 71.90	
TM-SB 25.20	
TM-185 2.90	

Starting Point	Formula
3248 C	
TM-TW 88.60	
TM-215 5.30	
TM-190 4.90	
TM-185 1.30	

Starting Point	Formula
3258 C	
TM-TW 68.60	
TM-215 22.10	
TM-190 6.00	
TM-MX 3.30	

Starting Point	Formula
3268 C	
TM-215 41.70	
TM-MX 28.30	
TM-TW 17.70	
TM-190 12.30	

Starting Point	Formula
3278 C	
TM-215 68.70	
TM-190 18.70	
TM-MX 12.60	

Starting Point	Formula
3288 C	
TM-215 78.70	
TM-190 19.30	
TM-SB 2.00	

Techmark TM

Starting Point	Formula
3298 C	
TM-215 77.00	
TM-190 11.50	
TM-SB 11.50	

Starting Point	Formula
3308 C	
TM-215 70.20	
TM-SB 28.00	
TM-185 1.80	

Starting Point	Formula
331 C	
TM-TW 99.00	
TM-215 0.93	
TM-190 0.07	

Starting Point	Formula
332 C	
TM-TW 93.20	
TM-215 6.30	
TM-190 0.50	

Starting Point	Formula
333 C	
TM-TW 78.70	
TM-215 19.70	
TM-190 1.60	

Starting Point	Formula
334 C	
TM-215 96.80	
TM-SB 3.20	

Starting Point	Formula
335 C	
TM-215 89.00	
TM-SB 11.00	

Starting Point	Formula
336 C	
TM-215 85.00	
TM-SB 15.00	

Starting Point	Formula
337 C	
TM-TW 94.20	
TM-215 3.00	
TM-190 2.00	
TM-185 0.80	

Starting Point	Formula
338 C	
TM-TW 83.30	
TM-215 8.70	
TM-190 5.80	
TM-185 2.20	

Starting Point	Formula
339 C	
TM-TW 50.00	
TM-215 26.00	
TM-190 17.50	
TM-185 6.50	

Starting Point	Formula
340 C	
TM-215 52.00	
TM-190 35.00	
TM-185 13.00	

Starting Point	Formula
341 C	
TM-215 48.80	
TM-190 31.30	
TM-185 12.80	
TM-SB 7.10	

Starting Point	Formula
342 C	
TM-215 45.60	
TM-190 27.50	
TM-SB 14.30	
TM-185 12.60	

Starting Point	Formula
343 C	
TM-215 39.20	
TM-SB 28.60	
TM-190 20.00	
TM-185 12.20	

Starting Point	Formula
3375 C	
TM-TW 52.80	
TM-MX 40.40	
TM-215 6.20	
TM-185 0.60	

Techmark TM

Starting Point	Formula
3385 C	
TM-TW 47.80	
TM-MX 35.00	
TM-215 15.90	
TM-185 1.30	

Starting Point	Formula
3395 C	
TM-TW 35.00	
TM-215 33.30	
TM-MX 30.00	
TM-185 1.70	

Starting Point	Formula
3405 C	
TM-215 54.10	
TM-MX 43.20	
TM-185 2.70	

Starting Point	Formula
3415 C	
TM-215 80.60	
TM-185 8.10	
TM-MX 8.10	
TM-SB 3.20	

Starting Point	Formula
3425 C	
TM-215 69.20	
TM-SB 17.60	
TM-185 13.20	

Starting Point	Formula
3435 C	
TM-215 54.40	
TM-SB 29.20	
TM-185 16.40	

Starting Point	Formula
344 C	
TM-TW 86.50	
TM-215 6.80	
TM-185 4.30	
TM-190 1.40	
TM-MX 1.00	

Starting Point	Formula
345 C	
TM-TW 72.80	
TM-215 13.70	
TM-185 8.60	
TM-190 2.90	
TM-MX 2.00	

Starting Point	Formula
346 C	
TM-TW 65.30	
TM-215 14.80	
TM-MX 10.10	
TM-185 6.60	
TM-190 3.20	

Starting Point	Formula
347 C	
TM-215 56.30	
TM-185 23.30	
TM-190 12.10	
TM-MX 8.30	

Starting Point	Formula
348 C	
TM-215 47.70	
TM-185 29.30	
TM-190 10.30	
TM-MX 7.00	
TM-SB 5.70	

Starting Point	Formula
349 C	
TM-215 41.10	
TM-185 28.60	
TM-SB 15.40	
TM-190 8.90	
TM-MX 6.00	

Starting Point	Formula
350 C	
TM-SB 33.30	
TM-215 32.90	
TM-185 21.90	
TM-190 7.10	
TM-MX 4.80	

Starting Point	Formula
351 C	
TM-TW 95.80	
TM-215 2.60	
TM-185 0.90	
TM-MX 0.70	

Starting Point	Formula
352 C	
TM-TW 87.50	
TM-215 7.80	
TM-185 2.60	
TM-MX 2.10	

Starting Point	Formula
353 C	
TM-TW 75.00	
TM-215 15.60	
TM-185 5.20	
TM-MX 4.20	

Techmark TM

Starting Point	Formula
354 C	
TM-215	62.50
TM-185	20.80
TM-MX	16.70

Starting Point	Formula
355 C	
TM-215	60.90
TM-185	20.30
TM-MX	16.30
TM-SB	2.50

Starting Point	Formula
356 C	
TM-215	57.40
TM-185	19.10
TM-MX	15.30
TM-SB	8.20

Starting Point	Formula
357 C	
TM-215	45.50
TM-SB	27.30
TM-185	15.10
TM-MX	12.10

Starting Point	Formula
358 C	
TM-TW	86.40
TM-185	4.80
TM-MX	4.60
TM-215	3.30
TM-190	0.90

Starting Point	Formula
359 C	
TM-TW	70.00
TM-185	10.60
TM-MX	10.10
TM-215	7.30
TM-190	2.00

Starting Point	Formula
360 C	
TM-TW	40.00
TM-185	21.10
TM-MX	20.40
TM-215	14.80
TM-190	3.90

Starting Point	Formula
361 C	
TM-MX	36.50
TM-185	30.50
TM-215	26.00
TM-190	7.00

Starting Point	Formula
362 C	
TM-MX	34.40
TM-185	29.90
TM-215	24.60
TM-190	6.60
TM-SB	4.50

Starting Point	Formula
363 C	
TM-MX	32.30
TM-185	29.30
TM-215	23.10
TM-SB	9.10
TM-190	6.20

Starting Point	Formula
364 C	
TM-MX	28.20
TM-185	28.10
TM-215	20.10
TM-SB	18.20
TM-190	5.40

Starting Point	Formula
365 C	
TM-TW	78.63
TM-MX	16.11
TM-185	3.98
TM-190	1.28

Starting Point	Formula
366 C	
TM-TW	77.26
TM-MX	12.22
TM-185	7.98
TM-190	2.56

Starting Point	Formula
367 C	
TM-TW	54.60
TM-MX	24.40
TM-185	15.90
TM-190	5.10

Starting Point	Formula
368 C	
TM-MX	45.00
TM-185	40.00
TM-190	15.00

Starting Point	Formula
369 C	
TM-MX	44.85
TM-185	39.63
TM-190	14.22
TM-SB	1.50

Techmark TM

Starting Point	Formula
370 C	
TM-MX	41.62
TM-185	38.50
TM-190	13.88
TM-SB	6.00

Starting Point	Formula
371 C	
TM-185	35.00
TM-MX	33.75
TM-SB	20.00
TM-190	11.25

Starting Point	Formula
372 C	
TM-TW	62.20
TM-MX	24.50
TM-185	10.00
TM-215	3.30

Starting Point	Formula
373 C	
TM-MX	47.80
TM-TW	34.10
TM-185	13.10
TM-215	5.00

Starting Point	Formula
374 C	
TM-MX	48.90
TM-TW	27.80
TM-185	16.50
TM-215	6.80

Starting Point	Formula
375 C	
TM-MX	53.60
TM-185	31.80
TM-215	14.60

Starting Point	Formula
376 C	
TM-MX	51.90
TM-185	31.20
TM-215	14.20
TM-SB	2.70

Starting Point	Formula
377 C	
TM-MX	49.30
TM-185	30.30
TM-215	13.50
TM-SB	6.90

Starting Point	Formula
378 C	
TM-MX	35.00
TM-SB	30.50
TM-185	25.00
TM-215	9.50

Starting Point	Formula
379 C	
TM-TW	80.20
TM-185	11.10
TM-MX	7.60
TM-190	0.80
TM-215	0.30

Starting Point	Formula
380 C	
TM-TW	66.00
TM-185	19.00
TM-MX	13.10
TM-190	1.40
TM-215	0.50

Starting Point	Formula
381 C	
TM-TW	50.00
TM-185	31.70
TM-MX	15.75
TM-190	2.55

Starting Point	Formula
382 C	
TM-185	63.40
TM-MX	31.50
TM-190	5.10

Starting Point	Formula
383 C	
TM-185	58.12
TM-MX	35.10
TM-190	4.68
TM-SB	2.10

Starting Point	Formula
384 C	
TM-185	52.83
TM-MX	38.72
TM-190	4.25
TM-SB	4.20

Starting Point	Formula
385 C	
TM-MX	53.25
TM-185	31.70
TM-SB	12.50
TM-190	2.55

Techmark TM

Starting Point	Formula
386 C	
TM-TW 80.00	
TM-185 11.45	
TM-MX 7.95	
TM-215 0.60	

Starting Point	Formula
387 C	
TM-TW 60.00	
TM-185 22.00	
TM-MX 16.80	
TM-215 1.20	

Starting Point	Formula
388 C	
TM-TW 43.50	
TM-MX 32.10	
TM-185 21.80	
TM-215 2.60	

Starting Point	Formula
389 C	
TM-MX 54.00	
TM-185 42.00	
TM-215 4.00	

Starting Point	Formula
390 C	
TM-MX 51.10	
MT-185 39.80	
TM-SB 5.30	
TM-215 3.80	

Starting Point	Formula
391 C	
TM-MX 50.00	
TM-185 38.80	
TM-SB 7.50	
TM-215 3.70	

Starting Point	Formula
392 C	
TM-MX 45.90	
TM-185 35.70	
TM-SB 15.00	
TM-215 3.40	

Starting Point	Formula
393 C	
TM-TW 80.00	
TM-185 10.00	
TM-MX 9.65	
TM-215 0.35	

Starting Point	Formula
394 C	
TM-TW 60.00	
MT-185 20.00	
MT-MX 19.30	
TM-215 0.70	

Starting Point	Formula
395 C	
TM-TW 50.00	
TM-185 25.90	
TM-MX 22.70	
TM-215 1.40	

Starting Point	Formula
396 C	
TM-185 51.80	
TM-MX 45.50	
TM-215 2.70	

Starting Point	Formula
397 C	
TM-185 50.80	
TM-MX 44.50	
TM-215 2.70	
TM-SB 2.00	

Starting Point	Formula
398 C	
TM-185 49.80	
TM-MX 43.60	
TM-SB 4.00	
TM-215 2.60	

Starting Point	Formula
399 C	
TM-185 47.70	
TM-MX 41.80	
TM-SB 8.00	
TM-215 2.50	

Starting Point	Formula
3935 C	
TM-WT 51.50	
TM-MX 35.00	
TM-185 13.20	
TM-215 0.30	

Starting Point	Formula
3945 C	
TM-MX 39.80	
TM-TW 29.80	
TM-185 29.80	
TM-215 0.60	

Techmark TM

Starting Point	Formula
3955 C	
TM-MX 54.10	
TM-185 42.50	
TM-215 3.40	

Starting Point	Formula
3965 C	
TM-MX 54.20	
TM-185 45.20	
TM-190 0.60	

Starting Point	Formula
3975 C	
TM-185 94.00	
TM-SB 3.00	
TM-190 2.20	
TM-180 0.80	

Starting Point	Formula
3985 C	
TM-185 85.20	
TM-SB 6.30	
TM-190 4.50	
TM-180 4.00	

Starting Point	Formula
3995 C	
TM-185 72.30	
TM-SB 18.50	
TM-180 5.20	
TM-190 4.00	

Starting Point	Formula
400 C	
TM-TW 96.64	
TM-SB 2.40	
TM-185 0.60	
TM-180 0.36	

Starting Point	Formula
401 C	
TM-TW 94.40	
TM-SB 4.00	
TM-185 1.00	
TM-180 0.60	

Starting Point	Formula
402 C	
TM-TW 91.50	
TM-SB 6.10	
TM-185 1.50	
TM-180 0.90	

Starting Point	Formula
403 C	
TM-TW 85.90	
TM-SB 10.00	
TM-185 2.50	
TM-180 1.50	

Starting Point	Formula
404 C	
TM-TW 75.80	
TM-SB 17.30	
TM-185 4.30	
TM-180 2.60	

Starting Point	Formula
405 C	
TM-TW 55.60	
TM-SB 31.70	
TM-185 7.90	
TM-180 4.80	

Starting Point	Formula
406 C	
TM-TW 95.80	
TM-SB 2.50	
TM-155 0.85	
TM-185 0.85	

Starting Point	Formula
407 C	
TM-TW 93.60	
TM-SB 3.80	
TM-155 1.30	
TM-185 1.30	

Starting Point	Formula
408 C	
TM-TW 90.10	
TM-SB 5.90	
TM-155 2.00	
TM-185 2.00	

Starting Point	Formula
409 C	
TM-TW 84.80	
TM-SB 9.20	
TM-155 3.10	
TM-185 3.10	

Starting Point	Formula
410 C	
TM-TW 71.80	
TM-SB 16.90	
TM-155 5.70	
TM-185 5.60	

Techmark TM

Starting Point	Formula
411 C	
TM-TW 48.30	
TM-SB 31.00	
TM-155 10.40	
TM-185 10.30	

Starting Point	Formula
412 C	
TM-SB 90.00	
TM-155 10.00	

Starting Point	Formula
413 C	
TM-TW 97.00	
TM-SB 2.20	
TM-185 0.80	

Starting Point	Formula
414 C	
TM-TW 95.10	
TM-SB 3.60	
TM-185 1.30	

Starting Point	Formula
415 C	
TM-TW 91.70	
TM-SB 6.10	
TM-185 2.20	

Starting Point	Formula
416 C	
TM-TW 86.30	
TM-SB 10.00	
TM-185 3.60	

Starting Point	Formula
417 C	
TM-TW 74.20	
TM-SB 19.80	
TM-185 6.00	

Starting Point	Formula
418 C	
TM-TW 74.20	
TM-SB 33.00	
TM-185 10.00	

Starting Point	Formula
419 C	
TM-SB 90.00	
TM-215 10.00	

Starting Point	Formula
420 C	
TM-TW 97.00	
TM-SB 2.79	
TM-185 0.21	

Starting Point	Formula
421 C	
TM-TW 95.04	
TM-SB 4.60	
TM-185 0.36	

Starting Point	Formula
422 C	
TM-TW 91.80	
TM-SB 7.60	
TM-185 0.60	

Starting Point	Formula
423 C	
TM-TW 85.00	
TM-SB 13.50	
TM-185 1.10	

Starting Point	Formula
424 C	
TM-TW 74.90	
TM-SB 23.20	
TM-185 1.90	

Starting Point	Formula
425 C	
TM-TW 74.90	
TM-SB 38.70	
TM-185 3.20	

Starting Point	Formula
426 C	
TM-SB 90.00	
TM-205 10.00	

Techmark TM

Starting Point	Formula
427 C	
TM-TW	98.47
TM-SB	1.40
TM-205	0.13

Starting Point	Formula
428 C	
TM-TW	96.95
TM-SB	2.80
TM-205	0.25

Starting Point	Formula
429 C	
TM-TW	93.90
TM-SB	5.60
TM-205	0.50

Starting Point	Formula
430 C	
TM-TW	88.80
TM-SB	11.20

Starting Point	Formula
431 C	
TM-TW	77.70
TM-SB	22.30

Starting Point	Formula
432 C	
TM-TW	65.00
TM-SB	35.00

Starting Point	Formula
433 C	
TM-SB	80.00
TM-205	20.00

Starting Point	Formula
434 C	
TM-TW	97.25
TM-215	1.20
TM-180	1.00
TM-160	0.55

Starting Point	Formula
435 C	
TM-TW	94.95
TM-215	2.20
TM-180	1.85
TM-160	1.00

Starting Point	Formula
436 C	
TM-TW	89.90
TM-215	4.40
TM-180	3.70
TM-160	2.00

Starting Point	Formula
437 C	
TM-TW	55.80
TM-215	13.90
TM-MX	12.20
TM-180	12.20
TM-160	5.90

Starting Point	Formula
438 C	
TM-215	31.50
TM-180	27.60
TM-MX	27.50
TM-160	13.40

Starting Point	Formula
439 C	
TM-180	40.50
TM-215	36.40
TM-155	12.10
TM-SB	11.00

Starting Point	Formula
440 C	
TM-180	35.70
TM-215	32.10
TM-SB	21.50
TM-155	10.70

Starting Point	Formula
441 C	
TM-TW	96.22
TM-215	2.15
TM-180	0.95
TM-160	0.68

Starting Point	Formula
442 C	
TM-TW	92.45
TM-215	4.30
TM-180	1.90
TM-160	1.35

Techmark TM

Starting Point	Formula
443 C	
TM-TW 77.20	
TM-MX 9.70	
TM-215 7.60	
TM-180 3.30	
TM-160 2.20	

Starting Point	Formula
444 C	
TM-TW 54.50	
TM-MX 19.50	
TM-215 15.20	
TM-180 6.50	
TM-160 4.30	

Starting Point	Formula
445 C	
TM-MX 42.90	
TM-215 33.30	
TM-180 14.30	
TM-160 9.50	

Starting Point	Formula
446 C	
TM-215 37.00	
TM-MX 34.60	
TM-180 19.10	
TM-160 8.70	
TM-SB 0.60	

Starting Point	Formula
447 C	
TM-215 54.60	
TM-180 36.40	
TM-160 4.50	
TM-SB 4.50	

Starting Point	Formula
Warm Gray 1 C	
TM-TW 98.48	
TM-SB 0.94	
TM-185 0.34	
TM-180 0.24	

Starting Point	Formula
Warm Gray 2 C	
TM-TW 97.59	
TM-SB 1.27	
TM-185 0.60	
TM-180 0.54	

Starting Point	Formula
Warm Gray 3 C	
TM-TW 93.66	
TM-SB 4.51	
TM-185 1.02	
TM-180 0.81	

Starting Point	Formula
Warm Gray 4 C	
TM-TW 90.68	
TM-SB 6.55	
TM-185 1.51	
TM-180 1.26	

Starting Point	Formula
Warm Gray 5 C	
TM-TW 88.81	
TM-SB 7.88	
TM-185 1.80	
TM-180 1.51	

Starting Point	Formula
Warm Gray 6 C	
TM-TW 88.22	
TM-SB 8.29	
TM-185 1.91	
TM-180 1.58	

Starting Point	Formula
Warm Gray 7 C	
TM-TW 80.90	
TM-SB 13.11	
TM-185 3.01	
TM-180 2.98	

Starting Point	Formula
Warm Gray 8 C	
TM-TW 79.12	
TM-SB 13.60	
TM-180 3.80	
TM-185 3.48	

Starting Point	Formula
Warm Gray 9 C	
TM-TW 69.87	
TM-SB 19.65	
TM-180 5.24	
TM-185 5.24	

Starting Point	Formula
Warm Gray 10 C	
TM-TW 64.36	
TM-SB 23.76	
TM-180 5.94	
TM-185 5.94	

Starting Point	Formula
Warm Gray 11 C	
TM-TW 51.82	
TM-SB 32.64	
TM-180 7.77	
TM-185 7.77	

Techmark TM

Starting Point	Formula
Cool Gray 1 C	
TM-TW 98.26	
TM-SB 1.29	
TM-185 0.40	
TM-155 0.05	

Starting Point	Formula
Cool Gray 2 C	
TM-TW 97.45	
TM-SB 2.23	
TM-185 0.26	
TM-155 0.06	

Starting Point	Formula
Cool Gray 3 C	
TM-TW 95.93	
TM-SB 3.60	
TM-185 0.39	
TM-155 0.08	

Starting Point	Formula
Cool Gray 4 C	
TM-TW 94.69	
TM-SB 4.75	
TM-185 0.42	
TM-155 0.14	

Starting Point	Formula
Cool Gray 5 C	
TM-TW 92.43	
TM-SB 6.53	
TM-185 0.74	
TM-155 0.30	

Starting Point	Formula
Cool Gray 6 C	
TM-TW 89.88	
TM-SB 8.99	
TM-185 0.84	
TM-155 0.29	

Starting Point	Formula
Cool Gray 7 C	
TM-TW 87.77	
TM-SB 11.20	
TM-185 0.75	
TM-155 0.28	

Starting Point	Formula
Cool Gray 8 C	
TM-TW 82.24	
TM-SB 16.63	
TM-185 0.87	
TM-155 0.26	

Starting Point	Formula
Cool Gray 9 C	
TM-TW 78.27	
TM-SB 20.23	
TM-185 1.25	
TM-155 0.25	

Starting Point	Formula
Cool Gray 10 C	
TM-TW 75.62	
TM-SB 22.53	
TM-185 1.61	
TM-155 0.24	

Starting Point	Formula
Cool Gray 11 C	
TM-TW 64.92	
TM-SB 32.94	
TM-185 1.93	
TM-155 0.21	

Starting Point	Formula
448 C	
TM-175 27.90	
TM-185 27.30	
TM-SB 20.00	
TM-MX 17.80	
TM-190 7.00	

Starting Point	Formula
449 C	
TM-175 33.80	
TM-185 32.90	
TM-MX 21.60	
TM-190 7.70	
TM-SB 4.00	

Starting Point	Formula
450 C	
TM-175 35.20	
TM-185 34.30	
TM-MX 22.50	
TM-190 8.00	

Starting Point	Formula
451 C	
TM-TW 70.10	
TM-185 10.90	
TM-175 10.10	
TM-MX 6.40	
TM-190 2.50	

Starting Point	Formula
452 C	
TM-TW 85.20	
TM-185 5.80	
TM-175 5.00	
TM-MX 2.90	
TM-190 1.10	

Techmark TM

Starting Point	Formula
453 C	
TM-TW 90.20	
TM-185 3.90	
TM-175 3.30	
TM-MX 1.85	
TM-190 0.75	

Starting Point	Formula
454 C	
TM-TW 92.70	
TM-185 2.90	
TM-175 2.50	
TM-MX 1.35	
TM-190 0.55	

Starting Point	Formula
4485 C	
TM-185 51.30	
TM-175 28.40	
TM-SB 17.50	
TM-190 2.80	

Starting Point	Formula
4495 C	
TM-185 54.70	
TM-175 23.30	
TM-MX 10.00	
TM-TW 6.70	
TM-190 5.30	

Starting Point	Formula
4505 C	
TM-185 36.40	
TM-TW 33.40	
TM-175 15.60	
TM-MX 11.00	
TM-190 3.60	

Starting Point	Formula
4515 C	
TM-TW 75.00	
TM-185 16.40	
TM-175 7.00	
TM-190 1.60	

Starting Point	Formula
4525 C	
TM-TW 82.50	
TM-185 11.70	
TM-175 4.70	
TM-190 1.10	

Starting Point	Formula
4535 C	
TM-TW 93.40	
TM-185 4.20	
TM-175 2.10	
TM-190 0.30	

Starting Point	Formula
4545 C	
TM-TW 96.50	
TM-185 2.10	
TM-175 1.30	
TM-190 0.10	

Starting Point	Formula
455 C	
TM-185 35.90	
TM-MX 31.20	
TM-SB 23.80	
TM-180 5.10	
TM-205 4.00	

Starting Point	Formula
456 C	
TM-185 43.70	
TM-MX 38.10	
TM-SB 7.10	
TM-180 6.20	

Starting Point	Formula
457 C	
TM-185 47.00	
TM-MX 41.00	
TM-180 6.70	
TM-205 5.30	

Starting Point	Formula
458 C	
TM-TW 70.00	
TM-185 17.70	
TM-MX 9.50	
TM-180 1.56	
TM-205 1.24	

Starting Point	Formula
459 C	
TM-TW 87.50	
TM-185 7.38	
TM-MX 3.95	
TM-180 0.65	
TM-205 0.52	

Starting Point	Formula
460 C	
TM-TW 92.00	
TM-185 4.74	
TM-MX 2.51	
TM-180 0.42	
TM-205 0.33	

Starting Point	Formula
461 C	
TM-TW 96.80	
TM-185 1.90	
TM-MX 1.00	
TM-180 0.17	
TM-205 0.13	

Techmark TM

Starting Point	Formula
462 C	
TM-185	32.20
TM-155	21.00
TM-SB	20.00
TM-MX	17.80
TM-190	9.00

Starting Point	Formula
463 C	
TM-185	37.00
TM-155	24.60
TM-MX	21.00
TM-190	10.50
TM-SB	6.00

Starting Point	Formula
464 C	
TM-185	40.30
TM-155	26.20
TM-MX	22.30
TM-190	11.20

Starting Point	Formula
465 C	
TM-TW	76.90
TM-185	13.05
TM-155	6.70
TM-190	3.35

Starting Point	Formula
466 C	
TM-TW	87.39
TM-185	7.13
TM-155	3.65
TM-190	1.83

Starting Point	Formula
467 C	
TM-TW	93.10
TM-185	3.90
TM-155	2.00
TM-190	1.00

Starting Point	Formula
468 C	
TM-TW	96.20
TM-185	2.16
TM-155	1.09
TM-190	0.55

Starting Point	Formula
4625 C	
TM-SB	47.10
TM-180	35.30
TM-185	17.60

Starting Point	Formula
4635 C	
TM-185	32.90
TM-180	27.50
TM-MX	15.00
TM-190	9.60
TM-SB	7.50
TM-TW	7.50

Starting Point	Formula
4645 C	
TM-TW	36.20
TM-MX	23.00
TM-185	18.10
TM-180	15.10
TM-190	5.30
TM-SB	2.30

Starting Point	Formula
4655 C	
TM-TW	68.00
TM-MX	11.80
TM-185	8.90
TM-180	7.70
TM-190	2.70
TM-SB	0.90

Starting Point	Formula
4665 C	
TM-TW	84.00
TM-185	4.70
TM-MX	4.70
TM-180	4.60
TM-190	1.40
TM-SB	0.60

Starting Point	Formula
4675 C	
TM-TW	85.90
TM-180	4.20
TM-MX	4.10
TM-185	4.10
TM-190	1.20
TM-SB	0.50

Starting Point	Formula
4685 C	
TM-TW	96.00
TM-185	1.20
TM-180	1.20
TM-MX	1.20
TM-190	0.30
TM-SB	0.10

Starting Point	Formula
469 C	
TM-180	29.00
TM-SB	26.10
TM-MX	20.20
TM-185	19.50
TM-215	5.20

Starting Point	Formula
470 C	
TM-180	36.70
TM-MX	25.10
TM-185	24.20
TM-SB	7.50
TM-215	6.50

Techmark TM

Starting Point	Formula
471 C	
TM-180	35.50
TM-MX	29.00
TM-185	28.00
TM-215	7.50

Starting Point	Formula
472 C	
TM-TW	49.50
TM-180	17.80
TM-185	14.90
TM-MX	14.30
TM-215	3.70

Starting Point	Formula
473 C	
TM-TW	76.80
TM-180	8.53
TM-185	6.73
TM-MX	6.47
TM-215	1.67

Starting Point	Formula
474 C	
TM-TW	84.40
TM-180	5.89
TM-185	4.49
TM-MX	4.31
TM-215	1.11

Starting Point	Formula
475 C	
TM-TW	92.20
TM-180	2.85
TM-185	2.25
TM-MX	2.15
TM-215	0.55

Starting Point	Formula
4695 C	
TM-155	36.70
TM-185	33.30
TM-SB	30.00

Starting Point	Formula
4705 C	
TM-185	32.60
TM-155	27.90
TM-TW	25.50
TM-SB	14.00

Starting Point	Formula
4715 C	
TM-TW	56.20
TM-185	21.10
TM-155	13.20
TM-SB	9.50

Starting Point	Formula
4725 C	
TM-TW	76.20
TM-185	10.20
TM-155	7.20
TM-SB	6.40

Starting Point	Formula
4735 C	
TM-TW	88.70
TM-185	4.80
TM-155	3.30
TM-SB	3.20

Starting Point	Formula
4745 C	
TM-TW	93.60
TM-185	2.60
TM-155	1.90
TM-SB	1.90

Starting Point	Formula
4755 C	
TM-TW	97.16
TM-185	1.23
TM-155	0.93
TM-SB	0.68

Starting Point	Formula
476 C	
TM-185	27.97
TM-155	27.00
TM-SB	25.00
TM-MX	10.50
TM-205	9.53

Starting Point	Formula
477 C	
TM-155	39.50
TM-185	37.60
TM-205	9.40
TM-MX	7.50
TM-SB	6.00

Starting Point	Formula
478 C	
TM-155	42.00
TM-185	40.00
TM-205	10.00
TM-MX	8.00

Starting Point	Formula
479 C	
TM-TW	73.00
TM-185	11.51
TM-155	8.75
TM-MX	3.40
TM-205	3.34

Techmark TM

Starting Point	Formula
480 C	
TM-TW	86.80
TM-185	5.44
TM-155	4.41
TM-MX	1.70
TM-205	1.65

Starting Point	Formula
481 C	
TM-TW	92.76
TM-185	2.97
TM-155	2.44
TM-MX	0.93
TM-205	0.90

Starting Point	Formula
482 C	
TM-TW	96.05
TM-185	1.62
TM-155	1.33
TM-MX	0.51
TM-205	0.49

Starting Point	Formula
483 C	
TM-155	43.62
TM-185	29.08
TM-SB	27.30

Starting Point	Formula
484 C	
TM-155	55.09
TM-185	36.72
TM-SB	8.19

Starting Point	Formula
485 C	
TM-155	60.00
TM-185	40.00

Starting Point	Formula
486 C	
TM-TW	76.80
TM-155	12.78
TM-185	10.82

Starting Point	Formula
487 C	
TM-TW	88.41
TM-185	5.03
TM-155	6.56

Starting Point	Formula
488 C	
TM-TW	93.68
TM-155	3.58
TM-185	2.74

Starting Point	Formula
489 C	
TM-TW	96.56
TM-155	1.95
TM-185	1.49

Starting Point	Formula
490 C	
TM-180	32.67
TM-SB	29.20
TM-155	22.50
TM-MX	8.13
TM-215	7.50

Starting Point	Formula
491 C	
TM-180	37.10
TM-155	31.95
TM-MX	11.50
TM-215	10.65
TM-SB	8.80

Starting Point	Formula
492 C	
TM-180	39.00
TM-155	36.00
TM-MX	13.00
TM-215	12.00

Starting Point	Formula
493 C	
TM-TW	75.00
TM-180	9.75
TM-155	9.00
TM-MX	3.25
TM-215	3.00

Starting Point	Formula
494 C	
TM-TW	90.40
TM-180	3.75
TM-155	3.45
TM-MX	1.25
TM-215	1.15

Starting Point	Formula
495 C	
TM-TW	94.15
TM-155	2.42
TM-180	2.09
TM-MX	0.70
TM-215	0.64

Techmark TM

Starting Point	Formula
496 C	
TM-TW 98.20	
TM-155 1.00	
TM-180 0.67	
TM-215 0.13	

Starting Point	Formula
497 C	
TM-180 35.25	
TM-SB 25.00	
TM-MX 19.12	
TM-215 15.00	
TM-160 5.63	

Starting Point	Formula
498 C	
TM-180 43.48	
TM-MX 23.58	
TM-215 18.50	
TM-SB 7.50	
TM-160 6.94	

Starting Point	Formula
499 C	
TM-180 47.00	
TM-MX 25.50	
TM-215 20.00	
TM-160 7.50	

Starting Point	Formula
500 C	
TM-TW 62.50	
TM-160 18.26	
TM-180 9.78	
TM-MX 5.30	
TM-215 5.30	

Starting Point	Formula
501 C	
TM-TW 86.29	
TM-160 6.86	
TM-180 3.48	
TM-MX 1.89	
TM-215 1.48	

Starting Point	Formula
502 C	
TM-TW 93.14	
TM-160 3.43	
TM-180 1.74	
TM-MX 0.95	
TM-215 0.74	

Starting Point	Formula
503 C	
TM-TW 98.20	
TM-160 1.20	
TM-180 0.50	
TM-215 0.10	

Starting Point	Formula
4975 C	
TM-SB 57.20	
TM-180 37.10	
TM-160 5.70	

Starting Point	Formula
4985 C	
TM-180 35.80	
TM-TW 34.50	
TM-SB 19.80	
TM-160 9.90	

Starting Point	Formula
4995 C	
TM-TW 66.00	
TM-180 19.60	
TM-SB 10.40	
TM-160 4.00	

Starting Point	Formula
5005 C	
TM-TW 81.80	
TM-180 10.40	
TM-SB 6.10	
TM-160 1.70	

Starting Point	Formula
5015 C	
TM-TW 92.10	
TM-180 4.80	
TM-SB 3.10	

Starting Point	Formula
5025 C	
TM-TW 95.80	
TM-180 2.60	
TM-SB 1.60	

Starting Point	Formula
5035 C	
TM-TW 97.80	
TM-180 1.30	
TM-SB 0.90	

Starting Point	Formula
504 C	
TM-180 31.28	
TM-SB 27.27	
TM-MX 26.66	
TM-205 8.86	
TM-155 5.93	

Techmark TM

Starting Point	Formula
505 C	
TM-180	36.82
TM-MX	35.37
TM-205	11.76
TM-SB	8.18
TM-155	7.87

Starting Point	Formula
506 C	
TM-180	39.20
TM-MX	39.10
TM-205	13.00
TM-155	8.70

Starting Point	Formula
507 C	
TM-TW	75.00
TM-180	7.62
TM-MX	7.60
TM-155	7.25
TM-205	2.53

Starting Point	Formula
508 C	
TM-TW	87.50
TM-MX	3.80
TM-180	3.80
TM-155	3.63
TM-205	1.27

Starting Point	Formula
509 C	
TM-TW	94.15
TM-155	1.83
TM-180	1.72
TM-MX	1.72
TM-205	0.58

Starting Point	Formula
510 C	
TM-TW	97.30
TM-180	1.20
TM-155	1.20
TM-205	0.30

Starting Point	Formula
511 C	
TM-155	35.70
TM-SB	28.60
TM-160	18.64
TM-MX	13.95
TM-215	3.11

Starting Point	Formula
512 C	
TM-160	42.13
TM-MX	31.54
TM-155	10.71
TM-SB	8.60
TM-215	7.02

Starting Point	Formula
513 C	
TM-160	52.20
TM-MX	39.10
TM-215	8.70

Starting Point	Formula
514 C	
TM-TW	80.00
TM-160	7.83
TM-MX	5.86
TM-155	5.00
TM-215	1.31

Starting Point	Formula
515 C	
TM-TW	90.00
TM-160	3.92
TM-160	3.92
TM-MX	2.92
TM-215	0.66

Starting Point	Formula
516 C	
TM-TW	95.00
TM-160	1.96
TM-MX	1.46
TM-155	1.25
TM-215	0.33

Starting Point	Formula
517 C	
TM-TW	97.10
TM-160	1.14
TM-MX	0.84
TM-155	0.73
TM-215	0.19

Starting Point	Formula
5115 C	
TM-155	51.70
TM-SB	48.30

Starting Point	Formula
5125 C	
TM-155	50.00
TM-TW	26.70
TM-SB	23.30

Starting Point	Formula
5135 C	
TM-TW	64.50
TM-155	24.20
TM-SB	11.30

Techmark TM

Starting Point	Formula
5145 C	
TM-TW 83.80	
TM-155 9.90	
TM-SB 6.30	

Starting Point	Formula
5155 C	
TM-TW 92.60	
TM-155 4.00	
TM-SB 3.40	

Starting Point	Formula
5165 C	
TM-TW 96.30	
TM-155 2.00	
TM-SB 1.70	

Starting Point	Formula
5175 C	
TM-TW 98.00	
TM-155 1.00	
TM-SB 1.00	

Starting Point	Formula
518 C	
TM-175 41.87	
TM-SB 22.60	
TM-MX 20.57	
TM-180 10.00	
TM-215 4.96	

Starting Point	Formula
519 C	
TM-175 53.86	
TM-MX 26.45	
TM-SB 6.80	
TM-180 6.50	
TM-215 6.39	

Starting Point	Formula
520 C	
TM-175 59.00	
TM-MX 29.00	
TM-215 7.00	
TM-180 5.00	

Starting Point	Formula
521 C	
TM-TW 75.00	
TM-175 13.57	
TM-MX 6.87	
TM-180 3.15	
TM-215 1.61	

Starting Point	Formula
522 C	
TM-TW 83.92	
TM-175 8.72	
TM-MX 4.29	
TM-180 2.03	
TM-215 1.04	

Starting Point	Formula
523 C	
TM-TW 88.40	
TM-175 5.21	
TM-180 3.21	
TM-MX 2.56	
TM-215 0.62	

Starting Point	Formula
524 C	
TM-TW 91.00	
TM-180 3.92	
TM-175 3.16	
TM-MX 1.55	
TM-215 0.37	

Starting Point	Formula
5185 C	
TM-SB 55.90	
TM-175 31.10	
TM-180 13.00	

Starting Point	Formula
5195 C	
TM-175 49.60	
TM-SB 35.60	
TM-180 14.80	

Starting Point	Formula
5205 C	
TM-TW 46.50	
TM-175 18.60	
TM-SB 14.00	
TM-MX 11.60	
TM-180 9.30	

Starting Point	Formula
5215 C	
TM-TW 82.00	
TM-SB 6.40	
TM-175 5.80	
TM-180 5.80	

Starting Point	Formula
5225 C	
TM-TW 91.00	
TM-SB 3.60	
TM-175 2.70	
TM-180 2.70	

Techmark TM

Starting Point	Formula
5235 C	
TM-TW	95.90
TM-SB	1.80
TM-180	1.20
TM-175	1.10

Starting Point	Formula
5245 C	
TM-TW	98.20
TM-SB	0.80
TM-180	0.60
TM-175	0.40

Starting Point	Formula
525 C	
TM-175	62.39
TM-SB	23.10
TM-MX	10.47
TM-205	3.77

Starting Point	Formula
526 C	
TM-175	69.82
TM-MX	17.25
TM-SB	6.90
TM-205	6.03

Starting Point	Formula
527 C	
TM-175	73.00
TM-MX	20.00
TM-205	7.00

Starting Point	Formula
528 C	
TM-TW	71.40
TM-175	24.72
TM-MX	2.88
TM-205	1.00

Starting Point	Formula
529 C	
TM-TW	85.70
TM-175	12.36
TM-MX	1.44
TM-205	0.50

Starting Point	Formula
530 C	
TM-TW	91.70
TM-175	7.44
TM-MX	0.63
TM-205	0.23

Starting Point	Formula
531 C	
TM-TW	95.40
TM-175	3.68
TM-155	0.50
TM-MX	0.31
TM-205	0.11

Starting Point	Formula
5255 C	
TM-SB	53.10
TM-175	42.60
TM-205	4.30

Starting Point	Formula
5265 C	
TM-175	65.60
TM-SB	19.70
TM-205	9.80
TM-TW	4.90

Starting Point	Formula
5275 C	
TM-TW	40.00
TM-175	40.00
TM-SB	14.00
TM-205	6.00

Starting Point	Formula
5285 C	
TM-TW	71.50
TM-175	17.90
TM-SB	7.90
TM-205	2.70

Starting Point	Formula
5295 C	
TM-TW	87.20
TM-175	6.90
TM-SB	5.10
TM-205	0.80

Starting Point	Formula
5305 C	
TM-TW	93.40
TM-175	3.50
TM-SB	2.80
TM-205	0.30

Starting Point	Formula
5315 C	
TM-TW	96.97
TM-SB	1.52
TM-175	1.40
TM-205	0.11

Techmark TM

Starting Point	Formula
532 C	
TM-175	46.27
TM-SB	36.36
TM-215	17.37

Starting Point	Formula
533 C	
TM-175	58.30
TM-215	21.90
TM-SB	19.80

Starting Point	Formula
534 C	
TM-175	72.70
TM-215	27.30

Starting Point	Formula
535 C	
TM-TW	75.00
TM-175	12.14
TM-MX	7.50
TM-215	4.53
TM-180	0.83

Starting Point	Formula
536 C	
TM-TW	86.40
TM-175	6.62
TM-MX	4.06
TM-215	2.47
TM-180	0.45

Starting Point	Formula
537 C	
TM-TW	92.60
TM-175	3.61
TM-MX	2.19
TM-215	1.35
TM-180	0.25

Starting Point	Formula
538 C	
TM-TW	96.00
TM-175	1.97
TM-MX	1.15
TM-215	0.74
TM-180	0.14

Starting Point	Formula
539 C	
TM-SB	33.30
TM-205	31.90
TM-215	17.40
TM-155	17.40

Starting Point	Formula
540 C	
TM-205	43.04
TM-215	23.48
TM-155	23.48
TM-SB	10.00

Starting Point	Formula
541 C	
TM-205	47.82
TM-155	26.09
TM-215	26.09

Starting Point	Formula
542 C	
TM-TW	59.30
TM-MX	22.19
TM-205	8.75
TM-215	4.99
TM-155	4.77

Starting Point	Formula
543 C	
TM-TW	79.70
TM-MX	11.03
TM-205	4.38
TM-215	2.50
TM-155	2.39

Starting Point	Formula
544 C	
TM-TW	88.90
TM-MX	6.05
TM-205	2.39
TM-215	1.36
TM-155	1.30

Starting Point	Formula
545 C	
TM-TW	93.20
TM-MX	3.69
TM-205	1.47
TM-215	0.84
TM-155	0.80

Starting Point	Formula
5395 C	
TM-SB	33.60
TM-205	26.80
TM-215	25.10
TM-155	14.50

Starting Point	Formula
5405 C	
TM-TW	34.20
TM-SB	19.60
TM-215	19.60
TM-205	18.80
TM-155	7.80

Techmark TM

Starting Point	Formula
5415 C	
TM-TW	59.20
TM-215	13.00
TM-SB	11.80
TM-205	11.30
TM-155	4.70

Starting Point	Formula
5425 C	
TM-TW	81.20
TM-SB	7.90
TM-215	4.90
TM-205	4.20
TM-155	1.80

Starting Point	Formula
5435 C	
TM-TW	92.00
TM-SB	4.10
TM-215	1.60
TM-205	1.60
TM-155	0.70

Starting Point	Formula
5445 C	
TM-TW	95.94
TM-SB	2.34
TM-215	0.74
TM-205	0.74
TM-155	0.24

Starting Point	Formula
5455 C	
TM-TW	98.07
TM-SB	1.09
TM-215	0.36
TM-205	0.36
TM-155	0.12

Starting Point	Formula
546 C	
TM-215	41.30
TM-SB	30.00
TM-155	17.50
TM-205	11.20

Starting Point	Formula
547 C	
TM-215	53.69
TM-155	22.75
TM-205	14.56
TM-SB	9.00

Starting Point	Formula
548 C	
TM-215	59.00
TM-155	25.00
TM-205	16.00

Starting Point	Formula
549 C	
TM-TW	74.25
TM-215	14.60
TM-155	6.19
TM-205	4.96

Starting Point	Formula
550 C	
TM-TW	86.25
TM-215	7.23
TM-205	3.46
TM-155	3.06

Starting Point	Formula
551 C	
TM-TW	92.50
TM-215	3.94
TM-205	1.89
TM-155	1.67

Starting Point	Formula
552 C	
TM-TW	96.24
TM-215	1.97
TM-205	0.95
TM-155	0.84

Starting Point	Formula
5463 C	
TM-215	45.10
TM-SB	33.70
TM-205	12.70
TM-155	8.50

Starting Point	Formula
5473 C	
TM-215	40.50
TM-TW	32.90
TM-SB	15.20
TM-155	7.60
TM-205	3.80

Starting Point	Formula
5483 C	
TM-TW	62.10
TM-215	22.60
TM-SB	8.60
TM-155	4.20
TM-205	2.50

Starting Point	Formula
5493 C	
TM-TW	81.20
TM-215	11.60
TM-SB	4.30
TM-155	2.00
TM-205	0.90

Techmark TM

Starting Point	Formula
5503 C	
TM-TW	89.60
TM-215	5.60
TM-SB	3.60
TM-155	0.80
TM-205	0.40

Starting Point	Formula
5513 C	
TM-TW	96.86
TM-215	1.64
TM-SB	1.23
TM-205	0.27

Starting Point	Formula
5523 C	
TM-TW	98.04
TM-215	1.12
TM-SB	0.70
TM-205	0.14

Starting Point	Formula
5467 C	
TM-SB	37.90
TM-205	34.50
TM-185	27.60

Starting Point	Formula
5477 C	
TM-TW	38.60
TM-SB	22.70
TM-185	20.50
TM-205	18.20

Starting Point	Formula
5487 C	
TM-TW	64.90
TM-SB	15.00
TM-185	11.20
TM-205	8.90

Starting Point	Formula
5497 C	
TM-TW	83.70
TM-SB	8.60
TM-185	4.10
TM-205	3.60

Starting Point	Formula
5507 C	
TM-TW	92.20
TM-SB	4.10
TM-185	2.10
TM-205	1.60

Starting Point	Formula
5517 C	
TM-TW	95.30
TM-SB	2.60
TM-185	1.20
TM-205	0.90

Starting Point	Formula
5527 C	
TM-TW	97.90
TM-SB	1.20
TM-185	0.50
TM-205	0.40

Starting Point	Formula
553 C	
TM-SB	30.00
TM-MX	24.50
TM-205	24.50
TM-185	21.00

Starting Point	Formula
554 C	
TM-205	31.85
TM-MX	31.85
TM-185	27.30
TM-SB	9.00

Starting Point	Formula
555 C	
TM-205	35.00
TM-MX	35.00
TM-185	30.00

Starting Point	Formula
556 C	
TM-TW	69.67
TM-185	10.25
TM-205	10.04
TM-MX	10.04

Starting Point	Formula
557 C	
TM-TW	85.60
TM-MX	7.15
TM-185	3.66
TM-205	3.59

Starting Point	Formula
558 C	
TM-TW	90.70
TM-MX	4.61
TM-185	2.37
TM-205	2.32

Techmark TM

Starting Point	Formula
559 C	
TM-TW 92.40	
TM-MX 3.78	
TM-185 1.93	
TM-205 1.89	

Starting Point	Formula
5535 C	
TM-SB 52.10	
TM-215 39.60	
TM-185 8.30	

Starting Point	Formula
5545 C	
TM-TW 41.40	
TM-215 26.60	
TM-SB 24.60	
TM-185 7.40	

Starting Point	Formula
5555 C	
TM-TW 72.80	
TM-SB 13.20	
TM-215 9.80	
TM-185 4.20	

Starting Point	Formula
5565 C	
TM-TW 84.20	
TM-SB 7.90	
TM-215 5.30	
TM-185 2.60	

Starting Point	Formula
5575 C	
TM-TW 92.60	
TM-SB 3.80	
TM-215 2.40	
TM-185 1.20	

Starting Point	Formula
5585 C	
TM-TW 95.20	
TM-SB 2.50	
TM-215 1.80	
TM-185 0.50	

Starting Point	Formula
5595 C	
TM-TW 97.40	
TM-SB 1.20	
TM-215 0.70	
TM-185 0.70	

Starting Point	Formula
560 C	
TM-215 62.40	
TM-180 22.00	
TM-SB 9.40	
TM-190 6.20	

Starting Point	Formula
561 C	
TM-215 74.10	
TM-180 14.80	
TM-190 7.40	
TM-SB 3.70	

Starting Point	Formula
562 C	
TM-215 39.00	
TM-MX 33.00	
TM-180 14.50	
TM-190 13.50	

Starting Point	Formula
563 C	
TM-TW 75.90	
TM-215 9.96	
TM-MX 7.65	
TM-180 3.36	
TM-190 3.13	

Starting Point	Formula
564 C	
TM-TW 86.90	
TM-215 5.43	
TM-MX 4.13	
TM-180 1.83	
TM-190 1.71	

Starting Point	Formula
565 C	
TM-TW 93.40	
TM-215 2.72	
TM-MX 2.10	
TM-180 0.92	
TM-190 0.86	

Starting Point	Formula
566 C	
TM-TW 96.00	
TM-215 1.83	
TM-MX 1.30	
TM-180 0.55	
TM-190 0.52	

Starting Point	Formula
5605 C	
TM-SB 41.70	
TM-185 33.30	
TM-205 25.00	

Techmark TM

Starting Point	Formula
5615 C	
TM-TW	37.50
TM-185	28.70
TM-SB	20.80
TM-205	13.00

Starting Point	Formula
5625 C	
TM-TW	67.90
TM-185	14.50
TM-SB	11.40
TM-205	6.20

Starting Point	Formula
5635 C	
TM-TW	86.00
TM-SB	5.80
TM-185	5.70
TM-205	2.50

Starting Point	Formula
5645 C	
TM-TW	93.10
TM-SB	2.90
TM-185	2.80
TM-205	1.20

Starting Point	Formula
5655 C	
TM-TW	95.85
TM-185	1.82
TM-SB	1.58
TM-205	0.75

Starting Point	Formula
5665 C	
TM-TW	97.55
TM-185	1.20
TM-SB	0.84
TM-205	0.41

Starting Point	Formula
567 C	
TM-215	72.00
TM-180	16.00
TM-SB	10.00
TM-190	2.00

Starting Point	Formula
568 C	
TM-215	78.50
TM-180	14.30
TM-190	3.60
TM-SB	3.60

Starting Point	Formula
569 C	
TM-215	45.20
TM-MX	38.00
TM-190	9.00
TM-180	7.80

Starting Point	Formula
570 C	
TM-TW	77.30
TM-215	10.27
TM-MX	8.61
TM-190	2.05
TM-180	1.77

Starting Point	Formula
571 C	
TM-TW	88.70
TM-215	5.14
TM-MX	4.24
TM-190	1.03
TM-180	0.89

Starting Point	Formula
572 C	
TM-TW	94.20
TM-215	3.47
TM-MX	1.60
TM-190	0.39
TM-180	0.34

Starting Point	Formula
573 C	
TM-TW	97.00
TM-215	2.08
TM-MX	0.64
TM-190	0.15
TM-180	0.13

Starting Point	Formula
574 C	
TM-MX	48.00
TM-185	26.00
TM-SB	14.40
TM-205	11.60

Starting Point	Formula
575 C	
TM-185	41.32
TM-MX	32.11
TM-205	18.37
TM-SB	8.20

Starting Point	Formula
576 C	
TM-185	45.00
TM-MX	35.00
TM-205	20.00

Techmark TM

Starting Point	Formula
577 C	
TM-TW 77.00	
TM-185 11.82	
TM-MX 7.13	
TM-205 4.05	

Starting Point	Formula
578 C	
TM-TW 77.00	
TM-185 5.91	
TM-MX 3.56	
TM-205 2.03	

Starting Point	Formula
579 C	
TM-TW 93.30	
TM-185 3.45	
TM-MX 2.07	
TM-205 1.18	

Starting Point	Formula
580 C	
TM-TW 95.00	
TM-185 2.70	
TM-MX 1.48	
TM-205 0.82	

Starting Point	Formula
5743 C	
TM-185 45.50	
TM-SB 45.50	
TM-205 9.00	

Starting Point	Formula
5753 C	
TM-185 57.00	
TM-SB 20.70	
TM-TW 18.20	
TM-205 4.10	

Starting Point	Formula
5763 C	
TM-TW 46.00	
TM-185 34.00	
TM-SB 16.70	
TM-215 3.30	

Starting Point	Formula
5773 C	
TM-TW 74.50	
TM-185 14.50	
TM-SB 8.80	
TM-215 2.20	

Starting Point	Formula
5783 C	
TM-TW 86.80	
TM-185 7.30	
TM-SB 4.60	
TM-215 1.30	

Starting Point	Formula
5793 C	
TM-TW 93.28	
TM-185 3.78	
TM-SB 2.29	
TM-215 0.65	

Starting Point	Formula
5803 C	
TM-TW 96.08	
TM-185 2.28	
TM-SB 1.23	
TM-215 0.41	

Starting Point	Formula
5747 C	
TM-185 50.00	
TM-SB 37.50	
TM-215 12.50	

Starting Point	Formula
5757 C	
TM-185 54.20	
TM-TW 25.00	
TM-SB 15.60	
TM-215 5.20	

Starting Point	Formula
5767 C	
TM-TW 59.10	
TM-185 29.60	
TM-SB 8.50	
TM-215 2.80	

Starting Point	Formula
5777 C	
TM-TW 82.00	
TM-185 11.70	
TM-SB 4.90	
TM-215 1.40	

Starting Point	Formula
5787 C	
TM-TW 93.52	
TM-185 3.94	
TM-SB 2.07	
TM-215 0.47	

Techmark TM

Starting Point	Formula
5797 C	
TM-TW 94.90	
TM-185 3.10	
TM-SB 1.60	
TM-215 0.40	

Starting Point	Formula
5807 C	
TM-TW 97.18	
TM-185 1.77	
TM-SB 0.88	
TM-215 0.17	

Starting Point	Formula
581 C	
TM-185 35.78	
TM-MX 35.69	
TM-SB 25.00	
TM-205 3.53	

Starting Point	Formula
582 C	
TM-185 44.12	
TM-MX 44.03	
TM-SB 7.50	
TM-205 4.35	

Starting Point	Formula
583 C	
TM-185 47.70	
TM-MX 47.60	
TM-205 4.70	

Starting Point	Formula
584 C	
TM-TW 84.00	
TM-185 14.90	
TM-205 1.10	

Starting Point	Formula
585 C	
TM-TW 79.90	
TM-185 11.15	
TM-MX 8.15	
TM-205 0.80	

Starting Point	Formula
586 C	
TM-TW 85.90	
TM-185 7.81	
TM-MX 5.73	
TM-205 0.56	

Starting Point	Formula
587 C	
TM-TW 91.50	
TM-185 4.69	
TM-MX 3.47	
TM-205 0.34	

Starting Point	Formula
5815 C	
TM-185 59.10	
TM-SB 40.90	

Starting Point	Formula
5825 C	
TM-185 59.20	
TM-TW 21.30	
TM-SB 19.50	

Starting Point	Formula
5835 C	
TM-TW 68.50	
TM-185 23.70	
TM-SB 7.80	

Starting Point	Formula
5845 C	
TM-TW 79.00	
TM-185 15.80	
TM-SB 5.20	

Starting Point	Formula
5855 C	
TM-TW 92.70	
TM-185 5.00	
TM-SB 2.30	

Starting Point	Formula
5865 C	
TM-TW 96.00	
TM-185 2.80	
TM-SB 1.20	

Starting Point	Formula
5875 C	
TM-TW 97.50	
TM-185 1.75	
TM-SB 0.75	

Techmark TM

Starting Point	Formula
600 C	
TM-TW	89.92
TM-100	5.36
TM-185	4.71

Starting Point	Formula
601 C	
TM-TW	90.58
TM-110	9.24
TM-215	0.18

Starting Point	Formula
602 C	
TM-TW	86.86
TM0110	12.86
TM-215	0.28

Starting Point	Formula
603 C	
TM-TW	72.88
TM-110	26.59
TM-215	0.53

Starting Point	Formula
604 C	
TM-TW	54.55
TM-110	44.66
TM-215	0.79

Starting Point	Formula
605 C	
TM-110	66.66
TM-120	16.16
TM-TW	15.35
TM-215	1.83

Starting Point	Formula
606 C	
TM-120	85.40
TM-TW	11.26
TM-215	3.34

Starting Point	Formula
607 C	
TM-TW	94.36
TM-100	3.68
TM-120	1.76
TM-205	0.20

Starting Point	Formula
608 C	
TM-TW	92.71
TM-110	6.14
TM-120	0.87
TM-205	0.27

Starting Point	Formula
609 C	
TM-TW	87.71
TM-110	10.68
TM-120	1.18
TM-205	0.44

Starting Point	Formula
610 C	
TM-TW	69.64
TM-100	23.33
TM-120	6.29
TM-205	0.74

Starting Point	Formula
611 C	
TM-100	44.38
TM-TW	43.87
TM-120	10.56
TM-205	1.20

Starting Point	Formula
612 C	
TM-100	58.75
TM-120	31.53
TM-MX	7.02
TM-205	2.70

Starting Point	Formula
613 C	
TM-120	74.03
TM-100	21.00
TM-205	4.97

Starting Point	Formula
614 C	
TM-TW	93.56
TM-110	4.67
TM-SB	1.77

Starting Point	Formula
615 C	
TM-TW	90.06
TM-110	7.18
TM-SB	2.76

Techmark TM

Starting Point	Formula
616 C	
TM-TW	86.14
TM-110	10.01
TM-SB	3.85

Starting Point	Formula
617 C	
TM-TW	77.34
TM-110	16.83
TM-SB	5.83

Starting Point	Formula
618 C	
TM-MX	44.23
TM-110	23.87
TM-TW	21.57
TM-SB	10.33

Starting Point	Formula
619 C	
TM-110	41.43
TM-MX	29.06
TM-SB	16.96
TM-TW	12.51

Starting Point	Formula
620 C	
TM-110	45.38
TM-SB	28.47
TM-MX	26.15

Starting Point	Formula
621 C	
TM-TW	96.86
TM-SB	1.97
TM-215	0.81
TM-100	0.33

Starting Point	Formula
622 C	
TM-TW	94.35
TM-SB	3.67
TM-215	1.58
TM-110	0.40

Starting Point	Formula
623 C	
TM-MX	50.00
TM-TW	41.66
TM-SB	5.84
TM-215	2.50

Starting Point	Formula
624 C	
TM-MX	50.00
TM-TW	34.28
TM-SB	10.91
TM-215	4.89

Starting Point	Formula
625 C	
TM-SB	44.13
TM-215	29.17
TM-TW	23.21
TM-120	3.48

Starting Point	Formula
626 C	
TM-MX	46.77
TM-SB	36.88
TM-215	15.82
TM-205	0.54

Starting Point	Formula
627 C	
TM-SB	84.56
TM-215	15.44

Starting Point	Formula
628 C	
TM-TW	98.21
TM-215	1.06
TM-205	0.74

Starting Point	Formula
629 C	
TM-TW	97.01
TM-215	1.56
TM-205	1.44

Starting Point	Formula
630 C	
TM-TW	94.17
TM-215	2.98
TM-205	2.86

Starting Point	Formula
631 C	
TM-TW	84.89
TM-190	7.17
TM-215	5.04
TM-210	2.90

Techmark TM

Starting Point	Formula
632 C	
TM-TW	50.48
TM-MX	20.00
TM-190	17.99
TM-215	7.22
TM-210	4.31

Starting Point	Formula
633 C	
TM-190	65.19
TM-MX	20.00
TM-SB	8.59
TM-215	3.69
TM-TW	2.54

Starting Point	Formula
634 C	
TM-190	83.27
TM-SB	15.13
TM-215	1.60

Starting Point	Formula
635 C	
TM-TW	76.05
TM-MX	20.00
TM-190	3.61
TM-SB	0.34

Starting Point	Formula
636 C	
TM-TW	71.93
TM-MX	20.00
TM-190	7.37
TM-SB	0.56
TM-110	0.14

Starting Point	Formula
637 C	
TM-TW	88.28
TM-190	9.90
TM-200	1.28
TM-110	0.55

Starting Point	Formula
638 C	
TM-TW	55.43
TM-190	21.49
TM-MX	20.00
TM-200	2.09
TM-110	0.99

Starting Point	Formula
639 C	
TM-190	58.51
TM-TW	20.05
TM-MX	20.00
TM-110	1.44

Starting Point	Formula
640 C	
TM-190	73.31
TM-MX	20.00
TM-200	4.63
TM-110	2.07

Starting Point	Formula
641 C	
TM-190	55.16
TM-200	21.67
TM-MX	20.00
TM-110	3.17

Starting Point	Formula
642 C	
TM-TW	97.55
TM-190	1.53
TM-295	0.56
TM-100	0.36

Starting Point	Formula
643 C	
TM-TW	96.25
TM-190	2.28
TM-SB	0.85
TM-295	0.62

Starting Point	Formula
644 C	
TM-TW	91.87
TM-SB	4.25
TM-200	2.95
TM-295	0.93

Starting Point	Formula
645 C	
TM-TW	86.87
TM-SB	6.64
TM-200	5.14
TM-295	1.35

Starting Point	Formula
646 C	
TM-TW	77.73
TM-SB	9.95
TM-200	9.69
TM-295	2.63

Starting Point	Formula
647 C	
TM-TW	34.07
TM-200	22.27
TM-MX	20.00
TM-SB	17.31
TM-295	6.35

Techmark TM

Starting Point	Formula
648 C	
TM-SB	28.46
TM-200	26.09
TM-295	25.45
TM-MX	20.00

Starting Point	Formula
649 C	
TM-TW	98.80
TM-205	0.72
TM-155	0.48

Starting Point	Formula
650 C	
TM-TW	97.18
TM-205	1.41
TM-155	1.00
TM-110	0.42

Starting Point	Formula
651 C	
TM-TW	92.53
TM-205	3.51
TM-155	2.55
TM-110	1.41

Starting Point	Formula
652 C	
TM-TW	82.82
TM-205	8.37
TM-155	5.67
TM-110	3.14

Starting Point	Formula
653 C	
TM-TW	43.96
TM-MX	20.00
TM-205	19.21
TM-155	11.56
TM-110	5.28

Starting Point	Formula
654 C	
TM-205	41.51
TM-155	24.90
TM-MX	20.00
TM-110	7.28
TM-TW	6.30

Starting Point	Formula
655 C	
TM-205	46.92
TM-155	33.26
TM-SB	19.82

Starting Point	Formula
656 C	
TM-TW	99.15
TM-205	0.59
TM-295	0.26

Starting Point	Formula
657 C	
TM-TW	98.37
TM-205	1.25
TM-295	0.38

Starting Point	Formula
658 C	
TM-TW	96.82
TM-205	2.45
TM-295	0.73

Starting Point	Formula
659 C	
TM-TW	90.43
TM-205	6.78
TM-295	1.91
TM-110	0.88

Starting Point	Formula
660 C	
TM-TW	57.49
TM-MX	20.00
TM-205	17.87
TM-295	3.31
TM-110	1.42

Starting Point	Formula
661 C	
TM-205	84.60
TM-TW	15.40

Starting Point	Formula
662 C	
TM-210	100.00

Starting Point	Formula
663 C	
TM-TW	99.29
TM-295	0.60
TM-200	0.11

Techmark TM

Starting Point	Formula
664 C	
TM-TW	78.06
TM-MX	20.00
TM-SB	1.01
TM-295	0.93

Starting Point	Formula
665 C	
TM-TW	96.59
TM-150	1.84
TM-200	0.82
TM-295	0.75

Starting Point	Formula
666 C	
TM-TW	90.57
TM-150	5.50
TM-200	2.27
TM-295	1.66

Starting Point	Formula
667 C	
TM-TW	71.52
TM-SB	15.40
TM-295	10.47
TM-150	2.34

Starting Point	Formula
668 C	
TM-TW	64.09
TM-150	16.02
TM-295	14.64
TM-200	5.26

Starting Point	Formula
669 C	
TM-TW	34.14
TM-295	33.71
TM-150	25.86
TM-200	6.28

Starting Point	Formula
670 C	
TM-TW	98.19
TM-155	1.46
TM-295	0.35

Starting Point	Formula
671 C	
TM-TW	96.97
TM-155	2.48
TM-295	0.55

Starting Point	Formula
672 C	
TM-TW	93.42
TM-155	5.74
TM-295	0.84

Starting Point	Formula
673 C	
TM-TW	86.60
TM-155	12.08
TM-295	1.33

Starting Point	Formula
674 C	
TM-TW	50.82
TM-MX	25.00
TM-160	20.27
TM-SB	2.66
TM-150	1.25

Starting Point	Formula
675 C	
TM-160	50.53
TM-MX	25.00
TM-TW	14.66
TM-150	6.26
TM-SB	3.55

Starting Point	Formula
676 C	
TM-155	65.71
TM-MX	25.00
TM-SB	9.29

Starting Point	Formula
677 C	
TM-TW	72.64
TM-MX	25.00
TM-155	1.66
TM-SB	0.47
TM-205	0.23

Starting Point	Formula
678 C	
TM-TW	71.13
TM-MX	25.00
TM-155	2.50
TM-SB	1.37

Starting Point	Formula
679 C	
TM-TW	95.52
TM-155	2.58
TM-SB	1.30
TM-295	0.60

Techmark TM

Starting Point	Formula
680 C	
TM-TW	89.78
TM-155	6.63
TM-SB	2.89
TM-295	0.70

Starting Point	Formula
681 C	
TM-TW	55.87
TM-MX	25.00
TM-155	13.14
TM-SB	4.83
TM-295	1.16

Starting Point	Formula
682 C	
TM-155	35.14
TM-TW	28.64
TM-MX	25.00
TM-SB	9.54
TM-295	1.69

Starting Point	Formula
683 C	
TM-155	46.24
TM-MX	25.00
TM-SB	21.80
TM-TW	4.19
TM-180	2.76

Starting Point	Formula
684 C	
TM-TW	97.05
TM-155	1.92
TM-SB	0.98
TM-180	0.05

Starting Point	Formula
685 C	
TM-TW	94.57
TM-155	3.75
TM-SB	1.68
TM-180	0.01

Starting Point	Formula
686 C	
TM-TW	92.20
TM-160	4.51
TM-SB	2.65
TM-180	0.63

Starting Point	Formula
687 C	
TM-TW	59.09
TM-MX	25.00
TM-160	9.02
TM-SB	5.38
TM-180	1.50

Starting Point	Formula
688 C	
TM-TW	46.83
TM-MX	25.00
TM-160	17.12
TM-SB	8.32
TM-180	2.73

Starting Point	Formula
689 C	
TM-160	31.35
TM-MX	25.00
TM-TW	23.33
TM-SB	14.27
TM-180	5.88

Starting Point	Formula
690 C	
TM-160	38.23
TM-SB	27.95
TM-180	20.26
TM-TW	13.57

Starting Point	Formula
691 C	
TM-TW	96.39
TM-SB	1.79
TM-160	0.93
TM-130	0.88

Starting Point	Formula
692 C	
TM-TW	94.59
TM-SB	2.61
TM-160	1.50
TM-130	1.30

Starting Point	Formula
693 C	
TM-TW	65.56
TM-MX	25.00
TM-SB	4.36
TM-160	2.98
TM-130	2.10

Starting Point	Formula
694 C	
TM-TW	59.33
TM-MX	25.00
TM-SB	6.61
TM-160	5.63
TM-130	3.43

Starting Point	Formula
695 C	
TM-TW	45.15
TM-MX	25.00
TM-160	11.67
TM-SB	11.32
TM-130	6.85

Techmark TM

Starting Point	Formula
696 C	
TM-MX	25.00
TM-TW	22.26
TM-160	20.86
TM-SB	18.97
TM-130	12.91

Starting Point	Formula
697 C	
TM-SB	26.12
TM-MX	25.00
TM-160	24.29
TM-130	17.35
TM-TW	7.24

Starting Point	Formula
698 C	
TM-TW	96.72
TM-155	1.43
TM-130	1.06
TM-SB	0.79

Starting Point	Formula
699 C	
TM-TW	95.24
TM-155	2.73
TM-130	1.28
TM-SB	0.74

Starting Point	Formula
700 C	
TM-TW	90.97
TM-160	4.70
TM-130	3.04
TM-SB	1.29

Starting Point	Formula
701 C	
TM-TW	59.24
TM-MX	25.00
TM-155	10.60
TM-130	3.63
TM-SB	1.53

Starting Point	Formula
702 C	
TM-TW	43.58
TM-MX	25.00
TM-160	18.97
TM-130	9.13
TM-SB	3.33

Starting Point	Formula
703 C	
TM-160	37.28
TM-MX	25.00
TM-130	20.32
TM-TW	9.56
TM-SB	7.85

Starting Point	Formula
704 C	
TM-160	41.24
TM-130	30.94
TM-MX	15.90
TM-SB	11.92

Starting Point	Formula
705 C	
TM-TW	97.92
TM-155	1.71
TM-130	0.36

Starting Point	Formula
706 C	
TM-TW	96.20
TM-155	2.83
TM-130	0.97

Starting Point	Formula
707 C	
TM-TW	67.93
TM-MX	25.00
TM-155	5.23
TM-130	1.84

Starting Point	Formula
708 C	
TM-TW	61.26
TM-MX	25.00
TM-155	10.21
TM-130	3.53

Starting Point	Formula
709 C	
TM-TW	47.87
TM-MX	25.00
TM-160	18.06
TM-130	9.04

Starting Point	Formula
710 C	
TM-160	30.10
TM-TW	27.40
TM-MX	25.00
TM-130	17.01
TM-SB	0.49

Starting Point	Formula
711 C	
TM-160	37.22
TM-130	30.24
TM-MX	25.00
TM-TW	4.98
TM-SB	2.56

Techmark TM

Starting Point	Formula
712 C	
TM-TW	95.07
TM-120	2.94
TM-130	1.81
TM-205	0.18

Starting Point	Formula
713 C	
TM-TW	90.69
TM-120	6.08
TM-130	3.02
TM-205	0.21

Starting Point	Formula
714 C	
TM-TW	82.66
TM-120	12.02
TM-130	5.01
TM-205	0.30

Starting Point	Formula
715 C	
TM-TW	64.85
TM-120	26.11
TM-130	8.58
TM-205	0.46

Starting Point	Formula
716 C	
TM-120	35.98
TM-MX	25.00
TM-TW	22.97
TM-130	13.44
TM-SB	2.61

Starting Point	Formula
717 C	
TM-120	47.83
TM-MX	25.00
TM-130	21.93
TM-SB	5.24

Starting Point	Formula
718 C	
TM-120	42.92
TM-130	25.07
TM-MX	25.00
TM-SB	7.00

Starting Point	Formula
719 C	
TM-TW	95.08
TM-120	2.20
TM-130	1.47
TM-SB	1.25

Starting Point	Formula
720 C	
TM-TW	93.00
TM-120	3.29
TM-130	2.01
TM-SB	1.71

Starting Point	Formula
721 C	
TM-TW	85.97
TM-120	7.16
TM-130	3.62
TM-SB	3.24

Starting Point	Formula
722 C	
TM-TW	68.45
TM-120	17.87
TM-130	7.36
TM-SB	6.32

Starting Point	Formula
723 C	
TM-TW	30.32
TM-MX	25.00
TM-120	23.51
TM-130	11.12
TM-SB	10.05

Starting Point	Formula
724 C	
TM-120	33.90
TM-MX	25.00
TM-SB	20.74
TM-130	20.36

Starting Point	Formula
725 C	
TM-SB	28.08
TM-120	27.33
TM-MX	25.00
TM-130	19.58

Starting Point	Formula
726 C	
TM-TW	94.06
TM-120	2.39
TM-SB	2.26
TM-130	1.28

Starting Point	Formula
727 C	
TM-TW	90.65
TM-120	4.10
TM-SB	3.37
TM-130	1.87

Techmark TM

Starting Point	Formula
728 C	
TM-TW	62.54
TM-MX	25.00
TM-SB	5.16
TM-120	4.46
TM-130	2.84

Starting Point	Formula
729 C	
TM-TW	54.83
TM-MX	25.00
TM-SB	7.90
TM-120	7.68
TM-130	4.59

Starting Point	Formula
730 C	
TM-TW	32.39
TM-MX	25.00
TM-120	18.17
TM-SB	14.90
TM-130	9.54

Starting Point	Formula
731 C	
TM-SB	30.71
TM-MX	25.00
TM-120	22.72
TM-130	16.77
TM-TW	4.81

Starting Point	Formula
732 C	
TM-SB	41.89
TM-MX	25.00
TM-120	18.97
TM-130	14.14

Starting Point	Formula
7401 C	
TM-TW	94.23
TM-185	3.09
TM-100	1.93
TM-155	0.75

Starting Point	Formula
7402 C	
TM-TW	87.15
TM-100	11.24
TM-155	1.36
TM-SB	0.25

Starting Point	Formula
7403 C	
TM-TW	76.66
TM-100	20.55
TM-155	2.17
TM-SB	0.61

Starting Point	Formula
7404 C	
TM-100	60.02
TM-MX	25.00
TM-TW	13.46
TM-155	1.52

Starting Point	Formula
7405 C	
TM-100	80.29
TM-185	17.93
TM-155	1.77

Starting Point	Formula
7406 C	
TM-185	77.36
TM-MX	18.82
TM-155	1.94
TM-SB	1.88

Starting Point	Formula
7407 C	
TM-185	40.55
TM-MX	25.00
TM-TW	24.53
TM-SB	5.33
TM-155	4.59

Starting Point	Formula
7408 C	
TM-100	71.33
TM-MX	25.00
TM-130	3.12
TM-SB	0.56

Starting Point	Formula
7409 C	
TM-100	69.00
TM-MX	25.00
TM-130	4.18
TM-SB	1.82

Starting Point	Formula
7410 C	
TM-TW	83.25
TM-120	9.81
TM-130	6.68
TM-215	0.25

Starting Point	Formula
7411 C	
TM-100	58.05
TM-TW	35.51
TM-140	4.81
TM-SB	1.63

Techmark TM

Starting Point	Formula
7412 C	
TM-120	28.00
TM-TW	26.92
TM-MX	25.00
TM-130	12.54
TM-SB	7.54

Starting Point	Formula
7413 C	
TM-100	66.41
TM-MX	25.00
TM-140	7.83
TM-215	0.76

Starting Point	Formula
7414 C	
TM-120	35.42
TM-MX	25.00
TM-130	15.25
TM-TW	13.88
TM-SB	10.46

Starting Point	Formula
7415 C	
TM-TW	82.77
TM-100	10.71
TM-160	6.14
TM-215	0.39

Starting Point	Formula
7416 C	
TM-100	43.92
TM-TW	41.52
TM-140	14.49
TM-SB	0.07

Starting Point	Formula
7417 C	
TM-100	46.31
TM-MX	18.67
TM-140	18.49
TM-TW	16.53

Starting Point	Formula
7418 C	
TM-180	31.35
TM-TW	30.68
TM-MX	25.00
TM-SB	6.62
TM-160	6.35

Starting Point	Formula
7419 C	
TM-180	33.15
TM-MX	25.00
TM-TW	24.57
TM-160	9.83
TM-190	7.46

Starting Point	Formula
7420 C	
TM-160	58.69
TM-130	28.40
TM-SB	12.92

Starting Point	Formula
7421 C	
TM-155	51.70
TM-SB	31.83
TM-130	16.47

Starting Point	Formula
7422 C	
TM-TW	98.09
TM-160	1.22
TM-130	0.69

Starting Point	Formula
7423 C	
TM-TW	48.05
TM-MX	25.00
TM-160	20.85
TM-130	6.09

Starting Point	Formula
7424 C	
TM-160	36.08
TM-TW	28.59
TM-MX	25.00
TM-180	10.33

Starting Point	Formula
7425 C	
TM-160	37.09
TM-MX	25.00
TM-180	18.21
TM-TW	15.07
TM-SB	4.63

Starting Point	Formula
7426 C	
TM-160	53.71
TM-MX	25.00
TM-130	19.04
TM-215	2.26

Starting Point	Formula
7427 C	
TM-155	44.80
TM-130	29.40
TM-TW	15.01
TM-SB	10.80

Techmark TM

Starting Point	Formula
7428 C	
TM-155	39.34
TM-SB	26.20
TM-MX	25.00
TM-100	9.46

Starting Point	Formula
7429 C	
TM-TW	98.09
TM-140	1.54
TM-205	0.37

Starting Point	Formula
7430 C	
TM-TW	96.27
TM-140	3.03
TM-205	0.70

Starting Point	Formula
7431 C	
TM-TW	92.81
TM-140	5.96
TM-205	1.24

Starting Point	Formula
7432 C	
TM-TW	56.68
TM-160	30.19
TM-100	11.41
TM-205	1.71

Starting Point	Formula
7433 C	
TM-160	44.05
TM-MX	25.00
TM-100	14.79
TM-TW	14.23
TM-205	1.93

Starting Point	Formula
7434 C	
TM-160	69.78
TM-100	21.45
TM-SB	69.78

Starting Point	Formula
7435 C	
TM-155	56.90
TM-MX	25.00
TM-SB	15.36
TM-100	2.74

Starting Point	Formula
7436 C	
TM-TW	99.03
TM-295	0.66
TM-155	0.31

Starting Point	Formula
7437 C	
TM-TW	95.09
TM-SB	2.16
TM-160	1.45
TM-295	1.30

Starting Point	Formula
7438 C	
TM-TW	92.61
TM-160	4.87
TM-295	2.52

Starting Point	Formula
7439 C	
TM-TW	86.80
TM-160	8.53
TM-SB	3.61
TM-200	1.06

Starting Point	Formula
7440 C	
TM-TW	81.54
TM-155	13.33
TM-SB	2.87
TM-200	2.26

Starting Point	Formula
7441 C	
TM-TW	59.19
TM-MX	25.00
TM-295	10.29
TM-160	5.52

Starting Point	Formula
7442 C	
TM-160	37.40
TM-TW	29.56
TM-MX	25.00
TM-205	8.04

Starting Point	Formula
7443 C	
TM-TW	98.37
TM-160	1.10
TM-200	0.53

Techmark TM

Starting Point	Formula
7444 C	
TM-TW 95.16	
TM-160 2.93	
TM-200 1.45	
TM-SB 0.46	

Starting Point	Formula
7445 C	
TM-TW 92.34	
TM-SB 4.39	
TM-295 2.47	
TM-200 0.80	

Starting Point	Formula
7446 C	
TM-TW 84.68	
TM-160 10.37	
TM-200 4.59	

Starting Point	Formula
7447 C	
TM-TW 43.59	
TM-160 28.61	
TM-SB 20.25	
TM-205 7.56	

Starting Point	Formula
7448 C	
TM-SB 51.26	
TM-TW 24.27	
TM-160 23.49	
TM-200 0.62	

Starting Point	Formula
7449 C	
TM-SB 59.79	
TM-MX 25.00	
TM-140 10.11	
TM-160 5.10	

Starting Point	Formula
7450 C	
TM-TW 97.76	
TM-205 1.50	
TM-140 0.74	

Starting Point	Formula
7451 C	
TM-TW 94.97	
TM-200 3.02	
TM-295 1.79	
TM-140 0.21	

Starting Point	Formula
7452 C	
TM-TW 92.00	
TM-295 4.29	
TM-200 3.71	

Starting Point	Formula
7453 C	
TM-TW 90.26	
TM-200 4.89	
TM-160 3.90	
TM-SB 0.95	

Starting Point	Formula
7454 C	
TM-TW 57.71	
TM-MX 25.00	
TM-200 7.47	
TM-160 5.50	
TM-185 4.32	

Starting Point	Formula
7455 C	
TM-TW 58.50	
TM-160 22.34	
TM-200 19.16	

Starting Point	Formula
7456 C	
TM-TW 83.52	
TM-295 7.51	
TM-200 5.48	
TM-185 3.48	

Starting Point	Formula
7457 C	
TM-TW 99.03	
TM-200 0.92	
TM-295 0.05	

Starting Point	Formula
7458 C	
TM-TW 86.40	
TM-190 8.41	
TM-SB 3.65	
TM-205 1.54	

Starting Point	Formula
7459 C	
TM-TW 68.15	
TM-190 22.28	
TM-SB 7.68	
TM-205 1.87	

Techmark TM

Starting Point	Formula
7460 C	
TM-190	71.81
TM-MX	25.00
TM-215	3.10
TM-210	0.09

Starting Point	Formula
7461 C	
TM-190	52.90
TM-TW	41.10
TM-SB	4.21
TM-295	1.79

Starting Point	Formula
7462 C	
TM-200	31.78
TM-MX	25.00
TM-TW	21.54
TM-160	12.91
TM-185	8.68

Starting Point	Formula
7463 C	
TM-SB	38.83
TM-MX	25.00
TM-205	20.90
TM-160	15.27

Starting Point	Formula
7464 C	
TM-TW	93.62
TM-190	4.19
TM-185	2.06
TM-295	0.13

Starting Point	Formula
7465 C	
TM-TW	63.94
TM-MX	25.00
TM-215	6.12
TM-200	2.83
TM-185	2.11

Starting Point	Formula
7466 C	
TM-TW	39.95
TM-190	25.84
TM-MX	25.00
TM-215	9.20

Starting Point	Formula
7467 C	
TM-190	33.28
TM-TW	30.41
TM-MX	25.00
TM-215	11.31

Starting Point	Formula
7468 C	
TM-190	53.71
TM-TW	32.86
TM-SB	12.87
TM-295	0.55

Starting Point	Formula
7469 C	
TM-190	71.96
TM-SB	17.01
TM-TW	9.27
TM-295	9.27

Starting Point	Formula
7470 C	
TM-TW	25.87
TM-MX	25.00
TM-200	23.29
TM-185	19.00
TM-160	6.84

Starting Point	Formula
7471 C	
TM-TW	93.41
TM-190	3.37
TM-215	3.21

Starting Point	Formula
7472 C	
TM-TW	54.91
TM-MX	25.00
TM-190	13.38
TM-185	4.94
TM-SB	1.78

Starting Point	Formula
7473 C	
TM-TW	34.72
TM-MX	25.00
TM-190	23.95
TM-185	12.24
TM-SB	4.09

Starting Point	Formula
7474 C	
TM-190	36.38
TM-MX	25.00
TM-TW	17.41
TM-SB	12.67
TM-215	8.54

Starting Point	Formula
7475 C	
TM-TW	36.56
TM-MX	25.00
TM-SB	16.75
TM-190	16.73
TM-185	4.97

Techmark TM

Starting Point	Formula
7476 C	
TM-SB	37.88
TM-190	29.13
TM-MX	25.00
TM-215	4.25
TM-TW	3.75

Starting Point	Formula
7477 C	
TM-SB	44.50
TM-190	35.32
TM-TW	18.72
TM-160	1.47

Starting Point	Formula
7478 C	
TM-TW	94.03
TM-215	4.21
TM-185	1.77

Starting Point	Formula
7479 C	
TM-TW	72.21
TM-215	14.45
TM-100	13.34

Starting Point	Formula
7480 C	
TM-TW	39.79
TM-215	25.04
TM-MX	22.81
TM-100	12.36

Starting Point	Formula
7481 C	
TM-215	30.39
TM-100	30.23
TM-MX	22.23
TM-TW	17.16

Starting Point	Formula
7482 C	
TM-220	37.00
TM-MX	25.00
TM-TW	20.56
TM-185	17.44

Starting Point	Formula
7483 C	
TM-SB	35.85
TM-215	22.81
TM-185	21.90
TM-MX	19.44

Starting Point	Formula
7484 C	
TM-TW	96.34
TM-185	2.26
TM-220	1.03
TM-160	0.38

Starting Point	Formula
7485 C	
TM-TW	85.03
TM-100	9.01
TM-185	3.07
TM-190	2.89

Starting Point	Formula
7486 C	
TM-TW	85.08
TM-100	9.30
TM-190	2.86
TM-185	2.77

Starting Point	Formula
7487 C	
TM-TW	63.86
TM-100	26.70
TM-215	6.14
TM-185	3.29

Starting Point	Formula
7488 C	
TM-100	59.58
TM-TW	24.96
TM-215	10.92
TM-MX	4.54

Starting Point	Formula
7489 C	
TM-185	38.36
TM-MX	25.00
TM-TW	19.58
TM-220	14.49
TM-160	2.57

Starting Point	Formula
7490 C	
TM-100	86.43
TM-200	7.30
TM-160	4.85
TM-TW	1.42

Starting Point	Formula
7491 C	
TM-185	61.55
TM-TW	19.31
TM-215	14.06
TM-140	5.08

Techmark TM

Starting Point	Formula
7492 C	
TM-TW	81.26
TM-100	16.64
TM-205	1.48
TM-130	0.62

Starting Point	Formula
7493 C	
TM-TW	61.55
TM-MX	25.00
TM-100	8.85
TM-SB	4.06
TM-205	0.55

Starting Point	Formula
7494 C	
TM-TW	79.27
TM-SB	9.33
TM-100	9.29
TM-220	2.12

Starting Point	Formula
7495 C	
TM-100	55.67
TM-MX	25.00
TM-SB	13.20
TM-TW	4.02
TM-205	2.12

Starting Point	Formula
7496 C	
TM-185	45.57
TM-MX	25.00
TM-220	17.82
TM-130	6.46
TM-TW	5.16

Starting Point	Formula
7497 C	
TM-SB	31.61
TM-MX	25.00
TM-TW	24.69
TM-100	16.61
TM-130	2.10

Starting Point	Formula
7498 C	
TM-SB	51.72
TM-100	44.75
TM-MX	2.31
TM-205	1.23

Starting Point	Formula
7499 C	
TM-TW	96.86
TM-100	2.73
TM-130	0.38
TM-200	0.03

Starting Point	Formula
7500 C	
TM-TW	94.57
TM-100	4.09
TM-130	0.98
TM-200	0.36

Starting Point	Formula
7501 C	
TM-TW	91.71
TM-185	5.30
TM-SB	2.44
TM-130	0.55

Starting Point	Formula
7502 C	
TM-TW	82.68
TM-185	11.64
TM-SB	4.64
TM-130	1.04

Starting Point	Formula
7503 C	
TM-TW	54.30
TM-100	35.06
TM-160	8.17
TM-200	2.46

Starting Point	Formula
7504 C	
TM-185	38.31
TM-TW	33.13
TM-155	19.35
TM-220	9.21

Starting Point	Formula
7505 C	
TM-SB	28.73
TM-MX	25.00
TM-185	23.01
TM-TW	15.49
TM-130	7.77

Starting Point	Formula
7506 C	
TM-TW	68.42
TM-MX	25.00
TM-100	4.53
TM-160	1.41
TM-185	0.64

Starting Point	Formula
7507 C	
TM-TW	90.79
TM-185	7.63
TM-130	1.58

Techmark TM

Starting Point	Formula
7508 C	
TM-TW	81.29
TM-185	14.06
TM-SB	2.70
TM-130	1.95

Starting Point	Formula
7509 C	
TM-TW	47.53
TM-MX	25.00
TM-185	20.05
TM-SB	4.30
TM-130	3.12

Starting Point	Formula
7510 C	
TM-185	36.24
TM-TW	25.80
TM-MX	25.00
TM-SB	7.49
TM-130	5.46

Starting Point	Formula
7511 C	
TM-185	49.46
TM-MX	25.00
TM-SB	11.76
TM-130	9.53
TM-TW	4.25

Starting Point	Formula
7512 C	
TM-120	52.79
TM-TW	16.91
TM-SB	16.78
TM-130	13.53

Starting Point	Formula
7513 C	
TM-TW	95.04
TM-130	2.55
TM-SB	2.03
TM-120	0.38

Starting Point	Formula
7514 C	
TM-TW	87.21
TM-120	4.74
TM-SB	4.20
TM-180	3.84

Starting Point	Formula
7515 C	
TM-TW	78.76
TM-120	8.42
TM-SB	6.46
TM-180	6.36

Starting Point	Formula
7516 C	
TM-MX	25.00
TM-TW	22.03
TM-120	21.40
TM-SB	16.44
TM-180	15.12

Starting Point	Formula
7517 C	
TM-SB	30.84
TM-120	27.59
TM-130	24.27
TM-TW	17.30

Starting Point	Formula
7518 C	
TM-SB	41.75
TM-TW	31.61
TM-180	15.52
TM-100	11.13

Starting Point	Formula
7519 C	
TM-SB	48.51
TM-TW	23.20
TM-100	17.61
TM-180	10.85

Starting Point	Formula
7520 C	
TM-TW	95.06
TM-180	2.13
TM-185	1.50
TM-SB	1.31

Starting Point	Formula
7521 C	
TM-TW	81.01
TM-100	11.59
TM-160	6.18
TM-205	1.22

Starting Point	Formula
7522 C	
TM-100	38.37
TM-TW	36.33
TM-160	21.80
TM-190	3.50

Starting Point	Formula
7523 C	
TM-TW	60.63
TM-180	19.02
TM-SB	13.08
TM-100	7.26

Techmark TM

Starting Point	Formula
7524 C	
TM-TW 48.36	
TM-180 24.37	
TM-SB 13.92	
TM-100 13.35	

Starting Point	Formula
7525 C	
TM-100 51.65	
TM-TW 22.77	
TM-160 21.66	
TM-205 3.92	

Starting Point	Formula
7526 C	
TM-130 40.10	
TM-MX 25.00	
TM-SB 24.12	
TM-100 10.79	

Starting Point	Formula
7527 C	
TM-TW 95.20	
TM-SB 3.02	
TM-185 1.57	
TM-155 0.20	

Starting Point	Formula
7528 C	
TM-TW 93.18	
TM-SB 4.83	
TM-185 1.42	
TM-180 0.57	

Starting Point	Formula
7529 C	
TM-TW 88.77	
TM-SB 8.65	
TM-120 1.56	
TM-180 1.02	

Starting Point	Formula
7530 C	
TM-TW 78.15	
TM-SB 15.97	
TM-120 3.92	
TM-180 2.13	

Starting Point	Formula
7531 C	
TM-TW 54.71	
TM-SB 30.79	
TM-120 9.47	
TM-180 5.03	

Starting Point	Formula
7532 C	
TM-SB 48.10	
TM-MX 25.00	
TM-TW 12.08	
TM-120 8.37	
TM-180 6.45	

Starting Point	Formula
7533 C	
TM-SB 75.72	
TM-180 10.90	
TM-120 8.81	
TM-MX 4.57	

Starting Point	Formula
7534 C	
TM-TW 95.08	
TM-SB 3.22	
TM-185 1.47	
TM-160 0.23	

Starting Point	Formula
7535 C	
TM-TW 88.16	
TM-SB 6.99	
TM-185 4.47	
TM-160 0.38	

Starting Point	Formula
7536 C	
TM-TW 79.77	
TM-SB 11.44	
TM-185 8.28	
TM-160 0.52	

Starting Point	Formula
7537 C	
TM-TW 89.10	
TM-SB 8.45	
TM-185 2.00	
TM-215 0.45	

Starting Point	Formula
7538 C	
TM-TW 84.32	
TM-SB 12.46	
TM-185 2.48	
TM-215 0.74	

Starting Point	Formula
7539 C	
TM-TW 79.11	
TM-SB 18.13	
TM-185 2.52	
TM-220 0.23	

Techmark TM

Starting Point	Formula
7540 C	
TM-TW	52.75
TM-SB	39.62
TM-160	4.32
TM-220	3.31

Starting Point	Formula
7541 C	
TM-TW	98.60
TM-190	0.89
TM-160	0.51

Starting Point	Formula
7542 C	
TM-TW	65.05
TM-MX	25.00
TM-190	4.65
TM-185	3.01
TM-160	2.30

Starting Point	Formula
7543 C	
TM-TW	91.15
TM-SB	7.30
TM-200	0.95
TM-160	0.60

Starting Point	Formula
7544 C	
TM-TW	79.90
TM-SB	17.06
TM-200	1.93
TM-160	1.11

Starting Point	Formula
7545 C	
TM-TW	54.20
TM-SB	38.92
TM-205	5.95
TM-160	0.92

Starting Point	Formula
7546 C	
TM-SB	48.06
TM-MX	25.00
TM-TW	14.37
TM-200	7.12
TM-160	5.45

Starting Point	Formula
7547 C	
TM-SB	81.05
TM-160	11.46
TM-MX	7.19
TM-190	0.31