



Pelco-D Protocol Specification

for SX800, SX801

Nov.09.2022

Version 2.12.0

FUJIFILM

Change history

Ver.	Date			Revision
2.5	2019/7/19			First version
2.51	2010/1/31			Add SX801as the applicable model, Add 5.7.15 Download Firmware
2.80	2020/12/11			<p>SX800, 801 FW Ver.1.40 supported</p> <ul style="list-style-type: none"> - 5.5.1 Set VLC Filter: Add 4th Filter (for the specific user) to the VLC FL argument. - 5.2.11 Query Zoom Position: Add a command that returns the zoom position (0x5D: Query Zoom Position Response). - 5.6.11 Set Antialiasing: Adds a command to control ON/OFF of antialiasing on the OSD. - 5.6.15 Query Display Setting: Add to get the antialiasing ON/OFF status of the OSD (0x53 Query Display Setting Response) - 5.6.15 Query Display Setting: Add to get the display ON/OFF status for zoom bar and AF frame (0x55 Query Display Setting Response) - Appendix 1,2: Tables for Zoom control data vs. focal length and Focus control data vs. subject distance are attached
1.6	March 4, 2022			<p>Unified specification version with corresponding firmware version.</p> <ul style="list-style-type: none"> - 5.4.6 Set Auto Day/Night Control Mode: Added command comments. - 5.4.7 Set Manual Day/Night: Added command comments. - 5.5.1 Set VLC Filter: Added command comments. - 5.12 Added Original Command 9 (In-House Custom Parameter No. 9, "DayNight Setting Ex").
2.00	March 11, 2022			<ul style="list-style-type: none"> - 5.2.1 Set Zoom Speed: Added description of new command and parameters for backward compatibility. - 5.2.2 Set Focus Speed: Added description of new command and parameters for backward compatibility. - 5.3.11 Set Manual Shutter Speed: Added descriptions of shutter speed items. - 5.3.12 Query Manual Shutter Speed: Added descriptions of shutter speed items. - 5.5.11 Set Select White Balance: Added arguments. - 5.11 Added Original Command 8 (In-House Custom Parameter No. 8, "Image Quality Parameter Fine"). - 5.13 Added Original Command 10 (In-House Custom Parameter No. 10, "Zoom Focus Setting Ex").
2.00.4	April 27, 2022			Clerical error correction
2.12.0	Nov 10 2022			Arguments addition (0x02 : Crop) for Set Digital Zoom (F0 37). Change response value (0~1 → 0~2) when Query ImageQuality Setting F0 3D/3F) is set to 0x37.

Table of contents

1	SUMMARY	11
2	OVERVIEW	11
3	OVERVIEW ABOUT PELCO-D	11
3.1	SEND COMMAND FORMAT.....	12
3.2	RECEIVE COMMAND FORMAT	13
3.2.1	Receive command (General Response)	13
3.2.2	Receive command (Extended Response).....	13
3.2.3	Receive command (Query Response)	14
3.2.4	Receive command (Extended Response2)	15
4	FUNCTIONAL SPECIFICATIONS	16
5	COMMAND DETAILS	17
5.1	STANDARD COMMAND	17
5.1.1	Send command.....	17
5.1.2	Receive command	18
5.2	EXTENDED COMMAND	19
5.2.1	Set Zoom Speed.....	19
5.2.2	Set Focus Speed	21
5.2.3	Auto focus on/off.....	23
5.2.4	Auto Iris on/off.....	25
5.2.5	AGC auto/on/off	27
5.2.6	Backlight compensation on/off	29

5.2.7	<Reserved>	30
5.2.8	Set Zoom Position	31
5.2.9	Set Remote Baud Rate	33
5.2.10	Time Set Opcode	35
5.2.11	Query Zoom Position (Standard)	38
5.3	FF EXTENDED COMMAND (ORIGINAL COMMANDS OF THIS SPECIFICATION)	39
5.3.1	Query Focus Position	40
5.3.2	Query Zoom Position	41
5.3.3	<Reserved>	42
5.3.4	<Reserved>	42
5.3.5	Query Serial Number	42
5.3.6	Query Few Version	43
5.3.7	Query Lens Status	44
5.3.8	Set Focus Position	46
5.3.9	Set Manual Iris	48
5.3.10	Set Shutter Limit on Auto	50
5.3.11	Set Manual Shutter Speed	52
5.3.12	Query Manual Shutter Speed	55
5.3.13	Set Manual ISO	58
5.3.14	Query Manual ISO	60
5.3.15	Query Manual Iris	62
5.3.16	<Reserved>	63
5.3.17	<Reserved>	63
5.3.18	<Reserved>	63
5.3.19	<Reserved>	63

5.3.20	<Reserved>	63
5.3.21	<Reserved>	63
5.3.22	<Reserved>	63
5.3.23	Query Manual Setting (Query Manual Setting Response)	64
5.4	ORIGINAL COMMAND1 (ORIGINAL COMMANDS OF THIS SPECIFICATION: No.1: PHOTO SETTING)	66
5.4.1	Set AF Area	67
5.4.2	Set AF Sensitivity	69
5.4.3	One-push AF	70
5.4.4	<Reserved>	70
5.4.5	<Reserved>	70
5.4.6	Set Auto Day/Night Control Mode	71
5.4.7	Set Manual Day/Night	72
5.4.8	Set Infrared WaveLength	73
5.4.9	Set OIS Mode	74
5.4.10	<Reserved>	74
5.4.11	Set Photo Mode Preset	75
5.4.12	Set DayNight Control by External	76
5.4.13	<Reserved>	76
5.4.14	Query Photo Setting (Query Photo Setting Response)	77
5.5	ORIGINAL COMMAND2 ((ORIGINAL COMMANDS OF THIS SPECIFICATION: No.2: IMAGE QUALITY PARAMETER)	79
5.5.1	Set VLC Filter	80
5.5.2	Set WideDynamicRange	81
5.5.3	<Reserved>	81
5.5.4	Set DeHeatHaze Mode	82
5.5.5	Set Defogging Mode	83

5.5.6	Set Brightness Level	84
5.5.7	Set Contrast Level	86
5.5.8	Set ColorSaturation Level	87
5.5.9	Set Sharpness Level.....	88
5.5.10	Set ColorTemperature on WhiteBalance.....	89
5.5.11	Set Select WhiteBalance	90
5.5.12	Set Digital Zoom	91
5.5.13	Set NR Level.....	92
5.5.14	<Reserved>	93
5.5.15	Query ImageQuality Setting (Query ImageQuality Setting Response)	93
5.6	ORIGINAL COMMAND2 (ORIGINAL COMMANDS OF THIS SPECIFICATION: No.2: IMAGEQUALITY PARAMETER)	95
5.6.1	<Reserved>	96
5.6.2	Set DayTime Display	96
5.6.3	Set DisplayPosition of DayTime.....	97
5.6.4	Set Title Display.....	98
5.6.5	<Reserved>	98
5.6.6	Set DisplayPosition of Title	99
5.6.7	Set ID Display	100
5.6.8	Set DisplayPosition of ID	101
5.6.9	Set Center Position Display	102
5.6.10	<Reserved>	102
5.6.11	SetAntialiasing	103
5.6.12	<Reserved>	103
5.6.13	<Reserved>	103
5.6.14	<Reserved>	103

5.6.15	Query Display Setting (Query Display Setting Response)	104
5.7	ORIGINAL COMMAND 4 (ORIGINAL COMMANDS OF THIS SPECIFICATION: No...4: OPERATION SETTING).....	106
5.7.1	Set Display Mode of time	107
5.7.2	Set DisplayMode of YMD	108
5.7.3	<Reserved>	109
5.7.4	Set Video Mode	109
5.7.5	Set HD Format.....	110
5.7.6	Set VideoDisplay Mode.....	111
5.7.7	<Reserved>	111
5.7.8	Set RS485 ID	112
5.7.9	<Reserved>	112
5.7.10	Set Termination for RS485.....	113
5.7.11	<Reserved>	113
5.7.12	Set RecordingMode on Scared	114
5.7.13	SetDisplay Scared Capacity Remaining.....	115
5.7.14	Format SDcard	116
5.7.15	Download Firmware	117
5.7.16	Recode LogData on SDcard	118
5.7.17	Preset parameters	119
5.7.18	Reboot.....	120
5.7.19	Set Language	121
5.7.20	<Reserved>	122
5.7.21	<Reserved>	122
5.7.22	<Reserved>	122
5.7.23	Query Operation Setting (Query Operation Setting Response)	122

5.8	ORIGINAL COMMAND 5 (ORIGINAL COMMANDS OF THIS SPECIFICATION: No...5: SET KEY)	125
5.8.1	SetEncodeMode	126
5.8.2	Record LiveView on SDcard	127
5.8.3	Set 1st file of playing Movie	128
5.8.4	Play Movie from SDcard	129
5.8.5	Delete Movie from SDcard	130
5.8.6	Select Movie mode Play mode.....	131
5.8.7	<Reserved>	132
5.8.8	<Reserved>	132
5.8.9	<Reserved>	132
5.8.10	<Reserved>	132
5.8.11	<Reserved>	132
5.8.12	Set SDI ON MENU OK	133
5.8.13	Set Direction	134
5.8.14	Set Back CMD	135
5.8.15	Query Key Setting (Query Key Setting Response)	136
5.9	ORIGINAL COMMAND 6 (ORIGINAL COMMANDS OF THIS SPECIFICATION : No. 6 : QUERY SDCARD)	138
5.9.1	Query Number of Movies on SDcard (Query Number of Movies on SDcard Response)	139
5.9.2	Query Year of Movie on SDcard (Query Year of Movie on SDcard Response)	140
5.9.3	Query MonthDay of Movie on SDcard (Query MonthDay of Movie on SDcard Response)	141
5.9.4	Query HourMinute of Movie on SDcard (Query HourMinute of Movie on SDcard Response)	142
5.10	ORIGINAL COMMAND7 (RESERVED)	143
5.11	ORIGINAL COMMAND 8 (IN-HOUSE CUSTOM PARAMETER NO. 8: IMAGEQUALITY PARAMETER FINE)	145
5.11.1	<Reserved>	146
5.11.2	<Reserved>	147

5.11.3	<Reserved>	148
5.11.4	<Reserved>	149
5.11.5	<Reserved>	150
5.11.6	Set Brightness Level Fine	151
5.11.7	Set Contrast Level Fine	152
5.11.8	Set ColorSaturation Level Fine	153
5.11.9	Set Sharpness Level Fine	154
5.11.10	<Reserved>	155
5.11.11	Set WhiteBalance Shift Red Fine	156
5.11.12	Set WhiteBalance Shift Blue Fine	157
5.11.13	<Reserved>	158
5.11.14	<Reserved>	159
5.11.15	Query ImageQuality Setting Fine (Query ImageQuality Setting Response Fine)	160
5.12	ORIGINAL COMMAND 9 (IN-HOUSE CUSTOM PARAMETER No. 9: DAYNIGHT SETTING Ex)	162
5.12.1	Set DayNight Mode	163
5.12.2	Set Day to Night Threshold	164
5.12.3	Set Night to Day Threshold	165
5.12.4	Set DayNight Auto Delay	166
5.12.5	Set Day Start Time	167
5.12.6	Set Night Start Time	168
5.12.7	Set Optical Filter Day	169
5.12.8	Set Optical Filter Night	170
5.12.9	<Reserved>	171
5.12.10	Query DayNight Setting Ex (Query DayNight Setting Ex Response)	172
5.13	ORIGINAL COMMAND 10 (IN-HOUSE CUSTOM PARAMETER No. 10: ZOOM FOCUS SETTING Ex)	174

5.13.1	Set Zoom Speed Ex.....	175
5.13.2	Set Focus Speed Ex	176
5.13.3	Set Digital Zoom Ex	177
5.13.4	Query Zoom Focus Speed Setting Ex (Query Zoom Focus Setting Ex Response).....	178

Appendix 1. Table of ZOOM Position vs Focal length

Appendix 2. Table of FOCUS Position vs Subject distance

1 Summary

This document specifies the Pelco-D protocol in FUJIFILM CCTV lens / cameras. The CCTV lens / cameras to which this version is applied are as follows.

Applicable model: Long Range Surveillance Camera "FUJIFILM SX800", "FUJIFILM SX801", FW Ver. **2.00** and later

Note: The specification for "FUJIFILM SX801C" is partially different.

2 Overview

Pelco-D is a protocol proposed by Pelco, mainly for controlling a PTZ camera. It is a commonly published protocol and is adopted from SX800 because it is being standardized worldwide.

3 Overview about Pelco-D

The Pelco-D protocol is a master-slave type protocol, and up to 255 slaves can be connected to one master. The slave side does not transmit data without receiving a request from the master. The address that can be set as this specification is 31 patterns of 1 to 31 at maximum (※ RS485_ID is 1 to 31). Communication shall be set according to the following contents.

■ Serial data format

Baudrate: 2400, 4800, 9600, 19200, 38400, 115200

StartBit: 1

DataLength: 8

StopBit: 1

Parity: None

3.1 Send command format

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	—	—	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. CMND1 is an extension command (* When adding a command, register this)
4. CMND2 is a command for basic operation
5. Set DATA1 and DATA2 according to the contents of CMND1 and CMND2
6. Set the sum of 2nd to 6th Bytes in 8 bits to CKSM

3.2 Receive command format

The receive command format differs depending on the command. The commands defined by Pelco are as follows,

3.2.1 Receive command (General Response)

Reply as 4 Bytes data.

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

3.2.2 Receive command (Extended Response)

Reply as 7 Bytes data.

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	—	—	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set specific data for each commands to DATA1 and DATA2
5. Set the sum of ADDR to DATA2 in 8 bits is set to CKSM

3.2.3 Receive command (Query Response)

Reply as 18 Bytes data

Byte	1	2	3	17	18
	SYNC	ADDR	DATA1	DATA15	CKSM
	0xFF	—	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set specific data for each commands to DATA1 to DATA15
4. Set the sum of ADDR to DATA15 in 8 bits to CKSM

* As for Query Serial Number command in this specification, set the sum of ADDR to DATA 15 in 8 bits to CKSM

3.2.4 Receive command(Extended Response2)

Reply as 7 Bytes data

* The difference from Extended Response (3.2.2) is that new CMD1 and CMD2 are used instead of CMD1 and CMD2 received in RESP1 and RESP2.

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	—	—	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set RESP1, RESP2
4. Set specific data for each commands to DATA1 and DATA2
5. Set the sum of 2nd to 6th Bytes in 8 bits to CKSM

4 Functional specifications

The address used for communication and the baud rate are switched from software by setting.

Address => 1 to 31 (When shipped from factory or after reset, RS485_ID=7 (= device setting ID))

Baud rate => 0 to 5 [Value: 0: 2400, 1: 4800, 2: 9600, 3: 19200, 4: 38400, 5: 115200] (When shipped from the factory or after reset, Baud rate is "2: 9600")

Pelco has specified that all commands of Standard Command described in the next chapter are automatically stopped after driving for up to 15 seconds for runaway detection, and this specification also follows this. As for timeout, if the drive command is received again before the timeout occurs, the timer is reset.

Notes on communicating with the SX800, SX801

- SX800 and SX801 do not have the ability to queue commands, so if you issue the next send command before receiving the receive command for the previous send command, the previous command will be discarded

5 Command details

The commands are classified into commands defined by Pelco and commands uniquely defined in this specification.

The commands defined by Pelco are further classified into "Standard Command", "Extended Command", and "Original Command".

5.1 Standard Command

Basic commands defined by Pelco-D.

5.1.1 Send command

Since Bit3-Bit7 of CMND1 is not used in the latest Pelco-D, this specification does not support either.

Bit 0 to Bit 4 of CMND2 is used as a PTZ camera control command only when this camera is in HOST mode. (※ for pan head control)

Byte 3, CMND:1							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Sense	0	0	Auto/Manual Scan	Camera On/Off	Iris Close	Iris Open	Focus Near
Byte 4, CMND:2							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Focus Far	Zoom Wide	Zoom Tele	Down	Up	Left	Right	Always 0

5.1.2 Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2 Extended Command

Extended command specified by Pelco-D.

5.2.1 Set Zoom Speed

Command to change zoom speed (from version 2.00, use 5.13.1, "Set Zoom Speed Ex")

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x25	0x00	ZOOM_SPEED	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set the speed (ZOOM_SPEED) according to the purpose in DATA 2
6. Set the sum of 2nd to 6th Bytes in 8 bits to CKSM

■ Argument of ZOOM_SPEED

DATA2	Description	New commands executed by this command (5.13.1, "Set Zoom Speed Ex")
0x00	Slowest Speed (=Low Medium Speed)	The new command 0x07 is executed internally.
0x01	Low Medium Speed	The new command 0x05 is executed internally.
0x02	High Medium Speed	The new command 0x03 is executed internally.
0x03	Highest Speed (=High Medium Speed)	The new command 0x01 is executed internally.
Others	Low Medium Speed	The new command 0x05 is executed internally.

Note: With firmware version 1.60 and earlier, 0x00 and 0x02 select the same zoom speeds as 0x01 and 0x03, respectively

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.2 Set Focus Speed

Command to change focus speed (from version 2.00, use 5.13.2, "Set Focus Speed Ex")

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x27	0x00	FOCUS_SPEED	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set the speed (FOCUS_SPEED) according to the purpose in DATA 2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

Argument of FOCUS_SPEED

DATA2	Description	New commands executed by this command (5.13.2, "Set Focus Speed Ex")
0x00	Slowest Speed (=High Medium Speed)	The new command 0x07 is executed internally.
0x01	Low Medium Speed (=High Medium Speed)	The new command 0x05 is executed internally.
0x02	High Medium Speed	The new command 0x03 is executed internally.
0x03	Highest Speed (=High Medium Speed)	The new command 0x01 is executed internally.
Others	High Medium Speed	The new command 0x03 is executed internally.

Note: With firmware version 1.60 and earlier, all arguments select the same focus speed.

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.3 Auto focus on/off

Command to switch auto focus on / off / quick AF

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x2B	0x00	AUTO F_CTL	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set AUTO F_CTL to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ AUTO F_CTL

DATA2	Description
0x00	AF on
0x01	AF off (MF)
0x02	Quick AF
Others	AF on

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.4 Auto Iris on/off

Command to switch auto iris on / off

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x2D	0x00	AUTO_I_CTL	—

1. Always set 0xFF to SYNC
2. Set 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set AUTO_I_CTL to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of AUTO_I_CTL

DATA2	Description
0x00	Off (Manual iris)
0x01	On (Auto iris)
Others	On (Auto iris)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.5 AGC auto/on/off

Command to switch AGC standard/off/Hyper

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x2F	0x00	AGC_CTL	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set AGC_CTL to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of AGC_CTL

DATA2	Setting
0x00	Standard
0x01	Off
0x02	Hyper
Others	Standard

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.6 Backlight compensation on/off

Command to switch backlight compensation on / off

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x31	0x00	BLC_CTL	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set BLC_CTL to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of BLC_CTL

DATA2	Description
0x00	OFF
0x01	1: Soft
0x02	2: Hard
Others	OFF

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.7 <Reserved>

5.2.8 Set Zoom Position

Command to set zoom position

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x4F	ZOOM_P MSB	ZOOM_P LSB	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set the zoom position (MSB) according to the purpose to DATA1
5. Set the zoom position (LSB) according to the purpose to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of ZOOM_P

DATA1,DATA2	Description
0~65535	Zoom Position

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.9 Set Remote Baud Rate

Command to set Remote baud rate

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x67	0x00	SET B_RARE	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the baud rate according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set the baud rate accordance with the opposite to DATA2
6. Set the sum of ADDT to DATA2 in 8 bits to CKSM

■ Argument of SET B_RARE

DATA	Baud rate
0x00	2400
0x01	4800
0x02	9600(Default)
0x03	19200
0x04	38400
0x05	115200
Others	9600

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

5.2.10 Time Set Opcode

Command to set the clock and get the report of clock setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	SUB OP CODE	0x77	Various	Various	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set SUB OP CODE to CMND1
4. Set the command accordance with the purpose to CMND2
5. Set the value which are selected by SUB OP CODE to DATA1 and DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of SUB OP CODE

Set binary numbers to Second, Minute, Hour, Month, Day, and Year.

In addition, for example, when 24 or more numbers is put into Hour, it is ignored.

CMND1	DATA1	DATA2	Description
0x00	Second		Set second (0x00-0x3B) and synchronize time
0x01	0x00	0x00	Report second
0x02	Hour	Minute	Set hour(0x00-0x17) and minute
0x03	0x00	0x00	Report hour and minute
0x04	Month	Day	Set month(0x01-0x0C) and date(0x01-0x1F)
0x05	0x00	0x00	Report month and date
0x06	Year		Set year (2019 => 0x07E3)
0x07	0x00	0x00	Report year
Other	0x00	0x00	Invalid (no reaction)

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	—	—	Various	Various	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. As for RESP1, set 0x01(ACK) or 0x00(NAK) when setting and set received CMND1 when getting the report.
4. As for RESP2, set 0x01 when setting, and set received CMND2 when getting the report.
5. Set the value selected by SUB OP CODE to DATA1 and DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of SUB OP CODE

CMND1 of Send command	RESP1	RESP2	DATA1	DATA2	Description
0x00	0x01 or 0x00	0x01	0x00	0x00	Receive second (0x00-0x3B) and synchronize time
0x01	0x01	0x77	Second		Report second
0x02	0x01 or 0x00	0x01	0x00	0x00	Set hour(0x00-0x17) and minute
0x03	0x03	0x77	Hour	Minute	Report hour and minute
0x04	0x01 or 0x00	0x01	0x00	0x00	Set month(0x01-0x0C) and date(0x01-0x1F)
0x05	0x05	0x77	Month	Day	Report month and date
0x06	0x01 or 0x00	0x00	0x00	0x00	Set year (2019 => 0x07E3)
0x07	0x07	0x77	Year		Report year
Other	0x00	0x00	0x00	0x00	Invalid (no reaction)

5.2.11 Query Zoom Position (Standard)

A command that returns the zoom position (the value returned is the same as that returned by commands 5.3.2, "Query Zoom Position" and 5.3.23, "Query Manual Setting").

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x55	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command (0x5D:Query Zoom Position Response)

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x5D	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x5D to RESP2.
4. Set requested value to DATA1 and DATA2 (Ex. 0xFF00 → DATA1:0xFF, DATA2, 0x00)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

5.3 FF Extended Command (Original commands of this specification)

Commands specified by FUJIFILM in Extended Command

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM (**Original specification by FUJIFILM**)

(4) Receive command (Original specification by FUJIFILM)

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.3.1 Query Focus Position

Command to get the focus position

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x81	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2(for Response)
5. Set the sum of ADDR to DATA2 in 8bit to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x81	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2.
4. Set requested value to DATA1 and DATA2 (Ex. 0xFF00 -> DATA1:0xFF, DATA2, 0x00)
5. CKSM is the sum of ADDR to DATA2 in 8bit

5.3.2 Query Zoom Position

Command to get the zoom position (The data to be obtained by 5.2.11 Query Zoom Position command is the same)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x83	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x83	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2.
4. Set requested value to DATA1 and DATA2 (Ex. 0xFF00 → DATA1:0xFF, DATA2, 0x00)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

5.3.3 <Reserved>**5.3.4 <Reserved>****5.3.5 Query Serial Number**

Command to get Serial number

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x89	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7	8	9	10	11 - 17	18
	SYNC	ADDR	DATA1	DATA2	DATA3	DATA4	DATA5	DATA6	DATA7	DATA8	DATA9-DATA15	CKSM
	0xFF	—	—	—	—	—	—	—	—	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set Serial number as ASCII codes to DATA1 to DATA8
4. Set 0x00 to DATA9 to DATA15
5. Set the sum of ADDR to DATA15 in 8 bits to CKSM (* Note that it is different from Query Response)

5.3.6 Query Few Version

Command to get FW (Firmware) Version

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8B	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (For Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8B	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set major version to DATA and minor version to DATA2 (Ex. Ver1.10=DATA1:0x01,DATA2:0x10, Ver2.0A=DATA1:0x02,DATA2:0x0A)
5. Set the sum of ADDT to DATA2 in 8 bits to CKSM

5.3.7 Query Lens Status

Command to get the lens status

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8D	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (For Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8D	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set the lens status to DATA (See below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ DATA1 format

DATA1	Lens status	
0x00	No error	the lens work normally
0x01	Lens error	the zoom and/or the focus was stopped forcibly

5.3.8 Set Focus Position

Command to get the focus position

- Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8F	FOCUS MSB	FOCUS LSB	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. As for DATA1 and DATA2, see below
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA1	Value
0x00~0xFF	FOCUS MSB

DATA2	Description
0x00~0xFF	FOCUS LSB

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

5.3.9 Set Manual Iris

Command to set F number

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x91	0x00	MANU_FNO	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA2	F number (at the wide end)
0x01	F4
0x02	F4.5
0x03	F5.0
0x04	F5.6
0x05	F6.3
0x05	F7.1
0x07	F8
0x08	F9
0x09	F10

0x0A	F12
0x0B	F13
0x0C	F14
0x0D	F16
Others	F5.6

■ Received command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

5.3.10 Set Shutter Limit on Auto

Command to set the lowest limit of the shutter sped at AE

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x93	0x00	A_SHUT_LIM	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA2	Description
0x00	Manual shutter : The value set by SetManualShutterSpeed command (0x00,0x95)
0x01	Auto shutter : Lowest limit 1/8 sec
0x02	Auto shutter : Lowest limit 1/15 sec
0x03	Auto shutter : Lowest limit 1/30 sec
0x04	Auto shutter : Lowest limit 1/60 sec
0x05	Auto shutter : Lowest limit 1/125 sec
Others	Auto shutter : Lowest limit 1/30 sec

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

5.3.11 Set Manual Shutter Speed

Command to set the shutter speed

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x95	0x00	MANU_SHUT	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA2	Shutter sped (MANU_SHUT) [sec]
0x01	1
0x02	1/1.3
0x03	1/1.6
0x04	1/2
0x05	1/2.5
0x06	1/3
0x07	1/4
0x08	1/5
0x09	1/6

0x0A	1/8
0x0B	1/10
0x0C	1/13
0x0D	1/15
0x0E	1/20
0x0F	1/25
0x10	1/30
0x11	1/40
0x12	1/50
0x13	1/60
0x14	1/80
0x15	1/100
0x16	1/120
0x17	1/125
0x18	1/160
0x19	1/200
0x1A	1/250
0x1B	1/320
0x1C	1/400
0x1D	1/500
0x1E	1/640
0x1F	1/800
0x20	1/1000
0x21	1/1250

0x22	1/1600
0x23	1/2000
0x24	1/2500
0x25	1/3200
0x26	1/4000
0x27	1/5000
0x28	1/6400
0x29	1/8000
0x2A	1/10000
0x2B	1/12800
0x2C	1/16000
0x2D	1/20000
0x2E	1/32000
Others	1/30

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

5.3.12 Query Manual Shutter Speed

Command to get the shutter speed setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x97	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (For Response)
5. Set the sum of ADDT to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x97	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set the shutter speed value to DATA1 (See below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Shute speed value for DATA1

DATA1	Shutter speed value [sec]
0x01	1
0x02	1/1.3
0x03	1/1.6
0x04	1/2
0x05	1/2.5
0x06	1/3
0x07	1/4
0x08	1/5
0x09	1/6
0x0A	1/8
0x0B	1/10
0x0C	1/13
0x0D	1/15
0x0E	1/20
0x0F	1/25
0x10	1/30
0x11	1/40
0x12	1/50
0x13	1/60
0x14	1/80
0x15	1/100
0x16	1/120
0x17	1/125

0x18	1/160
0x19	1/200
0x1A	1/250
0x1B	1/320
0x1C	1/400
0x1D	1/500
0x1E	1/640
0x1F	1/800
0x20	1/1000
0x21	1/1250
0x22	1/1600
0x23	1/2000
0x24	1/2500
0x25	1/3200
0x26	1/4000
0x27	1/5000
0x28	1/6400
0x29	1/8000
0x2A	1/10000
0x2B	1/12800
0x2C	1/16000
0x2D	1/20000
0x2E	1/32000

5.3.13 Set Manual ISO

Command to set the ISO speed (sensitivity)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x99	0x00	MANU_ISO	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ ISO speed value (MANU_ISO for DATA2)

DATA2	ISO speed (MANU_ISO)
0x01	ISO 400
0x02	ISO 500
0x03	ISO 640
0x04	ISO 800
0x05	ISO 1000
0x05	ISO 1250
0x07	ISO 1600
0x08	ISO 2000
0x09	ISO 2500

0x0A	ISO 3200
0x0B	ISO 4000
0x0C	ISO 5000
0x0D	ISO 6400
0x0E	ISO 8000
0x0F	ISO 10000
0x10	ISO 12800
0x11	ISO 25600
0x12	ISO 51200
0x13	ISO 102400
0x14	ISO 204800
0x15	ISO 409600
0x16	ISO 819200
Others	ISO 400

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

5.3.14 Query Manual ISO

Command to get the ISO speed value

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9B	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDT to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9B	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set Manual ISO speed value to DATA1 (see below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ ISO speed value for DATA1

DATA1	ISO speed
0x01	ISO 400
0x02	ISO 500
0x03	ISO 640
0x04	ISO 800
0x05	ISO 1000
0x05	ISO 1250
0x07	ISO 1600
0x08	ISO 2000
0x09	ISO 2500
0x0A	ISO 3200
0x0B	ISO 4000
0x0C	ISO 5000
0x0D	ISO 6400
0x0E	ISO 8000
0x0F	ISO 10000
0x10	ISO 12800
0x11	ISO 25600
0x12	ISO 51200
0x13	ISO 102400
0x14	ISO 204800
0x15	ISO 409600
0x16	ISO 819200

5.3.15 Query Manual Iris

Command to get the F value of the iris

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9D	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9D	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set F value of the iris to DATA1 (See below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ F value of iris for DATA1

DATA1	F value at the wide end
0x01	F4
0x02	F4.5
0x03	F5.0
0x04	F5.6
0x05	F6.3
0x05	F7.1
0x07	F8
0x08	F9
0x09	F10
0x0A	F12
0x0B	F13
0x0C	F14
0x0D	F16

5.3.16 <Reserved>

5.3.17 <Reserved>

5.3.18 <Reserved>

5.3.19 <Reserved>

5.3.20 <Reserved>

5.3.21 <Reserved>

5.3.22 <Reserved>

5.3.23 Query Manual Setting (Query Manual Setting Response)

Command to get various setting status

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0xAD	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
4. Set 0x00 to DATA2
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0xAF	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to RESP1
4. Set 0xAF to RESP2
5. Set requested value to DATA1 and DATA2 (See below for the value).
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

CMND2 set by send command	DATA1 <i>returned</i> to receiving command	DATA2 <i>returned</i> to receiving command	Description
0x25	0x00	ZOOM_SPEED	<i>Returns</i> the zoom speed.
0x27	0x00	FOCUS SPEED	<i>Returns</i> the focus speed.
0x2B	0x00	AUTO F_CTL	AF On / Off / Quick AF
0x2D	0x00	AUTO I_CTL	Auto iris On / Off
0x2F	0x00	AGC_CTL	AGC standard/off/Hyper
0x31	0x00	BLC_CTL	Backlight compensation On / Off
0x4F	ZOOM MSB	ZOOM LSB	<i>Returns</i> the zoom position.
0x67	0x00	SET B_RARE	Set Remote baud rate.
0x8F	FOCUS MSB	FOCUS LSB	<i>Returns</i> the focus position.
0x91	0x00	MANU_FNO	F value of iris
0x93	0x00	A_SHUT_LIM	<i>Returns</i> the minimum shutter speed for autoexposure.
0x95	0x00	MANU_SHUT	<i>Returns</i> the shutter speed.
0x99	0x00	MANU_ISO	<i>Returns</i> the ISO sensitivity.
Others			Invalid

5.4 Original Command1 (Original commands of this specification: No.1: Photo Setting)

Original commands extended by FUJIFILM

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (**Original specification by FUJIFILM**)

(4) Receive command : (**Original specification by FUJIFILM**)

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.4.1 Set AF Area

Command to set AF area

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x03	0x00	FOCUS AREA	—

1. Set 0x00 to DATA1
2. Set 0 to 9 as FOCUS AREA to DATA2

■ Argument of FOCUS AREA

DATA2	Area
0x00	Center (Fixed)
0x01	Upper left
0x02	Upper center
0x03	Upper right
0x04	Middle left
0x05	Middle of middle
0x06	Middle right
0x07	Lower left
0x08	Lower center
0x09	Lower right
Others	Center (Fixed)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.2 Set AF Sensitivity

Command to set sensitivity at AF

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x05	0x00	SENS GAIN	—

1. Set 0x00 to DATA1
2. Set 1 to 3 as SENS GAIN to DATA2

■ Argument of SENS GAIN

DATA2	Sensitivity
0x01	Low
0x02	Middle
0x03	High
Others	Low

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.3 One-push AF

Command to execute One-push AF (Valid when Auto focus is Off)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x07	0x00	ONE_AF	—

1. Set 0x00 to DATA1
2. Set ONE_AF to DATA2

■ Argument of ONE_AF

DATA2	Operation
0x00	Execute One-push AF
Others	Invalid

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.4 <Reserved>

5.4.5 <Reserved>

5.4.6 Set Auto Day/Night Control Mode

Set threshold of Day/Night

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x0D	0x00	DN MODE	—

1. Set 0x00 to DATA1
2. Set 0 to 3 as DN MODE to DATA2

■ Argument of DN MODE

DATA2	Threshold
0x01	Dark
0x02	Middle
0x03	Bright
Others	Middle

Note: This command has been retained following firmware version 1.60 for backward compatibility, but the setting is stored separately from Original Command 9 (No. 9, "DayNight Setting Ex"). When executed in firmware versions later than 1.60, this command executes with the values for the existing control (Original Command 9).

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.7 Set Manual Day/Night

Command to set Day / night manually

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x0F	0x00	DN SET	—

1. Set 0x00 to DATA1
2. Set 1 to 4 as DN SET to DATA2
3. Set the sum of 2nd to 6th Bytes in 8 bit to CKSM

■ Argument of DN SET

DATA2	Day /Night Setting
0x00	Auto
0x01	Day
0x02	Night
Others	Day

Note: This command has been retained following firmware version 1.60 for backward compatibility, but the setting is stored separately from Original Command 9 (No. 9, "DayNight Setting Ex"). When executed in firmware versions later than 1.60, this command executes with the values for the existing control (Original Command 9).

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.8 Set Infrared WaveLength

Command to set Infrared wavelength

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x11	0x00	IWL SET	—

1. Set 0x00 to DATA1
2. Set 1 to 4 as IWL SET to DATA2

■ Argument of IWL SET

DATA2	Description
0x00	Visible light
0x01	950 nm
0x02	940 nm
0x03	850 nm
0x04	808 nm
Others	Visible light

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.9 Set OIS Mode

Command to set ON / OFF of OIS and EIS

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x13	0x00	OIS MODE	—

1. Set 0x00 to DATA1
2. Set 0 to 3 as OIS MODE to DATA2

■ Argument of OIS MODE

DATA2	Setting
0x01	AUTO(default)
0x02	Only OIS ON
0x03	Only EIS ON
0x04	Off
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.10 <Reserved>

5.4.11 Set Photo Mode Preset

Command to set Photo mode preset

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x17	0x00	PHOTO_PRST	—

1. Set 0x00 to DATA1
2. Set 1 or 2 as PHOTO_PRST to DATA2

■ Argument of PHOTO_PRST

DATA2	Description
0x01	Surveillance (Focus on resolution)
0x02	Movie (General image quality)
Others	Surveillance

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.12 Set DayNight Control by External

Command to switch Day / Night by DayNight trigger signal forcibly

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x19	0x00	EX_TGER	—

1. Set 0x00 to DATA1
2. Set 1 or 2 as EX_TGER to DATA2

■ Argument of EX_TGER

DATA2	Description
0x01	On (DayNight trigger: valid) VLC filter
0x02	On (DayNight trigger : valid) CLEAR filter (Raw glass)
0x03	Off (DayNight trigger : invalid)
Others	Off (DayNight trigger : invalid)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.4.13 <Reserved>

5.4.14 Query Photo Setting (Query Photo Setting Response)

Command to get the camera setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x1D	—	0x00	—

1. Set CMND2 of question target to DATA1 (See below for the contents of CMND2)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x1F	—	—	—

1. Set 0xF0 to RESP1
2. Set 0x1F to RESP2
3. Set the value according to the request to DATA1 and DATA2 (See below for the response)

CMND2 set by Send command	DATA1 <i>returned</i> to receiving command	DATA2 <i>returned</i> to receiving command	Description
0x03	0x00	0–9	<i>Returns</i> the AF area.
0x05	0x00	1–3	<i>Returns</i> the ISO sensitivity for autofocus.
0x07	0x00	AF_STATUS	AF status when One-Push AF 0x00: Finished 0x01 In process 0xFF: Abnormally
0x0D	0x00	0–3	<i>Returns</i> the Day/Night threshold.
0x0F	0x00	1–4	<i>Returns</i> the manual Day/night setting.
0x11	0x00	0–6	<i>Returns</i> the IR filter.
0x13	0x00	0–3	<i>Returns</i> OIS status (on/off).
0x17	0x00	1–2	<i>Returns</i> the shooting mode preset.
0x19	0x00	1–2	Day / Night swatch by DayNight trigger
Others			Invalid

5.5 Original Command2 ((Original commands of this specification: No.2: Image Quality Parameter)

An extended command unique to this specification.

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (**Original specification by FUJIFILM**)

(4) Receive command : (**Original specification by FUJIFILM**)

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.5.1 Set VLC Filter

Command to set the VLC (Visible Light Cut) filter

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x21	0x00	VLC FL	—

1. Set 0x00 to DATA1
2. Set VLC FL to DATA2

■ Argument of VLC FL

DATA2	Setting
0x00	Off
0x01	On
0x02	4th filter (Optional filter) *
Others	Off

* Please contact a sales representative for details.

Note: This command has been retained following firmware version 1.60 for backward compatibility, but the setting is stored separately from Original Command 9 (No. 9, "DayNight Setting Ex"). When executed in firmware versions later than 1.60, this command executes with the values for the existing control (Original Command 9, "Set Optical Filter Day/Night").

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.2 Set WideDynamicRange

Command to set the dynamic range

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x23	0x00	D_RANGE	—

1. Set 0x00 to DATA1
2. Set D_RANGE to DATA2

■ Argument of D_RANGE

DATA2	Description
0x01	Off
0x02	1
0x03	2
Other	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.3 <Reserved>

5.5.4 Set DeHeatHaze Mode

Command to change De-heat haze mode

■ Send command

Byte	1	2	3	4	5	6	7
Byte	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x27	0x00	DE_HEAT_MODE	—

1. Set 0x00 to DATA1
2. Set DE_HEAT_MOD to DATA2

■ Argument of DE_HEAT_MODE

DATA2	Description
0x00	Off
0x01	1
0x02	2
0x03	3
Others	Off

■ Receive command

Byte	1	2	3	4
Byte	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.5 Set Defogging Mode

Command to change De-fogging mode

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x29	0x00	DE_FOG_MODE	—

1. Set 0x00 to DATA1
2. Set DE_FOG_MODE to DATA2

■ Argument of DE_FOG

DATA2	Description
0x00	Off
0x01	1
0x02	2
0x03	3
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.6 Set Brightness Level

Command to set the brightness

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x2B	0x00	BRIGHT_LV	—

1. Set 0x00 to DATA1
2. Set BRIGHT_LV to DATA2

■ Agreement of BRIGHT_LV

DATA2	Description
0x01	1: Darkest
0x02	2
0x03	3
0x04	4
0x05	5
0x06	6
0x07	7
0x08	8
0x09	9
0x0A	10
0x0B	11 (Center : default)
0x0C	12

0x0D	13
0x0E	14
0x0F	15
0x10	16
0x11	17
0x12	18
0x13	19
0x14	20
0x15	21 : Brightest
Others	11

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.7 Set Contrast Level

Command to set the contrast

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x2D	0x00	CONT_LV	—

1. Set 0x00 to DATA1
2. Set CONT_LV to DATA2

■ Argument of CONT_LV

DATA2	Description
0x01	1 : Lowest
0x02	2
0x03	3
0x04	4
0x05	5 : Highest
Others	3

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.8 Set ColorSaturation Level

Command to set the color saturation level

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x2F	0x00	COLOR_ST_LV	—

1. Set 0x00 to DATA1
2. Set COLOR_ST_LV to DATA2

■ Argument of COLOR_ST_LV

DATA2	Description
0x01	1 : Lowest
0x02	2
0x03	3
0x04	4
0x05	5 : Highest
Others	3

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.9 Set Sharpness Level

Command to set the sharpness

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x31	0x00	SHARP_LV	—

1. Set 0x00 to DATA1
2. Set SHARP_LV to DATA2

■ Argument of SHARP_LV

DATA2	Description
0x01	1 : Softest
0x02	2
0x03	3
0x04	4
0x05	5 : Hardest
Others	4

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.10 Set ColorTemperature on WhiteBalance

Command to set the color temperature on the white balance

This command becomes effective when ColorTemperature (0x06) is set to DATA2 by Set Select WhiteBalance.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x33	0x00	C_WB_TEMP	—

1. Set 0x00 to DATA1
2. Set C_WB_TMP to DATA2

■ Argument of C_WB_TMP

DATA	Description
0x01	3000K
0x02	5000K
0x03	9000K
Others	5000K

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.11 Set Select WhiteBalance

Command to set the white balance

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x35	0x00	WB_SEL	—

1. Set 0x00 to DATA1
2. Set WB_SEL to DATA2

■ Argument of WB_SEL

DATA2	Description
0x01	Auto
0x02	Custom1 (Read preset, which can be set only by SDI menu)
0x03	Custom2 (Read preset, which can be set only by SDI menu)
0x04	Day
0x05	Cloud
0x06	ColorTemperature (Set the color temperature by Set ColorTemperature on WhiteBalance)
0x07	Auto (white priority)
Others	Auto

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.12 Set Digital Zoom

Command to switch the digital zoom

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x37	0x00	D_ZOOM	—

1. Set 0x00 to DATA1
2. Set D_ZOOM to DATA2

■ Argument of D_ZOOM

DATA2	Digital zoom
0x00	Off
0x01	On: Conventional Digital Zoom (Crop optical tele end)
0x02	Crop: Cropped at any position from wide end to tele end. Set magnification with Set Digital Zoom Ex.
Others	Off

■ Receive mode

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.13 Set NR Level

Command to set the noise reduction level

- Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x39	0x00	NR_lev	—

1. Set 0x00 to DATA1
2. Set NR_lev to DATA2

- Argument of NR_lev

DATA2	Level
0x01	1: Weak
0x02	2: Middle
0x03	3: Strong
Others	2: Middle

- Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.5.14 <Reserved>

5.5.15 Query ImageQuality Setting (Query ImageQuality Setting Response)

Command to get the image quality setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x3D	—	0x00	—

1. Set CMND2 of question target to DATA1 (See below for the content of CMND2)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x3F	—	—	—

1. Set 0xF0 to RESP1
2. Set 0x3f to RESP2
3. Set values according to the requested content in DATA1 and DATA2 (see below for the response content)

CMND2 set by send command	DATA1 returned to receiving command	DATA2 returned to receiving command	Description
0x21	0x00	0–2	Returns the VLC.
0x23	0x00	1–3	Returns the dynamic range.
0x27	0x00	0–5	Returns the heat-haze reduction setting.
0x29	0x00	0–5	Returns the fog reduction setting.
0x2B	0x00	1–5	Returns brightness.
0x2D	0x00	1–5	Returns contrast.
0x2F	0x00	1–5	Returns the saturation setting.
0x31	0x00	1–5	Returns sharpness.
0x33	0x00	C_WB_TEMP	Returns the color temperature.
0x35	0x00	1–6	Returns white balance.
0x37	0x00	0–2	Returns digital zoom.
0x39	0x00	1–3	Returns noise reduction.
Others			Invalid

5. 6 Original Command2 (Original commands of this specification: No.2: ImageQuality Parameter)

Original commands extended by FUJIFILM

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM **(Original specification by FUJIFILM)**

(4) Receive command : **(Original specification by FUJIFILM)**

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.6.1 <Reserved>**5.6.2 Set DayTime Display**

Command to set data and time

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x43	0x00	TIME_DISP SW	—

1. Set 0x00 to DATA1
2. Set TIME_DISP SW to DATA2

■ Argument of TIME_DISP SW

DATA2	SW
0x00	Off
0x01	On
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.3 Set DisplayPosition of DayTime

Command to set the display position of Date/Time

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x45	0x00	TIME_DISP POS	—

1. Set 0x00 to DATA1
2. Set TIME_DISP POS to DATA2

■ Argument of TIME_DISP POS

DATA2	Position
0x01	Upper right
0x02	Lower right
0x03	Upper left
0x04	Lower left
Others	Upper right

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.4 Set Title Display

Command to display the title

* The title can be set by SDI menu. See the operation manual.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x47	0x00	TITLE_DISP SW	—

1. Set 0x00 to DATA1
2. Set TITLE_DISP SW to DATA2

■ Argument of TITLE_DISP SW

DATA2	Display
0x00	Off
0x01	On
Other	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.5 <Reserved>

5.6.6 Set DisplayPosition of Title

Command to set the position of the title display

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x4B	0x00	TITLE_DISP POS	—

1. Set 0x00 to DATA1
2. Set TITLE_DISP POS to DATA2

■ Argument of TITLE_DISP POS

DATA2	Position
0x01	Upper right
0x02	Lower right
0x03	Upper left
0x04	Lower left
Others	Upper right

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.7 Set ID Display

Command to display ID

* The ID can be set by SDI menu. See the operation manual.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x4D	0x00	DISP_ID SW	—

1. Set 0x00 to DATA1
2. Set DISP_ID SW to DATA2

■ Argument of DISP_ID SW

DATA2	Display
0x00	Off
0x01	On
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.8 Set DisplayPosition of ID

Command to set the display position of ID

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x4F	0x00	ID_DISP POS	—

1. Set 0x00 to DATA1
2. Set ID_DISP POS to DATA2

■ Argument of ID_DISP POS

DATA2	Position
0x01	Upper right
0x02	Lower right
0x03	Upper center
0x04	Lower center
0x05	Upper left
0x06	Lower left
Others	Upper right

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.9 Set Center Position Display

Command to display the mark in the middle

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x51	0x00	DISP_C_POS SW	—

1. Set 0x00 to DATA1
2. Set DISP_C_POS SW to DATA2

■ Argument of DISP_C_POS SW

DATA2	Display
0x00	Off (Default)
0x01	On
Others	Off

* Display is OFF after turn on (does not hold the previous setting)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.10 <Reserved>

5.6.11 SetAntialiasing

Command to control the anti-aliasing process of OSD on/off

■Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x55	0x00	ANTIALIASING SW	—

1. Set 0x00 to DATA1
2. Set ANNTIALIASING SW to DATA2

■Argument of ANTIALIASING SW

DATA2	SW
0x00	Off
0x01	On (Default)
Other	On

■Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.12 <Reserved>

5.6.13 <Reserved>

5.6.14 <Reserved>

5.6.15 Query Display Setting (Query Display Setting Response)

Command to get the display setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x5D	—	0x00	—

1. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x5F	—	—	—

1. Set 0xF0 to RESP1
2. Set 0x5F to RESP2
3. Set requested value to DATA1 and DATA2 (the requested values, see below)

CMND2 set by send command	DATA1 returned to receiving command	DATA2 returned to receiving command	Description
0x43	0x00	0–1	Returns the date and time.
0x45	0x00	1–4	Returns the date and time display position.
0x47	0x00	0–1	Returns title display status.
0x4B	0x00	1–4	Returns the title display position.
0x4D	0x00	0–1	Returns ID display status.
0x4F	0x00	1–6	Returns the ID display position.
0x51	0x00	0–1	Returns the display status of the center reticle.
0x53	0x00	0–1	Display of the zoom bar and AF fram ON (Display): 1 OFF (No display): 0 (Display ON/OFF setting is doen be SetBack MCD 0xF0)
0x55	0x00	0–1	Anti-alias status for the OSD ON: 1 OFF: 0
Others			Invalid

5.7 Original Command 4 (Original commands of this specification: No...4: Operation Setting)

Original commands extended by FUJIFILM

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (**Original specification by FUJIFILM**)

(4) Receive command : (**Original specification by FUJIFILM**)

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.7.1 Set Display Mode of time

Command to switch the time display mode (24h ⇄ 12h)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x61	0x00	HOUR12_24 SEL	—

1. Set 0x00 to DATA1
2. Set HOUR12_24 SEL to DATA2

■ Argument of HOUR12_24 SEL

DATA2	Display mode
0x01	24h
0x02	12h
Others	24h

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.2 Set DisplayMode of YMD

Command to switch the YMD display mode

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x63	0x00	YMD SEL	—

1. Set 0x00 to DATA1
2. Set YMD SEL to DATA2

■ Argument of YMD SEL

DATA2	Display mode
0x01	Y-M-D
0x02	M-D-Y
0x03	D-M-Y
0x04	Y/M/D
0x05	M/D/Y
0x06	D/M/Y
Others	Y-M-D

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.3 <Reserved>

5.7.4 Set Video Mode

Command to switch the video mode (NTSC ⇔ PAL)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x67	0x00	VIDEO MODE	—

1. Set 0x00 to DATA1
2. Set VIDEO MODE to DATA2

■ VIDEO MODE 引数

DATA2	Video mode
0x01	NTSC
0x02	PAL
Others	NTSC

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.5 Set HD Format

Command to switch the image size of HD and the frame rate

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x69	0x00	HD_FORMAT_SW	—

1. Set 0x00 to DATA1
2. Set HD_FORMAT_SW to DATA2

■ Argument of HD_FORMAT SW

DATA2	Image size (Frame rate)
0x01	1080p (30p)
0x02	720p (60p)
0x03	480p (60p)
Others	1080p (30p)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.6 Set VideoDisplay Mode

Command to set the display mode of the video

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x6B	0x00	VIDEO_D_MODE	—

1. Set 0x00 to DATA1
2. Set VIDEO_D_MODE to DATA2

■ Argument of VIDEO_D_MODE

DATA2	Display mode
0x01	side cut
0x02	letter box
0x03	squeeze
Others	side cut

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.7 <Reserved>

5.7.8 Set RS485 ID

Command to set ID for RS485

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x6F	0x00	RS485_ID	—

1. Set 0x00 to DATA1
2. Set RS485_ID to DATA2 in 16bit binary

■ Argument of RS485_ID

DATA2	Setting
1~31	RS485 ID(Default : 7)
Others	7

* Power OFF→ON sequence is required to reflect the settings

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.9 <Reserved>

5.7.10 Set Termination for RS485

Command to switch the termination of RS485

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x73	0x00	TEMINAT SW	—

1. Set 0x00 to DATA1
2. Set TEMINAT SW to DATA2

■ Argument of TEMINAT SW

DATA2	Switch
0x00	Off
0x01	On
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.11 <Reserved>

5.7.12 Set RecordingMode on Scared

Command to set SD overwrite recording when card Full

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x77	0x00	SD_RECORD SW	—

1. Set 0x00 to DATA1
2. Set SD_RECORD SW to DATA2

■ Argument of SD_RECORD SW

DATA2	Setting
0x01	Overwrite
0x02	Stop recording (There is on/off setting to display the remaining amount)
Others	Overwrite

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.13 SetDisplay Scared Capacity Remaining

Command to set the display of remaining of SD card capacity

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x79	0x00	DISP_CARD_SW	—

1. Set 0x00 to DATA1
2. Set DISP_CARD_SW to DATA2

■ Argument of DISP_CARD_SW

DATA2	Setting
0x01	Display remaining of SD Card capacity : ON
0x02	Display remaining of SD Card capacity : OFF (Even if it is OFF, the remaining time will be displayed when it reaches 30 minutes.)
Others	Display remaining of SD Card capacity : ON

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.14 Format SDcard

Command to format SD card

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x7B	0x00	SD_FORMAT	—

1. Set 0x00 to DATA1
2. Set SD_FORMAT to DATA2

■ Argument of SD_FORMAT

DATA2	Format
0x00	Format SD card
Others	Do nothing

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.15 Download Firmware

Command used to update FW. SX800 and SX801 cannot update FW via RS485. Therefore, even if SX800 and SX801 are installed at a remote distance and controlled by RS485, FW update needs to use Ethernet I / F.

When this command is sent, the camera automatically reboots and starts up in the simple WebUI mode, and only the FW download operation via the Ethernet I / F is enabled (Note that the IP connection settings return to the default values when you issue this command in FW version 1.30 or earlier. If you issue this command in the FW version 1.40, the settings are maintained.). After the FW download is completed, reboot automatically again and restart in Pelco mode.

* Note: If this command is sent, it will not be possible to return via RS485, so be careful when sending the command.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x7D	0x00	FW_DL	—

1. Set 0x00 to DATA1
2. Set FW_DL to DATA2

■ Argument of FW_DL

DATA2	Action
0x01	Update FW
Others	Invalid

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.16 Recode LogData on SDcard

Command to copy the log data on the memory to SD card

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x7F	0x00	LOG_COPY_SD	—

1. Set 0x00 to DATA1
2. Set LOG_COPY_SD to DATA2

■ Argument of LOG_COPY_SD

DATA2	Action
0x00	Does not copy
0x01	Copy the log to SD card
Others	Does not copy

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.17 Preset parameters

Command to reset parameters to factory default

* After initializing parameters other than IP settings, the camera sends a receive command and restarts automatically.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x81	0x00	PRESET	—

1. Set 0x00 to DATA1
2. Set PRESET to DATA2

■ Argument of PRESET

DATA2	Action
0x00	Reset parameters other than IP setting
Others	Invalid

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.18 Reboot

Command to reboot

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x83	0x00	REBOOT	—

1. Set 0x00 to DATA1
2. Set REBOOT to DATA2

■ Argument of REBOOT

DATA2	Action
0x01	Reboot
Others	Invalid

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.19 Set Language

Command to set the language

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x85	0x00	LANGUAGE	—

1. Set 0x00 to DATA1
2. Set LANGUAGE to DATA2

■ Argument of LANGUAGE

DATA2	Language
0x00	English
0x01	French
0x02	Invalid
0x03	Japanese
Others	English

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.7.20 <Reserved>**5.7.21 <Reserved>****5.7.22 <Reserved>****5.7.23 Query Operation Setting (Query Operation Setting Response)**

Command to get the camera setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x8D	—	0x00	—

1. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x8F	—	—	—

1. Set 0xF to RESP1
2. Set 0x8F to RESP2
3. Set requested value to DATA1 and DATA2 (the requested values, see below)

CMND2 set by send command	DATA1 <i>returned</i> to receiving command	DATA2 <i>returned</i> to receiving command	Description
0x61	0x00	1–2	Data/ Time display mode(24h↔12h)
0x63	0x00	1–6	YMD mode
0x67	0x00	1–2	Video Mode (NTSC↔PAL)
0x69	0x00	1–4	HD image size and its frame rate
0x6B	0x00	1–3	<i>Returns</i> the video display mode.
0x6F	0x00	0–255	<i>Returns</i> the RS485 ID.
0x71			Invalid
0x73	0x00	0–1	Termination of RS485
0x77	0x00	1–2	Overwrite when SD card is full
0x79	0x00	1–2	Display the remaining of SD card capacity
0x7B	0x00	FOMAT_STATUS	Status of formatting SD card 0x00: Completed 0x01: In process 0xFF: Error
0x7F	0x00	0–1	Copy the log data to SD card
0x81	0x00	0	Reset parameters to factory default
0x85	0x00	0–3	<i>Returns</i> the language setting.
0x8B	0x00	SD_CARD_STATUS	Status of the SD card (Status of SD_CARD_STATUS is below)
Others			Invalid

※ Status of SD_CARD_STATUS

SD_CARD_STATUS	Status
0x00	Normal
0x01	SD card error
0x02	Unformatted
0x03	Protected
0x04	File system error
0x05	Full
0x06	No card

◆ Status of formatable card

0x00:Normal

0x01:SD card error

0x02:Unformatted

0x04: File system error

0x05: Full

※ However, formatting may fail when status were 0x01 or 0x04

◆ Video recordable status

0x00:Normal

◆ Video playable status

0x00:Normal

0x03:Protected

0x05: Full

5.8 Original Command 5 (Original commands of this specification: No...5: SET KEY)

Original commands extended by FUJIFILM

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (**Original specification by FUJIFILM**)

(4) Receive command : (**Original specification by FUJIFILM**)

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.8.1 SetEncodeMode

Command to set the video encode format

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x91	0x00	ENCODING	—

1. Set 0x00 to DATA1
2. Set ENCODING to DATA2

■ Argument of ENCODING

DATA2	Encode format
0x01	H.264,
0x02	MJPEG
0x03	MPEG4
Others	H.264

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.2 Record LiveView on SDcard

Command to record the live view into SD card

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x93	0x00	LV_RECORD	—

1. Set 0x00 to DATA1
2. Set LV_RECORD to DATA2

■ Argument of LV_RECORD

DATA2	Record
0x00	On
0x01	Off
Others	On

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.3 Set 1st file of playing Movie

Command to play the first file

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDcard command (0xF0, 0xB1), and then set the target frame.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x95	F_NO MSB	F_NO LSB	—

1. Set F_NO MSB to DATA1
2. Set F_NO LSB to DATA2

* Set the file index number to playback to F_NO

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

What is File index number:

The camera generates a table of file index numbers (F_NO) on the memory so that the latest file is 0x0001, only for the files recorded by the SX 800 and SX801 at startup. When the file is deleted, F_NO of the deleted file becomes an empty number until the file number table is updated next time the power is turned on.

5.8.4 Play Movie from SDcard

Command to set Play/Stop mode of the video file in the SD card

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x97	0x00	PLAY_SET	—

1. Set 0x00 to DATA1
2. Set PLAY_SET to DATA2

■ Argument of PLAY_SET

DATA2	Mode
0x00	Stop (Playback standby state: Thumbnail or inclusion JPEG displayed)
0x01	One frame playback
0x02	Continuous playback (Play from the current position in order of recording time. After the last frame, play the oldest frame in the card.)
0x03	Pause (Display freeze)
0x04	Playback again
Others	Stop (Playback standby state: Thumbnail or inclusion JPEG displayed)

* Default is 0x00. When transitioning from the movie mode to the playback mode, it is always 0x00, and the thumbnail or included JPEG display of the latest time stamp is displayed for the frame.

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.5 Delete Movie from SDcard

Command to set the target movie number to delete from SD card

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDcard command (0xF0, 0xB1), and then set the target frame.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x99	F_NO MSB	F_NO LSB	—

1. Set F_NO MSB to DATA1
2. Set F_NO LSB to DATA2

■ Argument of DISP_C_POS SW

DATA1 + DATA2	
File index number	Delete the movie of the file index number
0x0000	All delete

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.6 Select Movie mode/Play mode

Command to switch Movie mode/Playback mode

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x9B	0x00	MODE_SW	—

1. Set 0x00 to DATA1
2. Set MODE_SW to DATA2

■ Argument of MODE_SW

DATA2	Mode
0x01	Movie mode (When playing back the movie, playback is interrupted and transit to Movie mode)
0x02	Play back mode (When recording a movie, issue this command after stopping movie by 5.8.2 Record LiveView on SDcard (0xF0, 0x93))
Others	Movie mode

* Default is 0x01

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.7 <Reserved>

5.8.8 <Reserved>

5.8.9 <Reserved>

5.8.10 <Reserved>

5.8.11 <Reserved>

5.8.12 Set SDI ON MENU OK

Command to switch ON/OFF of SDI display and execute MENU OK command (* this command is available at Pelco Slave mode)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xA7	0x00	SDI_ON	—

1. Set 0x00 to DATA1
2. Set SDI_ON to DATA2

■ Argument of SDI_ON

DATA2	Mode
0x00	Off (SDI OFF and MENU OFF)
0x01	On (Execute instead of MENU OK key)
Others	Off (SDI OFF and MENU OFF)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.13 Set Direction

Command to move cursor (* this command is available at Pelco Slave mode)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xA9	0x00	CURSOR	—

1. Set 0x00 to DATA1
2. Set CURSOR to DATA2

■ CURSOR 引数

DATA2	Direction
0x01	Up
0x02	Down
0x03	Left
0x04	Right
Others	Invalid

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.14 Set Back CMD

Command to execute MENU BACK (* this command is available at Pelco Slave mode)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xAB	0x00	M_BACK	—

1. Set 0x00 to DATA1
2. Set M_BACK to DATA2

■ Argument of M_BACK

DATA2	Action
0x00	Invalid
0x01	MENU BACK
Others	Invalid

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.15 Query Key Setting (Query Key Setting Response)

Command to get the previous key setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xAD	—	0x00	—

1. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xAF	—	—	—

1. Set 0xF0 to RESP1
2. Set 0xAF to RESP2
3. Set requested value to DATA1 and DATA2 (See below for the value).

CMND2 set by send command	DATA1 returned to receiving command	DATA2 returned to receiving command	Description
0x91	0x00	1–2	Returns the video encoding.
0x93	0x00	0–1	Returns live-feed-to-memory-card recording status. 0x00 On 0x01 Off
0x95	number1	number2	Play the first file
0x97	0x00	0–4	Returns the status of video playback from the memory card. 0x00 Stop 0x01 One frame playback 0x02 Continuous playback 0x03 Pause (Display freeze) 0x04 Playback again
0x99	number1	number2	Returns the number of the frame to be deleted from the memory card.
0x9B	0x00	1–2	Returns the video/playback mode toggle status.
0xA7	0x00	0–1	Returns SDI display status (on/off).
0xA9	0x00	1–4	Returns cursor movement (0x00 when no cursor history).
0xAB	0x00	0–1	Returns MENU BACK status.
Others			Invalid

5.9 Original Command 6 (Original commands of this specification : No. 6 : Query SDcard)

Original commands extended by FUJIFILM

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (**Original specification by FUJIFILM**)

(4) Receive command : (**Original specification by FUJIFILM**)

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.9.1 Query Number of Movies on SDcard (Query Number of Movies on SDcard Response)

Command to get the number of movie files in the SD card

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB1	0xB3	0x00	—

1. Set the query target CMND2 to DATA1 (0xB3)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB3	NUMBER MSB	NUMBER LSB	—

1. Set 0xF0 to RESP1
2. Set 0xB3 to RESP2
3. Set NUMBER MSB to DATA1
4. Set NUMBER LSB to DATA2

5.9.2 Query Year of Movie on SDcard (Query Year of Movie on SDcard Response)

Command to get the recorded year of the movie file in the SD card

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDcard command (0xF0, 0xB1), and then set the target frame.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB5	F_NO MSB	F_NO LSB	—

1. Set F_NO MSB to DATA1
 2. Set F_NO LSB to DATA2
- * F_NO is the File Index number of the movie to playback

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB7	F_YY MSB	F_YY LSB	—

1. Set 0xF0 to RESP1
2. Set 0xB7 to RESP2
3. Set F_YY MSB to DATA1
4. Set F_YY LSB to DATA2

* F_YY is the recorded year represented by a 4-digit hexadecimal number (2 Bytes)

5.9.3 Query MonthDay of Movie on SDcard (Query MonthDay of Movie on SDcard Response)

Command to get the recorded date and month of the movie file in the SD card

How to use:

First, get the total number of the files by Query Number of Movies on SDcard(0xF0, 0xB1) command, then set the target file

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB9	F_NO MSB	F_NO LSB	—

1. Set F_NO MSB to DATA1
 2. Set F_NO LSB to DATA2
- * F_NO is the File Index number of the movie to playback

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xBB	F_MM	F_DD	—

1. Set 0xF0 to RESP1
 2. Set 0xB7 to RESP2
 3. Set F_MM to DATA1
 4. Set F_DD to DATA2
- * F_MM and F_DD are the recorded month and date

5.9.4 Query HourMinute of Movie on SDcard (Query HourMinute of Movie on SDcard Response)

Command to get the recorded time of day (24h notation) of the movie file in the SD card

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDcard command (0xF0, 0xB1), and then set the target frame.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xBD	F_NO MSB	F_NO LSB	—

1. Set F_NO MSB to DATA1
2. Set F_NO LSB to DATA2

* Fanons File Index number of the requested movie

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xBF	F_HH	F_MM	—

1. Set 0xF0 to RESP1
2. Set 0xB7 to RESP2 は 0xB7
3. Set F_HH(Hexadecimal) to DATA1
4. Set F_MM(Hexadecimal)to DATA2

* F_HH and F_MM are the recorded time of day (hour and minutes in 24h notation)

5.10 Original Command7 (In-House Custom Parameter No. 7: Query LogData)

An extended command unique to this specification.

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

(0) Send command:

Set the sum of ADDR to DATA2 in 8bit to CKSM

(1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

(2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

(3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM **(Original specification by FUJIFILM)**

(4) Receive command : (Extended Response2) **(Original specification by FUJIFILM)**

Set the sum of ADDR to DATA2 in 8bit to CKSM

5.10.1 Query LogData (Query LogData Response)

Command to get the LogData of the camera.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xD1	0xD3	LOG_TYPE	—

1. Set the query target CMND2 to DATA1 (0xD3)
2. Set LOG_TYPE to DATA2

■ LOG_TYPE arguments

DATA2 set by send command	Purpose	DATA1,DATA2 (LOG_DAT) set by the receiving command
0x01	Zoom	Cumulative number of moving pulses
0x02	Focus	Cumulative number of moving pulses
0x03	PowerOnTime	Cumulative energization time
0x04	OIS	Cumulative drive time (The time OIS is set to ON)
0x05	Thermal	Recording cycle Recording period : 3 years *) Delete from old records Data is managed in units of year, month, date, and time. Temperature data is obtained from the lens.
0x06	Error	Error history of the recording target
Others	Zoom	Cumulative number of moving pulses

5.11 Original Command 8 (In-House Custom Parameter No. 8: ImageQuality Parameter Fine)

An extended command unique to this specification. The checksum (CKSM) calculation is omitted from this chapter, as we have adopted the method outlined for Pelco-D in Chapter 3. New commands have been added for fine control of image quality parameters. *The command group described in Chapter 5.11 are available from version 2.00 (2022.2) of the firmware for both the SX800 and SX801.*

(0) Command sent:

Set the CKSM to the 8-bit sum of ADDR through DATA2.

(1) Response (General Response):

Set the CKSM to the 8-bit sum of ALARMS and the value returned for CKSM.

(2) Response (Extended Response):

Set the CKSM to the 8-bit sum of ADDR through DATA2.

(3) Response (Query Response):

Set the CKSM to the 8-bit sum of ADDR through DATA15 (*in-house custom parameter*).

(4) Response (Extended Response 2, an in-house custom parameter):

Set the CKSM to the 8-bit sum of ADDR through DATA2.

5.11.1 <Reserved>

5.11.2 <Reserved>

5.11.3 <Reserved>

5.11.4 <Reserved>

5.11.5 <Reserved>

5.11.6 Set Brightness Level Fine

A command used to set brightness.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xEB	0x00	BRIGHT_LV	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets BRIGHT_LV.

■ BRIGHT_LV arguments

DATA2	Description
0x01–0x64	1 – 100
Other	50

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.11.7 Set Contrast Level Fine

A command used to set contrast.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xED	0x00	CONT_LV	—

1. DATA1 is fixed at 0x0.
2. DATA2 sets CONT_LV.

■ CONT_LV arguments

DATA2	Description
0x01-0x64	1 – 100
Other	50

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.11.8 Set ColorSaturation Level Fine

A command used to set color saturation.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xEF	0x00	COLOR_ST_LV	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets COLOR_ST_LV.

■ COLOR_ST_LV arguments

DATA2	Description
0x01-0x64	1 – 100
Other	50

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.11.9 Set Sharpness Level Fine

A command used to set sharpness.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xF1	0x00	SHARP_LV	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets SHARP_LV.

■ SHARP_LV arguments

DATA2	Description
0x01–0x64	1 – 100
Other	20 / 80 *

* Varies with the setting for 5.4.11, “Set Photo Mode Preset” (video/surveillance).

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.11.10 <Reserved>

5.11.11 Set WhiteBalance Shift Red Fine

A command used to set the white-balance shift R component for the current white balance mode.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xF5	0x00	WB_SHIFT_R	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets C_WB_TMP.

■ WB_SHIFT_R arguments

DATA2	Description
0x77-0x89	0x77(-9) – 0x80(0) – 0x89(+9)
Other	0x80

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.11.12 Set WhiteBalance Shift Blue Fine

A command used to set the white-balance shift B component for the current white balance mode.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xF7	0x00	WB_SHIFT_B	—

1. DATA1 is the CMND2 query target (0xD3).
2. DATA2 sets WB_SEL.

■ WB_SHIFT_B arguments

DATA2	Description
0x77–0x89	0x77 (-9) – 0x80 (0) – 0x89 (+9)
Other	0x80

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.11.13 <Reserved>

5.11.14 <Reserved>

5.11.15 Query ImageQuality Setting Fine (Query ImageQuality Setting Response Fine)

A command that returns image quality parameters.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xFD	—	0x00	—

- 1 . DATA1 is the CMND2 query target (see the table below).
- 2 . DATA2 is fixed at 0x00.

■ Receive command (Extended Response 2)

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xFF	—	—	—

- 1 . RESP1 sets 0xF0.
- 2 . RESP2 sets 0xFF.
- 3 . DATA1 and DATA2 are set to values corresponding to the requested content (see table below).

CMND2 set by send command	DATA1 returned to receiving command	DATA2 returned to receiving command	Description
0xE1			Invalid
0xE3			Invalid
0xE5			Invalid
0xE7			Invalid
0xE9			Invalid
0xEB	0x00	1-100	Returns brightness.
0xED	0x00	1-100	Returns contrast.
0xEF	0x00	1-100	Returns saturation.
0xF1	0x00	1-100	Returns sharpness.
0xF3			Invalid
0xF5	0x00	1-100	Returns the white balance shift RED component.
0xF7	0x00	1-100	Returns the white balance shift BLUE component.
0xF9			Invalid
0xFB			Invalid
Other	0x00	0x00	Invalid

5.12 Original Command 9 (In-House Custom Parameter No. 9: DayNight Setting Ex)

An extended command unique to this specification. The checksum (CKSM) calculation is omitted from this chapter, as we have adopted the method outlined for Pelco-D in Chapter 3. New commands have been added for fine control of day/night parameters. *The command group described in Chapter 5.12 are available from version 1.60 (2021.10) of the firmware for both the SX800 and SX801. The existing day/night commands described in Chapter 5.4 have been retained following firmware version 1.60 for backward compatibility, but the settings for the existing commands are stored separately from those for the commands in this group.*

(0) Command sent:

Set the CKSM to the 8-bit sum of ADDR through DATA2.

(1) Response (General Response):

Set the CKSM to the 8-bit sum of ALARMS and the value returned for CKSM.

(2) Response (Extended Response):

Set the CKSM to the 8-bit sum of ADDR through DATA2.

(3) Response (Query Response):

Set the CKSM to the 8-bit sum of ADDR through DATA15 (*in-house custom parameter*).

(4) Response (Extended Response 2, an in-house custom parameter):

Set the CKSM to the 8-bit sum of ADDR through DATA2.

5.12.1 Set DayNight Mode

A command used to set the extended day/night mode.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x01	0x00	DN_MODE	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets DN_MODE.

■ DN_MODE arguments

DATA2	Description
0x00	AUTO
0x01	AUTO&SCHEDULED
0x02	SCHEDULED
0x03	DAY
0x04	NIGHT
Other	AUTO

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.2 Set Day to Night Threshold

A command used to set the threshold brightness for switching from day to night mode.

- Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x03	0x00	D2N_TH	—

- 1 . DATA1 is fixed at 0x00.
- 2 . DATA2 sets D2N_TH.

- D2N_TH arguments

DATA2	Description
0x00-0xFF	0 – 255

- Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.3 Set Night to Day Threshold

A command used to set the threshold brightness for switching from night to day mode.

- Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x05	0x00	N2D_TH	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets N2D_TH.

- N2D_TH arguments

DATA2	Description
0x00-0xFF	0 – 255

- Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.4 Set DayNight Auto Delay

A command used to set the delay (in seconds) for switching between day and night modes.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x07	0x00	AUTO_DELAY	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets AUTO_DELAY.

■ AUTO_DELAY arguments

DATA2	Description
0x00–0x3C	0–60
Other	7

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.5 Set Day Start Time

A command used to set the start time (SCHEDULED and AUTO&SCHEDULED) for day mode.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x09	DAYTIME_HH	DAYTIME_MM	—

1. DATA1 sets DAYTIME_HH.
2. DATA2 sets DAYTIME_MM.

■ DAYTIME_HH arguments

DATA2	Description
0x00–0x17	00–23
Other	07:00

■ DAYTIME_MM arguments

DATA2	Description
0x00–0x3B	00–59
Other	07:00

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.6 Set Night Start Time

A command used to set the start time (SCHEDULED and AUTO&SCHEDULED) for night mode.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x0B	NIGHTTIME_HH	NIGHTTIME_MM	—

1. DATA1 sets NIGHTTIME_HH.
2. DATA2 sets NIGHTTIME_MM.

■ NIGHTTIME_HH arguments

DATA2	Description
0x00–0x17	00–23
Other	17:00

■ NIGHTTIME_MM arguments

DATA2	Description
0x00–0x3B	00–59
Other	17:00

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.7 Set Optical Filter Day

A command used to set the optical filter for day mode.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x0D	0x00	OPT_DAY	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets OPT_DAY.

■ OPT_DAY arguments

DATA2	Description
0x00	IRC
0x01	VLC
Other	IRC

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.8 Set Optical Filter Night

A command used to set the optical filter for night mode.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x0F	0x00	OPT_NIGHT	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets OPT_NIGHT.

■ OPT_NIGHT arguments

DATA2	Description
0x00	CLEAR
0x01	VLC
Other	CLEAR

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.12.9 <Reserved>

5.12.10 Query DayNight Setting Ex (Query DayNight Setting Ex Response)

A command that returns extended day/night mode parameters.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x1D	—	0x00	—

- 1 . DATA1 is the CMND2 query target (see the table below).
- 2 . DATA2 is fixed at 0x00.

■ Receive command (Extended Response 2)

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x1F	—	—	—

- 1 . RESP1 sets 0xF1.
- 2 . RESP2 sets 0x1F.
- 3 . DATA1 and DATA2 are set to values corresponding to the requested content (see table below).

CMND2 set by send command	DATA1 returned to receiving command	DATA2 returned to receiving command	Description
0x01	0x00	0x00-0x04	Returns the extended day/night mode.
0x03	0x00	0x00-0xFF	The threshold brightness for switching from day to night mode.
0x05	0x00	0x00-0xFF	The threshold brightness for switching from night to day mode.
0x07	0x00	0x00-0x3C	The delay (in seconds) for switching between day and night modes.
0x09	0x00-0x17	0x00-0x3B	The start time (SCHEDULED and AUTO&SCHEDULED) for day mode.
0x0B	0x00-0x17	0x00-0x3B	The start time (SCHEDULED and AUTO&SCHEDULED) for night mode.
0x0D	0x00	0x00-0x01	Returns the optical filter for day mode.
0x0F	0x00	0x00-0x01	Returns the optical filter for night mode.
0x11			Invalid
0x13			Invalid
0x15			Invalid
0x17			Invalid
0x19			Invalid
0x1B			Invalid
Other	0x00	0x00	Invalid

5.13 Original Command 10 (In-House Custom Parameter No. 10: Zoom Focus Setting Ex)

An extended command unique to this specification. The checksum (CKSM) calculation is omitted from this chapter, as we have adopted the method outlined for Pelco-D in Chapter 3. New commands have been added for fine control of zoom and focus speed parameters. *The command group described in Chapter 5.13 are available from version 2.00 (2022.2) of the firmware for both the SX800 and SX801.*

(0) Command sent:

Set the CKSM to the 8-bit sum of ADDR through DATA2.

(1) Response (General Response):

Set the CKSM to the 8-bit sum of ALARMS and the value returned for CKSM.

(2) Response (Extended Response):

Set the CKSM to the 8-bit sum of ADDR through DATA2.

(3) Response (Query Response):

Set the CKSM to the 8-bit sum of ADDR through DATA15 (*in-house custom parameter*).

(4) Response (Extended Response 2, an in-house custom parameter):

Set the CKSM to the 8-bit sum of ADDR through DATA2.

5.13.1 Set Zoom Speed Ex

A command used to set the lens zoom speed.

- Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x25	0x00	Z_SPEED	—

1. DATA1 is fixed at 0x00.

2. DATA2 sets Z_SPEED.

- Z_SPEED arguments (time in seconds to go from widest angle to maximum zoom)

DATA2	Description	Values for existing command (5.2.1, "Set Zoom Speed") are now as follows
0x01	Approximately 4 seconds	0x03
0x02	Approximately 6 seconds	0x03
0x03	Approximately 8 seconds	0x02
0x04	Approximately 10 seconds	0x02
0x05	Approximately 12 seconds	0x01
0x06	Approximately 14 seconds	0x01
0x07	Approximately 16 seconds	0x00
0x08	Approximately 18 seconds	0x00
0x09	Approximately 20 seconds	0x00
0x0A	Approximately 22 seconds	0x00
Other	Handled as 0x01 (approximately 4 seconds)	0x03

- Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.13.2 Set Focus Speed Ex

A command used to set the lens focus speed.

- Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x27	0x00	F_SPEED	—

1. DATA1 is fixed at 0x00.

2. DATA2 sets F_SPEED.

- F_SPEED arguments (time in seconds to go from minimum to maximum focus distance)

DATA2	Description	Values for existing command (5.2.2, "Set Focus Speed") are now as follows
0x01	Approximately 4 seconds	0x03
0x02	Approximately 6 seconds	0x03
0x03	Approximately 8 seconds	0x02
0x04	Approximately 10 seconds	0x02
0x05	Approximately 12 seconds	0x01
0x06	Approximately 14 seconds	0x01
0x07	Approximately 16 seconds	0x00
0x08	Approximately 18 seconds	0x00
0x09	Approximately 20 seconds	0x00
0x0A	Approximately 22 seconds	0x00
Other	Handled as 0x01 (approximately 4 seconds)	0x03

- Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.13.3 Set Digital Zoom Ex

A command used to set the zoom ratio for digital zoom.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x21	0x00	DZ_MAG	—

1. DATA1 is fixed at 0x00.
2. DATA2 sets DZ_MAG.

■ DZ_MAG arguments

DATA2	Description	Notes
0x00	1.25×	Digital zoom is enabled and disabled via the existing command (F0 37).
0x01	1.50×	Ditto
0x02	1.75×	Ditto
0x03	2.00×	Ditto
Other	Handled as 0x00	Ditto

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.13.4 Query Zoom Focus Speed Setting Ex (Query Zoom Focus Setting Ex Response)

A command that returns the 10-step parameters for zoom/focus.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x2D	—	0x00	—

- 1 . DATA1 queries the setting for CMND2 (see table below).
- 2 . DATA2 is fixed at 0x00.

■ Receive command (Extended Response 2)

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF1	0x2F	—	—	—

- RESP1 sets 0xF1.
- RESP2 sets 0x2F.
- DATA1 and DATA2 are set to values corresponding to the requested content (see table below).

CMND2 set by send command	DATA1 returned to receiving command	DATA2 returned to receiving command	Description
0x21	0x00	0x00-0x03	Zoom ratio for digital zoom
0x23			Invalid
0x25	0x00	0x01-0x0A	Lens zoom speed
0x27	0x00	0x01-0x0A	Lens focus speed
0x29			Invalid
0x2B			Invalid
Other			Invalid

EOD

Appendix 1. Table of ZOOM Position vs Focal length for SX800/SX1 Var. 2.10 Digital ZOOM (Continued)												
Digital ZOOM (Continued)												
Lens		Field of View			Zone control			Motor Power			Vertical	
Focal Length	Vertical	Horizontal	Diagonal					Power	Focus	Shutter		
(mm)	(Degree)	(mm)	(mm)									
1	118.0	11.84	16.81	22.07	1	118.0	11.84	16.81	22.07	1	118.0	11.84
2	103.5	11.69	16.66	21.97	2	103.5	11.69	16.66	21.97	2	103.5	11.69
3	93.0	11.53	16.49	21.82	3	93.0	11.53	16.49	21.82	3	93.0	11.53
4	83.5	11.42	16.32	21.67	4	83.5	11.42	16.32	21.67	4	83.5	11.42
5	75.0	11.32	16.15	21.52	5	75.0	11.32	16.15	21.52	5	75.0	11.32
6	67.5	11.23	15.97	21.37	6	67.5	11.23	15.97	21.37	6	67.5	11.23
7	60.5	11.15	15.80	21.22	7	60.5	11.15	15.80	21.22	7	60.5	11.15
8	54.0	11.08	15.63	21.07	8	54.0	11.08	15.63	21.07	8	54.0	11.08
9	48.5	11.02	15.46	20.92	9	48.5	11.02	15.46	20.92	9	48.5	11.02
10	43.5	10.97	15.29	20.77	10	43.5	10.97	15.29	20.77	10	43.5	10.97
11	39.0	10.93	15.12	20.62	11	39.0	10.93	15.12	20.62	11	39.0	10.93
12	35.0	10.89	14.95	20.47	12	35.0	10.89	14.95	20.47	12	35.0	10.89
13	31.5	10.86	14.78	20.32	13	31.5	10.86	14.78	20.32	13	31.5	10.86
14	28.5	10.83	14.61	20.17	14	28.5	10.83	14.61	20.17	14	28.5	10.83
15	26.0	10.81	14.44	20.02	15	26.0	10.81	14.44	20.02	15	26.0	10.81
16	23.5	10.79	14.27	19.87	16	23.5	10.79	14.27	19.87	16	23.5	10.79
17	21.5	10.77	14.10	19.72	17	21.5	10.77	14.10	19.72	17	21.5	10.77
18	19.5	10.75	13.93	19.57	18	19.5	10.75	13.93	19.57	18	19.5	10.75
19	17.5	10.73	13.76	19.42	19	17.5	10.73	13.76	19.42	19	17.5	10.73
20	15.5	10.71	13.59	19.27	20	15.5	10.71	13.59	19.27	20	15.5	10.71
21	13.5	10.69	13.42	19.12	21	13.5	10.69	13.42	19.12	21	13.5	10.69
22	11.5	10.67	13.25	18.97	22	11.5	10.67	13.25	18.97	22	11.5	10.67
23	9.5	10.65	13.08	18.82	23	9.5	10.65	13.08	18.82	23	9.5	10.65
24	7.5	10.63	12.91	18.67	24	7.5	10.63	12.91	18.67	24	7.5	10.63
25	5.5	10.61	12.74	18.52	25	5.5	10.61	12.74	18.52	25	5.5	10.61
26	3.5	10.59	12.57	18.37	26	3.5	10.59	12.57	18.37	26	3.5	10.59
27	1.5	10.57	12.40	18.22	27	1.5	10.57	12.40	18.22	27	1.5	10.57
28	-0.5	10.55	12.23	18.07	28	-0.5	10.55	12.23	18.07	28	-0.5	10.55
29	-2.5	10.53	12.06	17.92	29	-2.5	10.53	12.06	17.92	29	-2.5	10.53
30	-4.5	10.51	11.89	17.77	30	-4.5	10.51	11.89	17.77	30	-4.5	10.51
31	-6.5	10.49	11.72	17.62	31	-6.5	10.49	11.72	17.62	31	-6.5	10.49
32	-8.5	10.47	11.55	17.47	32	-8.5	10.47	11.55	17.47	32	-8.5	10.47
33	-10.5	10.45	11.38	17.32	33	-10.5	10.45	11.38	17.32	33	-10.5	10.45
34	-12.5	10.43	11.21	17.17	34	-12.5	10.43	11.21	17.17	34	-12.5	10.43
35	-14.5	10.41	11.04	17.02	35	-14.5	10.41	11.04	17.02	35	-14.5	10.41
36	-16.5	10.39	10.87	16.87	36	-16.5	10.39	10.87	16.87	36	-16.5	10.39
37	-18.5	10.37	10.70	16.72	37	-18.5	10.37	10.70	16.72	37	-18.5	10.37
38	-20.5	10.35	10.53	16.57	38	-20.5	10.35	10.53	16.57	38	-20.5	10.35
39	-22.5	10.33	10.36	16.42	39	-22.5	10.33	10.36	16.42	39	-22.5	10.33
40	-24.5	10.31	10.19	16.27	40	-24.5	10.31	10.19	16.27	40	-24.5	10.31
41	-26.5	10.29	10.02	16.12	41	-26.5	10.29	10.02	16.12	41	-26.5	10.29
42	-28.5	10.27	9.85	15.97	42	-28.5	10.27	9.85	15.97	42	-28.5	10.27
43	-30.5	10.25	9.68	15.82	43	-30.5	10.25	9.68	15.82	43	-30.5	10.25
44	-32.5	10.23	9.51	15.67	44	-32.5	10.23	9.51	15.67	44	-32.5	10.23
45	-34.5	10.21	9.34	15.52	45	-34.5	10.21	9.34	15.52	45	-34.5	10.21
46	-36.5	10.19	9.17	15.37	46	-36.5	10.19	9.17	15.37	46	-36.5	10.19
47	-38.5	10.17	9.00	15.22	47	-38.5	10.17	9.00	15.22	47	-38.5	10.17
48	-40.5	10.15	8.83	15.07	48	-40.5	10.15	8.83	15.07	48	-40.5	10.15
49	-42.5	10.13	8.66	14.92	49	-42.5	10.13	8.66	14.92	49	-42.5	10.13
50	-44.5	10.11	8.49	14.77	50	-44.5	10.11	8.49	14.77	50	-44.5	10.11
51	-46.5	10.09	8.32	14.62	51	-46.5	10.09	8.32	14.62	51	-46.5	10.09
52	-48.5	10.07	8.15	14.47	52	-48.5	10.07	8.15	14.47	52	-48.5	10.07
53	-50.5	10.05	7.98	14.32	53	-50.5	10.05	7.98	14.32	53	-50.5	10.05
54	-52.5	10.03	7.81	14.17	54	-52.5	10.03	7.81	14.17	54	-52.5	10.03
55	-54.5	10.01	7.64	14.02	55	-54.5	10.01	7.64	14.02	55	-54.5	10.01
56	-56.5	0.99	7.47	13.87	56	-56.5	0.99	7.47	13.87	56	-56.5	0.99
57	-58.5	0.97	7.30	13.72	57	-58.5	0.97	7.30	13.72	57	-58.5	0.97

Appendix 1. Table of ZOOM Position vs Focal length for SX800 FW Ver 2.10 Digital ZOOM (Extended)

Motor Pulse Length	Field of View				Digital ZOOM (Extended)			
	Vertical	Horizontal	Diagonal		SetAbsoluteZoomPosition	GetAbsoluteZoomPosition	SetZoomControl	GetZoomControl
Steps (mm)					[DEC]	[HEX]	[DEC]	[HEC]
1	20.0	11.847	20.974	24.017	0	0	1	
2	20.0	11.847	20.974	24.017	0	0	0	0.000
3	20.0	11.495	20.349	23.300	0	0	0	0.010
4	20.0	11.321	20.051	22.942	0	0	0	0.015
5	20.0	11.148	19.846	22.477	0	0	0	0.020
6	22.0	10.972	19.418	22.231	0	0	0	0.025
7	22.0	10.972	19.418	22.231	0	0	0	0.026
8	22.0	10.584	19.729	21.440	0	0	0	0.036
9	22.0	10.414	19.428	21.993	0	0	0	0.041
10	22.0	10.356	19.555	20.323	0	0	0	0.045
11	24.0	10.035	17.555	20.323	0	0	0	0.051
12	25.0	9.669	17.022	19.574	0	0	0	0.057
13	25.0	9.669	17.022	19.574	0	0	0	0.060
14	25.0	9.465	16.748	19.168	0	0	0	0.066
15	25.0	9.380	16.588	18.900	0	0	0	0.070
16	25.0	9.083	16.061	18.380	0	0	0	0.081
17	25.0	8.979	15.760	18.001	0	0	0	0.082
18	25.0	8.979	15.760	18.001	0	0	0	0.083
19	25.0	8.528	15.097	17.214	0	0	0	0.097
20	25.0	8.174	14.447	16.830	0	0	0	0.103
21	25.0	8.174	14.447	16.830	0	0	0	0.103
22	28.0	7.987	14.116	16.151	0	0	0	0.108
23	28.0	7.987	14.116	16.151	0	0	0	0.108
24	28.0	7.871	13.856	15.359	0	0	0	0.118
25	28.0	7.871	13.856	15.359	0	0	0	0.118
26	28.0	7.727	13.600	14.883	0	0	0	0.128
27	28.0	7.221	12.640	14.937	0	0	0	0.133
28	28.0	6.941	12.284	14.630	0	0	0	0.143
29	28.0	6.941	12.284	14.630	0	0	0	0.143
30	28.0	6.822	11.953	13.760	0	0	0	0.148
31	28.0	6.452	11.345	13.044	0	0	0	0.159
32	28.0	6.174	10.744	12.442	0	0	0	0.169
33	28.0	6.174	10.744	12.442	0	0	0	0.169
34	28.0	6.285	10.020	12.608	0	0	0	0.174
35	28.0	6.285	10.020	12.608	0	0	0	0.174
36	28.0	6.033	9.667	12.204	0	0	0	0.185
37	28.0	6.033	9.667	12.204	0	0	0	0.185
38	28.0	5.925	9.473	11.833	0	0	0	0.185
39	28.0	5.925	9.473	11.833	0	0	0	0.185
40	41.0	5.726	10.121	11.580	0	0	0	0.200
41	41.0	5.726	10.121	11.580	0	0	0	0.200
42	42.0	5.521	9.769	11.168	0	0	0	0.210
43	42.0	5.521	9.769	11.168	0	0	0	0.210
44	42.0	5.411	9.545	10.945	0	0	0	0.215
45	42.0	5.411	9.545	10.945	0	0	0	0.215
46	42.0	5.197	9.211	10.540	0	0	0	0.225
47	42.0	5.197	9.211	10.540	0	0	0	0.225
48	42.0	5.065	8.987	10.348	0	0	0	0.235
49	42.0	5.065	8.987	10.348	0	0	0	0.235
50	42.0	4.876	8.647	10.044	0	0	0	0.245
51	42.0	4.876	8.647	10.044	0	0	0	0.245
52	42.0	4.685	8.344	9.537	0	0	0	0.251
53	42.0	4.685	8.344	9.537	0	0	0	0.251
54	42.0	4.470	8.044	9.050	0	0	0	0.261
55	42.0	4.470	8.044	9.050	0	0	0	0.261
56	42.0	4.282	7.749	8.558	0	0	0	0.271
57	42.0	4.282	7.749	8.558	0	0	0	0.271
58	42.0	4.075	7.403	8.245	0	0	0	0.281
59	42.0	4.075	7.403	8.245	0	0	0	0.281
60	42.0	3.882	7.095	7.956	0	0	0	0.291
61	42.0	3.882	7.095	7.956	0	0	0	0.291
62	42.0	3.692	6.795	7.656	0	0	0	0.301
63	42.0	3.692	6.795	7.656	0	0	0	0.301
64	42.0	3.505	6.495	7.356	0	0	0	0.311
65	42.0	3.505	6.495	7.356	0	0	0	0.311
66	42.0	3.310	6.195	7.056	0	0	0	0.321
67	42.0	3.310	6.195	7.056	0	0	0	0.321
68	42.0	3.120	5.895	6.756	0	0	0	0.331
69	42.0	3.120	5.895	6.756	0	0	0	0.331
70	42.0	2.935	5.595	6.456	0	0	0	0.341
71	42.0	2.935	5.595	6.456	0	0	0	0.341
72	42.0	2.745	5.295	6.116	0	0	0	0.351
73	42.0	2.745	5.295	6.116	0	0	0	0.351
74	42.0	2.555	4.995	5.856	0	0	0	0.361
75	42.0	2.555	4.995	5.856	0	0	0	0.361
76	42.0	2.370	4.695	5.516	0	0	0	0.371
77	42.0	2.370	4.695	5.516	0	0	0	0.371
78	42.0	2.180	4.395	5.236	0	0	0	0.381
79	42.0	2.180	4.395	5.236	0	0	0	0.381
80	42.0	2.000	4.095	4.917	0	0	0	0.391
81	42.0	2.000	4.095	4.917	0	0	0	0.391
82	42.0	1.810	3.795	4.638	0	0	0	0.401
83	42.0	1.810	3.795	4.638	0	0	0	0.401
84	42.0	1.620	3.495	4.380	0	0	0	0.411
85	42.0	1.620	3.495	4.380	0	0	0	0.411
86	42.0	1.430	3.195	4.021	0	0	0	0.421
87	42.0	1.430	3.195	4.021	0	0	0	0.421
88	42.0	1.240	2.895	3.726	0	0	0	0.431
89	42.0	1.240	2.895	3.726	0	0	0	0.431
90	42.0	1.050	2.595	3.426	0	0	0	0.441
91	42.0	1.050	2.595	3.426	0	0	0	0.441

Appendix 2. Table of FOCUS Position vs Subject distance for SX800/801 FW Ver. 2.10 and later

1. Precision Control Commands

Corresponding commands	SX800	SX801	Commands									
	Pelco		Set Zoom Position (0x00.0x4F) Query Zoom Position (0x00.0x83)									
	CGI		SetAbsoluteZoomPosition GetAbsoluteZoomPosition									
	SDK		FF.NET_SetAbsoluteZoomPosition FF.Net_GetAbsoluteZoomPosition									

Digital Zoom Extended

Focal Length(Digital Zoom OFF)	mm	20	32	51	82	132	212	341	548	800		
Focal Length (x1.25)	mm	25	40	64	103	165	265	426	685	1000		
Focal Length (x1.50)	mm	30	48	77	123	198	318	512	822	1200		
Focal Length (x1.75)	mm	35	56	89	144	231	371	597	959	1400		
Focal Length (x2.00)	mm	40	64	102	164	264	424	682	1096	1600		
Zoom Position	HEX	0000	20D2	41A4	6276	8348	A41A	C4EC	E5BD	FFFF		
Control Resolution *	Pulse	14	35	87	219	550	1378	3458	6605	9571		
Focus Position [HEX]												
Over near	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000		
10	7DD4	7943	6FE6	5FC5	4A47	3611	2837					
12	7F46	7BF5	7501	6932	592C	49B7	3F10					
14	803D	7E34	78EE	7168	667A	5BF4	5439	273E				
17	8134	7FFF	7D40	79EB	74FA	6FE4	6ADE	460F				
20	81AF	8158	80C9	7FFF	7E82	7CF5	7B42	5B4E	2B0E			
24	822B	82B1	83ED	85C6	880B	89C5	8AA1	7024	43E6			
28	82A6	8397	85E3	8A08	8E98	92FF	95A5	7EC9	578B			
33	8322	847D	87DA	8DAE	94C0	9B77	9FAF	8C65	6A01			
40		8563	89D0	9154	9AE9	A3D3	A9AC	99D6	7C49			
47	839D	8649	8AFE	93C3	9F47	A9C1	B0B1	A346	8924			
56		86BC	8C2B	9631	A30D	A39	B726	ABF2	950A			
67	8419	872F	8D59	9852	A66D	B3E4	BCBB	B380	9E50			
79			8E22	89D7	A935	B77A	C116	B95D	A740			
94		87A2	8E87	9B5C	AB64	ABBB	C4EE	BE92	86BC			
110		8815	8F50	9C46	AD2E	BD3B	C7E6	D099	286C			
130	8494		8FB4	9D2F	AEC5	BF66	CA90	C635	B8CB			
160			9019	9E67	B08E	C1AE	CD54	C9F2	BDEB			
190		8888	907D	9F02	B18D	C34F	CF47	CC89	C170			
220			90E2	9F9E	B28B	C481	D0A9	CE64	C401			
270		9146	A03A	B389	C5CE	D24D	D099	C702				
320			A088	B421	C6C8	D37A	D227	C914				
380			AUD5	B45A	C7A7	D466	D37D	CAD8				
450		91AB	A123	B520	C84D	D538	D495	CC5E				
530			A171	B585	C8D8	D5E3	D57B	CD9F				
630				B5E5	C963	D680	D64C	CEBC				
750			A1BF	B651	C9B7	D6F6	D6FB	CFAC				
890		920F		B684	C426	D76C	D78D	D078				
1,100			A20D	B686	C479	D7D5	D820	D148				
1,300			B6E9	CAB1	D817	D817	D882	D1CB				
1,500			B71C	CACD	D84B	D8C8	D22F					
1,800			A25B	C804	D87F	D914	D29B					
2,100			B74F	C820	D8B4	D94C	D2E4					
2,500				B83C	D8CE	D97D	D32C					
3,000				B858	D8F5	D9AE	D370					
3,500			B782	CB73	D910	D9D1	D39D					
4,200				B88F	D92A	D92A	D9ED	D3CB				
5,000					D937	DA09	D3EF					
6,000				CBAB	D944	DATE	D40F					
7,100					D951	DA33	D425					
8,400					D95E	DA41	D43C					
Inf	850F	896E	9274	A2A8	B7B5	CBC7	D96C	DA4F	D44E			
Over inf	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF	FFFF			

2. Rough Control Commands

Corresponding commands	SX800	SX801	Commands	
	OnVIF Preset		Function ID 5.6 ; 1 or 8 step(s) move for near side	
	CGI		Function ID 7.8 ; 1 or 8 step(s) move for far side	
	SDK		FF.NET_SetFocus (1 step move with MOD1 or INF1)	

Digital Zoom OFF and ON

Argument	Focus Position	
	[DEC]	[HEX]
1	0	0000
2	3449	0D79
3	6898	1AF2
4	10348	286C
5	13797	35E5
6	17246	435E
7	20695	50D7
8	24144	5E50
9	27594	6BCA
10	31043	7943
11	34492	86BC
12	37941	9435
13	41391	A1AF
14	44840	AF28
15	48289	BCA1
16	51738	CA1A
17	55187	D793
18	58637	E50D
19	62086	F286
20	65535	FFFF

Digital Zoom Continuous

Focal Length	mm	20	32	51	82	132	212	341	548	800	1000	1200	1400	1600

<