

Reference No. : *CLP011 rev-F*

Date: *December 8, 2018*

Subject: *Oce' Lightjet Recommended Starting Values for FUJIFILM Papers*

The calibration targets for all the FUJICOLOR Crystal Archive Professional Papers and Printing Materials for the OCE Light Jet 430, 500XL and 5000 printers can be downloaded from the following URL (website).

https://dgs.oce.com/PrinterSupport/LJ_Customer_Access/LJ430_Cust_index.htm

Paper Type	Dmax R	Dmax G	Dmax B
FUJICOLOR Crystal Archive Professional Maxima	2.70	2.60	2.45
FUJICOLOR Crystal Archive Super Type CN	2.40	2.38	2.35
FUJICOLOR Crystal Archive Super Type PDN	2.40	2.38	2.35
FUJICOLOR Crystal Archive Digital Pearl	2.45	2.40	2.37
FUJICOLOR Crystal Archive Deep Matte/Velvet ¹	1.50	1.50	1.50
FUJICOLOR Crystal Archive Super Type P	2.00	2.05	2.00
FUJICOLOR Crystal Archive Album <i>Lustre</i>	2.05	2.05	2.00
FUJICOLOR Crystal Archive Album HD Paper	2.20	2.20	2.20
FUJICOLOR Crystal Archive Textured Paper – <i>Thick Glossy</i> ²	2.40	2.38	2.35
FUJICOLOR Crystal Archive Textured Paper – <i>Thin Canvas Glossy</i>	2.15	2.15	2.05
FUJICOLOR Crystal Archive Textured Paper – <i>Canvas Matte</i>	1.50	1.50	1.50
FUJICOLOR Crystal Archive Quality Paper Digital Pro	2.25	2.25	2.20
FUJIFLEX Crystal Archive Printing Material	2.50	2.45	2.40
FUJITRANS Crystal Archive Display Material ³	3.25	3.25	3.35
FUJICLEAR Crystal Archive Display Material ³	3.25	3.20	3.05

¹ Fujifilm Deep Matte balancing kit required

² Canvas and Linen textures; use FUJICOLOR Super Type CN target

³ Development Time: 1 minute 50 seconds (Densities measured with status A transmission densitometer filters)