

UVIVID 800 TRANSLUCENT

Fujifilm Formulation Guide

Version 1.0
Base Colors
No White

UVividTM 800

UV Narrow Web Printing Inks

Translucent Matching System

This booklet furnishes the necessary formulas to simulate all the colors in the PANTONE® Color Guide. The formulations used in this guide are hand matched and/or predictive simulations of the PANTONE®* references using UVivid 800 Series UV Flexo colors. The printed formulas were achieved using an IGT C1-5 Proofing Machine to duplicate a 440 anilox, printed onto Leneta Card Stock. The printed formulas were viewed in daylight (D65).

Each Base Color has been carefully selected for its cleanliness of tone and suitability for intermixing. In addition, each ink has been formulated to be free of lead and other heavy metals.

Although every care is taken in producing these formulations, variations in substrates and printing conditions may affect the color achieved. Fujifilm assumes no responsibility for actual color achieved versus the Pantone standard print. For this reason, all formulations must be proofed prior to a production run to ensure color accuracy.

All formulations are percentages by weight using the following UVivid 800 UV Flexo colors:

DESCRIPTION	
800-021 Orange EL	800-180 Warm Red
800-064 Yellow GS	800-190 Process Blue EL
800-127 Violet EL	800-205 Reflex Blue
800-155 Rubine	800-325 Green EL
800-160 Rhodamine	800-MX Mixing Clear
800-175 Purple	800-SB Shading Black

Fujifilm's color mixing ink formulations for screen process printing produce only simulations of PANTONE Colors in this color reproduction method due to differences in ink film, opacity and pigment selection. The selection used in blending inks may cause metamerism. Pantone, Inc. assumes no responsibility for formula accuracy.

*PANTONE® is the property of Pantone Inc.

UVivid 800 Translucent

PANTONE Yellow C UV 800-064 100.00	Formula	PANTONE Yellow 012 C UV 800-064 98.50 UV 800-021 1.50	Formula	PANTONE Orange 021 C UV 800-021 100.00	Formula	PANTONE Warm Red C UV 800-180 80.00 UV 800-LVX 20.00	Formula
PANTONE Red 032 C UV 800-180 65.04 UV 800-LVX 27.80 UV 800-155 7.16	Formula	PANTONE Rubine Red C UV 800-155 79.96 UV 800-LVX 19.29 UV 800-127 0.75	Formula	PANTONE Rhodamine Red C UV 800-160 100.00	Formula	PANTONE Purple C UV 800-175 77.23 UV 800-LVX 22.77	Formula
PANTONE Violet C UV 800-175 87.21 UV 800-205 12.79	Formula	PANTONE Blue 072 C UV 800-190 41.50 UV 800-205 35.90 UV 800-127 22.60	Formula	PANTONE Reflex Blue C UV 800-205 100.00	Formula	PANTONE Process Blue C UV 800-190 100.00	Formula
PANTONE Green C UV 800-325 100.00	Formula	PANTONE Black C UV 800-SB 100.00	Formula	PANTONE 100 C UV 800-LVX 84.79 UV 800-064 15.21	Formula	PANTONE 101 C UV 800-LVX 74.76 UV 800-064 25.24	Formula

UVivid 800 Translucent

PANTONE 102 C UV 800-064 71.04 UV 800-LVX 28.96	Formula	PANTONE 103 C UV 800-064 94.67 UV 800-SB 3.36 UV 800-021 1.97	Formula	PANTONE 104 C UV 800-064 92.01 UV 800-SB 6.27 UV 800-021 1.72	Formula	PANTONE 105 C UV 800-064 49.06 UV 800-LVX 38.34 UV 800-SB 12.60	Formula
PANTONE 106 C UV 800-LVX 71.14 UV 800-064 28.02 UV 800-021 0.84	Formula	PANTONE 107 C UV 800-LVX 52.50 UV 800-064 46.50 UV 800-021 1.00	Formula	PANTONE 108 C UV 800-064 84.55 UV 800-LVX 13.55 UV 800-021 1.90	Formula	PANTONE 109 C UV 800-064 98.00 UV 800-180 2.00	Formula
PANTONE 110 C UV 800-064 87.23 UV 800-021 8.44 UV 800-LVX 2.31 UV 800-SB 2.02	Formula	PANTONE 111 C UV 800-064 76.73 UV 800-LVX 9.57 UV 800-SB 7.72 UV 800-021 5.98	Formula	PANTONE 112 C UV 800-064 63.10 UV 800-LVX 22.71 UV 800-SB 10.16 UV 800-021 4.03	Formula	PANTONE 113 C UV 800-LVX 67.95 UV 800-064 31.40 UV 800-180 0.65	Formula
PANTONE 114 C UV 800-LVX 60.04 UV 800-064 39.13 UV 800-180 0.83	Formula	PANTONE 115 C UV 800-LVX 54.92 UV 800-064 44.06 UV 800-180 1.02	Formula	PANTONE 116 C UV 800-064 97.56 UV 800-180 2.44	Formula	PANTONE 117 C UV 800-064 85.06 UV 800-LVX 7.53 UV 800-180 4.01 UV 800-SB 3.40	Formula

UVivid 800 Translucent

PANTONE 118 C UV 800-064 75.71 UV 800-LVX 14.69 UV 800-SB 6.06 UV 800-180 3.54	Formula	PANTONE 119 C UV 800-064 48.16 UV 800-LVX 38.35 UV 800-SB 12.15 UV 800-180 1.34	Formula	PANTONE 120 C UV 800-LVX 78.18 UV 800-064 20.85 UV 800-180 0.97	Formula	PANTONE 121 C UV 800-LVX 71.71 UV 800-064 27.10 UV 800-180 1.19	Formula
PANTONE 122 C UV 800-LVX 61.08 UV 800-064 34.30 UV 800-021 4.62	Formula	PANTONE 123 C UV 800-064 87.76 UV 800-180 4.00 UV 800-LVX 8.24	Formula	PANTONE 124 C UV 800-064 65.71 UV 800-LVX 28.94 UV 800-180 4.40 UV 800-SB 0.95	Formula	PANTONE 125 C UV 800-064 76.29 UV 800-LVX 12.64 UV 800-180 5.56 UV 800-SB 5.51	Formula
PANTONE 126 C UV 800-064 64.33 UV 800-LVX 22.83 UV 800-SB 8.45 UV 800-180 4.39	Formula	PANTONE 1205 C UV 800-LVX 90.43 UV 800-064 8.84 UV 800-180 0.73	Formula	PANTONE 1215 C UV 800-LVX 81.72 UV 800-064 16.96 UV 800-180 1.32	Formula	PANTONE 1225 C UV 800-LVX 58.46 UV 800-064 38.54 UV 800-180 3.00	Formula
PANTONE 1235 C UV 800-064 78.10 UV 800-180 8.10 UV 800-LVX 13.80	Formula	PANTONE 1245 C UV 800-064 58.26 UV 800-LVX 32.08 UV 800-180 5.74 UV 800-SB 3.92	Formula	PANTONE 1255 C UV 800-064 50.66 UV 800-LVX 37.78 UV 800-SB 6.70 UV 800-180 4.86	Formula	PANTONE 1265 C UV 800-064 46.78 UV 800-LVX 35.23 UV 800-SB 13.42 UV 800-180 4.57	Formula

UVivid 800 Translucent

PANTONE 127 C UV 800-LVX 80.85 UV 800-064 18.57 UV 800-155 0.58	Formula	PANTONE 128 C UV 800-LVX 69.84 UV 800-064 29.26 UV 800-155 0.90	Formula	PANTONE 129 C UV 800-LVX 64.57 UV 800-064 34.26 UV 800-155 1.17	Formula	PANTONE 130 C UV 800-064 97.00 UV 800-155 3.00	Formula
PANTONE 131 C UV 800-064 91.11 UV 800-155 5.23 UV 800-SB 1.88 UV 800-LVX 1.78	Formula	PANTONE 132 C UV 800-064 81.55 UV 800-SB 6.85 UV 800-LVX 6.73 UV 800-155 4.87	Formula	PANTONE 133 C UV 800-064 54.57 UV 800-LVX 23.58 UV 800-SB 19.11 UV 800-155 2.74	Formula	PANTONE 134 C UV 800-LVX 80.23 UV 800-064 17.75 UV 800-180 2.02	Formula
PANTONE 135 C UV 800-LVX 67.36 UV 800-064 29.50 UV 800-180 3.14	Formula	PANTONE 136 C UV 800-LVX 55.13 UV 800-064 40.38 UV 800-180 4.49	Formula	PANTONE 137 C UV 800-064 90.02 UV 800-180 9.98	Formula	PANTONE 138 C UV 800-064 83.88 UV 800-180 14.29 UV 800-SB 1.83	Formula
PANTONE 139 C UV 800-064 76.98 UV 800-180 11.99 UV 800-SB 6.50 UV 800-LVX 4.53	Formula	PANTONE 140 C UV 800-064 51.01 UV 800-LVX 25.53 UV 800-SB 16.83 UV 800-180 6.63	Formula	PANTONE 1345 C UV 800-LVX 87.23 UV 800-064 10.52 UV 800-180 2.25	Formula	PANTONE 1355 C UV 800-LVX 79.67 UV 800-064 16.84 UV 800-180 3.49	Formula

UVivid 800 Translucent

PANTONE 1365 C UV 800-LVX 62.87 UV 800-064 31.50 UV 800-180 5.63	Formula	PANTONE 1375 C UV 800-064 58.00 UV 800-180 12.00 UV 800-LVX 30.00	Formula	PANTONE 1385 C UV 800-064 69.94 UV 800-180 15.15 UV 800-LVX 12.24 UV 800-SB 2.67	Formula	PANTONE 1395 C UV 800-064 62.74 UV 800-180 13.55 UV 800-LVX 13.30 UV 800-SB 10.41	Formula
PANTONE 1405 C UV 800-064 44.83 UV 800-LVX 26.47 UV 800-SB 20.15 UV 800-180 8.55	Formula	PANTONE 141 C UV 800-LVX 76.78 UV 800-064 21.52 UV 800-155 1.70	Formula	PANTONE 142 C UV 800-LVX 60.62 UV 800-064 36.82 UV 800-155 2.56	Formula	PANTONE 143 C UV 800-064 48.94 UV 800-LVX 47.72 UV 800-155 3.34	Formula
PANTONE 144 C UV 800-064 83.65 UV 800-155 8.89 UV 800-LVX 7.46	Formula	PANTONE 145 C UV 800-064 82.96 UV 800-155 8.39 UV 800-LVX 7.25 UV 800-SB 1.40	Formula	PANTONE 146 C UV 800-064 81.75 UV 800-155 8.34 UV 800-SB 6.26 UV 800-LVX 3.65	Formula	PANTONE 147 C UV 800-064 40.84 UV 800-LVX 38.85 UV 800-SB 17.15 UV 800-155 3.16	Formula
PANTONE 148 C UV 800-LVX 89.31 UV 800-064 8.21 UV 800-180 2.48	Formula	PANTONE 149 C UV 800-LVX 80.87 UV 800-064 15.19 UV 800-180 3.94	Formula	PANTONE 150 C UV 800-LVX 61.86 UV 800-064 31.04 UV 800-180 7.10	Formula	PANTONE 151 C UV 800-064 75.00 UV 800-180 25.00	Formula

UVivid 800 Translucent

PANTONE 152 C UV 800-064 74.16 UV 800-180 18.75 UV 800-LVX 5.67 UV 800-SB 1.42	Formula	PANTONE 153 C UV 800-064 66.93 UV 800-180 17.03 UV 800-LVX 10.96 UV 800-SB 5.08	Formula	PANTONE 154 C UV 800-064 65.69 UV 800-180 17.12 UV 800-SB 10.45 UV 800-LVX 6.74	Formula	PANTONE 1485 C UV 800-LVX 79.25 UV 800-021 20.75	Formula
PANTONE 1495 C UV 800-LVX 54.21 UV 800-021 45.79	Formula	PANTONE 1505 C UV 800-021 86.88 UV 800-LVX 13.12	Formula	PANTONE 1525 C UV 800-021 77.08 UV 800-LVX 18.93 UV 800-SB 3.99	Formula	PANTONE 1535 C UV 800-021 61.88 UV 800-LVX 27.69 UV 800-SB 10.43	Formula
PANTONE 1545 C UV 800-LVX 39.05 UV 800-021 37.13 UV 800-SB 23.82	Formula	PANTONE 155 C UV 800-LVX 92.80 UV 800-064 5.98 UV 800-155 1.22	Formula	PANTONE 156 C UV 800-LVX 84.10 UV 800-064 13.41 UV 800-155 2.49	Formula	PANTONE 157 C UV 800-LVX 60.16 UV 800-064 34.09 UV 800-155 5.75	Formula
PANTONE 158 C UV 800-064 85.37 UV 800-155 14.63	Formula	PANTONE 159 C UV 800-064 82.98 UV 800-155 15.37 UV 800-SB 1.65	Formula	PANTONE 160 C UV 800-064 77.45 UV 800-155 16.08 UV 800-SB 6.47	Formula	PANTONE 161 C UV 800-064 67.59 UV 800-SB 21.66 UV 800-155 10.75	Formula

UVivid 800 Translucent

PANTONE 1555 C UV 800-LVX 86.41 UV 800-064 10.34 UV 800-155 3.25	Formula	PANTONE 1565 C UV 800-LVX 67.42 UV 800-064 26.41 UV 800-155 6.17	Formula	PANTONE 1575 C UV 800-064 70.91 UV 800-LVX 18.43 UV 800-155 10.66	Formula	PANTONE 1585 C UV 800-064 50.00 UV 800-180 36.00 UV 800-LVX 14.00	Formula
PANTONE 1595 C UV 800-064 66.91 UV 800-LVX 19.17 UV 800-155 13.92	Formula	PANTONE 1605 C UV 800-064 66.55 UV 800-155 14.87 UV 800-LVX 13.93 UV 800-SB 4.65	Formula	PANTONE 1615 C UV 800-064 72.52 UV 800-155 15.55 UV 800-SB 9.11 UV 800-LVX 2.82	Formula	PANTONE 162 C UV 800-LVX 91.48 UV 800-064 4.03 UV 800-180 4.49	Formula
PANTONE 163 C UV 800-LVX 74.53 UV 800-064 14.07 UV 800-180 11.40	Formula	PANTONE 164 C UV 800-LVX 46.41 UV 800-064 34.15 UV 800-180 19.44	Formula	PANTONE 165 C UV 800-064 56.20 UV 800-180 43.80	Formula	PANTONE 166 C UV 800-064 56.42 UV 800-180 29.98 UV 800-LVX 12.27 UV 800-SB 1.33	Formula
PANTONE 167 C UV 800-064 55.31 UV 800-180 27.35 UV 800-LVX 12.75 UV 800-SB 4.59	Formula	PANTONE 168 C UV 800-064 52.41 UV 800-180 20.31 UV 800-SB 19.22 UV 800-LVX 8.06	Formula	PANTONE 1625 C UV 800-LVX 85.85 UV 800-180 9.25 UV 800-064 4.90	Formula	PANTONE 1635 C UV 800-LVX 72.62 UV 800-180 15.07 UV 800-064 12.31	Formula

UVivid 800 Translucent

PANTONE 1645 C UV 800-LVX 39.21 UV 800-064 33.24 UV 800-180 27.55	Formula	PANTONE 1655 C UV 800-064 50.00 UV 800-180 50.00	Formula	PANTONE 1665 C UV 800-064 61.18 UV 800-180 37.23 UV 800-SB 1.59	Formula	PANTONE 1675 C UV 800-064 44.86 UV 800-180 28.91 UV 800-LVX 18.82 UV 800-SB 7.41	Formula
PANTONE 1685 C UV 800-064 41.08 UV 800-180 23.91 UV 800-LVX 21.44 UV 800-SB 13.57	Formula	PANTONE 169 C UV 800-LVX 94.05 UV 800-180 5.95	Formula	PANTONE 170 C UV 800-LVX 78.03 UV 800-180 16.93 UV 800-064 5.04	Formula	PANTONE 171 C UV 800-LVX 40.62 UV 800-180 34.68 UV 800-064 24.70	Formula
PANTONE 172 C UV 800-180 62.39 UV 800-064 29.06 UV 800-LVX 8.55	Formula	PANTONE 173 C UV 800-064 39.99 UV 800-180 35.89 UV 800-LVX 21.52 UV 800-SB 2.60	Formula	PANTONE 174 C UV 800-064 49.65 UV 800-180 32.98 UV 800-SB 10.13 UV 800-LVX 7.24	Formula	PANTONE 175 C UV 800-064 30.31 UV 800-LVX 29.92 UV 800-180 19.89 UV 800-SB 19.88	Formula
PANTONE 176 C UV 800-LVX 93.05 UV 800-180 6.95	Formula	PANTONE 177 C UV 800-LVX 81.81 UV 800-180 18.19	Formula	PANTONE 178 C UV 800-LVX 64.61 UV 800-180 35.39	Formula	PANTONE 179 C UV 800-180 75.13 UV 800-LVX 23.57 UV 800-SB 1.30	Formula

UVivid 800 Translucent

PANTONE 180 C UV 800-180 70.42 UV 800-LVX 25.19 UV 800-SB 4.39	Formula	PANTONE 181 C UV 800-180 48.03 UV 800-LVX 37.06 UV 800-SB 14.91	Formula	PANTONE 1765 C UV 800-LVX 92.19 UV 800-180 3.97 UV 800-155 3.84	Formula	PANTONE 1775 C UV 800-LVX 88.62 UV 800-180 7.11 UV 800-155 4.27	Formula
PANTONE 1785 C UV 800-LVX 63.08 UV 800-180 32.67 UV 800-155 4.25	Formula	PANTONE 1788 C UV 800-180 76.09 UV 800-155 10.87 UV 800-LVX 13.04	Formula	PANTONE 1795 C UV 800-180 81.41 UV 800-LVX 16.48 UV 800-SB 2.11	Formula	PANTONE 1805 C UV 800-180 72.33 UV 800-LVX 21.75 UV 800-SB 5.92	Formula
PANTONE 1815 C UV 800-180 74.53 UV 800-SB 15.31 UV 800-LVX 10.16	Formula	PANTONE 1767 C UV 800-LVX 94.84 UV 800-155 3.74 UV 800-180 1.42	Formula	PANTONE 1777 C UV 800-LVX 76.94 UV 800-180 15.90 UV 800-155 7.16	Formula	PANTONE 1787 C UV 800-LVX 57.58 UV 800-180 34.19 UV 800-155 8.23	Formula
PANTONE 1797 C UV 800-180 65.18 UV 800-LVX 28.47 UV 800-155 3.82 UV 800-SB 2.53	Formula	PANTONE 1807 C UV 800-180 60.62 UV 800-LVX 28.56 UV 800-SB 8.20 UV 800-155 2.62	Formula	PANTONE 1817 C UV 800-180 48.58 UV 800-LVX 26.88 UV 800-SB 24.54	Formula	PANTONE 182 C UV 800-LVX 93.70 UV 800-160 3.81 UV 800-180 2.49	Formula

UVivid 800 Translucent

PANTONE 183 C UV 800-LVX 84.85 UV 800-160 12.74 UV 800-180 2.41	Formula	PANTONE 184 C UV 800-LVX 57.95 UV 800-160 25.00 UV 800-180 17.05	Formula	PANTONE 185 C UV 800-LVX 61.77 UV 800-160 38.23	Formula	PANTONE 186 C UV 800-180 71.03 UV 800-160 26.65 UV 800-SB 2.32	Formula
PANTONE 187 C UV 800-180 71.27 UV 800-160 21.85 UV 800-SB 6.88	Formula	PANTONE 188 C UV 800-180 56.72 UV 800-LVX 25.68 UV 800-SB 17.60	Formula	PANTONE 189 C UV 800-LVX 87.04 UV 800-160 12.11 UV 800-180 0.85	Formula	PANTONE 190 C UV 800-LVX 74.63 UV 800-160 19.74 UV 800-180 5.63	Formula
PANTONE 191 C UV 800-LVX 46.30 UV 800-160 36.14 UV 800-180 17.56	Formula	PANTONE 192 C UV 800-160 49.77 UV 800-180 42.06 UV 800-LVX 8.17	Formula	PANTONE 193 C UV 800-180 48.06 UV 800-160 40.87 UV 800-LVX 7.76 UV 800-SB 3.31	Formula	PANTONE 194 C UV 800-180 40.01 UV 800-LVX 27.63 UV 800-160 22.93 UV 800-SB 9.43	Formula
PANTONE 195 C UV 800-LVX 45.12 UV 800-180 31.87 UV 800-SB 18.43 UV 800-160 4.58	Formula	PANTONE 1895 C UV 800-LVX 95.85 UV 800-155 4.15	Formula	PANTONE 1905 C UV 800-LVX 91.51 UV 800-155 6.49 UV 800-180 2.00	Formula	PANTONE 1915 C UV 800-LVX 74.63 UV 800-155 15.80 UV 800-180 9.57	Formula

UVivid 800 Translucent

PANTONE 1925 C UV 800-LVX 48.38 UV 800-180 32.29 UV 800-155 19.33	Formula	PANTONE 1935 C UV 800-180 41.71 UV 800-LVX 36.95 UV 800-155 19.61 UV 800-SB 1.73	Formula	PANTONE 1945 C UV 800-180 43.00 UV 800-LVX 33.91 UV 800-155 17.29 UV 800-SB 5.80	Formula	PANTONE 1955 C UV 800-180 44.67 UV 800-LVX 24.24 UV 800-155 20.74 UV 800-SB 10.35	Formula
PANTONE 196 C UV 800-LVX 96.62 UV 800-155 1.71 UV 800-021 1.67	Formula	PANTONE 197 C UV 800-LVX 91.75 UV 800-155 6.50 UV 800-064 1.75	Formula	PANTONE 198 C UV 800-LVX 56.90 UV 800-155 26.46 UV 800-064 16.64	Formula	PANTONE 199 C UV 800-155 45.91 UV 800-064 40.70 UV 800-LVX 13.39	Formula
PANTONE 200 C UV 800-155 44.76 UV 800-064 41.73 UV 800-LVX 12.07 UV 800-SB 1.44	Formula	PANTONE 201 C UV 800-155 41.05 UV 800-064 38.41 UV 800-LVX 15.26 UV 800-SB 5.28	Formula	PANTONE 202 C UV 800-155 37.05 UV 800-064 36.62 UV 800-LVX 17.34 UV 800-SB 8.99	Formula	PANTONE 203 C UV 800-LVX 95.40 UV 800-155 4.60	Formula
PANTONE 204 C UV 800-LVX 88.99 UV 800-155 11.01	Formula	PANTONE 205 C UV 800-LVX 69.68 UV 800-155 26.14 UV 800-064 4.18	Formula	PANTONE 206 C UV 800-155 53.97 UV 800-064 24.53 UV 800-LVX 21.50	Formula	PANTONE 207 C UV 800-155 52.11 UV 800-064 23.16 UV 800-LVX 21.62 UV 800-SB 3.11	Formula

UVivid 800 Translucent

PANTONE 208 C UV 800-155 40.54 UV 800-LVX 29.19 UV 800-064 21.45 UV 800-SB 8.82	Formula	PANTONE 209 C UV 800-155 34.36 UV 800-LVX 28.74 UV 800-064 22.13 UV 800-SB 14.77	Formula	PANTONE 210 C UV 800-LVX 83.91 UV 800-160 16.09	Formula	PANTONE 211 C UV 800-LVX 72.76 UV 800-160 27.24	Formula
PANTONE 212 C UV 800-LVX 51.15 UV 800-160 45.82 UV 800-180 3.03	Formula	PANTONE 213 C UV 800-160 71.67 UV 800-LVX 16.78 UV 800-180 11.55	Formula	PANTONE 214 C UV 800-160 81.59 UV 800-180 16.73 UV 800-SB 1.68	Formula	PANTONE 215 C UV 800-160 75.50 UV 800-180 18.92 UV 800-SB 5.58	Formula
PANTONE 216 C UV 800-160 47.81 UV 800-LVX 18.78 UV 800-180 18.33 UV 800-SB 15.08	Formula	PANTONE 217 C UV 800-LVX 94.39 UV 800-175 2.64 UV 800-160 2.16 UV 800-180 0.81	Formula	PANTONE 218 C UV 800-LVX 76.95 UV 800-175 14.14 UV 800-155 8.91	Formula	PANTONE 219 C UV 800-LVX 59.65 UV 800-155 28.00 UV 800-175 12.35	Formula
PANTONE 220 C UV 800-155 61.31 UV 800-LVX 35.65 UV 800-SB 3.04	Formula	PANTONE 221 C UV 800-155 63.50 UV 800-LVX 30.70 UV 800-SB 5.80	Formula	PANTONE 222 C UV 800-155 55.10 UV 800-LVX 28.32 UV 800-SB 16.58	Formula	PANTONE 223 C UV 800-LVX 79.49 UV 800-160 20.51	Formula

UVivid 800 Translucent

PANTONE 224 C UV 800-LVX 63.63 UV 800-160 36.37	Formula	PANTONE 225 C UV 800-160 78.30 UV 800-LVX 21.70	Formula	PANTONE 226 C UV 800-160 65.91 UV 800-155 34.09	Formula	PANTONE 227 C UV 800-160 62.49 UV 800-155 34.13 UV 800-SB 3.38	Formula
PANTONE 228 C UV 800-155 36.66 UV 800-LVX 31.27 UV 800-160 23.22 UV 800-SB 8.85	Formula	PANTONE 229 C UV 800-155 40.81 UV 800-LVX 39.35 UV 800-SB 19.84	Formula	PANTONE 230 C UV 800-LVX 85.17 UV 800-160 14.83	Formula	PANTONE 231 C UV 800-LVX 63.71 UV 800-160 36.29	Formula
PANTONE 232 C UV 800-160 69.94 UV 800-LVX 30.06	Formula	PANTONE 233 C UV 800-160 98.39 UV 800-SB 1.61	Formula	PANTONE 234 C UV 800-160 94.08 UV 800-SB 5.92	Formula	PANTONE 235 C UV 800-160 88.43 UV 800-SB 11.57	Formula
PANTONE 236 C UV 800-LVX 85.10 UV 800-175 9.69 UV 800-160 5.21	Formula	PANTONE 237 C UV 800-LVX 73.05 UV 800-175 13.59 UV 800-160 13.36	Formula	PANTONE 238 C UV 800-LVX 50.11 UV 800-160 30.51 UV 800-175 19.38	Formula	PANTONE 239 C UV 800-160 44.22 UV 800-LVX 32.03 UV 800-175 23.75	Formula

UVivid 800 Translucent

PANTONE 240 C UV 800-160 49.65 UV 800-LVX 27.63 UV 800-175 21.72 UV 800-SB 1.00	Formula	PANTONE 241 C UV 800-160 68.88 UV 800-175 19.78 UV 800-LVX 7.49 UV 800-SB 3.85	Formula	PANTONE 242 C UV 800-160 74.01 UV 800-SB 15.01 UV 800-175 7.00 UV 800-LVX 3.98	Formula	PANTONE 2365 C UV 800-LVX 91.22 UV 800-175 6.59 UV 800-160 2.19	Formula
PANTONE 2375 C UV 800-LVX 63.83 UV 800-175 20.88 UV 800-160 15.29	Formula	PANTONE 2385 C UV 800-175 34.48 UV 800-160 34.16 UV 800-LVX 31.36	Formula	PANTONE 2395 C UV 800-160 53.81 UV 800-175 46.19	Formula	PANTONE 2405 C UV 800-160 59.67 UV 800-175 38.40 UV 800-SB 1.93	Formula
PANTONE 2415 C UV 800-160 61.34 UV 800-175 33.68 UV 800-SB 4.98	Formula	PANTONE 2425 C UV 800-160 62.93 UV 800-175 25.51 UV 800-SB 11.56	Formula	PANTONE 243 C UV 800-LVX 90.31 UV 800-175 8.54 UV 800-160 1.15	Formula	PANTONE 244 C UV 800-LVX 82.64 UV 800-175 13.62 UV 800-160 3.74	Formula
PANTONE 245 C UV 800-LVX 71.10 UV 800-175 21.77 UV 800-160 7.13	Formula	PANTONE 246 C UV 800-175 44.76 UV 800-160 27.80 UV 800-LVX 27.44	Formula	PANTONE 247 C UV 800-175 46.05 UV 800-160 29.75 UV 800-LVX 24.20	Formula	PANTONE 248 C UV 800-175 41.72 UV 800-160 38.24 UV 800-LVX 17.02 UV 800-SB 3.02	Formula

UVivid 800 Translucent

PANTONE 249 C UV 800-160 39.30 UV 800-LVX 25.33 UV 800-175 23.03 UV 800-SB 12.34	Formula	PANTONE 250 C UV 800-LVX 90.65 UV 800-175 9.35	Formula	PANTONE 251 C UV 800-LVX 81.46 UV 800-175 18.54	Formula	PANTONE 252 C UV 800-LVX 55.14 UV 800-175 44.86	Formula
PANTONE 253 C UV 800-175 80.83 UV 800-LVX 19.17	Formula	PANTONE 254 C UV 800-175 78.07 UV 800-LVX 19.85 UV 800-SB 2.08	Formula	PANTONE 255 C UV 800-175 67.68 UV 800-LVX 20.89 UV 800-SB 11.43	Formula	PANTONE 256 C UV 800-LVX 94.80 UV 800-175 4.61 UV 800-064 0.40 UV 800-205 0.19	Formula
PANTONE 257 C UV 800-LVX 94.54 UV 800-155 3.95 UV 800-190 1.51	Formula	PANTONE 258 C UV 800-LVX 90.33 UV 800-155 7.26 UV 800-190 2.41	Formula	PANTONE 259 C UV 800-LVX 67.14 UV 800-155 26.27 UV 800-190 6.59	Formula	PANTONE 260 C UV 800-LVX 48.35 UV 800-155 42.40 UV 800-190 9.25	Formula
PANTONE 261 C UV 800-LVX 42.96 UV 800-155 41.37 UV 800-SB 7.96 UV 800-190 7.71	Formula	PANTONE 262 C UV 800-LVX 48.01 UV 800-155 31.51 UV 800-SB 15.89 UV 800-190 4.59	Formula	PANTONE 2562 C UV 800-LVX 85.68 UV 800-175 14.32	Formula	PANTONE 2572 C UV 800-LVX 74.19 UV 800-175 25.81	Formula

UVivid 800 Translucent

PANTONE 2582 C UV 800-175 60.03 UV 800-LVX 39.97	Formula	PANTONE 2592 C UV 800-175 98.18 UV 800-205 1.82	Formula	PANTONE 2602 C UV 800-175 85.77 UV 800-127 14.23	Formula	PANTONE 2612 C UV 800-127 47.59 UV 800-LVX 30.04 UV 800-155 22.37	Formula
PANTONE 2622 C UV 800-175 55.54 UV 800-LVX 28.16 UV 800-SB 14.36 UV 800-180 1.94	Formula	PANTONE 2563 C UV 800-LVX 86.77 UV 800-175 12.32 UV 800-205 0.91	Formula	PANTONE 2573 C UV 800-LVX 78.34 UV 800-175 20.40 UV 800-205 1.26	Formula	PANTONE 2583 C UV 800-LVX 69.73 UV 800-175 22.56 UV 800-127 7.12 UV 800-155 0.59	Formula
PANTONE 2593 C UV 800-LVX 61.71 UV 800-127 19.43 UV 800-155 10.40 UV 800-160 8.46	Formula	PANTONE 2603 C UV 800-LVX 43.89 UV 800-127 27.86 UV 800-160 21.93 UV 800-021 6.32	Formula	PANTONE 2613 C UV 800-LVX 46.05 UV 800-127 23.25 UV 800-160 17.34 UV 800-155 9.13 UV 800-SB 4.23	Formula	PANTONE 2623 C UV 800-LVX 40.90 UV 800-127 35.86 UV 800-180 20.42 UV 800-SB 2.82	Formula
PANTONE 2567 C UV 800-LVX 85.06 UV 800-175 13.29 UV 800-205 1.65	Formula	PANTONE 2577 C UV 800-LVX 75.80 UV 800-175 21.82 UV 800-205 2.38	Formula	PANTONE 2587 C UV 800-LVX 49.13 UV 800-175 46.64 UV 800-205 4.23	Formula	PANTONE 2597 C UV 800-127 50.36 UV 800-LVX 24.17 UV 800-160 17.87 UV 800-155 7.60	Formula

UVivid 800 Translucent

PANTONE 2607 C UV 800-127 73.56 UV 800-160 22.79 UV 800-SB 3.65	Formula	PANTONE 2617 C UV 800-127 39.75 UV 800-160 30.92 UV 800-LVX 22.83 UV 800-SB 6.50	Formula	PANTONE 2627 C UV 800-155 60.53 UV 800-205 21.50 UV 800-LVX 16.26 UV 800-127 1.71	Formula	PANTONE 263 C UV 800-LVX 93.65 UV 800-127 5.45 UV 800-205 0.90	Formula
PANTONE 264 C UV 800-LVX 86.80 UV 800-175 11.30 UV 800-205 1.90	Formula	PANTONE 265 C UV 800-LVX 59.13 UV 800-175 35.47 UV 800-205 5.40	Formula	PANTONE 266 C UV 800-127 49.56 UV 800-LVX 41.47 UV 800-205 8.97	Formula	PANTONE 267 C UV 800-LVX 53.65 UV 800-127 45.99 UV 800-SB 0.36	Formula
PANTONE 268 C UV 800-LVX 48.56 UV 800-127 28.75 UV 800-180 14.89 UV 800-205 7.80	Formula	PANTONE 269 C UV 800-LVX 39.64 UV 800-127 23.97 UV 800-175 23.74 UV 800-SB 12.65	Formula	PANTONE 2635 C UV 800-LVX 90.08 UV 800-175 8.00 UV 800-205 1.92	Formula	PANTONE 2645 C UV 800-LVX 82.00 UV 800-175 14.85 UV 800-205 3.15	Formula
PANTONE 2655 C UV 800-LVX 69.14 UV 800-175 25.91 UV 800-205 4.95	Formula	PANTONE 2665 C UV 800-LVX 47.62 UV 800-175 44.98 UV 800-205 7.40	Formula	PANTONE 2685 C UV 800-127 96.08 UV 800-205 2.51 UV 800-SB 1.41	Formula	PANTONE 2695 C UV 800-175 69.47 UV 800-SB 22.25 UV 800-205 8.28	Formula

UVivid 800 Translucent

PANTONE 270 C UV 800-LVX 91.21 UV 800-175 6.02 UV 800-205 2.77	Formula	PANTONE 271 C UV 800-LVX 84.64 UV 800-175 10.50 UV 800-205 4.86	Formula	PANTONE 272 C UV 800-LVX 74.20 UV 800-175 17.76 UV 800-205 8.04	Formula	PANTONE 273 C UV 800-205 34.60 UV 800-160 33.22 UV 800-127 19.51 UV 800-SB 12.67	Formula
PANTONE 274 C UV 800-127 46.55 UV 800-155 34.33 UV 800-190 14.26 UV 800-SB 4.86	Formula	PANTONE 275 C UV 800-155 62.19 UV 800-205 33.49 UV 800-SB 4.32	Formula	PANTONE 276 C UV 800-155 55.95 UV 800-205 24.18 UV 800-SB 19.87	Formula	PANTONE 2705 C UV 800-LVX 92.05 UV 800-127 4.66 UV 800-205 3.29	Formula
PANTONE 2715 C UV 800-LVX 86.31 UV 800-127 8.31 UV 800-205 5.38	Formula	PANTONE 2725 C UV 800-LVX 64.06 UV 800-160 18.28 UV 800-205 17.66	Formula	PANTONE 2735 C UV 800-205 46.65 UV 800-160 40.90 UV 800-127 11.38 UV 800-SB 1.07	Formula	PANTONE 2745 C UV 800-127 71.62 UV 800-205 12.86 UV 800-LVX 10.67 UV 800-SB 4.85	Formula
PANTONE 2755 C UV 800-127 75.36 UV 800-205 13.39 UV 800-SB 8.63 UV 800-LVX 2.62	Formula	PANTONE 2765 C UV 800-127 76.69 UV 800-SB 23.31	Formula	PANTONE 2706 C UV 800-LVX 93.59 UV 800-175 4.80 UV 800-190 1.61	Formula	PANTONE 2716 C UV 800-LVX 89.09 UV 800-175 6.11 UV 800-205 4.80	Formula

UVivid 800 Translucent

PANTONE 2726 C UV 800-LVX 57.52 UV 800-175 25.17 UV 800-205 17.31	Formula	PANTONE 2736 C UV 800-205 65.62 UV 800-160 21.36 UV 800-LVX 13.02	Formula	PANTONE 2746 C UV 800-205 47.03 UV 800-LVX 28.45 UV 800-127 18.84 UV 800-155 5.68	Formula	PANTONE 2756 C UV 800-205 46.09 UV 800-155 26.67 UV 800-LVX 23.52 UV 800-SB 3.72	Formula
PANTONE 2766 C UV 800-127 48.28 UV 800-205 25.25 UV 800-064 14.53 UV 800-SB 11.94	Formula	PANTONE 2707 C UV 800-LVX 93.72 UV 800-175 4.16 UV 800-190 2.12	Formula	PANTONE 2717 C UV 800-LVX 89.11 UV 800-175 6.88 UV 800-190 4.01	Formula	PANTONE 2727 C UV 800-LVX 77.50 UV 800-205 20.58 UV 800-190 1.92	Formula
PANTONE 2747 C UV 800-205 92.87 UV 800-SB 7.13	Formula	PANTONE 2757 C UV 800-205 61.02 UV 800-155 30.80 UV 800-SB 8.18	Formula	PANTONE 2767 C UV 800-155 39.99 UV 800-205 39.81 UV 800-SB 20.20	Formula	PANTONE 2708 C UV 800-LVX 96.42 UV 800-205 3.58	Formula
PANTONE 2718 C UV 800-LVX 84.51 UV 800-205 15.49	Formula	PANTONE 2728 C UV 800-LVX 58.16 UV 800-205 41.84	Formula	PANTONE 2738 C UV 800-205 80.00 UV 800-127 20.00	Formula	PANTONE 2748 C UV 800-205 60.82 UV 800-155 29.44 UV 800-LVX 9.74	Formula

UVivid 800 Translucent

PANTONE 2758 C UV 800-127 53.28 UV 800-205 29.92 UV 800-064 16.80	Formula	PANTONE 2768 C UV 800-127 70.73 UV 800-SB 23.70 UV 800-190 5.57	Formula	PANTONE 277 C UV 800-LVX 96.03 UV 800-205 3.97	Formula	PANTONE 278 C UV 800-LVX 93.97 UV 800-205 6.03	Formula
PANTONE 279 C UV 800-LVX 85.93 UV 800-205 14.07	Formula	PANTONE 280 C UV 800-205 91.64 UV 800-SB 8.36	Formula	PANTONE 281 C UV 800-205 82.65 UV 800-SB 12.83 UV 800-LVX 4.52	Formula	PANTONE 282 C UV 800-205 72.86 UV 800-SB 27.14	Formula
PANTONE 283 C UV 800-LVX 93.89 UV 800-205 4.80 UV 800-190 1.31	Formula	PANTONE 284 C UV 800-LVX 89.30 UV 800-205 7.82 UV 800-190 2.88	Formula	PANTONE 285 C UV 800-LVX 70.80 UV 800-205 20.48 UV 800-190 8.72	Formula	PANTONE 286 C UV 800-205 49.96 UV 800-LVX 35.97 UV 800-190 14.07	Formula
PANTONE 287 C UV 800-205 56.68 UV 800-190 21.56 UV 800-LVX 17.85 UV 800-SB 3.91	Formula	PANTONE 288 C UV 800-205 55.10 UV 800-LVX 28.53 UV 800-190 8.63 UV 800-SB 7.74	Formula	PANTONE 289 C UV 800-205 72.56 UV 800-SB 27.44	Formula	PANTONE 290 C UV 800-LVX 97.38 UV 800-205 2.12 UV 800-190 0.50	Formula

UVivid 800 Translucent

PANTONE 291 C UV 800-LVX 95.37 UV 800-205 3.43 UV 800-190 1.20	Formula	PANTONE 292 C UV 800-LVX 89.24 UV 800-205 6.50 UV 800-190 4.26	Formula	PANTONE 293 C UV 800-205 35.57 UV 800-LVX 34.74 UV 800-190 29.69	Formula	PANTONE 294 C UV 800-190 50.38 UV 800-205 40.83 UV 800-SB 8.79	Formula
PANTONE 295 C UV 800-190 46.13 UV 800-205 37.80 UV 800-SB 16.07	Formula	PANTONE 296 C UV 800-205 53.01 UV 800-SB 46.99	Formula	PANTONE 2905 C UV 800-LVX 94.06 UV 800-205 3.18 UV 800-190 2.76	Formula	PANTONE 2915 C UV 800-LVX 89.00 UV 800-190 6.03 UV 800-205 4.97	Formula
PANTONE 2925 C UV 800-LVX 78.99 UV 800-190 12.82 UV 800-205 8.19	Formula	PANTONE 2935 C UV 800-LVX 46.07 UV 800-190 30.07 UV 800-205 23.86	Formula	PANTONE 2945 C UV 800-190 43.86 UV 800-LVX 30.62 UV 800-205 23.06 UV 800-SB 2.46	Formula	PANTONE 2955 C UV 800-190 36.84 UV 800-205 27.04 UV 800-LVX 22.19 UV 800-SB 13.93	Formula
PANTONE 2965 C UV 800-190 35.65 UV 800-205 33.98 UV 800-SB 30.37	Formula	PANTONE 297 C UV 800-LVX 91.52 UV 800-190 5.58 UV 800-205 2.90	Formula	PANTONE 298 C UV 800-LVX 86.97 UV 800-190 8.81 UV 800-205 4.22	Formula	PANTONE 299 C UV 800-LVX 79.40 UV 800-190 14.45 UV 800-205 6.15	Formula

UVivid 800 Translucent

PANTONE 300 C UV 800-190 45.17 UV 800-LVX 38.72 UV 800-205 16.11	Formula	PANTONE 301 C UV 800-190 79.95 UV 800-205 15.91 UV 800-SB 4.14	Formula	PANTONE 302 C UV 800-190 68.79 UV 800-SB 15.87 UV 800-205 15.34	Formula	PANTONE 303 C UV 800-190 50.43 UV 800-SB 31.04 UV 800-205 18.53	Formula
PANTONE 2975 C UV 800-LVX 96.92 UV 800-205 1.76 UV 800-190 1.32	Formula	PANTONE 2985 C UV 800-LVX 90.58 UV 800-190 7.32 UV 800-205 2.10	Formula	PANTONE 2995 C UV 800-LVX 78.18 UV 800-190 17.62 UV 800-205 4.20	Formula	PANTONE 3005 C UV 800-LVX 46.28 UV 800-190 44.95 UV 800-205 8.77	Formula
PANTONE 3015 C UV 800-190 65.78 UV 800-LVX 23.84 UV 800-205 7.56 UV 800-SB 2.82	Formula	PANTONE 3025 C UV 800-190 66.34 UV 800-LVX 15.54 UV 800-SB 12.54 UV 800-205 5.58	Formula	PANTONE 3035 C UV 800-190 50.46 UV 800-SB 22.28 UV 800-LVX 21.23 UV 800-205 6.03	Formula	PANTONE 304 C UV 800-LVX 94.86 UV 800-190 5.14	Formula
PANTONE 305 C UV 800-LVX 89.98 UV 800-190 10.02	Formula	PANTONE 306 C UV 800-LVX 79.83 UV 800-190 20.17	Formula	PANTONE 307 C UV 800-190 93.73 UV 800-LVX 4.53 UV 800-SB 1.74	Formula	PANTONE 308 C UV 800-190 90.61 UV 800-SB 9.39	Formula

UVivid 800 Translucent

PANTONE 309 C UV 800-190 71.45 UV 800-SB 27.13 UV 800-LVX 1.42	Formula	PANTONE 310 C UV 800-LVX 91.57 UV 800-190 8.43	Formula	PANTONE 311 C UV 800-LVX 87.06 UV 800-190 12.94	Formula	PANTONE 312 C UV 800-LVX 74.20 UV 800-190 25.52 UV 800-325 0.28	Formula
PANTONE 313 C UV 800-LVX 45.00 UV 800-190 43.51 UV 800-325 11.49	Formula	PANTONE 314 C UV 800-190 59.18 UV 800-LVX 29.30 UV 800-325 9.82 UV 800-SB 1.70	Formula	PANTONE 315 C UV 800-190 64.84 UV 800-LVX 14.43 UV 800-325 13.35 UV 800-SB 7.38	Formula	PANTONE 316 C UV 800-190 47.87 UV 800-LVX 24.45 UV 800-SB 22.81 UV 800-325 4.87	Formula
PANTONE 3105 C UV 800-LVX 92.29 UV 800-190 7.71	Formula	PANTONE 3115 C UV 800-LVX 87.33 UV 800-190 12.67	Formula	PANTONE 3125 C UV 800-LVX 73.67 UV 800-190 21.83 UV 800-325 4.50	Formula	PANTONE 3135 C UV 800-190 42.37 UV 800-LVX 35.83 UV 800-325 21.80	Formula
PANTONE 3145 C UV 800-190 50.45 UV 800-LVX 26.97 UV 800-325 18.47 UV 800-SB 4.11	Formula	PANTONE 3155 C UV 800-190 58.43 UV 800-325 25.26 UV 800-SB 8.67 UV 800-LVX 7.64	Formula	PANTONE 3165 C UV 800-190 58.07 UV 800-325 25.37 UV 800-SB 16.56	Formula	PANTONE 317 C UV 800-LVX 96.94 UV 800-190 3.06	Formula

UVivid 800 Translucent

PANTONE 318 C UV 800-LVX 95.09 UV 800-190 4.91	Formula	PANTONE 319 C UV 800-LVX 90.09 UV 800-190 8.70 UV 800-325 1.21	Formula	PANTONE 320 C UV 800-325 34.86 UV 800-LVX 34.84 UV 800-190 30.30	Formula	PANTONE 321 C UV 800-190 35.44 UV 800-LVX 33.70 UV 800-325 29.06 UV 800-SB 1.80	Formula
PANTONE 322 C UV 800-190 34.52 UV 800-LVX 30.52 UV 800-325 28.06 UV 800-SB 6.90	Formula	PANTONE 323 C UV 800-190 34.21 UV 800-325 28.16 UV 800-LVX 23.25 UV 800-SB 14.38	Formula	PANTONE 324 C UV 800-LVX 96.00 UV 800-190 3.75 UV 800-064 0.25	Formula	PANTONE 325 C UV 800-LVX 92.95 UV 800-190 6.48 UV 800-064 0.57	Formula
PANTONE 326 C UV 800-LVX 77.13 UV 800-190 16.88 UV 800-064 5.72 UV 800-SB 0.27	Formula	PANTONE 327 C UV 800-190 45.06 UV 800-LVX 21.77 UV 800-064 20.65 UV 800-325 11.96 UV 800-021 0.56	Formula	PANTONE 328 C UV 800-190 54.72 UV 800-064 23.47 UV 800-LVX 16.59 UV 800-SB 5.22	Formula	PANTONE 329 C UV 800-190 45.78 UV 800-LVX 27.06 UV 800-064 19.00 UV 800-SB 8.16	Formula
PANTONE 330 C UV 800-LVX 42.37 UV 800-190 27.40 UV 800-SB 20.17 UV 800-064 10.06	Formula	PANTONE 3242 C UV 800-LVX 92.83 UV 800-190 4.66 UV 800-325 2.51	Formula	PANTONE 3252 C UV 800-LVX 88.22 UV 800-190 6.11 UV 800-325 5.67	Formula	PANTONE 3262 C UV 800-LVX 71.72 UV 800-325 18.58 UV 800-190 9.70	Formula

UVivid 800 Translucent

PANTONE 3272 C UV 800-325 52.80 UV 800-LVX 31.10 UV 800-190 16.10	Formula	PANTONE 3282 C UV 800-325 52.57 UV 800-LVX 22.01 UV 800-190 21.05 UV 800-SB 4.37	Formula	PANTONE 3292 C UV 800-325 48.14 UV 800-190 19.95 UV 800-LVX 16.37 UV 800-SB 15.54	Formula	PANTONE 3302 C UV 800-325 33.55 UV 800-SB 25.26 UV 800-LVX 25.23 UV 800-190 15.96	Formula
PANTONE 3245 C UV 800-LVX 92.89 UV 800-325 3.64 UV 800-190 3.47	Formula	PANTONE 3255 C UV 800-LVX 86.00 UV 800-325 9.46 UV 800-190 4.54	Formula	PANTONE 3265 C UV 800-LVX 69.85 UV 800-325 23.91 UV 800-190 6.24	Formula	PANTONE 3275 C UV 800-325 53.41 UV 800-LVX 39.13 UV 800-190 7.46	Formula
PANTONE 3285 C UV 800-325 47.22 UV 800-LVX 38.85 UV 800-190 10.44 UV 800-SB 3.49	Formula	PANTONE 3295 C UV 800-325 64.33 UV 800-LVX 14.37 UV 800-190 12.61 UV 800-SB 8.69	Formula	PANTONE 3305 C UV 800-325 40.70 UV 800-SB 25.27 UV 800-LVX 24.48 UV 800-190 9.55	Formula	PANTONE 3248 C UV 800-LVX 94.35 UV 800-190 4.66 UV 800-064 0.99	Formula
PANTONE 3258 C UV 800-LVX 89.10 UV 800-190 7.84 UV 800-064 3.06	Formula	PANTONE 3268 C UV 800-LVX 68.14 UV 800-190 19.58 UV 800-064 11.98 UV 800-155 0.30	Formula	PANTONE 3278 C UV 800-LVX 43.08 UV 800-190 25.99 UV 800-064 19.15 UV 800-325 11.37 UV 800-155 0.41	Formula	PANTONE 3288 C UV 800-LVX 35.66 UV 800-190 33.20 UV 800-064 27.17 UV 800-155 3.97	Formula

UVivid 800 Translucent

PANTONE 3298 C UV 800-190 34.40 UV 800-LVX 33.60 UV 800-064 22.15 UV 800-SB 9.85	Formula	PANTONE 3308 C UV 800-190 29.10 UV 800-SB 28.08 UV 800-LVX 25.10 UV 800-064 17.72	Formula	PANTONE 331 C UV 800-LVX 97.27 UV 800-190 1.88 UV 800-325 0.85	Formula	PANTONE 332 C UV 800-LVX 95.76 UV 800-325 2.35 UV 800-190 1.89	Formula
PANTONE 333 C UV 800-LVX 85.72 UV 800-325 11.96 UV 800-190 2.32	Formula	PANTONE 334 C UV 800-325 81.24 UV 800-LVX 12.73 UV 800-190 3.57 UV 800-SB 2.46	Formula	PANTONE 335 C UV 800-325 70.49 UV 800-LVX 17.20 UV 800-SB 8.78 UV 800-190 3.53	Formula	PANTONE 336 C UV 800-325 81.33 UV 800-SB 15.92 UV 800-127 2.75	Formula
PANTONE 337 C UV 800-LVX 95.08 UV 800-190 3.52 UV 800-064 1.40	Formula	PANTONE 338 C UV 800-LVX 91.22 UV 800-190 5.65 UV 800-064 3.13	Formula	PANTONE 339 C UV 800-LVX 71.19 UV 800-190 15.38 UV 800-064 13.16 UV 800-SB 0.27	Formula	PANTONE 340 C UV 800-LVX 33.81 UV 800-064 27.23 UV 800-190 24.17 UV 800-325 14.42 UV 800-SB 0.37	Formula
PANTONE 341 C UV 800-LVX 36.28 UV 800-190 29.51 UV 800-064 28.00 UV 800-SB 6.21	Formula	PANTONE 342 C UV 800-LVX 32.72 UV 800-190 28.59 UV 800-064 26.79 UV 800-SB 11.90	Formula	PANTONE 343 C UV 800-LVX 32.53 UV 800-190 24.25 UV 800-064 22.60 UV 800-SB 20.62	Formula	PANTONE 3375 C UV 800-LVX 89.49 UV 800-325 10.51	Formula

UVivid 800 Translucent

PANTONE 3385 C UV 800-LVX 81.17 UV 800-325 18.12 UV 800-064 0.71	Formula	PANTONE 3395 C UV 800-LVX 52.54 UV 800-325 39.82 UV 800-064 6.44 UV 800-190 1.20	Formula	PANTONE 3405 C UV 800-325 77.48 UV 800-064 14.00 UV 800-LVX 8.52	Formula	PANTONE 3415 C UV 800-325 54.66 UV 800-064 23.50 UV 800-190 11.73 UV 800-SB 10.11	Formula
PANTONE 3425 C UV 800-325 60.83 UV 800-SB 16.97 UV 800-064 16.22 UV 800-190 5.98	Formula	PANTONE 3435 C UV 800-064 29.23 UV 800-SB 28.76 UV 800-190 21.21 UV 800-325 20.80	Formula	PANTONE 344 C UV 800-LVX 94.06 UV 800-064 3.00 UV 800-190 2.94	Formula	PANTONE 345 C UV 800-LVX 91.71 UV 800-064 4.42 UV 800-190 3.87	Formula
PANTONE 346 C UV 800-LVX 86.28 UV 800-064 7.90 UV 800-190 5.82	Formula	PANTONE 347 C UV 800-064 47.80 UV 800-LVX 27.88 UV 800-190 23.90 UV 800-155 0.42	Formula	PANTONE 348 C UV 800-064 54.91 UV 800-190 27.54 UV 800-LVX 13.88 UV 800-155 3.67	Formula	PANTONE 349 C UV 800-064 40.99 UV 800-LVX 24.09 UV 800-190 23.23 UV 800-SB 11.69	Formula
PANTONE 350 C UV 800-064 31.28 UV 800-LVX 31.18 UV 800-SB 18.59 UV 800-190 15.73 UV 800-155 3.22	Formula	PANTONE 351 C UV 800-LVX 92.53 UV 800-325 6.02 UV 800-064 1.45	Formula	PANTONE 352 C UV 800-LVX 89.62 UV 800-325 8.01 UV 800-064 2.37	Formula	PANTONE 353 C UV 800-LVX 86.62 UV 800-325 10.09 UV 800-064 3.29	Formula

UVivid 800 Translucent

PANTONE 354 C UV 800-064 45.13 UV 800-LVX 25.59 UV 800-190 16.16 UV 800-325 13.12	Formula	PANTONE 355 C UV 800-064 62.07 UV 800-190 25.66 UV 800-LVX 12.27	Formula	PANTONE 356 C UV 800-325 58.02 UV 800-064 33.34 UV 800-SB 8.64	Formula	PANTONE 357 C UV 800-325 40.67 UV 800-064 23.11 UV 800-SB 21.82 UV 800-LVX 14.40	Formula
PANTONE 358 C UV 800-LVX 87.89 UV 800-064 9.64 UV 800-190 2.47	Formula	PANTONE 359 C UV 800-LVX 86.19 UV 800-064 10.99 UV 800-190 2.82	Formula	PANTONE 360 C UV 800-LVX 58.81 UV 800-064 34.00 UV 800-190 7.19	Formula	PANTONE 361 C UV 800-064 60.26 UV 800-LVX 26.94 UV 800-190 11.94 UV 800-021 0.86	Formula
PANTONE 362 C UV 800-064 51.19 UV 800-LVX 35.19 UV 800-190 10.95 UV 800-SB 2.67	Formula	PANTONE 363 C UV 800-064 51.33 UV 800-LVX 32.63 UV 800-190 11.14 UV 800-SB 4.90	Formula	PANTONE 364 C UV 800-064 53.24 UV 800-LVX 25.46 UV 800-190 11.62 UV 800-SB 9.68	Formula	PANTONE 365 C UV 800-LVX 89.05 UV 800-064 9.61 UV 800-190 1.34	Formula
PANTONE 366 C UV 800-LVX 85.72 UV 800-064 12.58 UV 800-190 1.70	Formula	PANTONE 367 C UV 800-LVX 73.04 UV 800-064 24.04 UV 800-190 2.92	Formula	PANTONE 368 C UV 800-064 59.10 UV 800-LVX 33.34 UV 800-190 6.89 UV 800-021 0.67	Formula	PANTONE 369 C UV 800-064 73.78 UV 800-LVX 15.25 UV 800-190 9.11 UV 800-SB 1.86	Formula

UVivid 800 Translucent

PANTONE 370 C UV 800-064 71.77 UV 800-LVX 13.48 UV 800-190 8.94 UV 800-SB 5.81	Formula	PANTONE 371 C UV 800-064 55.30 UV 800-LVX 21.44 UV 800-SB 16.32 UV 800-190 6.94	Formula	PANTONE 372 C UV 800-LVX 90.92 UV 800-064 7.71 UV 800-325 1.37	Formula	PANTONE 373 C UV 800-LVX 87.47 UV 800-064 10.72 UV 800-325 1.81	Formula
PANTONE 374 C UV 800-LVX 80.54 UV 800-064 16.87 UV 800-325 2.59	Formula	PANTONE 375 C UV 800-064 64.51 UV 800-LVX 26.28 UV 800-325 9.21	Formula	PANTONE 376 C UV 800-064 72.79 UV 800-LVX 14.55 UV 800-325 11.23 UV 800-SB 1.43	Formula	PANTONE 377 C UV 800-064 69.49 UV 800-LVX 14.94 UV 800-325 10.44 UV 800-SB 5.13	Formula
PANTONE 378 C UV 800-064 57.99 UV 800-SB 17.18 UV 800-LVX 15.14 UV 800-325 9.69	Formula	PANTONE 379 C UV 800-LVX 81.88 UV 800-064 17.22 UV 800-325 0.90	Formula	PANTONE 380 C UV 800-LVX 69.83 UV 800-064 28.70 UV 800-325 1.47	Formula	PANTONE 381 C UV 800-LVX 51.56 UV 800-064 45.91 UV 800-325 2.53	Formula
PANTONE 382 C UV 800-064 61.59 UV 800-LVX 35.54 UV 800-325 2.47 UV 800-205 0.40	Formula	PANTONE 383 C UV 800-064 71.16 UV 800-LVX 21.83 UV 800-325 3.80 UV 800-SB 3.21	Formula	PANTONE 384 C UV 800-064 86.52 UV 800-SB 6.77 UV 800-325 4.45 UV 800-LVX 2.26	Formula	PANTONE 385 C UV 800-064 50.78 UV 800-LVX 31.92 UV 800-SB 14.36 UV 800-325 2.94	Formula

UVivid 800 Translucent

PANTONE 386 C UV 800-LVX 80.90 UV 800-064 18.57 UV 800-325 0.53	Formula	PANTONE 387 C UV 800-LVX 62.37 UV 800-064 36.62 UV 800-325 1.01	Formula	PANTONE 388 C UV 800-LVX 53.34 UV 800-064 45.22 UV 800-325 1.44	Formula	PANTONE 389 C UV 800-064 82.32 UV 800-LVX 15.25 UV 800-325 2.43	Formula
PANTONE 390 C UV 800-064 95.05 UV 800-325 3.16 UV 800-SB 1.79	Formula	PANTONE 391 C UV 800-064 91.23 UV 800-SB 6.22 UV 800-325 2.55	Formula	PANTONE 392 C UV 800-064 78.27 UV 800-SB 11.59 UV 800-LVX 7.71 UV 800-325 2.43	Formula	PANTONE 393 C UV 800-LVX 86.08 UV 800-064 13.75 UV 800-325 0.17	Formula
PANTONE 394 C UV 800-LVX 65.28 UV 800-064 34.28 UV 800-325 0.44	Formula	PANTONE 395 C UV 800-LVX 51.46 UV 800-064 47.79 UV 800-325 0.75	Formula	PANTONE 396 C UV 800-064 86.56 UV 800-LVX 12.23 UV 800-325 1.21	Formula	PANTONE 397 C UV 800-064 96.70 UV 800-SB 2.01 UV 800-325 1.29	Formula
PANTONE 398 C UV 800-064 96.07 UV 800-SB 3.93	Formula	PANTONE 399 C UV 800-064 92.51 UV 800-SB 6.75 UV 800-325 0.74	Formula	PANTONE 3935 C UV 800-LVX 81.45 UV 800-064 18.55	Formula	PANTONE 3945 C UV 800-064 56.03 UV 800-LVX 43.69 UV 800-325 0.28	Formula

UVivid 800 Translucent

PANTONE 3955 C UV 800-064 99.37 UV 800-325 0.63	Formula	PANTONE 3965 C UV 800-064 99.53 UV 800-325 0.36 UV 800-SB 0.11	Formula	PANTONE 3975 C UV 800-064 96.38 UV 800-SB 3.62	Formula	PANTONE 3985 C UV 800-064 90.37 UV 800-SB 9.23 UV 800-LVX 0.40	Formula
PANTONE 3995 C UV 800-064 74.69 UV 800-SB 20.56 UV 800-LVX 3.73 UV 800-325 1.02	Formula	PANTONE 400 C UV 800-LVX 96.12 UV 800-175 1.79 UV 800-SB 1.61 UV 800-190 0.48	Formula	PANTONE 401 C UV 800-LVX 94.01 UV 800-SB 3.31 UV 800-175 2.12 UV 800-190 0.56	Formula	PANTONE 402 C UV 800-LVX 93.26 UV 800-SB 5.12 UV 800-127 1.18 UV 800-190 0.44	Formula
PANTONE 403 C UV 800-LVX 85.22 UV 800-SB 14.44 UV 800-127 0.34	Formula	PANTONE 404 C UV 800-LVX 76.37 UV 800-SB 14.55 UV 800-021 6.18 UV 800-205 2.90	Formula	PANTONE 405 C UV 800-LVX 72.51 UV 800-SB 20.21 UV 800-021 4.96 UV 800-205 2.32	Formula	PANTONE 406 C UV 800-LVX 96.27 UV 800-175 2.28 UV 800-SB 0.99 UV 800-190 0.46	Formula
PANTONE 407 C UV 800-LVX 93.81 UV 800-SB 3.51 UV 800-175 2.14 UV 800-205 0.54	Formula	PANTONE 408 C UV 800-LVX 87.82 UV 800-SB 6.51 UV 800-175 3.76 UV 800-064 1.17 UV 800-205 0.74	Formula	PANTONE 409 C UV 800-LVX 80.91 UV 800-SB 13.07 UV 800-175 3.64 UV 800-064 1.67 UV 800-205 0.71	Formula	PANTONE 410 C UV 800-LVX 77.61 UV 800-SB 17.40 UV 800-175 4.99	Formula

UVivid 800 Translucent

PANTONE 411 C UV 800-LVX 63.62 UV 800-SB 25.03 UV 800-175 8.41 UV 800-064 2.94	Formula	PANTONE 412 C UV 800-SB 42.05 UV 800-LVX 28.29 UV 800-064 15.16 UV 800-175 14.50	Formula	PANTONE 413 C UV 800-LVX 96.13 UV 800-175 1.71 UV 800-SB 1.42 UV 800-190 0.74	Formula	PANTONE 414 C UV 800-LVX 91.64 UV 800-SB 3.08 UV 800-175 2.98 UV 800-325 2.30	Formula
PANTONE 415 C UV 800-LVX 87.96 UV 800-SB 5.87 UV 800-175 3.20 UV 800-325 2.97	Formula	PANTONE 416 C UV 800-LVX 81.46 UV 800-SB 14.10 UV 800-325 3.55 UV 800-175 0.89	Formula	PANTONE 417 C UV 800-LVX 76.14 UV 800-SB 17.14 UV 800-325 4.56 UV 800-175 2.16	Formula	PANTONE 418 C UV 800-LVX 68.08 UV 800-SB 26.92 UV 800-325 5.00	Formula
PANTONE 419 C UV 800-SB 100.00	Formula	PANTONE 420 C UV 800-LVX 95.26 UV 800-325 2.79 UV 800-155 1.95	Formula	PANTONE 421 C UV 800-LVX 92.14 UV 800-325 4.33 UV 800-155 2.84 UV 800-SB 0.69	Formula	PANTONE 422 C UV 800-LVX 88.22 UV 800-325 6.16 UV 800-155 3.94 UV 800-SB 1.68	Formula
PANTONE 423 C UV 800-LVX 82.08 UV 800-SB 7.30 UV 800-325 6.60 UV 800-155 3.57 UV 800-064 0.45	Formula	PANTONE 424 C UV 800-LVX 73.75 UV 800-325 11.32 UV 800-SB 8.27 UV 800-155 6.66	Formula	PANTONE 425 C UV 800-LVX 60.60 UV 800-325 15.68 UV 800-SB 14.56 UV 800-155 9.16	Formula	PANTONE 426 C UV 800-SB 64.82 UV 800-LVX 26.74 UV 800-155 8.44	Formula

UVivid 800 Translucent

PANTONE 427 C UV 800-LVX 96.64 UV 800-175 2.48 UV 800-190 0.88	Formula	PANTONE 428 C UV 800-LVX 97.51 UV 800-205 1.58 UV 800-160 0.91	Formula	PANTONE 429 C UV 800-LVX 92.08 UV 800-175 4.28 UV 800-190 1.95 UV 800-SB 1.69	Formula	PANTONE 430 C UV 800-LVX 86.17 UV 800-SB 7.45 UV 800-205 4.61 UV 800-064 1.77	Formula
PANTONE 431 C UV 800-LVX 76.54 UV 800-SB 11.17 UV 800-190 7.26 UV 800-155 5.03	Formula	PANTONE 432 C UV 800-LVX 52.67 UV 800-SB 25.29 UV 800-190 13.09 UV 800-155 8.95	Formula	PANTONE 433 C UV 800-SB 43.35 UV 800-205 25.49 UV 800-064 17.03 UV 800-155 14.13	Formula	PANTONE 434 C UV 800-LVX 95.63 UV 800-160 3.18 UV 800-190 1.02 UV 800-021 0.17	Formula
PANTONE 435 C UV 800-LVX 89.96 UV 800-160 6.17 UV 800-325 3.41 UV 800-SB 0.46	Formula	PANTONE 436 C UV 800-LVX 78.77 UV 800-160 11.21 UV 800-325 7.40 UV 800-021 2.62	Formula	PANTONE 437 C UV 800-LVX 29.30 UV 800-160 28.60 UV 800-325 23.36 UV 800-021 18.26 UV 800-064 0.48	Formula	PANTONE 438 C UV 800-160 35.78 UV 800-325 31.39 UV 800-021 25.53 UV 800-SB 7.30	Formula
PANTONE 439 C UV 800-160 28.51 UV 800-325 26.55 UV 800-021 24.84 UV 800-SB 20.10	Formula	PANTONE 440 C UV 800-SB 29.13 UV 800-325 25.70 UV 800-021 25.09 UV 800-160 20.08	Formula	PANTONE 441 C UV 800-LVX 90.69 UV 800-325 4.93 UV 800-160 4.38	Formula	PANTONE 442 C UV 800-LVX 83.57 UV 800-325 8.40 UV 800-160 7.05 UV 800-021 0.98	Formula

UVivid 800 Translucent

PANTONE 443 C UV 800-LVX 73.21 UV 800-325 13.41 UV 800-160 10.84 UV 800-021 2.54	Formula	PANTONE 444 C UV 800-LVX 51.12 UV 800-325 24.89 UV 800-160 14.80 UV 800-021 9.19	Formula	PANTONE 445 C UV 800-325 45.93 UV 800-160 32.91 UV 800-021 17.85 UV 800-SB 3.31	Formula	PANTONE 446 C UV 800-325 42.05 UV 800-160 27.60 UV 800-021 16.38 UV 800-SB 13.97	Formula
PANTONE 447 C UV 800-325 30.73 UV 800-SB 25.68 UV 800-160 18.14 UV 800-021 13.65 UV 800-LVX 11.8	Formula	PANTONE WARM GRAY 1 C UV 800-LVX 98.54 UV 800-SB 1.33 UV 800-180 0.08 UV 800-155 0.05	Formula	PANTONE WARM GRAY 2 C UV 800-LVX 97.33 UV 800-SB 1.97 UV 800-180 0.40 UV 800-155 0.30	Formula	PANTONE WARM GRAY 3 C UV 800-LVX 95.72 UV 800-SB 2.50 UV 800-180 1.00 UV 800-155 0.78	Formula
PANTONE WARM GRAY 4 C UV 800-LVX 90.78 UV 800-SB 4.44 UV 800-180 2.53 UV 800-155 2.25	Formula	PANTONE WARM GRAY 5 C UV 800-LVX 92.46 UV 800-SB 6.90 UV 800-180 0.46 UV 800-155 0.18	Formula	PANTONE WARM GRAY 6 C UV 800-LVX 91.81 UV 800-SB 5.72 UV 800-180 1.94 UV 800-155 0.53	Formula	PANTONE WARM GRAY 7 C UV 800-LVX 74.96 UV 800-SB 12.74 UV 800-180 7.49 UV 800-155 4.81	Formula
PANTONE WARM GRAY 8 C UV 800-LVX 67.73 UV 800-SB 16.89 UV 800-180 9.25 UV 800-155 6.13	Formula	PANTONE WARM GRAY 9 C UV 800-LVX 80.70 UV 800-SB 17.65 UV 800-180 1.65	Formula	PANTONE WARM GRAY 10 C UV 800-LVX 79.00 UV 800-SB 19.79 UV 800-180 1.21	Formula	PANTONE WARM GRAY 11 C UV 800-LVX 76.00 UV 800-SB 23.00 UV 800-180 1.00	Formula

UVivid 800 Translucent

PANTONE COOL GRAY 1 C UV 800-LVX 99.23 UV 800-SB 0.60 UV 800-205 0.17	Formula	PANTONE COOL GRAY 2 C UV 800-LVX 98.80 UV 800-SB 0.85 UV 800-205 0.35	Formula	PANTONE COOL GRAY 3 C UV 800-LVX 97.90 UV 800-SB 1.40 UV 800-205 0.70	Formula	PANTONE COOL GRAY 4 C UV 800-LVX 97.16 UV 800-SB 1.74 UV 800-205 1.10	Formula
PANTONE COOL GRAY 5 C UV 800-LVX 95.27 UV 800-SB 3.65 UV 800-205 1.08	Formula	PANTONE COOL GRAY 6 C UV 800-LVX 95.03 UV 800-SB 2.72 UV 800-205 2.25	Formula	PANTONE COOL GRAY 7 C UV 800-LVX 92.95 UV 800-SB 4.37 UV 800-205 2.68	Formula	PANTONE COOL GRAY 8 C UV 800-LVX 90.30 UV 800-SB 6.31 UV 800-205 3.39	Formula
PANTONE COOL GRAY 9 C UV 800-LVX 81.71 UV 800-SB 13.72 UV 800-205 4.57	Formula	PANTONE COOL GRAY 10 C UV 800-LVX 79.28 UV 800-SB 15.23 UV 800-205 5.49	Formula	PANTONE COOL GRAY 11 C UV 800-LVX 71.44 UV 800-SB 21.81 UV 800-205 6.75	Formula	PANTONE BLACK 2C UV 800-SB 76.92 UV 800-064 23.08	Formula
PANTONE BLACK 3C UV 800-SB 80.00 UV 800-325 20.00	Formula	PANTONE BLACK 4C UV 800-SB 75.98 UV 800-021 24.02	Formula	PANTONE BLACK 5C UV 800-SB 67.30 UV 800-155 22.33 UV 800-LVX 10.37	Formula	PANTONE BLACK 6C UV 800-SB 85.71 UV 800-205 14.29	Formula

UVivid 800 Translucent

PANTONE 448 C UV 800-064 48.46 UV 800-SB 20.12 UV 800-LVX 13.78 UV 800-155 11.16 UV 800-190 6.48	Formula	PANTONE 449 C UV 800-064 64.47 UV 800-SB 19.95 UV 800-155 9.58 UV 800-190 6.00	Formula	PANTONE 450 C UV 800-064 67.68 UV 800-155 16.87 UV 800-190 10.86 UV 800-SB 4.59	Formula	PANTONE 451 C UV 800-LVX 65.65 UV 800-064 24.16 UV 800-155 5.97 UV 800-190 4.22	Formula
PANTONE 452 C UV 800-LVX 82.23 UV 800-064 12.08 UV 800-155 3.28 UV 800-190 2.41	Formula	PANTONE 453 C UV 800-LVX 89.82 UV 800-064 6.60 UV 800-155 1.97 UV 800-190 1.61	Formula	PANTONE 454 C UV 800-LVX 94.22 UV 800-064 3.60 UV 800-155 1.17 UV 800-190 1.01	Formula	PANTONE 4485 C UV 800-064 70.37 UV 800-SB 27.36 UV 800-155 2.27	Formula
PANTONE 4495 C UV 800-064 52.41 UV 800-LVX 32.08 UV 800-SB 13.27 UV 800-155 2.24	Formula	PANTONE 4505 C UV 800-LVX 46.92 UV 800-064 39.73 UV 800-SB 11.07 UV 800-155 2.28	Formula	PANTONE 4515 C UV 800-LVX 80.04 UV 800-064 14.45 UV 800-SB 4.60 UV 800-155 0.91	Formula	PANTONE 4525 C UV 800-LVX 89.71 UV 800-064 7.14 UV 800-SB 2.68 UV 800-155 0.47	Formula
PANTONE 4535 C UV 800-LVX 93.34 UV 800-064 4.54 UV 800-SB 1.83 UV 800-155 0.29	Formula	PANTONE 4545 C UV 800-LVX 96.16 UV 800-064 2.50 UV 800-SB 1.19 UV 800-155 0.15	Formula	PANTONE 455 C UV 800-064 54.71 UV 800-LVX 22.85 UV 800-SB 21.85 UV 800-155 0.59	Formula	PANTONE 456 C UV 800-064 63.10 UV 800-LVX 27.46 UV 800-SB 7.89 UV 800-155 1.55	Formula

UVivid 800 Translucent

PANTONE 457 C UV 800-064 91.50 UV 800-180 5.48 UV 800-205 3.02	Formula	PANTONE 458 C UV 800-LVX 73.31 UV 800-064 25.27 UV 800-SB 0.72 UV 800-155 0.70	Formula	PANTONE 459 C UV 800-LVX 81.34 UV 800-064 17.64 UV 800-SB 0.57 UV 800-155 0.45	Formula	PANTONE 460 C UV 800-LVX 88.80 UV 800-064 10.55 UV 800-155 0.49 UV 800-190 0.16	Formula
PANTONE 461 C UV 800-LVX 94.88 UV 800-064 4.92 UV 800-155 0.20	Formula	PANTONE 462 C UV 800-064 63.08 UV 800-SB 21.40 UV 800-155 11.98 UV 800-190 3.54	Formula	PANTONE 463 C UV 800-064 71.71 UV 800-155 13.39 UV 800-SB 11.75 UV 800-190 3.15	Formula	PANTONE 464 C UV 800-064 74.37 UV 800-155 17.16 UV 800-SB 4.36 UV 800-190 4.11	Formula
PANTONE 465 C UV 800-LVX 57.79 UV 800-064 32.99 UV 800-155 6.57 UV 800-190 2.65	Formula	PANTONE 466 C UV 800-LVX 79.07 UV 800-064 16.06 UV 800-155 3.44 UV 800-190 1.43	Formula	PANTONE 467 C UV 800-LVX 87.66 UV 800-064 9.34 UV 800-155 2.10 UV 800-190 0.90	Formula	PANTONE 468 C UV 800-LVX 92.75 UV 800-064 5.40 UV 800-155 1.26 UV 800-190 0.59	Formula
PANTONE 4625 C UV 800-021 36.60 UV 800-064 32.28 UV 800-SB 31.12	Formula	PANTONE 4635 C UV 800-LVX 55.23 UV 800-021 27.27 UV 800-SB 10.47 UV 800-064 3.87 UV 800-180 3.16	Formula	PANTONE 4645 C UV 800-LVX 50.74 UV 800-021 29.60 UV 800-SB 10.15 UV 800-064 5.07 UV 800-180 4.44	Formula	PANTONE 4655 C UV 800-LVX 85.50 UV 800-021 8.61 UV 800-SB 4.03 UV 800-180 1.86	Formula

UVivid 800 Translucent

PANTONE 4665 C UV 800-LVX 90.75 UV 800-180 3.45 UV 800-064 3.26 UV 800-SB 2.54	Formula	PANTONE 4675 C UV 800-LVX 96.03 UV 800-180 1.79 UV 800-SB 1.31 UV 800-064 0.87	Formula	PANTONE 4685 C UV 800-LVX 97.63 UV 800-180 1.14 UV 800-SB 0.88 UV 800-064 0.35	Formula	PANTONE 469 C UV 800-064 60.28 UV 800-SB 22.47 UV 800-180 17.25	Formula
PANTONE 470 C UV 800-064 46.08 UV 800-LVX 26.03 UV 800-180 19.27 UV 800-SB 8.62	Formula	PANTONE 471 C UV 800-064 63.97 UV 800-180 32.31 UV 800-205 2.72 UV 800-SB 1.00	Formula	PANTONE 472 C UV 800-LVX 76.66 UV 800-064 14.09 UV 800-180 8.51 UV 800-205 0.74	Formula	PANTONE 473 C UV 800-LVX 92.40 UV 800-064 3.65 UV 800-180 3.58 UV 800-SB 0.37	Formula
PANTONE 474 C UV 800-LVX 94.21 UV 800-180 2.79 UV 800-064 2.73 UV 800-SB 0.27	Formula	PANTONE 475 C UV 800-LVX 96.74 UV 800-180 1.92 UV 800-064 1.34	Formula	PANTONE 4695 C UV 800-064 41.48 UV 800-SB 21.94 UV 800-LVX 21.89 UV 800-155 14.69	Formula	PANTONE 4705 C UV 800-LVX 45.62 UV 800-064 26.98 UV 800-SB 13.70 UV 800-155 13.70	Formula
PANTONE 4715 C UV 800-LVX 63.36 UV 800-064 17.19 UV 800-SB 10.44 UV 800-155 9.01	Formula	PANTONE 4725 C UV 800-LVX 84.39 UV 800-064 6.40 UV 800-SB 4.92 UV 800-155 4.29	Formula	PANTONE 4735 C UV 800-LVX 92.27 UV 800-SB 2.87 UV 800-064 2.43 UV 800-155 2.43	Formula	PANTONE 4745 C UV 800-LVX 95.58 UV 800-SB 1.93 UV 800-155 1.54 UV 800-064 0.95	Formula

UVivid 800 Translucent

PANTONE 4755 C UV 800-LVX 97.96 UV 800-SB 1.08 UV 800-155 0.96	Formula	PANTONE 476 C UV 800-064 44.74 UV 800-SB 28.60 UV 800-LVX 15.23 UV 800-155 11.43	Formula	PANTONE 477 C UV 800-064 63.11 UV 800-155 18.12 UV 800-SB 16.54 UV 800-205 2.23	Formula	PANTONE 478 C UV 800-064 40.00 UV 800-021 32.00 UV 800-155 16.00 UV 800-205 12.00	Formula
PANTONE 479 C UV 800-LVX 67.80 UV 800-064 21.27 UV 800-155 7.98 UV 800-205 2.95	Formula	PANTONE 480 C UV 800-LVX 88.46 UV 800-064 7.04 UV 800-155 3.24 UV 800-205 1.26	Formula	PANTONE 481 C UV 800-LVX 93.82 UV 800-064 3.49 UV 800-155 1.94 UV 800-205 0.75	Formula	PANTONE 482 C UV 800-LVX 95.83 UV 800-064 2.24 UV 800-155 1.38 UV 800-205 0.55	Formula
PANTONE 483 C UV 800-064 48.37 UV 800-SB 19.63 UV 800-155 12.51 UV 800-LVX 11.31 UV 800-180 8.18	Formula	PANTONE 484 C UV 800-064 63.29 UV 800-155 20.78 UV 800-180 9.45 UV 800-SB 6.48	Formula	PANTONE 485 C UV 800-064 55.69 UV 800-155 24.86 UV 800-180 19.45	Formula	PANTONE 486 C UV 800-LVX 78.99 UV 800-064 13.34 UV 800-155 7.67	Formula
PANTONE 487 C UV 800-LVX 87.94 UV 800-064 7.54 UV 800-155 4.52	Formula	PANTONE 488 C UV 800-LVX 93.78 UV 800-064 3.65 UV 800-155 2.57	Formula	PANTONE 489 C UV 800-LVX 96.26 UV 800-064 2.05 UV 800-155 1.69	Formula	PANTONE 490 C UV 800-LVX 38.19 UV 800-SB 25.08 UV 800-180 21.97 UV 800-064 14.76	Formula

UVivid 800 Translucent

PANTONE 491 C UV 800-LVX 43.53 UV 800-180 30.47 UV 800-SB 15.80 UV 800-064 10.20	Formula	PANTONE 492 C UV 800-180 63.22 UV 800-SB 14.92 UV 800-LVX 13.61 UV 800-155 8.25	Formula	PANTONE 493 C UV 800-LVX 88.97 UV 800-155 8.39 UV 800-064 2.64	Formula	PANTONE 494 C UV 800-LVX 94.56 UV 800-155 4.30 UV 800-180 1.14	Formula
PANTONE 495 C UV 800-LVX 93.96 UV 800-160 5.79 UV 800-205 0.25	Formula	PANTONE 496 C UV 800-LVX 96.03 UV 800-160 3.37 UV 800-127 0.60	Formula	PANTONE 497 C UV 800-LVX 43.79 UV 800-SB 30.12 UV 800-021 20.11 UV 800-180 5.98	Formula	PANTONE 498 C UV 800-180 30.11 UV 800-LVX 23.12 UV 800-021 20.51 UV 800-325 16.50 UV 800-SB 9.76	Formula
PANTONE 499 C UV 800-180 48.30 UV 800-325 21.40 UV 800-021 20.80 UV 800-155 7.50 UV 800-SB 2	Formula	PANTONE 500 C UV 800-LVX 87.49 UV 800-155 6.58 UV 800-021 4.03 UV 800-SB 1.90	Formula	PANTONE 501 C UV 800-LVX 94.90 UV 800-155 3.85 UV 800-021 0.75 UV 800-SB 0.50	Formula	PANTONE 502 C UV 800-LVX 93.56 UV 800-160 5.58 UV 800-325 0.86	Formula
PANTONE 503 C UV 800-LVX 96.35 UV 800-160 3.28 UV 800-205 0.37	Formula	PANTONE 4975 C UV 800-SB 34.78 UV 800-064 30.74 UV 800-LVX 19.27 UV 800-180 15.21	Formula	PANTONE 4985 C UV 800-160 31.14 UV 800-021 30.16 UV 800-LVX 30.13 UV 800-190 8.57	Formula	PANTONE 4995 C UV 800-LVX 66.70 UV 800-180 25.34 UV 800-SB 5.11 UV 800-190 2.85	Formula

UVivid 800 Translucent

PANTONE 5005 C UV 800-LVX 69.84 UV 800-160 15.72 UV 800-021 10.71 UV 800-190 3.73	Formula	PANTONE 5015 C UV 800-LVX 88.39 UV 800-160 5.92 UV 800-021 4.00 UV 800-205 1.69	Formula	PANTONE 5025 C UV 800-LVX 93.96 UV 800-160 3.78 UV 800-021 1.34 UV 800-205 0.92	Formula	PANTONE 5035 C UV 800-LVX 94.82 UV 800-012 1.39 UV 800-180 1.27 UV 800-127 1.04 UV 800-160 0.78 UV 800-SB 0.7	Formula
PANTONE 504 C UV 800-021 52.30 UV 800-160 15.27 UV 800-SB 14.56 UV 800-205 9.14 UV 800-LVX 8.73	Formula	PANTONE 505 C UV 800-021 56.61 UV 800-160 27.62 UV 800-205 12.58 UV 800-LVX 3.19	Formula	PANTONE 506 C UV 800-180 65.00 UV 800-LVX 23.14 UV 800-205 11.86	Formula	PANTONE 507 C UV 800-LVX 85.82 UV 800-160 11.59 UV 800-021 1.60 UV 800-205 0.99	Formula
PANTONE 508 C UV 800-LVX 90.73 UV 800-160 8.70 UV 800-190 0.57	Formula	PANTONE 509 C UV 800-LVX 93.23 UV 800-160 3.47 UV 800-175 3.30	Formula	PANTONE 510 C UV 800-LVX 94.73 UV 800-175 3.05 UV 800-160 2.22	Formula	PANTONE 511 C UV 800-160 64.15 UV 800-SB 18.68 UV 800-LVX 9.81 UV 800-325 7.36	Formula
PANTONE 512 C UV 800-160 82.63 UV 800-325 13.79 UV 800-SB 3.58	Formula	PANTONE 513 C UV 800-160 85.76 UV 800-325 14.24	Formula	PANTONE 514 C UV 800-LVX 79.87 UV 800-175 16.33 UV 800-160 3.80	Formula	PANTONE 515 C UV 800-LVX 87.74 UV 800-175 10.57 UV 800-160 1.69	Formula

UVivid 800 Translucent

PANTONE 516 C UV 800-LVX 91.81 UV 800-175 7.57 UV 800-160 0.62	Formula	PANTONE 517 C UV 800-LVX 94.03 UV 800-175 5.60 UV 800-160 0.37	Formula	PANTONE 5115 C UV 800-LVX 58.55 UV 800-SB 22.89 UV 800-155 18.56	Formula	PANTONE 5125 C UV 800-LVX 67.80 UV 800-155 19.12 UV 800-SB 9.59 UV 800-190 3.49	Formula
PANTONE 5135 C UV 800-LVX 69.20 UV 800-155 17.36 UV 800-SB 9.80 UV 800-190 3.64	Formula	PANTONE 5145 C UV 800-LVX 87.30 UV 800-155 8.06 UV 800-190 2.49 UV 800-SB 2.15	Formula	PANTONE 5155 C UV 800-LVX 94.62 UV 800-155 3.86 UV 800-190 1.52	Formula	PANTONE 5165 C UV 800-LVX 95.82 UV 800-175 3.62 UV 800-205 0.56	Formula
PANTONE 5175 C UV 800-LVX 96.42 UV 800-175 3.09 UV 800-205 0.49	Formula	PANTONE 518 C UV 800-LVX 51.62 UV 800-155 21.42 UV 800-SB 17.62 UV 800-325 9.34	Formula	PANTONE 519 C UV 800-LVX 38.18 UV 800-155 36.68 UV 800-325 21.20 UV 800-SB 3.94	Formula	PANTONE 520 C UV 800-155 47.54 UV 800-325 28.88 UV 800-LVX 23.58	Formula
PANTONE 521 C UV 800-LVX 89.30 UV 800-127 9.08 UV 800-064 1.62	Formula	PANTONE 522 C UV 800-LVX 94.92 UV 800-127 5.08	Formula	PANTONE 523 C UV 800-LVX 92.65 UV 800-175 6.55 UV 800-205 0.80	Formula	PANTONE 524 C UV 800-LVX 94.97 UV 800-175 4.42 UV 800-205 0.61	Formula

UVivid 800 Translucent

PANTONE 5185 C UV 800-LVX 45.25 UV 800-SB 32.93 UV 800-160 21.82	Formula	PANTONE 5195 C UV 800-LVX 56.34 UV 800-160 23.16 UV 800-SB 17.75 UV 800-205 2.75	Formula	PANTONE 5205 C UV 800-LVX 68.47 UV 800-160 17.13 UV 800-SB 11.82 UV 800-205 1.67 UV 800-190 0.91	Formula	PANTONE 5215 C UV 800-LVX 89.27 UV 800-160 6.58 UV 800-SB 2.45 UV 800-205 1.70	Formula
PANTONE 5225 C UV 800-LVX 94.40 UV 800-160 3.83 UV 800-205 1.28 UV 800-SB 0.49	Formula	PANTONE 5235 C UV 800-LVX 96.15 UV 800-160 2.80 UV 800-205 1.05	Formula	PANTONE 5245 C UV 800-LVX 97.92 UV 800-127 1.58 UV 800-032 0.50	Formula	PANTONE 525 C UV 800-160 50.43 UV 800-LVX 23.24 UV 800-SB 17.45 UV 800-205 8.88	Formula
PANTONE 526 C UV 800-160 54.26 UV 800-LVX 29.14 UV 800-205 12.17 UV 800-SB 4.43	Formula	PANTONE 527 C UV 800-175 66.00 UV 800-LVX 25.91 UV 800-325 8.09	Formula	PANTONE 528 C UV 800-LVX 75.67 UV 800-160 18.82 UV 800-205 5.51	Formula	PANTONE 529 C UV 800-LVX 84.91 UV 800-175 14.18 UV 800-205 0.91	Formula
PANTONE 530 C UV 800-LVX 90.34 UV 800-175 9.10 UV 800-205 0.56	Formula	PANTONE 531 C UV 800-LVX 93.00 UV 800-175 7.00	Formula	PANTONE 5255 C UV 800-160 51.31 UV 800-SB 30.27 UV 800-205 18.42	Formula	PANTONE 5265 C UV 800-LVX 33.04 UV 800-205 25.18 UV 800-021 24.81 UV 800-160 16.97	Formula

UVivid 800 Translucent

PANTONE 5275 C UV 800-LVX 60.71 UV 800-127 15.48 UV 800-SB 13.89 UV 800-190 8.02 UV 800-155 1.9	Formula	PANTONE 5285 C UV 800-LVX 83.63 UV 800-205 6.96 UV 800-160 4.83 UV 800-021 4.58	Formula	PANTONE 5295 C UV 800-LVX 93.87 UV 800-205 2.91 UV 800-160 2.79 UV 800-021 0.43	Formula	PANTONE 5305 C UV 800-LVX 95.79 UV 800-175 2.83 UV 800-205 1.38	Formula
PANTONE 5315 C UV 800-LVX 95.77 UV 800-175 3.38 UV 800-190 0.85	Formula	PANTONE 532 C UV 800-325 39.92 UV 800-SB 33.10 UV 800-155 26.98	Formula	PANTONE 533 C UV 800-325 50.26 UV 800-155 25.14 UV 800-SB 15.36 UV 800-127 9.24	Formula	PANTONE 534 C UV 800-175 48.84 UV 800-325 40.44 UV 800-SB 10.72	Formula
PANTONE 535 C UV 800-LVX 92.41 UV 800-205 3.39 UV 800-155 2.22 UV 800-325 1.98	Formula	PANTONE 536 C UV 800-LVX 95.41 UV 800-205 3.56 UV 800-180 1.03	Formula	PANTONE 537 C UV 800-LVX 94.60 UV 800-175 3.82 UV 800-190 1.58	Formula	PANTONE 538 C UV 800-LVX 96.03 UV 800-175 2.82 UV 800-190 1.15	Formula
PANTONE 539 C UV 800-205 55.54 UV 800-SB 19.99 UV 800-064 18.29 UV 800-155 6.18	Formula	PANTONE 540 C UV 800-205 68.14 UV 800-064 28.82 UV 800-155 3.04	Formula	PANTONE 541 C UV 800-205 54.35 UV 800-190 23.91 UV 800-064 21.74	Formula	PANTONE 542 C UV 800-LVX 91.49 UV 800-205 6.06 UV 800-190 2.45	Formula

UVivid 800 Translucent

PANTONE 543 C UV 800-LVX 95.75 UV 800-205 3.64 UV 800-190 0.61	Formula	PANTONE 544 C UV 800-LVX 97.32 UV 800-205 2.68	Formula	PANTONE 545 C UV 800-LVX 97.88 UV 800-205 2.12	Formula	PANTONE 5395 C UV 800-127 51.68 UV 800-SB 48.32	Formula
PANTONE 5405 C UV 800-LVX 73.31 UV 800-205 14.22 UV 800-064 8.65 UV 800-180 3.82	Formula	PANTONE 5415 C UV 800-LVX 71.79 UV 800-205 14.88 UV 800-064 7.66 UV 800-021 5.67	Formula	PANTONE 5425 C UV 800-LVX 86.24 UV 800-190 6.96 UV 800-155 4.21 UV 800-021 2.59	Formula	PANTONE 5435 C UV 800-LVX 96.00 UV 800-205 3.26 UV 800-064 0.36 UV 800-180 0.38	Formula
PANTONE 5445 C UV 800-LVX 94.85 UV 800-175 3.35 UV 800-190 1.80	Formula	PANTONE 5455 C UV 800-LVX 96.04 UV 800-175 2.59 UV 800-190 1.37	Formula	PANTONE 546 C UV 800-205 40.63 UV 800-064 38.20 UV 800-SB 16.69 UV 800-155 4.48	Formula	PANTONE 547 C UV 800-205 51.55 UV 800-064 42.98 UV 800-SB 5.47	Formula
PANTONE 548 C UV 800-205 40.32 UV 800-064 38.71 UV 800-190 16.13 UV 800-SB 4.84	Formula	PANTONE 549 C UV 800-LVX 88.17 UV 800-205 6.43 UV 800-064 3.01 UV 800-190 2.39	Formula	PANTONE 550 C UV 800-LVX 93.61 UV 800-190 4.52 UV 800-155 1.87	Formula	PANTONE 551 C UV 800-LVX 96.85 UV 800-205 2.16 UV 800-190 0.99	Formula

UVivid 800 Translucent

PANTONE 552 C UV 800-LVX 97.92 UV 800-205 1.68 UV 800-190 0.40	Formula	PANTONE 5463 C UV 800-190 56.54 UV 800-SB 38.89 UV 800-205 4.57	Formula	PANTONE 5473 C UV 800-LVX 55.98 UV 800-190 21.93 UV 800-SB 18.54 UV 800-205 3.55	Formula	PANTONE 5483 C UV 800-LVX 77.46 UV 800-190 12.93 UV 800-SB 9.61	Formula
PANTONE 5493 C UV 800-LVX 93.68 UV 800-190 2.40 UV 800-205 2.22 UV 800-SB 1.70	Formula	PANTONE 5503 C UV 800-LVX 95.55 UV 800-205 1.86 UV 800-190 1.62 UV 800-SB 0.97	Formula	PANTONE 5513 C UV 800-LVX 97.30 UV 800-205 1.90 UV 800-325 0.80	Formula	PANTONE 5523 C UV 800-LVX 98.23 UV 800-205 1.27 UV 800-190 0.50	Formula
PANTONE 5467 C UV 800-064 54.32 UV 800-205 18.82 UV 800-SB 16.34 UV 800-127 10.52	Formula	PANTONE 5477 C UV 800-LVX 39.77 UV 800-064 23.15 UV 800-205 21.56 UV 800-021 15.52	Formula	PANTONE 5487 C UV 800-LVX 65.06 UV 800-064 16.34 UV 800-205 12.39 UV 800-SB 6.21	Formula	PANTONE 5497 C UV 800-LVX 84.70 UV 800-064 7.53 UV 800-205 6.14 UV 800-180 1.63	Formula
PANTONE 5507 C UV 800-LVX 93.05 UV 800-064 3.22 UV 800-205 3.09 UV 800-155 0.64	Formula	PANTONE 5517 C UV 800-LVX 95.95 UV 800-190 1.88 UV 800-155 1.43 UV 800-064 0.74	Formula	PANTONE 5527 C UV 800-LVX 97.77 UV 800-190 1.30 UV 800-155 0.93	Formula	PANTONE 553 C UV 800-064 43.86 UV 800-LVX 23.34 UV 800-205 17.45 UV 800-SB 15.35	Formula

UVivid 800 Translucent

PANTONE 554 C UV 800-064 52.92 UV 800-LVX 22.16 UV 800-205 21.82 UV 800-SB 3.10	Formula	PANTONE 555 C UV 800-064 66.08 UV 800-205 22.03 UV 800-190 11.89	Formula	PANTONE 556 C UV 800-LVX 79.29 UV 800-064 13.15 UV 800-205 5.88 UV 800-190 1.68	Formula	PANTONE 557 C UV 800-LVX 88.13 UV 800-064 7.19 UV 800-205 3.50 UV 800-190 1.18	Formula
PANTONE 558 C UV 800-LVX 92.96 UV 800-064 4.00 UV 800-205 2.17 UV 800-190 0.87	Formula	PANTONE 559 C UV 800-LVX 96.03 UV 800-064 2.03 UV 800-205 1.29 UV 800-190 0.65	Formula	PANTONE 5535 C UV 800-SB 47.23 UV 800-325 46.93 UV 800-064 5.84	Formula	PANTONE 5545 C UV 800-LVX 59.09 UV 800-325 21.44 UV 800-SB 15.53 UV 800-160 3.94	Formula
PANTONE 5555 C UV 800-LVX 76.05 UV 800-325 12.86 UV 800-SB 10.00 UV 800-127 1.09	Formula	PANTONE 5565 C UV 800-LVX 86.39 UV 800-325 7.55 UV 800-SB 4.88 UV 800-127 1.18	Formula	PANTONE 5575 C UV 800-LVX 93.06 UV 800-325 3.15 UV 800-SB 2.71 UV 800-205 1.08	Formula	PANTONE 5585 C UV 800-LVX 96.35 UV 800-325 1.53 UV 800-SB 1.15 UV 800-205 0.97	Formula
PANTONE 5595 C UV 800-LVX 97.45 UV 800-190 1.60 UV 800-180 0.95	Formula	PANTONE 560 C UV 800-325 37.14 UV 800-SB 31.48 UV 800-LVX 26.20 UV 800-160 5.18	Formula	PANTONE 561 C UV 800-325 48.37 UV 800-LVX 29.06 UV 800-SB 13.63 UV 800-160 8.94	Formula	PANTONE 562 C UV 800-325 58.07 UV 800-LVX 23.09 UV 800-180 11.85 UV 800-SB 5.11 UV 800-205 1.88	Formula

UVivid 800 Translucent

PANTONE 563 C UV 800-LVX 78.96 UV 800-325 16.17 UV 800-160 4.87	Formula	PANTONE 564 C UV 800-LVX 91.31 UV 800-325 7.35 UV 800-127 1.34	Formula	PANTONE 565 C UV 800-LVX 96.54 UV 800-190 1.86 UV 800-325 1.00 UV 800-160 0.60	Formula	PANTONE 566 C UV 800-LVX 98.06 UV 800-190 1.54 UV 800-160 0.40	Formula
PANTONE 5605 C UV 800-SB 47.83 UV 800-064 43.06 UV 800-190 9.11	Formula	PANTONE 5615 C UV 800-LVX 50.77 UV 800-064 22.19 UV 800-205 14.72 UV 800-021 12.32	Formula	PANTONE 5625 C UV 800-LVX 66.05 UV 800-064 15.55 UV 800-205 10.56 UV 800-021 7.84	Formula	PANTONE 5635 C UV 800-LVX 86.34 UV 800-064 5.63 UV 800-205 4.80 UV 800-021 3.23	Formula
PANTONE 5645 C UV 800-LVX 92.59 UV 800-064 4.11 UV 800-205 2.63 UV 800-155 0.67	Formula	PANTONE 5655 C UV 800-LVX 94.66 UV 800-064 2.07 UV 800-190 1.78 UV 800-155 1.49	Formula	PANTONE 5665 C UV 800-LVX 96.79 UV 800-190 1.29 UV 800-155 1.03 UV 800-064 0.89	Formula	PANTONE 567 C UV 800-325 47.22 UV 800-SB 30.65 UV 800-LVX 16.68 UV 800-160 5.45	Formula
PANTONE 568 C UV 800-325 60.90 UV 800-LVX 19.00 UV 800-SB 12.22 UV 800-160 7.88	Formula	PANTONE 569 C UV 800-325 67.65 UV 800-LVX 18.83 UV 800-180 11.59 UV 800-SB 1.93	Formula	PANTONE 570 C UV 800-LVX 87.18 UV 800-325 9.20 UV 800-190 2.06 UV 800-160 1.56	Formula	PANTONE 571 C UV 800-LVX 97.30 UV 800-190 2.70	Formula

UVivid 800 Translucent

PANTONE 572 C UV 800-LVX 97.86 UV 800-190 2.14	Formula	PANTONE 573 C UV 800-LVX 98.25 UV 800-190 1.75	Formula	PANTONE 574 C UV 800-064 56.75 UV 800-LVX 18.30 UV 800-SB 14.71 UV 800-205 10.24	Formula	PANTONE 575 C UV 800-064 60.27 UV 800-LVX 23.51 UV 800-205 12.45 UV 800-021 3.77	Formula
PANTONE 576 C UV 800-064 44.33 UV 800-LVX 43.57 UV 800-190 8.01 UV 800-155 4.09	Formula	PANTONE 577 C UV 800-LVX 85.28 UV 800-064 11.35 UV 800-190 2.32 UV 800-155 1.05	Formula	PANTONE 578 C UV 800-LVX 92.39 UV 800-064 6.17 UV 800-205 0.97 UV 800-190 0.47	Formula	PANTONE 579 C UV 800-LVX 93.33 UV 800-064 5.08 UV 800-190 1.14 UV 800-155 0.45	Formula
PANTONE 580 C UV 800-LVX 93.81 UV 800-064 4.81 UV 800-190 0.99 UV 800-155 0.39	Formula	PANTONE 5743 C UV 800-064 45.72 UV 800-LVX 25.82 UV 800-SB 19.99 UV 800-205 8.47	Formula	PANTONE 5753 C UV 800-064 42.31 UV 800-LVX 37.98 UV 800-SB 13.51 UV 800-205 6.20	Formula	PANTONE 5763 C UV 800-LVX 46.17 UV 800-064 36.94 UV 800-SB 9.45 UV 800-205 7.44	Formula
PANTONE 5773 C UV 800-LVX 76.78 UV 800-064 15.34 UV 800-SB 5.34 UV 800-205 2.54	Formula	PANTONE 5783 C UV 800-LVX 84.08 UV 800-064 8.30 UV 800-021 4.16 UV 800-205 3.46	Formula	PANTONE 5793 C UV 800-LVX 90.66 UV 800-064 5.91 UV 800-175 1.87 UV 800-205 1.56	Formula	PANTONE 5803 C UV 800-LVX 94.97 UV 800-064 3.38 UV 800-205 1.18 UV 800-155 0.47	Formula

UVivid 800 Translucent

PANTONE 5747 C UV 800-064 58.53 UV 800-SB 29.16 UV 800-325 12.31	Formula	PANTONE 5757 C UV 800-064 46.47 UV 800-LVX 36.71 UV 800-SB 14.07 UV 800-190 2.75	Formula	PANTONE 5767 C UV 800-LVX 65.04 UV 800-064 25.06 UV 800-SB 8.35 UV 800-190 1.55	Formula	PANTONE 5777 C UV 800-LVX 77.99 UV 800-064 16.71 UV 800-SB 3.67 UV 800-205 1.63	Formula
PANTONE 5787 C UV 800-LVX 88.92 UV 800-064 7.08 UV 800-021 2.16 UV 800-205 1.84	Formula	PANTONE 5797 C UV 800-LVX 91.80 UV 800-064 5.23 UV 800-021 1.56 UV 800-205 1.41	Formula	PANTONE 5807 C UV 800-LVX 96.00 UV 800-064 2.92 UV 800-205 0.78 UV 800-180 0.30	Formula	PANTONE 581 C UV 800-064 59.90 UV 800-LVX 19.24 UV 800-SB 18.96 UV 800-190 1.90	Formula
PANTONE 582 C UV 800-064 77.76 UV 800-LVX 14.31 UV 800-SB 4.90 UV 800-205 3.03	Formula	PANTONE 583 C UV 800-064 60.51 UV 800-LVX 37.13 UV 800-205 2.17 UV 800-190 0.19	Formula	PANTONE 584 C UV 800-LVX 70.62 UV 800-064 28.12 UV 800-190 0.87 UV 800-155 0.39	Formula	PANTONE 585 C UV 800-LVX 85.28 UV 800-064 14.12 UV 800-190 0.44 UV 800-155 0.16	Formula
PANTONE 586 C UV 800-LVX 88.88 UV 800-064 10.68 UV 800-190 0.34 UV 800-155 0.10	Formula	PANTONE 587 C UV 800-LVX 91.74 UV 800-064 8.02 UV 800-190 0.24	Formula	PANTONE 5815 C UV 800-064 64.80 UV 800-160 12.51 UV 800-SB 15.42 UV 800-190 7.27	Formula	PANTONE 5825 C UV 800-064 43.31 UV 800-LVX 34.55 UV 800-021 14.43 UV 800-205 7.71	Formula

UVivid 800 Translucent

PANTONE 5835 C UV 800-LVX 62.56 UV 800-064 24.27 UV 800-021 8.63 UV 800-205 4.54	Formula	PANTONE 5845 C UV 800-LVX 73.88 UV 800-064 16.44 UV 800-021 6.34 UV 800-205 3.34	Formula	PANTONE 5855 C UV 800-LVX 86.55 UV 800-064 8.11 UV 800-021 3.46 UV 800-205 1.88	Formula	PANTONE 5865 C UV 800-LVX 89.99 UV 800-064 6.54 UV 800-175 2.76 UV 800-190 0.71	Formula
PANTONE 5875 C UV 800-LVX 92.93 UV 800-064 4.43 UV 800-175 2.09 UV 800-190 0.55	Formula	PANTONE 600 C UV 800-LVX 94.93 UV 800-064 5.07	Formula	PANTONE 601 C UV 800-LVX 93.03 UV 800-064 6.97	Formula	PANTONE 602 C UV 800-LVX 89.66 UV 800-064 10.34	Formula
PANTONE 603 C UV 800-LVX 72.82 UV 800-064 26.98 UV 800-SB 0.20	Formula	PANTONE 604 C UV 800-LVX 60.61 UV 800-064 39.04 UV 800-SB 0.35	Formula	PANTONE 605 C UV 800-064 99.01 UV 800-SB 0.99	Formula	PANTONE 606 C UV 800-064 97.32 UV 800-021 1.70 UV 800-SB 0.98	Formula
PANTONE 607 C UV 800-LVX 95.88 UV 800-064 3.98 UV 800-SB 0.14	Formula	PANTONE 608 C UV 800-LVX 92.50 UV 800-064 7.17 UV 800-SB 0.33	Formula	PANTONE 609 C UV 800-LVX 89.23 UV 800-064 10.30 UV 800-SB 0.47	Formula	PANTONE 610 C UV 800-LVX 78.99 UV 800-064 20.07 UV 800-SB 0.94	Formula

UVivid 800 Translucent

PANTONE 611 C UV 800-LVX 63.94 UV 800-064 34.49 UV 800-SB 1.57	Formula	PANTONE 612 C UV 800-064 77.94 UV 800-LVX 18.74 UV 800-SB 3.32	Formula	PANTONE 613 C UV 800-064 95.45 UV 800-SB 4.55	Formula	PANTONE 614 C UV 800-LVX 96.34 UV 800-064 2.92 UV 800-SB 0.74	Formula
PANTONE 615 C UV 800-LVX 93.63 UV 800-064 5.15 UV 800-SB 1.22	Formula	PANTONE 616 C UV 800-LVX 90.77 UV 800-064 7.54 UV 800-SB 1.69	Formula	PANTONE 617 C UV 800-LVX 81.55 UV 800-064 15.35 UV 800-SB 3.10	Formula	PANTONE 618 C UV 800-LVX 62.31 UV 800-064 31.98 UV 800-SB 5.71	Formula
PANTONE 619 C UV 800-064 46.42 UV 800-LVX 45.65 UV 800-SB 7.93	Formula	PANTONE 620 C UV 800-064 61.46 UV 800-LVX 27.05 UV 800-SB 11.49	Formula	PANTONE 621 C UV 800-LVX 96.77 UV 800-205 2.81 UV 800-190 0.42	Formula	PANTONE 622 C UV 800-LVX 86.14 UV 800-205 5.75 UV 800-325 5.72 UV 800-SB 2.39	Formula
PANTONE 623 C UV 800-LVX 80.11 UV 800-SB 10.21 UV 800-190 9.68	Formula	PANTONE 624 C UV 800-LVX 70.27 UV 800-325 16.07 UV 800-SB 10.85 UV 800-205 2.81	Formula	PANTONE 625 C UV 800-LVX 40.79 UV 800-325 34.65 UV 800-SB 19.34 UV 800-175 5.22	Formula	PANTONE 626 C UV 800-325 47.53 UV 800-SB 29.32 UV 800-LVX 21.16 UV 800-175 1.99	Formula

UVivid 800 Translucent

PANTONE 627 C UV 800-SB 38.43 UV 800-190 32.99 UV 800-064 24.62 UV 800-021 3.96	Formula	PANTONE 628 C UV 800-LVX 97.51 UV 800-205 1.61 UV 800-325 0.88	Formula	PANTONE 629 C UV 800-LVX 96.42 UV 800-190 2.16 UV 800-205 1.42	Formula	PANTONE 630 C UV 800-LVX 94.44 UV 800-190 4.06 UV 800-205 1.50	Formula
PANTONE 631 C UV 800-LVX 88.03 UV 800-190 10.61 UV 800-155 1.36	Formula	PANTONE 632 C UV 800-LVX 74.11 UV 800-190 21.29 UV 800-155 2.96 UV 800-064 1.64	Formula	PANTONE 633 C UV 800-LVX 46.14 UV 800-190 41.82 UV 800-155 6.64 UV 800-064 5.40	Formula	PANTONE 634 C UV 800-190 73.85 UV 800-LVX 11.02 UV 800-180 9.62 UV 800-064 5.51	Formula
PANTONE 635 C UV 800-LVX 96.03 UV 800-190 3.97	Formula	PANTONE 636 C UV 800-LVX 94.28 UV 800-190 5.72	Formula	PANTONE 637 C UV 800-LVX 87.30 UV 800-190 10.61 UV 800-175 2.09	Formula	PANTONE 638 C UV 800-LVX 80.59 UV 800-190 16.79 UV 800-175 2.62	Formula
PANTONE 639 C UV 800-LVX 64.05 UV 800-190 34.33 UV 800-155 1.62	Formula	PANTONE 640 C UV 800-190 55.17 UV 800-LVX 42.49 UV 800-180 2.34	Formula	PANTONE 641 C UV 800-190 97.73 UV 800-SB 2.27	Formula	PANTONE 642 C UV 800-LVX 96.09 UV 800-175 2.67 UV 800-190 1.24	Formula

UVivid 800 Translucent

PANTONE 643 C UV 800-LVX 95.23 UV 800-175 3.23 UV 800-190 1.54	Formula	PANTONE 644 C UV 800-LVX 91.33 UV 800-175 5.46 UV 800-190 3.21	Formula	PANTONE 645 C UV 800-LVX 90.46 UV 800-190 3.70 UV 800-205 3.37 UV 800-155 2.47	Formula	PANTONE 646 C UV 800-LVX 83.68 UV 800-190 8.97 UV 800-155 6.01 UV 800-205 1.34	Formula
PANTONE 647 C UV 800-LVX 63.72 UV 800-205 24.00 UV 800-064 8.27 UV 800-155 4.01	Formula	PANTONE 648 C UV 800-205 52.81 UV 800-064 18.51 UV 800-155 14.77 UV 800-LVX 13.91	Formula	PANTONE 649 C UV 800-LVX 96.15 UV 800-175 2.75 UV 800-190 1.10	Formula	PANTONE 650 C UV 800-LVX 94.83 UV 800-175 3.56 UV 800-190 1.61	Formula
PANTONE 651 C UV 800-LVX 95.37 UV 800-205 3.68 UV 800-175 0.95	Formula	PANTONE 652 C UV 800-LVX 90.98 UV 800-205 7.72 UV 800-021 1.30	Formula	PANTONE 653 C UV 800-LVX 68.79 UV 800-205 21.32 UV 800-064 7.01 UV 800-155 2.88	Formula	PANTONE 654 C UV 800-205 47.14 UV 800-LVX 28.03 UV 800-064 16.95 UV 800-155 7.88	Formula
PANTONE 655 C UV 800-205 76.74 UV 800-SB 14.26 UV 800-064 9.00	Formula	PANTONE 656 C UV 800-LVX 98.36 UV 800-205 1.64	Formula	PANTONE 657 C UV 800-LVX 86.25 UV 800-175 9.29 UV 800-190 4.46	Formula	PANTONE 658 C UV 800-LVX 78.06 UV 800-175 13.76 UV 800-190 8.18	Formula

UVivid 800 Translucent

PANTONE 659 C UV 800-LVX 65.29 UV 800-175 22.47 UV 800-190 12.24	Formula	PANTONE 660 C UV 800-205 56.74 UV 800-LVX 37.02 UV 800-190 6.24	Formula	PANTONE 661 C UV 800-205 62.80 UV 800-190 33.94 UV 800-SB 3.26	Formula	PANTONE 662 C UV 800-205 90.10 UV 800-064 9.90	Formula
PANTONE 663 C UV 800-LVX 98.01 UV 800-127 1.59 UV 800-190 0.40	Formula	PANTONE 664 C UV 800-LVX 97.65 UV 800-127 1.85 UV 800-190 0.50	Formula	PANTONE 665 C UV 800-LVX 94.59 UV 800-175 4.18 UV 800-205 1.23	Formula	PANTONE 666 C UV 800-LVX 87.05 UV 800-160 6.08 UV 800-205 4.67 UV 800-021 2.20	Formula
PANTONE 667 C UV 800-LVX 77.97 UV 800-180 11.86 UV 800-205 10.17	Formula	PANTONE 668 C UV 800-LVX 52.24 UV 800-160 18.47 UV 800-205 15.16 UV 800-021 14.13	Formula	PANTONE 669 C UV 800-160 51.85 UV 800-205 23.19 UV 800-064 19.08 UV 800-SB 5.88	Formula	PANTONE 670 C UV 800-LVX 95.44 UV 800-175 4.56	Formula
PANTONE 671 C UV 800-LVX 92.72 UV 800-175 7.28	Formula	PANTONE 672 C UV 800-LVX 87.93 UV 800-175 8.53 UV 800-160 3.54	Formula	PANTONE 673 C UV 800-LVX 84.85 UV 800-175 10.60 UV 800-155 4.55	Formula	PANTONE 674 C UV 800-175 40.73 UV 800-LVX 40.00 UV 800-160 10.67 UV 800-064 8.60	Formula

UVivid 800 Translucent

PANTONE 675 C UV 800-155 51.09 UV 800-LVX 46.14 UV 800-205 2.77	Formula	PANTONE 676 C UV 800-155 60.98 UV 800-LVX 33.54 UV 800-SB 5.48	Formula	PANTONE 677 C UV 800-LVX 96.01 UV 800-175 3.77 UV 800-205 0.22	Formula	PANTONE 678 C UV 800-LVX 94.90 UV 800-175 4.91 UV 800-205 0.19	Formula
PANTONE 679 C UV 800-LVX 93.69 UV 800-175 6.15 UV 800-205 0.16	Formula	PANTONE 680 C UV 800-LVX 91.57 UV 800-155 7.08 UV 800-190 1.35	Formula	PANTONE 681 C UV 800-LVX 82.11 UV 800-155 11.72 UV 800-021 3.36 UV 800-205 2.81	Formula	PANTONE 682 C UV 800-LVX 67.35 UV 800-155 16.02 UV 800-180 6.27 UV 800-021 5.58 UV 800-205 4.78	Formula
PANTONE 683 C UV 800-LVX 37.07 UV 800-180 26.05 UV 800-155 15.85 UV 800-021 11.99 UV 800-205 9.04	Formula	PANTONE 684 C UV 800-LVX 95.42 UV 800-175 4.24 UV 800-160 0.34	Formula	PANTONE 685 C UV 800-LVX 93.73 UV 800-175 5.24 UV 800-160 1.03	Formula	PANTONE 686 C UV 800-LVX 91.17 UV 800-160 6.39 UV 800-155 1.45 UV 800-190 0.99	Formula
PANTONE 687 C UV 800-LVX 88.22 UV 800-180 5.95 UV 800-127 5.83	Formula	PANTONE 688 C UV 800-LVX 71.92 UV 800-160 12.07 UV 800-180 11.58 UV 800-205 4.43	Formula	PANTONE 689 C UV 800-LVX 56.67 UV 800-180 28.17 UV 800-127 12.08 UV 800-190 3.08	Formula	PANTONE 690 C UV 800-021 45.58 UV 800-160 31.09 UV 800-127 16.31 UV 800-190 7.02	Formula

UVivid 800 Translucent

PANTONE 691 C UV 800-LVX 96.70 UV 800-175 3.30	Formula	PANTONE 692 C UV 800-LVX 95.56 UV 800-175 3.91 UV 800-180 0.53	Formula	PANTONE 693 C UV 800-LVX 93.69 UV 800-180 3.03 UV 800-127 2.62 UV 800-064 0.66	Formula	PANTONE 694 C UV 800-LVX 85.98 UV 800-180 9.28 UV 800-155 2.56 UV 800-190 2.18	Formula
PANTONE 695 C UV 800-LVX 79.84 UV 800-180 12.69 UV 800-127 4.28 UV 800-SB 3.19	Formula	PANTONE 696 C UV 800-LVX 59.83 UV 800-180 26.77 UV 800-SB 7.55 UV 800-127 5.85	Formula	PANTONE 697 C UV 800-LVX 49.53 UV 800-180 34.50 UV 800-SB 11.57 UV 800-127 4.40	Formula	PANTONE 698 C UV 800-LVX 96.77 UV 800-175 2.78 UV 800-160 0.45	Formula
PANTONE 699 C UV 800-LVX 95.26 UV 800-160 2.72 UV 800-175 2.02	Formula	PANTONE 700 C UV 800-LVX 93.72 UV 800-160 3.52 UV 800-155 2.37 UV 800-064 0.39	Formula	PANTONE 701 C UV 800-LVX 85.78 UV 800-180 5.31 UV 800-160 4.65 UV 800-155 3.29 UV 800-325 0.97	Formula	PANTONE 702 C UV 800-LVX 67.88 UV 800-180 16.50 UV 800-160 7.47 UV 800-155 5.40 UV 800-325 2.75	Formula
PANTONE 703 C UV 800-LVX 50.19 UV 800-180 38.88 UV 800-155 8.13 UV 800-190 2.80	Formula	PANTONE 704 C UV 800-180 71.26 UV 800-LVX 16.79 UV 800-155 7.00 UV 800-190 4.95	Formula	PANTONE 705 C UV 800-LVX 96.79 UV 800-175 3.21	Formula	PANTONE 706 C UV 800-LVX 95.55 UV 800-160 2.35 UV 800-175 2.10	Formula

UVivid 800 Translucent

PANTONE 707 C UV 800-LVX 92.73 UV 800-160 7.27	Formula	PANTONE 708 C UV 800-LVX 87.20 UV 800-160 7.63 UV 800-180 3.65 UV 800-155 1.52	Formula	PANTONE 709 C UV 800-LVX 73.31 UV 800-180 12.82 UV 800-160 10.11 UV 800-155 3.52 UV 800-325 0.24	Formula	PANTONE 710 C UV 800-LVX 51.49 UV 800-180 28.50 UV 800-160 14.56 UV 800-155 4.49 UV 800-325 0.96	Formula
PANTONE 711 C UV 800-180 55.36 UV 800-LVX 35.53 UV 800-155 8.01 UV 800-190 1.10	Formula	PANTONE 712 C UV 800-LVX 93.17 UV 800-064 3.96 UV 800-180 2.87	Formula	PANTONE 713 C UV 800-LVX 90.70 UV 800-021 9.30	Formula	PANTONE 714 C UV 800-LVX 81.31 UV 800-021 18.69	Formula
PANTONE 715 C UV 800-LVX 60.96 UV 800-021 32.24 UV 800-064 6.50 UV 800-SB 0.30	Formula	PANTONE 716 C UV 800-021 52.50 UV 800-LVX 24.33 UV 800-064 22.26 UV 800-SB 0.91	Formula	PANTONE 717 C UV 800-021 63.03 UV 800-064 36.02 UV 800-SB 0.95	Formula	PANTONE 718 C UV 800-021 73.56 UV 800-064 24.08 UV 800-SB 2.36	Formula
PANTONE 719 C UV 800-LVX 95.08 UV 800-021 4.38 UV 800-127 0.54	Formula	PANTONE 720 C UV 800-LVX 88.78 UV 800-021 10.54 UV 800-205 0.68	Formula	PANTONE 721 C UV 800-LVX 82.41 UV 800-021 16.59 UV 800-205 1.00	Formula	PANTONE 722 C UV 800-LVX 59.65 UV 800-021 37.65 UV 800-190 1.87 UV 800-SB 0.83	Formula

UVivid 800 Translucent

PANTONE 723 C UV 800-021 65.68 UV 800-LVX 30.41 UV 800-190 3.91	Formula	PANTONE 724 C UV 800-021 63.87 UV 800-064 26.83 UV 800-SB 9.30	Formula	PANTONE 725 C UV 800-021 60.13 UV 800-064 27.33 UV 800-SB 12.54	Formula	PANTONE 726 C UV 800-LVX 93.05 UV 800-021 4.80 UV 800-160 1.50 UV 800-190 0.65	Formula
PANTONE 727 C UV 800-LVX 88.76 UV 800-021 8.04 UV 800-160 2.15 UV 800-190 1.05	Formula	PANTONE 728 C UV 800-LVX 81.84 UV 800-021 13.63 UV 800-160 2.86 UV 800-190 1.67	Formula	PANTONE 729 C UV 800-LVX 70.86 UV 800-021 23.93 UV 800-SB 5.21	Formula	PANTONE 730 C UV 800-021 54.47 UV 800-LVX 36.04 UV 800-190 5.56 UV 800-160 3.93	Formula
PANTONE 731 C UV 800-021 57.07 UV 800-064 27.44 UV 800-SB 15.49	Formula	PANTONE 732 C UV 800-021 45.34 UV 800-064 33.89 UV 800-SB 20.77	Formula	PANTONE 7401 C UV 800-LVX 97.06 UV 800-064 2.33 UV 800-180 0.61	Formula	PANTONE 7402 C UV 800-LVX 94.25 UV 800-064 5.24 UV 800-155 0.51	Formula
PANTONE 7403 C UV 800-LVX 86.36 UV 800-064 12.56 UV 800-155 1.08	Formula	PANTONE 7404 C UV 800-LVX 61.07 UV 800-064 38.40 UV 800-155 0.53	Formula	PANTONE 7405 C UV 800-064 69.99 UV 800-LVX 24.76 UV 800-021 4.92 UV 800-190 0.33	Formula	PANTONE 7406 C UV 800-064 83.09 UV 800-LVX 10.24 UV 800-021 5.92 UV 800-SB 0.75	Formula

UVivid 800 Translucent

PANTONE 7407 C UV 800-LVX 64.84 UV 800-064 18.20 UV 800-021 15.11 UV 800-205 1.85	Formula	PANTONE 7408 C UV 800-064 48.15 UV 800-LVX 43.48 UV 800-021 7.69 UV 800-127 0.68	Formula	PANTONE 7409 C UV 800-064 59.92 UV 800-LVX 37.22 UV 800-155 2.86	Formula	PANTONE 7410 C UV 800-LVX 81.53 UV 800-021 16.69 UV 800-160 1.78	Formula
PANTONE 7411 C UV 800-LVX 59.55 UV 800-064 33.34 UV 800-175 4.00 UV 800-155 3.11	Formula	PANTONE 7412 C UV 800-021 49.69 UV 800-LVX 44.37 UV 800-064 3.94 UV 800-190 2.00	Formula	PANTONE 7413 C UV 800-064 63.52 UV 800-LVX 27.16 UV 800-155 8.74 UV 800-205 0.58	Formula	PANTONE 7414 C UV 800-021 70.13 UV 800-LVX 14.45 UV 800-064 12.05 UV 800-190 3.37	Formula
PANTONE 7415 C UV 800-LVX 92.23 UV 800-064 4.34 UV 800-155 1.96 UV 800-175 1.47	Formula	PANTONE 7416 C UV 800-LVX 55.41 UV 800-064 30.45 UV 800-155 14.14	Formula	PANTONE 7417 C UV 800-064 42.44 UV 800-LVX 32.53 UV 800-155 20.52 UV 800-021 4.51	Formula	PANTONE 7418 C UV 800-LVX 60.63 UV 800-180 33.98 UV 800-SB 3.42 UV 800-155 1.97	Formula
PANTONE 7419 C UV 800-160 40.61 UV 800-LVX 34.26 UV 800-021 18.92 UV 800-SB 6.21	Formula	PANTONE 7420 C UV 800-180 50.67 UV 800-175 23.56 UV 800-LVX 19.15 UV 800-SB 6.62	Formula	PANTONE 7421 C UV 800-021 41.32 UV 800-155 23.61 UV 800-SB 18.61 UV 800-LVX 16.46	Formula	PANTONE 7422 C UV 800-LVX 96.42 UV 800-175 2.48 UV 800-160 1.10	Formula

UVivid 800 Translucent

PANTONE 7423 C UV 800-LVX 66.59 UV 800-160 16.60 UV 800-180 12.62 UV 800-127 4.19	Formula	PANTONE 7424 C UV 800-160 50.26 UV 800-LVX 34.03 UV 800-180 13.46 UV 800-127 2.25	Formula	PANTONE 7425 C UV 800-LVX 48.58 UV 800-180 30.85 UV 800-155 18.08 UV 800-205 2.49	Formula	PANTONE 7426 C UV 800-180 57.83 UV 800-175 23.82 UV 800-LVX 13.83 UV 800-SB 4.52	Formula
PANTONE 7427 C UV 800-021 69.66 UV 800-155 25.43 UV 800-205 4.91	Formula	PANTONE 7428 C UV 800-LVX 35.16 UV 800-155 27.88 UV 800-SB 19.57 UV 800-021 17.39	Formula	PANTONE 7429 C UV 800-LVX 93.65 UV 800-175 5.89 UV 800-021 0.46	Formula	PANTONE 7430 C UV 800-LVX 95.35 UV 800-155 4.03 UV 800-205 0.62	Formula
PANTONE 7431 C UV 800-LVX 86.32 UV 800-155 9.60 UV 800-064 2.73 UV 800-205 1.35	Formula	PANTONE 7432 C UV 800-LVX 74.09 UV 800-155 17.22 UV 800-064 6.47 UV 800-205 2.22	Formula	PANTONE 7433 C UV 800-LVX 61.66 UV 800-155 28.00 UV 800-064 5.45 UV 800-SB 4.89	Formula	PANTONE 7434 C UV 800-LVX 45.28 UV 800-155 31.21 UV 800-021 19.32 UV 800-190 4.19	Formula
PANTONE 7435 C UV 800-LVX 48.61 UV 800-155 25.02 UV 800-180 15.55 UV 800-SB 10.82	Formula	PANTONE 7436 C UV 800-LVX 95.56 UV 800-175 4.14 UV 800-205 0.30	Formula	PANTONE 7437 C UV 800-LVX 92.08 UV 800-175 7.29 UV 800-205 0.63	Formula	PANTONE 7438 C UV 800-LVX 83.80 UV 800-175 16.20	Formula

UVivid 800 Translucent

PANTONE 7439 C UV 800-LVX 85.31 UV 800-175 10.18 UV 800-155 2.89 UV 800-190 1.62	Formula	PANTONE 7440 C UV 800-LVX 82.50 UV 800-175 12.83 UV 800-155 3.09 UV 800-SB 1.58	Formula	PANTONE 7441 C UV 800-LVX 62.18 UV 800-175 35.72 UV 800-205 2.10	Formula	PANTONE 7442 C UV 800-175 72.00 UV 800-LVX 25.22 UV 800-190 2.78	Formula
PANTONE 7443 C UV 800-LVX 95.24 UV 800-175 3.86 UV 800-190 0.90	Formula	PANTONE 7444 C UV 800-LVX 93.11 UV 800-175 4.43 UV 800-205 2.46	Formula	PANTONE 7445 C UV 800-LVX 90.14 UV 800-175 8.25 UV 800-190 1.61	Formula	PANTONE 7446 C UV 800-LVX 82.95 UV 800-175 12.03 UV 800-205 5.02	Formula
PANTONE 7447 C UV 800-LVX 69.63 UV 800-127 20.66 UV 800-SB 9.71	Formula	PANTONE 7448 C UV 800-021 38.53 UV 800-205 22.87 UV 800-LVX 20.00 UV 800-160 18.60	Formula	PANTONE 7449 C UV 800-LVX 34.96 UV 800-180 31.06 UV 800-SB 27.64 UV 800-205 6.34	Formula	PANTONE 7450 C UV 800-LVX 95.74 UV 800-175 2.23 UV 800-205 2.03	Formula
PANTONE 7451 C UV 800-LVX 92.78 UV 800-205 7.22	Formula	PANTONE 7452 C UV 800-LVX 84.34 UV 800-205 7.90 UV 800-175 7.76	Formula	PANTONE 7453 C UV 800-LVX 82.08 UV 800-175 11.09 UV 800-190 6.83	Formula	PANTONE 7454 C UV 800-LVX 84.32 UV 800-190 10.01 UV 800-155 5.67	Formula

UVivid 800 Translucent

PANTONE 7455 C UV 800-175 46.60 UV 800-LVX 29.99 UV 800-190 14.19 UV 800-325 9.22	Formula	PANTONE 7456 C UV 800-175 47.96 UV 800-LVX 29.99 UV 800-325 19.19 UV 800-190 2.86	Formula	PANTONE 7457 C UV 800-LVX 96.56 UV 800-190 1.72 UV 800-205 1.72	Formula	PANTONE 7458 C UV 800-LVX 92.67 UV 800-190 4.11 UV 800-205 2.90 UV 800-180 0.32	Formula
PANTONE 7459 C UV 800-LVX 81.63 UV 800-190 13.65 UV 800-155 3.63 UV 800-021 1.09	Formula	PANTONE 7460 C UV 800-190 55.49 UV 800-LVX 43.80 UV 800-325 0.71	Formula	PANTONE 7461 C UV 800-LVX 71.73 UV 800-190 18.90 UV 800-205 7.41 UV 800-180 1.96	Formula	PANTONE 7462 C UV 800-190 48.32 UV 800-LVX 30.00 UV 800-180 14.48 UV 800-127 7.20	Formula
PANTONE 7463 C UV 800-205 54.26 UV 800-064 27.28 UV 800-180 18.46	Formula	PANTONE 7464 C UV 800-LVX 96.66 UV 800-190 2.70 UV 800-205 0.64	Formula	PANTONE 7465 C UV 800-LVX 86.23 UV 800-190 9.46 UV 800-064 4.31	Formula	PANTONE 7466 C UV 800-LVX 69.68 UV 800-190 17.61 UV 800-325 12.71	Formula
PANTONE 7467 C UV 800-LVX 55.89 UV 800-190 24.14 UV 800-325 19.97	Formula	PANTONE 7468 C UV 800-LVX 61.95 UV 800-190 25.49 UV 800-155 8.62 UV 800-064 3.94	Formula	PANTONE 7469 C UV 800-LVX 41.60 UV 800-190 38.05 UV 800-155 13.52 UV 800-064 6.83	Formula	PANTONE 7470 C UV 800-LVX 41.13 UV 800-205 26.26 UV 800-064 23.34 UV 800-190 9.27	Formula

UVivid 800 Translucent

PANTONE 7471 C UV 800-LVX 93.87 UV 800-190 3.48 UV 800-325 2.65	Formula	PANTONE 7472 C UV 800-LVX 87.46 UV 800-190 8.27 UV 800-064 3.11 UV 800-155 1.16	Formula	PANTONE 7473 C UV 800-LVX 74.55 UV 800-190 13.99 UV 800-064 7.72 UV 800-SB 3.74	Formula	PANTONE 7474 C UV 800-LVX 60.46 UV 800-190 28.40 UV 800-SB 8.11 UV 800-064 3.03	Formula
PANTONE 7475 C UV 800-LVX 78.61 UV 800-190 10.83 UV 800-SB 10.56	Formula	PANTONE 7476 C UV 800-325 36.06 UV 800-021 27.46 UV 800-205 21.48 UV 800-LVX 15.00	Formula	PANTONE 7477 C UV 800-325 40.32 UV 800-175 32.30 UV 800-LVX 14.42 UV 800-SB 12.96	Formula	PANTONE 7478 C UV 800-LVX 92.70 UV 800-325 6.55 UV 800-064 0.75	Formula
PANTONE 7479 C UV 800-LVX 64.94 UV 800-325 22.59 UV 800-064 12.47	Formula	PANTONE 7480 C UV 800-LVX 41.53 UV 800-325 40.56 UV 800-064 17.05 UV 800-190 0.86	Formula	PANTONE 7481 C UV 800-325 45.00 UV 800-064 32.82 UV 800-LVX 20.90 UV 800-190 1.28	Formula	PANTONE 7482 C UV 800-064 43.55 UV 800-LVX 34.68 UV 800-190 21.04 UV 800-205 0.73	Formula
PANTONE 7483 C UV 800-325 36.96 UV 800-064 23.26 UV 800-SB 20.33 UV 800-LVX 19.45	Formula	PANTONE 7484 C UV 800-325 57.62 UV 800-SB 21.04 UV 800-LVX 13.15 UV 800-064 8.19	Formula	PANTONE 7485 C UV 800-LVX 98.74 UV 800-325 1.02 UV 800-SB 0.24	Formula	PANTONE 7486 C UV 800-LVX 91.89 UV 800-064 6.71 UV 800-190 1.40	Formula

UVivid 800 Translucent

PANTONE 7487 C UV 800-LVX 72.65 UV 800-064 18.91 UV 800-325 8.44	Formula	PANTONE 7488 C UV 800-LVX 49.71 UV 800-064 35.97 UV 800-325 14.32	Formula	PANTONE 7489 C UV 800-LVX 48.06 UV 800-064 39.66 UV 800-190 7.35 UV 800-175 4.93	Formula	PANTONE 7490 C UV 800-LVX 44.91 UV 800-064 42.39 UV 800-190 7.12 UV 800-SB 5.58	Formula
PANTONE 7491 C UV 800-LVX 43.90 UV 800-064 42.34 UV 800-190 4.28 UV 800-SB 9.48	Formula	PANTONE 7492 C UV 800-LVX 86.99 UV 800-064 11.68 UV 800-205 1.33	Formula	PANTONE 7493 C UV 800-LVX 88.76 UV 800-064 8.18 UV 800-205 2.04 UV 800-021 1.02	Formula	PANTONE 7494 C UV 800-LVX 88.26 UV 800-064 5.92 UV 800-SB 3.86 UV 800-190 1.96	Formula
PANTONE 7495 C UV 800-LVX 46.33 UV 800-064 44.49 UV 800-SB 6.48 UV 800-190 2.70	Formula	PANTONE 7496 C UV 800-064 64.69 UV 800-LVX 14.70 UV 800-325 10.44 UV 800-SB 10.17	Formula	PANTONE 7497 C UV 800-LVX 73.63 UV 800-SB 16.37 UV 800-064 9.59 UV 800-205 0.41	Formula	PANTONE 7498 C UV 800-064 58.33 UV 800-021 23.62 UV 800-205 18.05	Formula
PANTONE 7499 C UV 800-LVX 98.24 UV 800-064 1.52 UV 800-155 0.24	Formula	PANTONE 7500 C UV 800-LVX 95.41 UV 800-064 3.85 UV 800-127 0.74	Formula	PANTONE 7501 C UV 800-LVX 92.50 UV 800-064 5.73 UV 800-127 1.77	Formula	PANTONE 7502 C UV 800-LVX 87.81 UV 800-021 6.50 UV 800-064 4.24 UV 800-205 1.45	Formula

UVivid 800 Translucent

PANTONE 7503 C UV 800-LVX 59.99 UV 800-064 28.30 UV 800-127 9.82 UV 800-205 1.89	Formula	PANTONE 7504 C UV 800-064 47.90 UV 800-175 26.96 UV 800-LVX 20.00 UV 800-205 5.14	Formula	PANTONE 7505 C UV 800-021 49.01 UV 800-325 18.42 UV 800-LVX 17.75 UV 800-175 14.82	Formula	PANTONE 7506 C UV 800-LVX 97.18 UV 800-064 2.15 UV 800-155 0.67	Formula
PANTONE 7507 C UV 800-LVX 94.82 UV 800-021 4.49 UV 800-064 0.69	Formula	PANTONE 7508 C UV 800-LVX 85.87 UV 800-021 8.45 UV 800-064 4.88 UV 800-205 0.80	Formula	PANTONE 7509 C UV 800-LVX 76.29 UV 800-021 13.42 UV 800-064 9.01 UV 800-205 1.28	Formula	PANTONE 7510 C UV 800-064 63.06 UV 800-LVX 20.00 UV 800-127 12.71 UV 800-180 4.23	Formula
PANTONE 7511 C UV 800-064 38.81 UV 800-021 38.78 UV 800-LVX 18.61 UV 800-205 3.80	Formula	PANTONE 7512 C UV 800-064 46.57 UV 800-021 44.60 UV 800-SB 8.83	Formula	PANTONE 7513 C UV 800-LVX 92.69 UV 800-021 3.92 UV 800-160 2.83 UV 800-205 0.56	Formula	PANTONE 7514 C UV 800-LVX 87.69 UV 800-021 9.68 UV 800-127 1.57 UV 800-SB 1.06	Formula
PANTONE 7515 C UV 800-LVX 60.00 UV 800-021 22.47 UV 800-160 10.86 UV 800-325 6.67	Formula	PANTONE 7516 C UV 800-021 72.33 UV 800-LVX 20.00 UV 800-205 6.48 UV 800-325 1.19	Formula	PANTONE 7517 C UV 800-021 88.28 UV 800-205 7.94 UV 800-325 3.78	Formula	PANTONE 7518 C UV 800-021 62.72 UV 800-LVX 20.00 UV 800-205 17.28	Formula

UVivid 800 Translucent

PANTONE 7519 C UV 800-021 58.52 UV 800-LVX 20.00 UV 800-205 15.62 UV 800-325 5.86	Formula	PANTONE 7520 C UV 800-LVX 93.43 UV 800-160 3.12 UV 800-021 3.08 UV 800-205 0.37	Formula	PANTONE 7521 C UV 800-LVX 76.87 UV 800-064 11.36 UV 800-175 11.07 UV 800-205 0.70	Formula	PANTONE 7522 C UV 800-LVX 63.80 UV 800-064 21.33 UV 800-155 10.93 UV 800-SB 3.94	Formula
PANTONE 7523 C UV 800-LVX 58.86 UV 800-180 23.31 UV 800-064 12.92 UV 800-205 4.91	Formula	PANTONE 7524 C UV 800-LVX 47.10 UV 800-180 28.65 UV 800-064 18.78 UV 800-205 5.47	Formula	PANTONE 7525 C UV 800-LVX 42.48 UV 800-064 37.76 UV 800-155 15.42 UV 800-190 4.34	Formula	PANTONE 7526 C UV 800-021 72.94 UV 800-SB 13.06 UV 800-LVX 8.59 UV 800-180 5.41	Formula
PANTONE 7527 C UV 800-LVX 97.42 UV 800-180 1.53 UV 800-190 1.05	Formula	PANTONE 7528 C UV 800-LVX 95.87 UV 800-SB 2.15 UV 800-175 1.98	Formula	PANTONE 7529 C UV 800-LVX 94.92 UV 800-SB 4.13 UV 800-155 0.95	Formula	PANTONE 7530 C UV 800-LVX 91.16 UV 800-SB 7.35 UV 800-180 1.49	Formula
PANTONE 7531 C UV 800-LVX 57.94 UV 800-021 32.12 UV 800-205 8.03 UV 800-190 1.91	Formula	PANTONE 7532 C UV 800-LVX 64.95 UV 800-SB 23.33 UV 800-021 11.72	Formula	PANTONE 7533 C UV 800-021 33.92 UV 800-LVX 31.73 UV 800-SB 29.29 UV 800-190 5.06	Formula	PANTONE 7534 C UV 800-LVX 97.25 UV 800-180 1.64 UV 800-190 1.11	Formula

UVivid 800 Translucent

PANTONE 7535 C	Formula
UV 800-LVX 96.10	
UV 800-SB 3.90	

PANTONE 7536 C	Formula
UV 800-LVX 84.23	
UV 800-021 8.53	
UV 800-205 3.99	
UV 800-064 3.25	

PANTONE 7537 C	Formula
UV 800-LVX 90.58	
UV 800-021 5.83	
UV 800-205 2.69	
UV 800-190 0.90	

PANTONE 7538 C	Formula
UV 800-LVX 92.81	
UV 800-SB 5.01	
UV 800-205 1.54	
UV 800-325 0.64	

PANTONE 7539 C	Formula
UV 800-LVX 91.25	
UV 800-SB 6.77	
UV 800-205 1.98	

PANTONE 7540 C	Formula
UV 800-LVX 71.46	
UV 800-SB 21.16	
UV 800-205 7.38	

PANTONE 7541 C	Formula
UV 800-LVX 98.57	
UV 800-205 1.43	

PANTONE 7542 C	Formula
UV 800-LVX 95.69	
UV 800-205 2.97	
UV 800-064 0.90	
UV 800-021 0.44	

PANTONE 7543 C	Formula
UV 800-LVX 90.70	
UV 800-175 4.79	
UV 800-190 2.45	
UV 800-SB 2.06	

PANTONE 7544 C	Formula
UV 800-LVX 89.46	
UV 800-SB 5.39	
UV 800-205 5.15	

PANTONE 7545 C	Formula
UV 800-LVX 40.00	
UV 800-064 25.24	
UV 800-205 19.99	
UV 800-160 14.77	

PANTONE 7546 C	Formula
UV 800-021 40.61	
UV 800-205 33.31	
UV 800-LVX 21.40	
UV 800-064 4.68	

PANTONE 7547 C	Formula
UV 800-SB 48.18	
UV 800-205 26.59	
UV 800-155 25.23	