

# Pelco-D Protocol Specification

## for SX800, SX801

Dec.11. 2020

Ver.2.80

FUJIFILM

## Change history

Ver.	Date			Revision
2.5	2019/7/19			First version
2.51	2010/1/31			Add SX801 as the applicable model, Add 5.7.15 Download Firmware
2.80	2020/12/11			<p>SX800, 801 FW Ver.1.40 supported</p> <ul style="list-style-type: none"> <li>- 5.5.1 Set VLC Filter: Add 4th Filter (for the specific user) to the VLC FL argument.</li> <li>- 5.2.11 Query Zoom Position: Add a command that returns the zoom position (0x5D: Query Zoom Position Response).</li> <li>- 5.6.11 Set Antialiasing: Adds a command to control ON/OFF of antialiasing on the OSD.</li> <li>- 5.6.15 Query Display Setting: Add to get the antialiasing ON/OFF status of the OSD (0x53 Query Display Setting Response)</li> <li>- 5.6.15 Query Display Setting: Add to get the display ON/OFF status for zoom bar and AF frame (0x55 Query Display Setting Response)</li> <li>- Appendix 1,2: Tables for Zoom control data vs. focal length and Focus control data vs. subject distance are attached</li> </ul>

# Table of contents

<b>1</b>	<b>SUMMARY</b> .....	<b>9</b>
<b>2</b>	<b>OVERVIEW</b> .....	<b>9</b>
<b>3</b>	<b>OVERVIEW ABOUT PELCO-D</b> .....	<b>9</b>
3.1	SEND COMMAND FORMAT .....	10
3.2	RECEIVE COMMAND FORMAT.....	11
3.2.1	Receive command (General Response) .....	11
3.2.2	Receive command (Extended Response).....	11
3.2.3	Receive command (Query Response) .....	12
3.2.4	Receive command.....	13
<b>4</b>	<b>FUNCTIONAL SPECIFICATIONS</b> .....	<b>14</b>
<b>5</b>	<b>COMMAND DETAILS</b> .....	<b>15</b>
5.1	STANDARD COMMAND .....	15
5.1.1	Send command .....	15
5.1.2	Receive command.....	16
5.2	EXTENDED COMMAND .....	17
5.2.1	Set Zoom Speed.....	17
5.2.2	Set Focus Speed .....	19
5.2.3	Auto focus on/off.....	21
5.2.4	Auto Iris on/off .....	23
5.2.5	AGC auto/on/off.....	25
5.2.6	Backlight compensation on/off.....	27

5.2.7	<Reserved> .....	28
5.2.8	Set Zoom Position .....	29
5.2.9	Set Remote Baud Rate.....	31
5.2.10	Time Set Opcode.....	33
5.2.11	Query Zoom Position (Standard).....	36
5.3	FF EXTENDED COMMAND (ORIGINAL COMMANDS OF THIS SPECIFICATION) .....	37
5.3.1	Query Focus Position .....	38
5.3.2	Query Zoom Position.....	39
5.3.3	<Reserved> .....	40
5.3.4	<Reserved> .....	40
5.3.5	Query Serial Number.....	40
5.3.6	Query Few Version.....	41
5.3.7	Query Lens Status.....	42
5.3.8	Set Focus Position.....	44
5.3.9	Set Manual Iris.....	46
5.3.10	Set Shutter Limit on Auto.....	48
5.3.11	Set Manual Shutter Speed .....	50
5.3.12	Query Manual Shutter Speed .....	54
5.3.13	Set Manual ISO .....	57
5.3.14	Query Manual ISO.....	59
5.3.15	Query Manual Iris .....	61
5.3.16	<Reserved> .....	62
5.3.17	<Reserved> .....	62
5.3.18	<Reserved> .....	62
5.3.19	<Reserved> .....	62

5.3.20	<Reserved> .....	62
5.3.21	<Reserved> .....	62
5.3.22	<Reserved> .....	62
5.3.23	Query Manual Setting (Query Manual Setting Response) .....	63
5.4	ORIGINAL COMMAND1 (ORIGINAL COMMANDS OF THIS SPECIFICATION: NO.1: PHOTO SETTING).....	65
5.4.1	Set AF Area .....	66
5.4.2	Set AF Sensitivity .....	68
5.4.3	One-push AF .....	69
5.4.4	<Reserved> .....	69
5.4.5	<Reserved> .....	69
5.4.6	Set Auto Day/Night Control Mode .....	70
5.4.7	Set Manual Day/Night.....	71
5.4.8	Set Infrared WaveLength.....	72
5.4.9	Set OIS Mode .....	73
5.4.10	<Reserved> .....	73
5.4.11	Set Photo Mode Preset .....	74
5.4.12	Set DayNight Control by External .....	75
5.4.13	<Reserved> .....	75
5.4.14	Query Photo Setting (Query Photo Setting Response) .....	76
5.5	ORIGINAL COMMAND2 ((ORIGINAL COMMANDS OF THIS SPECIFICATION: NO.2: IMAGE QUALITY PARAMETER) .....	78
5.5.1	Set VLC Filter .....	79
5.5.2	Set WideDynamicRange .....	80
5.5.3	<Reserved> .....	80
5.5.4	Set DeHeatHaze Mode.....	81
5.5.5	Set Defogging Mode.....	82

5.5.6	Set Brightness Level.....	83
5.5.7	Set Contrast Level .....	85
5.5.8	Set ColorSaturation Level.....	86
5.5.9	Set Sharpness Level .....	87
5.5.10	Set ColorTemperature on WhiteBalance .....	88
5.5.11	Set Select WhiteBalance .....	89
5.5.12	Set Digital Zoom .....	90
5.5.13	Set NR Level .....	91
5.5.14	<Reserved> .....	91
5.5.15	Query ImageQuality Setting (Query ImageQuality Setting Response).....	92
5.6	ORIGINAL COMMAND2 (ORIGINAL COMMANDS OF THIS SPECIFICATION: NO.2: IMAGEQUALITY PARAMETER) .....	94
5.6.1	Set DayTime Display .....	95
5.6.2	Set DisplayPosition of DayTime .....	96
5.6.3	Set Title Display.....	96
5.6.4	<Reserved> .....	97
5.6.5	Set DisplayPosition of Title .....	97
5.6.6	Set ID Display.....	98
5.6.7	Set DisplayPosition of ID .....	100
5.6.8	Set Center Position Display .....	101
5.6.9	<Reserved> .....	101
5.6.10	<Reserved> .....	101
5.6.11	SetAntialiasing.....	102
5.6.12	<Reserved> .....	102
5.6.13	<Reserved> .....	102
5.6.14	<Reserved> .....	102

5.6.15	Query Display Setting (Query Display Setting Response).....	103
5.7	ORIGINAL COMMAND 4 (ORIGINAL COMMANDS OF THIS SPECIFICATION: NO...4: OPERATION SETTING) .....	105
5.7.1	Set Display Mode of time.....	106
5.7.2	Set DisplayMode of YMD .....	107
5.7.3	<Reserved> .....	108
5.7.4	Set Video Mode .....	108
5.7.5	Set HD Format.....	109
5.7.6	Set VideoDisplay Mode .....	110
5.7.7	<Reserved> .....	110
5.7.8	Set RS485 ID.....	111
5.7.9	<Reserved> .....	111
5.7.10	Set Termination for RS485 .....	112
5.7.11	<Reserved> .....	112
5.7.12	Set RecordingMode on Scared .....	113
5.7.13	SetDisplay Scared Capacity Remaining .....	114
5.7.14	Format SDcard .....	115
5.7.15	Download Firmware.....	116
5.7.16	Recode LogData on SDcard.....	117
5.7.17	Preset parameters .....	118
5.7.18	Reboot .....	119
5.7.19	Set Language .....	120
5.7.20	<Reserved> .....	121
5.7.21	<Reserved> .....	121
5.7.22	<Reserved> .....	121
5.7.23	Query Operation Setting (Query Operation Setting Response).....	121

5.8	ORIGINAL COMMAND 5 (ORIGINAL COMMANDS OF THIS SPECIFICATION: NO...5: SET KEY).....	124
5.8.1	SetEncodeMode .....	125
5.8.2	Record LiveView on SDcard.....	126
5.8.3	Set 1st file of playing Movie .....	127
5.8.4	Play Movie from SDcard .....	128
5.8.5	Delete Movie from SDcard .....	129
5.8.6	Select Movie mode Play mode .....	130
5.8.7	<Reserved> .....	131
5.8.8	<Reserved> .....	131
5.8.9	<Reserved> .....	131
5.8.10	<Reserved> .....	131
5.8.11	<Reserved> .....	131
5.8.12	Set SDI ON MENU OK.....	132
5.8.13	Set Direction .....	133
5.8.14	Set Back CMD .....	134
5.8.15	Query Key Setting (Query Key Setting Response).....	135
5.9	ORIGINAL COMMAND 6 (ORIGINAL COMMANDS OF THIS SPECIFICATION : No. 6 : QUERY SDCARD) .....	137
5.9.1	Query Number of Movies on SDcard (Query Number of Movies on SDcard Response) .....	138
5.9.2	Query Year of Movie on SDcard (Query Year of Movie on SDcard Response) .....	139
5.9.3	Query MonthDay of Movie on SDcard (Query MonthDay of Movie on SDcard Response).....	140
5.9.4	Query HourMinute of Movie on SDcard (Query HourMinute of Movie on SDcard Response) .....	141

Appendix 1. Table of ZOOM Position vs Focal length

Appendix 2. Table of FOCUS Position vs Subject distance



## 1 Summary

This document specifies the Pelco-D protocol in FUJIFILM CCTV lens / cameras. The CCTV lens / cameras to which this version is applied are as follows.

Applicable model: Long Range Surveillance Camera "FUJIFILM SX800", "FUJIFILM SX801", **FW Ver.1.40 and later**

Note: The specification for "FUJIFILM SX801C" is partially different.

## 2 Overview

Pelco-D is a protocol proposed by Pelco, mainly for controlling a PTZ camera. It is a commonly published protocol and is adopted from SX800 because it is being standardized worldwide.

## 3 Overview about Pelco-D

The Pelco-D protocol is a master-slave type protocol, and up to 255 slaves can be connected to one master. The slave side does not transmit data without receiving a request from the master. The address that can be set as this specification is 31 patterns of 1 to 31 at maximum (\* RS485\_ID is 1 to 31). Communication shall be set according to the following contents.

### ■ Serial data format

Baudrate: 2400, 4800, 9600, 19200, 38400, 115200

StartBit: 1

DataLength: 8

StopBit: 1

Parity: None

### 3.1 Send command format

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	—	—	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. CMND1 is an extension command (\* When adding a command, register this)
4. CMND2 is a command for basic operation
5. Set DATA1 and DATA2 according to the contents of CMND1 and CMND2
6. Set the sum of 2<sup>nd</sup> to 6<sup>th</sup> Bytes in 8 bits to CKSM

### 3.2 Receive command format

The receive command format differs depending on the command. The commands defined by Pelco are as follows,

#### 3.2.1 Receive command (General Response)

Reply as 4 Bytes data.

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

#### 3.2.2 Receive command (Extended Response)

Reply as 7 Bytes data.

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	—	—	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set specific data for each commands to DATA1 and DATA2
5. Set the sum of ADDR to DATA2 in 8 bits is set to CKSM

### 3.2.3 Receive command (Query Response)

Reply as 18 Bytes data

Byte	1	2	3	....	17	18
	SYNC	ADDR	DATA1	....	DATA15	CKSM
	0xFF	—	—	....	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set specific data for each commands to DATA1 to DATA15
4. Set the sum of ADDR to DATA15 in 8 bits to CKSM

\* As for Query Serial Number command in this specification, set the sum of ADDR to DATA 15 in 8 bits to CKSM

### 3.2.4 Receive command

Reply as 7 Bytes data

\* The difference from Extended Response (3.2.2) is that new CMD1 and CMD2 are used instead of CMD1 and CMD2 received in RESP1 and RESP2.

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	—	—	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set RESP1, RESP2
4. Set specific data for each commands to DATA1 and DATA2
5. Set the sum of 2nd to 6th Bytes in 8 bits to CKSM

## 4 Functional specifications

The address used for communication and the baud rate are switched from software by setting.

Address => 1 to 31 (When shipped from factory or after reset, RS485\_ID=7 (= device setting ID))

Baud rate => 0 to 5 [Value: 0: 2400, 1: 4800, 2: 9600, 3: 19200, 4: 38400, 5: 115200] (When shipped from the factory or after reset, Baud rate is "2: 9600")

Pelco has specified that all commands of Standard Command described in the next chapter are automatically stopped after driving for up to 15 seconds for runaway detection, and this specification also follows this. As for timeout, if the drive command is received again before the timeout occurs, the timer is reset.

### Notes on communicating with the SX800, SX801

- SX800 and SX801 do not have the ability to queue commands, so if you issue the next send command before receiving the receive command for the previous send command, the previous command will be discarded

## 5 Command details

The commands are classified into commands defined by Pelco and commands uniquely defined in this specification.

The commands defined by Pelco are further classified into "**Standard Command**", "**Extended Command**", and "**Original Command**".

### 5.1 Standard Command

Basic commands defined by Pelco-D.

#### 5.1.1 Send command

Since Bit3-Bit7 of CMND1 is not used in the latest Pelco-D, this specification does not support either.

Bit 0 to Bit 4 of CMND2 is used as a PTZ camera control command only when this camera is in HOST mode. (※ for pan head control)

Byte 3, CMND:1							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Sense	0	0	Auto/Manual Scan	Camera On/Off	Iris Close	Iris Open	Focus Near
Byte 4, CMND:2							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Focus Far	Zoom Wide	Zoom Tele	Down	Up	Left	Right	Always 0

### 5.1.2 Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM



## 5.2 Extended Command

Extended command specified by Pelco-D.

### 5.2.1 Set Zoom Speed

Command to change zoom speed

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x25	0x00	ZOOM_SPEED	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set the speed (ZOOM\_SPEED) according to the purpose in DATA 2
6. Set the sum of 2nd to 6th Bytes in 8 bits to CKSM

#### ■ Argument of ZOOM\_SPEED

DATA2	Purpose
0x00	Slowest Speed(=Low Medium Speed)
0x01	Low Medium Speed
0x02	High Medium Speed
0x03	Highest Speed(=High Medium Speed)
Others	Low Medium Speed

\* Zoom speed can be selected from 2 levels at this specification

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

## 5.2.2 Set Focus Speed

Command to change focus speed

### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x27	0x00	FOCUS_SPEED	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set the speed (FOCUS\_SPEED) according to the purpose in DATA 2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

### ■ Argument of FOCUS\_SPEED

DATA2	Purpose
0x00	Slowest Speed(=High Medium Speed)
0x01	Low Medium Speed(=High Medium Speed)
0x02	High Medium Speed
0x03	Highest Speed(=High Medium Speed)
Others	High Medium Speed

\* Focus speed can be selected only 1 level at this specification

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

### 5.2.3 Auto focus on/off

Command to switch auto focus on / off / quick AF

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x2B	0x00	AUTO F_CTL	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set AUTO F\_CTL to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ AUTO F\_CTL 引数

DATA2	Purpose
0x00	AF on
0x01	AF off (MF)
0x02	Quick AF
Others	AF on

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

## 5.2.4 Auto Iris on/off

Command to switch auto iris on / off

### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x2D	0x00	AUTO_I_CTL	—

1. Always set 0xFF to SYNC
2. Set 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set AUTO\_I\_CTL to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

### ■ Argument of AUTO\_I\_CTL

DATA2	Purpose
0x00	Off (Manual iris)
0x01	On (Auto iris)
Others	On (Auto iris)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM



### 5.2.5 AGC auto/on/off

Command to switch AGC standard/off/Hyper

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x2F	0x00	AGC_CTL	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set AGC\_CTL to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of AGC\_CTL

DATA2	Setting
0x00	Standard
0x01	Off
0x02	Hyper
Others	Standard

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

### 5.2.6 Backlight compensation on/off

Command to switch backlight compensation on / off

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x31	0x00	BLC_CTL	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set BLC\_CT to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of BLC\_CT

DATA2	Purpose
0x00	OFF
0x01	1: Soft
0x02	2: Hard
Others	OFF

## ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

**5.2.7 <Reserved>**

### 5.2.8 Set Zoom Position

Command to set zoom position

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x4F	ZOOM_P MSB	ZOOM_P LSB	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set the zoom position (MSB) according to the purpose to DATA1
5. Set the zoom position (LSB) according to the purpose to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of ZOOM\_P

DATA1,DATA2	Purpose
0~65535	Zoom Position

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM

### 5.2.9 Set Remote Baud Rate

Command to set Remote baud rate

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x67	0x00	SET B_RARE	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the baud rate according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. Set the baud rate accordance with the oppose to DATA2
6. Set the sum of ADDT to DATA2 in 8 bits to CKSM

■ Argument of SET B\_RARE

DATA	Baud rate
0x00	2400
0x01	4800
0x02	9600(Default)
0x03	19200
0x04	38400
0x05	115200
Others	9600

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of the received CKSM and ALARMS in 8 bits to CKSM



### 5.2.10 Time Set Opcode

Command to set the clock and get the report of clock setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	SUB OP CODE	0x77	Various	Various	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set SUB OP CODE to CMND1
4. Set the command accordance with the purpose to CMND2
5. Set the value which are selected by SUB OP CODE to DATA1 and DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Argument of SUB OP CODE

Set binary numbers to Second, Minute, Hour, Month, Day, and Year.

In addition, for example, when 24 or more numbers is put into Hour, it is ignored.

CMND1	DATA1	DATA2	Purpose
0x00	Second		Set second (0x00-0x3B) and synchronize time
0x01	0x00	0x00	Report second
0x02	Hour	Minute	Set hour(0x00-0x17) and minute
0x03	0x00	0x00	Report hour and minute
0x04	Month	Day	Set month(0x01-0x0C) and date(0x01-0x1F)
0x05	0x00	0x00	Report month and date
0x06	Year		Set year (2019 => 0x07E3)
0x07	0x00	0x00	Report year
Other	0x00	0x00	Invalid (no reaction)

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	—	—	Various	Various	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. As for RESP1, set 0x01(ACK) or 0x00(NAK) when setting and set received CMND1 when getting the report.
4. As for RESP2, set 0x01 when setting, and set received CMND2 when getting the report.
5. Set the value selected by SUB OP CODE to DATA1 and DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

## ■ Argument of SUB OP CODE

CMND1 of Send command	RESP1	RESP2	DATA1	DATA2	Purpose
0x00	0x01 or 0x00	0x01	0x00	0x00	Receive second (0x00-0x3B) and synchronize time
0x01	0x01	0x77	Second		Report second
0x02	0x01 or 0x00	0x01	0x00	0x00	Set hour(0x00-0x17) and minute
0x03	0x03	0x77	Hour	Minute	Report hour and minute
0x04	0x01 or 0x00	0x01	0x00	0x00	Set month(0x01-0x0C) and date(0x01-0x1F)
0x05	0x05	0x77	Month	Day	Report month and date
0x06	0x01 or 0x00	0x00	0x00	0x00	Set year (2019 => 0x07E3)
0x07	0x07	0x77	Year		Report year
Other	0x00	0x00	0x00	0x00	Invalid (no reaction)

### 5.2.11 Query Zoom Position (Standard)

Command to get the zoom position (The data to be obtained by 5.3.2 Query Zoom Position command is the same).

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x55	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

#### ■ Receive command (0x5D:Query Zoom Position Response)

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x5D	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x5D to RESP2.
4. Set requested value to DATA1 and DATA2 (Ex. 0xFF00 →DATA1:0xFF、DATA2、0x00)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

### 5.3 FF Extended Command (Original commands of this specification)

Commands specified by FF (FUJIFILM) in Extended Command

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

#### (0) Send command

Set the sum of ADDR to DATA2 in 8bit to CKSM

#### (1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

#### (2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

#### (3) Receive command (Query Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM (Original specification by FF)

#### (4) Receive command (Original specification by FF)

Set the sum of ADDR to DATA2 in 8bit to CKSM

### 5.3.1 Query Focus Position

Command to get the focus position

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x81	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2(for Response)
5. Set the sum of ADDR to DATA2 in 8bit to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x81	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2.
4. Set requested value to DATA1 and DATA2 (Ex. 0xFF00 -> DATA1:0xFF, DATA2, 0x00)
5. CKSM is the sum of ADDR to DATA2 in 8bit

### 5.3.2 Query Zoom Position

Command to get the zoom position (The data to be obtained by 5.2.11 Query Zoom Position command is the same)

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x83	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x83	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2.
4. Set requested value to DATA1 and DATA2 (Ex. 0xFF00 →DATA1:0xFF、DATA2、0x00)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

**5.3.3 <Reserved>****5.3.4 <Reserved>****5.3.5 Query Serial Number**

Command to get Serial number

## ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x89	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

## ■ Receive command

Byte	1	2	3	4	5	6	7	8	9	10	11 - 17	18
	SYNC	ADDR	DATA1	DATA2	DATA3	DATA4	DATA5	DATA6	DATA7	DATA8	DATA9-DATA15	CKSM
	0xFF	—	—	—	—	—	—	—	—	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set Serial number as ASCII codes to DATA1 to DATA8
4. Set 0x00 to DATA9 to DATA15
5. Set the sum of ADDR to DATA15 in 8 bits to CKSM (\* Note that it is different from Query Response)



### 5.3.6 Query Few Version

Command to get FW (Firmware) Version

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8B	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (For Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8B	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set major version to DATA and minor version to DATA2 (Ex. Ver1.10=DATA1:0x01,DATA2:0x10, Ver2.0A=DATA1:0x02,DATA2:0x0A)
5. Set the sum of ADDT to DATA2 in 8 bits to CKSM

### 5.3.7 Query Lens Status

Command to get the lens status

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8D	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (For Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8D	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set the lens status to DATA (See below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ DATA1 format

DATA1	Lens status	
0x00	No error	the lens work normally
0x01	Lens error	the zoom and/or the focus was stopped forcibly

### 5.3.8 Set Focus Position

Command to get the focus position

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x8F	FOCUS MSB	FOCUS LSB	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. As for DATA1 and DATA2, see below
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA1	Value
0x00~0xFF	FOCUS MSB

DATA2	内容
0x00~0xFF	FOCUS LSB

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

### 5.3.9 Set Manual Iris

Command to set F number

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x91	0x00	MANU_FNO	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA2	F number (at the wide end)
0x01	F4
0x02	F4.5
0x03	F5.0
0x04	F5.6
0x05	F6.3
0x05	F7.1
0x07	F8
0x08	F9
0x09	F10

0x0A	F12
0x0B	F13
0x0C	F14
0x0D	F16
Others	F5.6

■ Received command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

### 5.3.10 Set Shutter Limit on Auto

Command to set the lowest limit of the shutter speed at AE

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x93	0x00	A_SHUT_LIM	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA2	Value
0x00	Manual shutter : The value set by SetManualShutterSpeed command (0x00,0x95)
0x01	Auto shutter : Lowest limit 1/8 sec
0x02	Auto shutter : Lowest limit 1/15 sec
0x03	Auto shutter : Lowest limit 1/30 sec
0x04	Auto shutter : Lowest limit 1/60 sec
0x05	Auto shutter : Lowest limit 1/125 sec
Others	Auto shutter : Lowest limit 1/30 sec



■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

### 5.3.11 Set Manual Shutter Speed

Command to set the shutter speed

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x95	0x00	MANU_SHUT	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

DATA2	Shutter speed (MANU_SHUT) [sec]
0x01	1
0x02	1/1.3
0x03	1/1.6
0x04	1/2
0x05	1/2.5
0x06	1/3
0x07	1/4
0x08	1/5
0x09	1/6
0x0A	1/8
0x0B	1/10
0x0C	1/13
0x0D	1/15
0x0E	1/20
0x0F	1/25
0x10	1/30
0x11	1/40
0x12	1/50
0x13	1/60
0x14	1/80
0x15	1/100
0x16	1/120

0x17	1/125
0x18	1/160
0x19	1/200
0x1A	1/250
0x1B	1/320
0x1C	1/400
0x1D	1/500
0x1E	1/640
0x1F	1/800
0x20	1/1000
0x21	1/1250
0x22	1/1600
0x23	1/2000
0x24	1/2500
0x25	1/3200
0x26	1/4000
0x27	1/5000
0x28	1/6400
0x29	1/8000
0x2A	1/10000
0x2B	1/12800
0x2C	1/16000
0x2D	1/20000
Others	1/30

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

### 5.3.12 Query Manual Shutter Speed

Command to get the shutter speed setting

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x97	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (For Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x97	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set the shutter speed value to DATA1 (See below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

## ■ Shute speed value for DATA1

DATA1	Shutter speed value [sec]
0x01	1
0x02	1/1.3
0x03	1/1.6
0x04	1/2
0x05	1/2.5
0x06	1/3
0x07	1/4
0x08	1/5
0x09	1/6
0x0A	1/8
0x0B	1/10
0x0C	1/13
0x0D	1/15
0x0E	1/20
0x0F	1/25
0x10	1/30
0x11	1/40
0x12	1/50
0x13	1/60
0x14	1/80
0x15	1/100
0x16	1/120

0x17	1/125
0x18	1/160
0x19	1/200
0x1A	1/250
0x1B	1/320
0x1C	1/400
0x1D	1/500
0x1E	1/640
0x1F	1/800
0x20	1/1000
0x21	1/1250
0x22	1/1600
0x23	1/2000
0x24	1/2500
0x25	1/3200
0x26	1/4000
0x27	1/5000
0x28	1/6400
0x29	1/8000
0x2A	1/10000
0x2B	1/12800
0x2C	1/16000
0x2D	1/20000



### 5.3.13 Set Manual ISO

Command to set the ISO speed (sensitivity)

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x99	0x00	MANU_ISO	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1
5. As for DATA2, see below
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ ISO speed value (MANU\_ISO for DATA2)

DATA2	ISO speed (MANU_ISO)
0x01	ISO 400
0x02	ISO 500
0x03	ISO 640
0x04	ISO 800
0x05	ISO 1000
0x05	ISO 1250
0x07	ISO 1600
0x08	ISO 2000
0x09	ISO 2500

0x0A	ISO 3200
0x0B	ISO 4000
0x0C	ISO 5000
0x0D	ISO 6400
0x0E	ISO 8000
0x0F	ISO 10000
0x10	ISO 12800
0x11	ISO 25600
0x12	ISO 51200
0x13	ISO 102400
0x14	ISO 204800
0x15	ISO 409600
0x16	ISO 819200
Others	ISO 400

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to ALARMS
4. Set the sum of received CKSM and ALARMS to CKSM

### 5.3.14 Query Manual ISO

Command to get the ISO speed value

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9B	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9B	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set Manual ISO speed value to DATA1 (see below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ ISO speed value for DATA1

DATA1	ISO speed
0x01	ISO 400
0x02	ISO 500
0x03	ISO 640
0x04	ISO 800
0x05	ISO 1000
0x05	ISO 1250
0x07	ISO 1600
0x08	ISO 2000
0x09	ISO 2500
0x0A	ISO 3200
0x0B	ISO 4000
0x0C	ISO 5000
0x0D	ISO 6400
0x0E	ISO 8000
0x0F	ISO 10000
0x10	ISO 12800
0x11	ISO 25600
0x12	ISO 51200
0x13	ISO 102400
0x14	ISO 204800
0x15	ISO 409600
0x16	ISO 819200

### 5.3.15 Query Manual Iris

Command to get the F value of the iris

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9D	0x00	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the command according to the purpose to CMND1 and CMND2
4. Set 0x00 to DATA1 and DATA2 (for Response)
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0x9D	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set received CMND1 and CMND2 to RESP1 and RESP2
4. Set F value of the iris to DATA1 (See below)
5. Set 0x00 to DATA2
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ F value of iris for DATA1

DATA1	F value at the wide end
0x01	F4
0x02	F4.5
0x03	F5.0
0x04	F5.6
0x05	F6.3
0x06	F7.1
0x07	F8
0x08	F9
0x09	F10
0x0A	F12
0x0B	F13
0x0C	F14
0x0D	F16

5.3.16 <Reserved>

5.3.17 <Reserved>

5.3.18 <Reserved>

5.3.19 <Reserved>

5.3.20 <Reserved>

5.3.21 <Reserved>

5.3.22 <Reserved>

### 5.3.23 Query Manual Setting (Query Manual Setting Response)

Command to get various setting status

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0xAD	—	0x00	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
4. Set 0x00 to DATA2
5. Set the sum of ADDR to DATA2 in 8 bits to CKSM

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0x00	0xAF	—	—	—

1. Always set 0xFF to SYNC
2. Set address 1 to 31 to ADDR
3. Set 0x00 to RESP1
4. Set 0xAF to RESP2
5. Set requested value to DATA1 and DATA2 (See below for the value).
6. Set the sum of ADDR to DATA2 in 8 bits to CKSM

CMND2 set by send command	DATA1 set by receive command	DATA2 set by receive command	Setting
0x25	0x00	ZOOM_SPEED	Zoom speed
0x27	0x00	FOCUS_SPEED	Focus speed
0x2B	0x00	AUTO_F_CTL	AF On / Off / Quick AF
0x2D	0x00	AUTO_I_CTL	Auto iris On / Off
0x2F	0x00	AGC_CTL	AGC Standard / Off / Hyper
0x31	0x00	BLC_CTL	Backlight compensation On / Off
0x4F	ZOOM_MSB	ZOOM_LSB	Zoom position
0x8F	FOCUS_MSB	FOCUS_LSB	Focus position
0x91	0x00	MANU_FNO	F value of iris
0x93	0x00	A_SHUT_LIM	Slowest limit shutter speed at AE
0x95	0x00	MANU_SHUT	Shutter speed
0x99	0x00	MANU_ISO	ISO speed
Others			Invalid



## 5.4 Original Command1 (Original commands of this specification: No.1: Photo Setting)

Original commands extended by FF (FUJIFILM)

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

**(0) Send command :**

Set the sum of ADDR to DATA2 in 8bit to CKSM

**(1) Receive command (General Response):**

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

**(2) Receive command (Extended Response):**

Set the sum of ADDR to DATA2 in 8bit to CKSM

**(3) Receive command (Query Response):**

Set the sum of ADDR to DATA15 in 8bit to CKSM **(Original specification by FF)**

**(4) Receive command : (Original specification by FF)**

Set the sum of ADDR to DATA2 in 8bit to CKSM

### 5.4.1 Set AF Area

Command to set AF area

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x03	0x00	FOCUS AREA	—

1. Set 0x00 to DATA1
2. Set 0 to 9 as FOCUS AREA to DATA2

■ Argument of FOCUS AREA

DATA2	Area
0x00	Center (Fixed)
0x01	Upper left
0x02	Upper center
0x03	Upper right
0x04	Middle left
0x05	Middle of middle
0x06	Middle right
0x07	Lower left
0x08	Lower center
0x09	Lower right
Others	Center (Fixed)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

## 5.4.2 Set AF Sensitivity

Command to set sensitivity at AF

### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x05	0x00	SENS GAIN	—

1. Set 0x00 to DATA1
2. Set 1 to 3 as SENS GAIN to DATA2

### ■ Argument of SENS GAIN

DATA2	Sensitivity
0x01	Low
0x02	Middle
0x03	High
Others	Low

### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.4.3 One-push AF

Command to execute One-push AF (Valid when Auto focus is Off)

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x07	0x00	ONE_AF	—

1. Set 0x00 to DATA1
2. Set ONE\_AF to DATA2

#### ■ Argument of ONE\_AF

DATA2	Operation
0x00	Execute One-push AF
Others	Invalid

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

#### 5.4.4 <Reserved>

#### 5.4.5 <Reserved>

### 5.4.6 Set Auto Day/Night Control Mode

Set threshold of Day/Night

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x0D	0x00	DN MODE	—

1. Set 0x00 to DATA1
2. Set 0 to 3 as DN MODE to DATA2

■ Argument of DN MODE

DATA2	Threshold
0x01	Dark
0x02	Middle
0x03	Bright
Others	Middle

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.4.7 Set Manual Day/Night

Command to set Day / night manually

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x0F	0x00	DN SET	—

1. Set 0x00 to DATA1
2. Set 1 to 4 as DN SET to DATA2
3. Set the sum of 2<sup>nd</sup> to 6<sup>th</sup> Bytes in 8 bit to CKSM

■ Argument of DN SET

DATA2	Day /Night Setting
0x00	Auto
0x01	Day
0x02	Night
Others	Day

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.4.8 Set Infrared WaveLength

Command to set Infrared wavelength

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x11	0x00	IWL SET	—

1. Set 0x00 to DATA1
2. Set 1 to 4 as IWL SET to DATA2

■ Argument of IWL SET

DATA2	目的
0x00	Visible light
0x01	950 nm
0x02	940 nm
0x03	850 nm
0x04	808 nm
Others	Visible light

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—



### 5.4.9 Set OIS Mode

Command to set ON / OFF of OIS and EIS

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x13	0x00	OIS MODE	—

1. Set 0x00 to DATA1
2. Set 0 to 3 as OIS MODE to DATA2

#### ■ Argument of OIS MODE

DATA2	Setting
0x01	AUTO(default)
0x02	Only OIS ON
0x03	Only EIS ON
0x04	Off
Others	Off

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.4.10 <Reserved>

### 5.4.11 Set Photo Mode Preset

Command to set Photo mode preset

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x17	0x00	PHOTO_PRST	—

1. Set 0x00 to DATA1
2. Set 1 or 2 as PHOT\_PRST to DATA2

■ Argument of PHOTO\_PRST

DATA2	Purpose
0x01	Surveillance (Focus on resolution)
0x02	Movie (General image quality)
Others	Surveillance

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.4.12 Set DayNight Control by External

Command to switch Day / Night by DayNight trigger signal forcibly

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x19	0x00	EX_TGER	—

1. Set 0x00 to DATA1
2. Set 1 or 2 as EX\_TGER to DATA2

■ Argument of EX\_TGER

DATA2	Setting
0x01	On (DayNight trigger: valid) VLC filter
0x02	On (DayNight trigger : valid) CLEAR filter (Raw glass)
0x03	Off (DayNight trigger : invalid)
Others	Off (DayNight trigger : invalid)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.4.13 <Reserved>

#### 5.4.14 Query Photo Setting (Query Photo Setting Response)

Command to get the camera setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x1D	—	0x00	—

1. Set CMND2 of question target to DATA1 (See below for the contents of CMND2)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x1F	—	—	—

1. Set 0xF0 to RESP1
2. Set 0x1F to RESP2
3. Set the value according to the request to DATA1 and DATA2 (See below for the response)

CMND2 set by Send command	DATA1 set by Receive command	DATA2 set by Receive command	Setting
0x03	0x00	0~9	AF area setting
0x05	0x00	1~3	Sensitivity setting at AF
0x07	0x00	AF_STATUS	AF status when One-Push AF 0x00: Finished 0x01 In process 0xFF: Abnormally
0x0D	0x00	0~3	Threshold of Day/Night
0x0F	0x00	1~4	Day / Night setting manually
0x11	0x00	0~6	IR filter setting
0x13	0x00	0~3	On / Off setting of OIS
0x17	0x00	1~2	Preset of capture mode
0x19	0x00	1~2	Day / Night swatch by DayNight trigger
Others			Invalid

## 5.5 Original Command2 ((Original commands of this specification: No.2: Image Quality Parameter)

Original commands extended by FF (FUJIFILM)

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

### (0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

### (2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (Original specification by FF)

### (4) Receive command : (Original specification by FF)

Set the sum of ADDR to DATA2 in 8bit to CKSM

### 5.5.1 Set VLC Filter

Command to set the VLC (Visible Light Cut) filter

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x21	0x00	VLC FL	—

1. Set 0x00 to DATA1
2. Set VLC FL to DATA2

#### ■ Argument of VLC FL

DATA2	Setting
0x00	Off
0x01	On
0x02	4th filter (Optional filter) *
Others	Off

\* Please contact a sales representative for details.

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.2 Set WideDynamicRange

Command to set the dynamic range

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x23	0x00	D_RANGE	—

1. Set 0x00 to DATA1
2. Set D\_RANGE to DATA2

■ Argument of D\_RANGE

DATA2	Setting
0x01	Off
0x02	1
0x03	2
Other	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.3 <Reserved>



### 5.5.4 Set DeHeatHaze Mode

Command to change De-heat haze mode

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x27	0x00	DE_HEAT_MODE	—

1. Set 0x00 to DATA1
2. Set DE\_HEAT\_MOD to DATA2

#### ■ Argument of DE\_HEAT\_MODE

DATA2	Mode
0x00	Off
0x01	1
0x02	2
0x03	3
Others	Off

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.5 Set Defogging Mode

Command to change De-fogging mode

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x29	0x00	DE_FOG_MODE	—

1. Set 0x00 to DATA1
2. Set DE\_FOG\_MODE to DATA2

■ Argument of DE\_FOG

DATA2	Mode
0x00	Off
0x01	1
0x02	2
0x03	3
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.6 Set Brightness Level

Command to set the brightness

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x2B	0x00	BRIGHT_LV	—

1. Set 0x00 to DATA1
2. Set BRIGHT\_LV to DATA2

■ Agreement of BRIGHT\_LV

DATA2	Setting
0x01	1: Darkest
0x02	2
0x03	3
0x04	4
0x05	5
0x06	6
0x07	7
0x08	8
0x09	9
0x0A	10
0x0B	11 (Center : default)
0x0C	12

0x0D	13
0x0E	14
0x0F	15
0x10	16
0x11	17
0x12	18
0x13	19
0x14	20
0x15	21 : Brightest
Others	11

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.7 Set Contrast Level

Command to set the contrast

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x2D	0x00	CONT_LV	—

1. Set 0x00 to DATA1
2. Set CONT\_LV to DATA2

■ Argument of CONT\_LV

DATA2	Setting
0x01	1 : Lowest
0x02	2
0x03	3
0x04	4
0x05	5 : Highest
Others	3

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.8 Set ColorSaturation Level

Command to set the color saturation level

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x2F	0x00	COLOR_ST_LV	—

1. Set 0x00 to DATA1
2. Set COLOR\_ST\_LV to DATA2

#### ■ Argument of COLOR\_ST\_LV

DATA2	Setting
0x01	1 : Lowest
0x02	2
0x03	3
0x04	4
0x05	5 : Highest
Others	3

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.9 Set Sharpness Level

Command to set the sharpness

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x31	0x00	SHARP_LV	—

1. Set 0x00 to DATA1
2. Set SHARP\_LV to DATA2

■ Argument of SHARP\_LV

DATA2	Setting
0x01	1 : Softest
0x02	2
0x03	3
0x04	4
0x05	5 : Hardest
Others	4

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.10 Set ColorTemperature on WhiteBalance

Command to set the color temperature on the white balance

This command becomes effective when ColorTemperature (0x06) is set to DATA2 by Set Select WhiteBalance.

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x33	0x00	C_WB_TEMP	—

1. Set 0x00 to DATA1
2. Set C\_WB\_TMP to DATA2

#### ■ Argument of C\_WB\_TMP

DATA	Setting
0x01	3000K
0x02	5000K
0x03	9000K
Others	5000K

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—



### 5.5.11 Set Select WhiteBalance

Command to set the white balance

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x35	0x00	WB_SEL	—

1. Set 0x00 to DATA1
2. Set WB\_SEL to DATA2

#### ■ Argument of WB\_SEL

DATA2	Setting
0x01	Auto
0x02	Custom1 (Read preset, which can be set only by SDI menu)
0x03	Custom2 (Read preset, which can be set only by SDI menu)
0x04	Day
0x05	Cloud
0x06	ColorTemperature (Set the color temperature by Set ColorTemperature on WhiteBalance)
Others	Auto

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.12 Set Digital Zoom

Command to switch the digital zoom

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x37	0x00	D_ZOOM	—

1. Set 0x00 to DATA1
2. Set D\_ZOOM to DATA2

#### ■ Argument of D\_ZOOM

DATA2	Digital zoom
0x00	Off
0x01	On
Others	Off

#### ■ Receive mode

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.13 Set NR Level

Command to set the noise reduction level

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x39	0x00	NR_LEV	—

1. Set 0x00 to DATA1
2. Set NR\_LEV to DATA2

■ Argument of NR\_LEV

DATA2	Level
0x01	1: Weak
0x02	2: Middle
0x03	3: Strong
Others	2: Middle

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.5.14 <Reserved>

### 5.5.15 Query ImageQuality Setting (Query ImageQuality Setting Response)

Command to get the image quality setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x3D	—	0x00	—

1. Set CMND2 of question target to DATA1 (See below for the content of CMND2)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x3F	—	—	—

1. Set 0xF0 to RESP1
2. Set 0x3f to RESP2
3. Set values according to the requested content in DATA1 and DATA2 (see below for the response content)

CMND2 set by send command	DATA1 set by receive command	DATA2 set by receive command	Setting
0x21	0x00	0~2	VLC
0x23	0x00	1~3	Dynamic range
0x27	0x00	0~5	Heat haze level
0x29	0x00	0~5	De-fog level
0x2B	0x00	1~5	Brightness
0x2D	0x00	1~5	Contrast
0x2F	0x00	1~5	Color saturation
0x31	0x00	1~5	Sharpness
0x33	0x00	C_WB_TEMP	Color temperature
0x35	0x00	1~6	White balance
0x37	0x00	0~2	Digital zoom
0x39	0x00	1~3	Noise reduction
Others			Invalid

## 5.6 Original Command2 (Original commands of this specification: No.2: ImageQuality Parameter)

Original commands extended by FF (FUJIFILM)

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

### (0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

### (2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (Original specification by FF)

### (4) Receive command : (Original specification by FF)

Set the sum of ADDR to DATA2 in 8bit to CKSM

### 5.6.1 Set DayTime Display

Command to set data and time

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x43	0x00	TIME_DISP SW	—

1. Set 0x00 to DATA1
2. Set TIME\_DISP SW to DATA2

■ Argument of TIME\_DISP SW

DATA2	SW
0x00	Off
0x01	On
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.6.2 Set DisplayPosition of DayTime

Command to set the display position of DateTime

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x45	0x00	TIME_DISP POS	—

1. Set 0x00 to DATA1
2. Set TIME\_DISP POS to DATA2

■ Argument of TIME\_DISP POS

DATA2	Position
0x01	Upper right
0x02	Lower right
0x03	Upper left
0x04	Lower left
Others	Upper right

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.6.3 Set Title Display



Command to display the title

\* The title can be set by SDI menu. See the operation manual.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x47	0x00	TITLE_DISP SW	—

1. Set 0x00 to DATA1
2. Set TITLE\_DISP SW to DATA2

■ Argument of TITLE\_DISP SW

DATA2	Display
0x00	Off
0x01	On
Other	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

#### 5.6.4 <Reserved>

#### 5.6.5 Set DisplayPosition of Title

Command to set the position of the title display

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x4B	0x00	TITLE_DISP POS	—

1. Set 0x00 to DATA1
2. Set TITLE\_DISP POS to DATA2

■ Argument of TITLE\_DISP POS

DATA2	Position
0x01	Upper right
0x02	Lower right
0x03	Upper left
0x04	Lower left
Others	Upper right

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.6.6 Set ID Display

Command to display ID

\* The ID can be set by SDI menu. See the operation manual.

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x4D	0x00	DISP_ID SW	—

1. Set 0x00 to DATA1
2. Set DISP\_ID SW to DATA2

■ Argument of DISP\_ID SW

DATA2	Display
0x00	Off
0x01	On
Others	Off

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.6.7 Set DisplayPosition of ID

Command to set the display position of ID

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x4F	0x00	ID_DISP POS	—

1. Set 0x00 to DATA1
2. Set ID\_DISP POS to DATA2

■ Argument of ID\_DISP POS

DATA2	Position
0x01	Upper right
0x02	Lower right
0x03	Upper center
0x04	Lower center
0x05	Upper left
0x06	Lower left
Others	Upper right

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.6.8 Set Center Position Display

Command to display the mark in the middle

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x51	0x00	DISP_C_POS SW	—

1. Set 0x00 to DATA1
2. Set DISP\_C\_POS SW to DATA2

■ Argument of DISP\_C\_POS SW

DATA2	Display
0x00	Off (Default)
0x01	On
Others	Off

\* Display is OFF after turn on (does not hold the previous setting)

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.6.9 <Reserved>

### 5.6.10 <Reserved>

### 5.6.11 SetAntialiasing

Command to control the anti-aliasing process of OSD on/off

#### ■Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x55	0x00	ANTIALIASING SW	—

1. Set 0x00 to DATA1
2. Set ANNTIALIASING SW to DATA2

#### ■Argument of ANTIALIASING SW

DATA2	SW
0x00	Off
0x01	On (Default)
以外	On

#### ■Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.6.12 <Reserved>

5.6.13 <Reserved>

5.6.14 <Reserved>

### 5.6.15 Query Display Setting (Query Display Setting Response)

Command to get the display setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x5D	—	0x00	—

1. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x5F	—	—	—

1. Set 0xF0 to RESP1
2. Set 0x5F to RESP2
3. Set requested value to DATA1 and DATA2 (the requested values, see below)

CMND2 set by send command	DATA1 set by receive command	DATA2 set by receive command	Setting
0x43	0x00	0~1	Display of Date and Time
0x45	0x00	1~4	Display position of Date and Time
0x47	0x00	0~1	Display of Title
0x4B	0x00	1~4	Display position of Title
0x4D	0x00	0~1	Display of ID
0x4F	0x00	1~6	Display position of ID
0x51	0x00	0~1	Display of the center mark
0x53	0x00	0~1	Display of the zoom bar and AF fram ON (Display) : 1 OFF (No display): 0 (Display ON/OFF setting is doen be SetBack MCD 0xF0)
0x55	0x00	0~1	Anti-alias status for the OSD ON : 1 OFF : 0
Others			Invalid



## 5.7 Original Command 4 (Original commands of this specification: No...4: Operation Setting)

Original commands extended by FF (FUJIFILM)

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

### (0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

### (2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (Original specification by FF)

### (4) Receive command : (Original specification by FF)

Set the sum of ADDR to DATA2 in 8bit to CKSM

### 5.7.1 Set Display Mode of time

Command to switch the time display mode (24h ⇔ 12h)

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x61	0x00	HOUR12_24 SEL	—

1. Set 0x00 to DATA1
2. Set HOUR12\_24 SEL to DATA2

#### ■ Argument of HOUR12\_24 SEL

DATA2	Display mode
0x01	24h
0x02	12h
Others	24h

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.2 Set DisplayMode of YMD

Command to switch the YMD display mode

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x63	0x00	YMD SEL	—

1. Set 0x00 to DATA1
2. Set YMD SEL to DATA2

■ Argument of YMD SEL

DATA2	Display mode
0x01	Y-M-D
0x02	M-D-Y
0x03	D-M-Y
0x04	Y/M/D
0x05	M/D/Y
0x06	D/M/Y
Others	Y-M-D

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.3 <Reserved>

### 5.7.4 Set Video Mode

Command to switch the video mode (NTSC⇔PAL)

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x67	0x00	VIDEO MODE	—

1. Set 0x00 to DATA1
2. Set VIDEO MODE to DATA2

#### ■ VIDEO MODE 引数

DATA2	Video mode
0x01	NTSC
0x02	PAL
Others	NTSC

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.5 Set HD Format

Command to switch the image size of HD and the frame rate

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x69	0x00	HD_FORMAT SW	—

1. Set 0x00 to DATA1
2. Set HD\_FORMAT SW to DATA2

#### ■ Argument of HD\_FORMAT SW

DATA2	Image size (Frame rate)
0x01	1080p (30p)
0x02	720p (60p)
0x03	480p (60p)
Others	1080p (60p)

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.6 Set VideoDisplay Mode

Command to set the display mode of the video

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x6B	0x00	VIDEO_D_MODE	—

1. Set 0x00 to DATA1
2. Set VIDEO\_D\_MODE to DATA2

■ Argument of VIDEO\_D\_MODE

DATA2	Display mode
0x01	side cut
0x02	letter box
0x03	squeeze
Others	side cut

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.7 <Reserved>

### 5.7.8 Set RS485 ID

Command to set ID for RS485

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x6F	0x00	RS485_ID	—

1. Set 0x00 to DATA1
2. Set RS485\_ID to DATA2 in 16bit binary

■ Argument of RS485\_ID

DATA2	Setting
1~31	RS485 ID(Default : 7)
Others	7

\* Power OFF→ON sequence is required to reflect the settings

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.9 <Reserved>

### 5.7.10 Set Termination for RS485

Command to switch the termination of RS485

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x73	0x00	TEMINAT SW	—

1. Set 0x00 to DATA1
2. Set TEMINAT SW to DATA2

#### ■ Argument of TEMINAT SW

DATA2	Switch
0x00	Off
0x01	On
Others	Off

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.11 <Reserved>



### 5.7.12 Set RecordingMode on Scared

Command to set SD overwrite recording when card Full

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x77	0x00	SD_RECORD SW	—

1. Set 0x00 to DATA1
2. Set SD\_RECORD SW to DATA2

■ Argument of SD\_RECORD SW

DATA2	Setting
0x01	Overwrite
0x02	Stop recording (There is on/off setting to display the remaining amount)
Others	Overwrite

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.13 SetDisplay Scared Capacity Remaining

Command to set the display of remaining of SD card capacity

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x79	0x00	DISP_CARD_SW	—

1. Set 0x00 to DATA1
2. Set DISP\_CARD\_SW to DATA2

■ Argument of DISP\_CARD\_SW

DATA2	Setting
0x01	Display remaining of SD Card capacity : ON
0x02	Display remaining of SD Card capacity : OFF (Even if it is OFF, the remaining time will be displayed when it reaches 30 minutes.)
Others	Display remaining of SD Card capacity : ON

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.14 Format SDcard

Command to format SD card

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x7B	0x00	SD_FORMAT	—

1. Set 0x00 to DATA1
2. Set SD\_FORMAT to DATA2

#### ■ Argument of SD\_FORMAT

DATA2	Format
0x00	Format SD card
Others	Do nothing

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.15 Download Firmware

Command used to update FW. SX800 and SX801 cannot update FW via RS485. Therefore, even if SX800 and SX801 are installed at a remote distance and controlled by RS485, FW update needs to use Ethernet I / F.

When this command is sent, the camera automatically reboots and starts up in the simple WebUI mode, and only the FW download operation via the Ethernet I / F is enabled (Note that the IP connection settings return to the default values when you issue this command in FW version 1.30 or earlier. If you issue this command in the FW version 1.40, the settings are maintained.). After the FW download is completed, reboot automatically again and restart in Pelco mode.

\* Note: If this command is sent, it will not be possible to return via RS485, so be careful when sending the command.

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x7D	0x00	FW_DL	—

1. Set 0x00 to DATA1
2. Set FW\_DL to DATA2

#### ■ Argument of FW\_DL

DATA2	Action
0x01	Update FW
Others	Invalid

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.16 Recode LogData on SDcard

Command to copy the log data on the memory to SD card

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x7F	0x00	LOG_COPY_SD	—

1. Set 0x00 to DATA1
2. Set LOG\_COPY\_SD to DATA2

#### ■ Argument of LOG\_COPY\_SD

DATA2	Action
0x00	Does not copy
0x01	Copy the log to SD card
Others	Does not copy

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.17 Preset parameters

Command to reset parameters to factory default

\* After initializing parameters other than IP settings, the camera sends a receive command and restarts automatically.

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x81	0x00	PRESET	—

1. Set 0x00 to DATA1
2. Set PRESET to DATA2

#### ■ Argument of PRESET

DATA2	Action
0x00	Reset parameters other than IP setting
Others	Invalid

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.18 Reboot

Command to reboot

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x83	0x00	REBOOT	—

1. Set 0x00 to DATA1
2. Set REBOOT to DATA2

#### ■ Argument of REBOOT

DATA2	Action
0x01	Reboot
Others	Invalid

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.7.19 Set Language

Command to set the language

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x85	0x00	LANGUAGE	—

1. Set 0x00 to DATA1
2. Set LANGUAGE to DATA2

■ Argument of LANGUAGE

DATA2	Language
0x00	English
0x01	French
0x02	Invalid
0x03	Japanese
Others	English

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—



**5.7.20 <Reserved>****5.7.21 <Reserved>****5.7.22 <Reserved>****5.7.23 Query Operation Setting (Query Operation Setting Response)**

Command to get the camera setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x8D	—	0x00	—

1. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x8F	—	—	—

1. Set 0xF to RESP1
2. Set 0x8F to RESP2
3. Set requested value to DATA1 and DATA2 (the requested values, see below)

CMND2 set by send command	DATA1 set by receive command	DATA2 set by receive command	Setting
0x61	0x00	1~2	Data/ Time display mode(24h⇔12h)
0x63	0x00	1~6	YMD mode
0x67	0x00	1~2	Video Mode (NTSC⇔PAL)
0x69	0x00	1~4	HD image size and its frame rate
0x6B	0x00	1~3	Display mod of VIDEO
0x6F	0x00	0~255	RS485 ID
0x73	0x00	0~1	Termination of RS485
0x77	0x00	1~2	Overwrite when SD card is full
0x79	0x00	1~2	Display the remaining of SD card capacity
0x7B	0x00	FOMAT_STATUS	Status of formatting SD card 0x00: Completed 0x01: In process 0xFF: Error
0x7F	0x00	0~1	Copy the log data to SD card
0x81	0x00	0	Reset parameters to factory default
0x85	0x00	0~3	Language setting
0x8B	0x00	SD_CARD_STATUS	Status of the SD card (Status of SD_CARD_STATUS is below)
Others			Invalid

※ Status of SD\_CARD\_STATUS

SD_CARD_STATUS	Status
0x00	Normal
0x01	SD card error
0x02	Unformatted
0x03	Protected
0x04	File system error
0x05	Full
0x06	No card

◆ Status of formatable card

0x00:Normal

0x01:SD card error

0x02:Unformatted

0x04: File system error

0x05: Full

※ However, formatting may fail when status were 0x01 or 0x04

◆ Video recordable status

0x00:Normal

◆ Video playable status

0x00:Normal

0x03:Protected

0x05: Full

## 5.8 Original Command 5 (Original commands of this specification: No...5: SET KEY)

Original commands extended by FF (FUJIFILM)

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

### (0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

### (2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (Original specification by FF)

### (4) Receive command : (Original specification by FF)

Set the sum of ADDR to DATA2 in 8bit to CKSM

### 5.8.1 SetEncodeMode

Command to set the video encode format

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x91	0x00	ENCODING	—

1. Set 0x00 to DATA1
2. Set ENCODING to DATA2

■ Argument of ENCODING

DATA2	Encode format
0x01	H.264,
0x02	MJPEG
0x03	MPEG4
Others	H.264

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

## 5.8.2 Record LiveView on SDCard

Command to record the live view into SD card

### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x93	0x00	LV_RECORD	—

1. Set 0x00 to DATA1
2. Set LV\_RECORD to DATA2

### ■ Argument of LV\_RECORD

DATA2	Record
0x00	On
0x01	Off
Others	On

### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.8.3 Set 1st file of playing Movie

Command to play the first file

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDcard command (0xF0, 0xB1), and then set the target frame.

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x95	F_NO MSB	F_NO LSB	—

1. Set F\_NO MSB to DATA1

2. Set F\_NO LSB to DATA2

\* Set the file index number to playback to F\_NO

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

What is File index number:

The camera generates a table of file index numbers (F\_NO) on the memory so that the latest file is 0x0001, only for the files recorded by the SX 800 and SX801 at startup. When the file is deleted, F\_NO of the deleted file becomes an empty number until the file number table is updated next time the power is turned on.

### 5.8.4 Play Movie from SDCard

Command to set Play/Stop mode of the video file in the SD card

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x97	0x00	PLAY_SET	—

1. Set 0x00 to DATA1
2. Set PLAY\_SET to DATA2

■ Argument of PLAY\_SET

DATA2	Mode
0x00	Stop (Playback standby state: Thumbnail or inclusion JPEG displayed)
0x01	One frame playback
0x02	Continuous playback (Play from the current position in order of recording time. After the last frame, play the oldest frame in the card.)
0x03	Pause (Display freeze)
0x04	Playback again
Others	Stop (Playback standby state: Thumbnail or inclusion JPEG displayed)

\* Default is 0x00. When transitioning from the movie mode to the playback mode, it is always 0x00, and the thumbnail or included JPEG display of the latest time stamp is displayed for the frame.

■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—



### 5.8.5 Delete Movie from SDCard

Command to set the target movie number to delete from SD card

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDCard command (0xF0, 0xB1), and then set the target frame.

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x99	F_NO MSB	F_NO LSB	—

1. Set F\_NO MSB to DATA1
2. Set F\_NO LSB to DATA2

#### ■ Argument of DISP\_C\_POS SW

DATA1 + DATA2	
File index number	Delete the movie of the file index number
0x0000	All delete

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.8.6 Select Movie mode Play mode

Command to switch Movie mode/Playback mode

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0x9B	0x00	MODE_SW	—

1. Set 0x00 to DATA1
2. Set MODE\_SW to DATA2

#### ■ Argument of MODE\_SW

DATA2	Mode
0x01	Movie mode (When playing back the movie, playback is interrupted and transit to Movie mode)
0x02	Play back mode (When recording a movie, issue this command after stopping movie by 5.8.2 Record LiveView on SDcard (0xF0, 0x93))
Others	Movie mode

\* Default is 0x01

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

5.8.7 <Reserved>

5.8.8 <Reserved>

5.8.9 <Reserved>

5.8.10 <Reserved>

5.8.11 <Reserved>

### 5.8.12 Set SDI ON MENU OK

Command to switch ON/OFF of SDI display and execute MENU OK command (\* this command is available at Pelco Slave mode)

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xA7	0x00	SDI_ON	—

1. Set 0x00 to DATA1
2. Set SDI\_ON to DATA2

#### ■ Argument of SDI\_ON

DATA2	Mode
0x00	Off (SDI OFF and MENU OFF)
0x01	On (Execute instead of MENU OK key)
Others	Off (SDI OFF and MENU OFF)

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.8.13 Set Direction

Command to move cursor (\* this command is available at Pelco Slave mode)

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xA9	0x00	CURSOR	—

1. Set 0x00 to DATA1
2. Set CURSOR to DATA2

#### ■ CURSOR 引数

DATA2	Direction
0x01	Up
0x02	Down
0x03	Left
0x04	Right
Others	Invalid

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.8.14 Set Back CMD

Command to execute MENU BACK (\* this command is available at Pelco Slave mode)

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xAB	0x00	M_BACK	—

1. Set 0x00 to DATA1
2. Set M\_BACK to DATA2

#### ■ Argument of M\_BACK

DATA2	Action
0x00	Invalid
0x01	MENU BACK
Others	Invalid

#### ■ Receive command

Byte	1	2	3	4
	SYNC	ADDR	ALARMS	CKSM
	0xFF	—	0x00	—

### 5.8.15 Query Key Setting (Query Key Setting Response)

Command to get the previous key setting

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xAD	—	0x00	—

1. Set the query target CMND2 to DATA1 (the CMND2 values, see below)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xAF	—	—	—

1. Set 0xF0 to RESP1
2. Set 0xAF to RESP2
3. Set requested value to DATA1 and DATA2 (See below for the value).

CMND2 set by send command	DATA1 set by receive command	DATA2 set by receive command	Setting
0x91	0x00	1~2	Video encode format
0x93	0x00	0~1	Record Live view into SD card 0x00 On 0x01 Off
0x95	number1	number2	Play the first file
0x97	0x00	0~4	Play/Stop mode of the video file in the SD card 0x00 Stop 0x01 One frame playback 0x02 Continuous playback 0x03 Pause (Display freeze) 0x04 Playback again
0x99	number1	number2	Target movie number to delete from SD card
0x9B	0x00	1~2	Movie mode/Playback mode
0xA7	0x00	0~1	ON/OFF of SDI display
0xA9	0x00	1~4	Move cursor (0x00 when no cursor history)
0xAB	0x00	0~1	MENU BACK
Others			Invalid



## 5.9 Original Command 6 (Original commands of this specification : No. 6 : Query SDcard)

Original commands extended by FF (FUJIFILM)

The calculation method of CKSM is omitted in this chapter. That of [Chapter 3 Pelco-D outline] is adopted.

### (0) Send command :

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (1) Receive command (General Response):

Set the sum of the received CKSM and ALARMS in 8bit in CKSM

### (2) Receive command (Extended Response):

Set the sum of ADDR to DATA2 in 8bit to CKSM

### (3) Receive command (Query Response):

Set the sum of ADDR to DATA15 in 8bit to CKSM (Original specification by FF)

### (4) Receive command : (Original specification by FF)

Set the sum of ADDR to DATA2 in 8bit to CKSM

### 5.9.1 Query Number of Movies on SDcard (Query Number of Movies on SDcard Response)

Command to get the number of movie files in the SD card

■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB1	0xB3	0x00	—

1. Set the query target CMND2 to DATA1 (0xB3)
2. Set 0x00 to DATA2

■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB3	NUMBER MSB	NUMBER LSB	—

1. Set 0xF0 to RESP1
2. Set 0xB3 to RESP2
3. Set NUMBER MSB to DATA1
4. Set NUMBER LSB to DATA2

### 5.9.2 Query Year of Movie on SDcard (Query Year of Movie on SDcard Response)

Command to get the recorded year of the movie file in the SD card

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDcard command (0xF0, 0xB1), and then set the target frame.

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB5	F_NO MSB	F_NO LSB	—

1. Set F\_NO MSB to DATA1
2. Set F\_NO LSB to DATA2

\* F\_NO is the File Index number of the movie to playback

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB7	F_YY MSB	F_YY LSB	—

1. Set 0xF0 to RESP1
2. Set 0xB7 to RESP2
3. Set F\_YY MSB to DATA1
4. Set F\_YY LSB to DATA2

\* F\_YY is the recorded year represented by a 4-digit hexadecimal number (2 Bytes)

### 5.9.3 Query MonthDay of Movie on SDCard (Query MonthDay of Movie on SDCard Response)

Command to get the recorded date and month of the movie file in the SD card

How to use:

First, get the total number of the files by Query Number of Movies on SDCard(0xF0, 0xB1) command, then set the target file

#### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xB9	F_NO MSB	F_NO LSB	—

1. Set F\_NO MSB to DATA1
2. Set F\_NO LSB to DATA2

\* F\_NO is the File Index number of the movie to playback

#### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xBB	F_MM	F_DD	—

1. Set 0xF0 to RESP1
2. Set 0xB7 to RESP2
3. Set F\_MM to DATA1
4. Set F\_DD to DATA2

\* F\_MM and F\_DD are the recorded month and date

#### 5.9.4 Query HourMinute of Movie on SDcard (Query HourMinute of Movie on SDcard Response)

Command to get the recorded time of day (24h notation) of the movie file in the SD card

How to use:

First, read out the total number of movie in the SD card by Query Number of Movies on SDcard command (0xF0, 0xB1), and then set the target frame.

##### ■ Send command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	CMND1	CMND2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xBD	F_NO MSB	F_NO LSB	—

1. Set F\_NO MSB to DATA1
2. Set F\_NO LSB to DATA2

\* Fanons File Index number of the requested movie

##### ■ Receive command

Byte	1	2	3	4	5	6	7
	SYNC	ADDR	RESP1	RESP2	DATA1	DATA2	CKSM
	0xFF	—	0xF0	0xBF	F_HH	F_MM	—

1. Set 0xF0 to RESP1
2. Set 0xB7 to RESP2 (≠ 0xB7)
3. Set F\_HH(Hexadecimal) to DATA1
4. Set F\_MM(Hexadecimal)to DATA2

\* F\_HH and F\_MM are the recorded time of day (hour and minutes in 24h notation)

EOD

Appendix 1. Table of ZOOM Position vs Focal length for SX800/801 FW Ver.1.40

Lens		Field of View			Digital ZOOM : OFF				Digital ZOOM : OFF			
					Pelco (SX800,801) :		ONVIF (SX800,801) Zoom control *	Pelco (SX800,801) :		ONVIF (SX800,801) Zoom control *		
Motor Pulse	Focal Length	Vertical	Horizontal	Diagonal	CGI (SX800) :			CGI (SX800) :	CGI (SX800) :		CGI (SX800) :	
					SetAbsoluteZoomPosition	GetAbsoluteZoomPosition	SetAbsoluteZoomPosition		GetAbsoluteZoomPosition			
Steps	[mm]	[degree]			SDK(SX801) :		SDK(SX801) :	SDK(SX801) :		SDK(SX801) :		
					FF_NET_SetAbsoluteZoomPosition	FF_Net_GetAbsoluteZoomPositin		FF_NET_SetAbsoluteZoomPosition	FF_Net_GetAbsoluteZoomPositin			
					[DEC]	[HEX]	[DEC]	[DEC]	[DEC]	[HEX]	[DEC]	[DEC]
1	20.0	11.85	20.97	24.02	0	0000	1	Z < -0.95	0	0000	1	Z < -0.96
2	20.4	11.67	20.66	23.66	336	0150			269	010D		
3	20.8	11.50	20.35	23.30	672	02A0			538	021A		
4	21.2	11.32	20.03	22.95	991	03DF			793	0319		
5	21.6	11.15	19.72	22.59	1328	0530			1062	0426		
6	22.0	10.97	19.41	22.23	1680	0690	2	-0.95 <= Z < -0.90	1344	0540	2	-0.96 <= Z < -0.92
7	22.4	10.80	19.11	21.88	2016	07E0			1613	064D		
8	22.9	10.59	18.73	21.44	2353	0931			1882	075A		
9	23.3	10.42	18.42	21.09	2672	0A70			2137	0859		
10	23.7	10.25	18.12	20.75	3008	0BC0			2406	0966		
11	24.2	10.04	17.75	20.33	3361	0D21	3	-0.90 <= Z < -0.85	2689	0A81	3	-0.92 <= Z < -0.88
12	24.7	9.83	17.39	19.91	3697	0E71			2957	0B8D		
13	25.1	9.67	17.10	19.58	4033	0FC1			3226	0C9A		
14	25.6	9.47	16.75	19.17	4352	1100			3482	0D9A		
15	26.1	9.28	16.40	18.77	4688	1250			3751	0EA7		
16	26.6	9.09	16.06	18.38	5041	13B1	4	-0.85 <= Z < -0.80	4033	0FC1	4	-0.88 <= Z < -0.84
17	27.1	8.90	15.73	18.00	5377	1501			4302	10CE		
18	27.6	8.72	15.41	17.63	5713	1651			4571	11DB		
19	28.1	8.54	15.10	17.27	6033	1791			4826	12DA		
20	28.7	8.34	14.73	16.86	6369	18E1			5095	13E7		
21	29.2	8.18	14.45	16.53	6722	1A42	5	-0.80 <= Z < -0.75	5377	1501	5	-0.84 <= Z < -0.80
22	29.8	7.99	14.12	16.15	7058	1B92			5646	160E		
23	30.3	7.84	13.85	15.85	7394	1CE2			5915	171B		
24	30.9	7.67	13.56	15.51	7713	1E21			6170	181A		
25	31.5	7.52	13.28	15.19	8049	1F71			6439	1927		
26	32.1	7.37	13.01	14.89	8402	20D2	6	-0.75 <= Z < -0.70	6722	1A42	6	-0.80 <= Z < -0.76
27	32.7	7.22	12.76	14.60	8738	2222			6990	1B4E		
28	33.3	7.09	12.53	14.33	9074	2372			7259	1C5B		
29	34.0	6.94	12.27	14.03	9393	24B1			7515	1D5B		
30	34.6	6.83	12.06	13.79	9729	2601			7784	1E68		
31	35.3	6.70	11.83	13.53	10082	2762	7	-0.70 <= Z < -0.65	8066	1F82	7	-0.76 <= Z < -0.72
32	36.0	6.57	11.61	13.28	10418	28B2			8335	208F		
33	36.7	6.46	11.41	13.05	10754	2A02			8604	219C		
34	37.4	6.35	11.21	12.83	11074	2B42			8859	229B		
35	38.1	6.24	11.03	12.61	11410	2C92			9128	23A8		
36	38.8	6.14	10.85	12.41	11763	2DF3	8	-0.65 <= Z < -0.60	9410	24C2	8	-0.72 <= Z < -0.68
37	39.5	6.04	10.67	12.21	12099	2F43			9679	25CF		
38	40.3	5.93	10.48	11.99	12435	3093			9948	26DC		
39	41.0	5.83	10.31	11.80	12754	31D2			10203	27DB		
40	41.8	5.73	10.12	11.58	13090	3322			10472	28E8		
41	42.6	5.63	9.94	11.37	13443	3483	9	-0.60 <= Z < -0.55	10754	2A02	9	-0.68 <= Z < -0.64
42	43.4	5.52	9.76	11.17	13779	35D3			11023	2B0F		
43	44.3	5.41	9.57	10.95	14115	3723			11292	2C1C		
44	45.1	5.32	9.40	10.75	14435	3863			11548	2D1C		
45	46.0	5.21	9.21	10.54	14771	39B3			11816	2E28		

46	46.9	5.11	9.03	10.33	15123	3B13	10	-0.55 <= Z < -0.50	12099	2F43	10	-0.64 <= Z < -0.60
47	47.8	5.01	8.86	10.14	15460	3C64			12368	3050		
48	48.7	4.92	8.69	9.94	15796	3DB4			12636	315C		
49	49.6	4.83	8.53	9.76	16115	3EF3			12892	325C		
50	50.5	4.74	8.38	9.58	16451	4043			13161	3369		
51	51.5	4.65	8.21	9.40	16804	41A4	11	-0.50 <= Z < -0.45	13443	3483	11	-0.60 <= Z < -0.56
52	52.5	4.56	8.05	9.22	17140	42F4			13712	3590		
53	53.5	4.48	7.91	9.05	17476	4444			13981	369D		
54	54.5	4.39	7.76	8.88	17795	4583			14236	379C		
55	55.5	4.32	7.63	8.73	18131	46D3			14505	38A9		
56	56.6	4.23	7.48	8.56	18484	4834	12	-0.45 <= Z < -0.40	14787	39C3	12	-0.56 <= Z < -0.52
57	57.7	4.16	7.34	8.40	18820	4984			15056	3AD0		
58	58.8	4.08	7.21	8.25	19156	4AD4			15325	3BDD		
59	59.9	4.01	7.08	8.10	19476	4C14			15581	3CDD		
60	61.0	3.94	6.96	7.96	19812	4D64			15849	3DE9		
61	62.2	3.86	6.82	7.81	20165	4EC5	13	-0.40 <= Z < -0.35	16132	3F04	13	-0.52 <= Z < -0.48
62	63.4	3.79	6.70	7.67	20501	5015			16401	4011		
63	64.6	3.72	6.57	7.53	20837	5165			16669	411D		
64	65.8	3.65	6.46	7.39	21156	52A4			16925	421D		
65	67.1	3.58	6.33	7.25	21492	53F4			17194	432A		
66	68.4	3.51	6.21	7.11	21845	5555	14	-0.35 <= Z < -0.30	17476	4444	14	-0.48 <= Z < -0.44
67	69.7	3.44	6.10	6.98	22181	56A5			17745	4551		
68	71.0	3.38	5.99	6.85	22517	57F5			18014	465E		
69	72.4	3.32	5.87	6.72	22836	5934			18269	475D		
70	73.8	3.26	5.76	6.60	23173	5A85			18538	486A		
71	75.2	3.20	5.66	6.47	23525	5BE5	15	-0.30 <= Z < -0.25	18820	4984	15	-0.44 <= Z < -0.40
72	76.6	3.14	5.55	6.36	23861	5D35			19089	4A91		
73	78.1	3.08	5.45	6.24	24198	5E86			19358	4B9E		
74	79.6	3.02	5.35	6.12	24517	5FC5			19613	4C9D		
75	81.1	2.97	5.25	6.01	24853	6115			19882	4DAA		
76	82.7	2.91	5.15	5.89	25206	6276	16	-0.25 <= Z < -0.20	20165	4EC5	16	-0.40 <= Z < -0.36
77	84.3	2.86	5.05	5.78	25542	63C6			20433	4FD1		
78	85.9	2.81	4.95	5.68	25878	6516			20702	50DE		
79	87.5	2.76	4.86	5.57	26197	6655			20958	51DE		
80	89.2	2.70	4.77	5.47	26533	67A5			21227	52EB		
81	90.9	2.65	4.68	5.37	26886	6906	17	-0.20 <= Z < -0.15	21509	5405	17	-0.36 <= Z < -0.32
82	92.6	2.60	4.60	5.27	27222	6A56			21778	5512		
83	94.4	2.55	4.52	5.17	27558	6BA6			22047	561F		
84	96.2	2.51	4.43	5.07	27878	6CE6			22302	571E		
85	98.0	2.46	4.35	4.98	28214	6E36			22571	582B		
86	99.9	2.41	4.27	4.88	28567	6F97	18	-0.15 <= Z < -0.10	22853	5945	18	-0.32 <= Z < -0.28
87	101.8	2.37	4.20	4.79	28903	70E7			23122	5A52		
88	103.7	2.32	4.12	4.71	29239	7237			23391	5B5F		
89	105.7	2.28	4.04	4.62	29558	7376			23646	5C5E		
90	107.7	2.24	3.96	4.53	29894	74C6			23915	5D6B		
91	109.8	2.19	3.89	4.45	30247	7627	19	-0.10 <= Z < -0.05	24198	5E86	19	-0.28 <= Z < -0.24
92	111.9	2.15	3.81	4.37	30583	7777			24466	5F92		
93	114.0	2.11	3.74	4.29	30919	78C7			24735	609F		
94	116.2	2.07	3.67	4.21	31238	7A06			24991	619F		
95	118.4	2.04	3.61	4.13	31574	7B56			25260	62AC		
96	120.7	2.00	3.54	4.06	31927	7CB7	20	-0.05 <= Z < 0.00	25542	63C6	20	-0.24 <= Z < -0.20
97	123.0	1.96	3.47	3.98	32263	7E07			25811	64D3		
98	125.3	1.93	3.41	3.91	32599	7F57			26080	65E0		
99	127.7	1.89	3.35	3.84	32919	8097			26335	66DF		
100	130.1	1.86	3.29	3.77	33255	81E7			26604	67EC		
101	132.6	1.82	3.23	3.70	33608	8348	21	0.00 <= Z < 0.05	26886	6906	21	-0.20 <= Z < -0.16
102	135.1	1.79	3.17	3.63	33944	8498			27155	6A13		
103	137.7	1.76	3.11	3.56	34280	85E8			27424	6B20		
104	140.4	1.73	3.05	3.49	34599	8727			27679	6C1F		
105	143.1	1.69	3.00	3.42	34935	8877			27948	6D2C		
106	145.8	1.66	2.94	3.36	35288	89D8	22	0.05 <= Z < 0.10	28230	6E46	22	-0.16 <= Z < -0.12
107	148.6	1.63	2.89	3.30	35624	8B28			28499	6F53		
108	151.4	1.61	2.83	3.24	35960	8C78			28768	7060		
109	154.3	1.58	2.78	3.18	36280	8DB8			29024	7160		
110	157.3	1.55	2.73	3.12	36616	8F08			29292	726C		

111	160.3	1.52	2.67	3.06	36968	9068	23	0.10 <= Z < 0.15	29575	7387	23	-0.12 <= Z < -0.08
112	163.4	1.49	2.62	3.01	37305	91B9			29844	7494		
113	166.5	1.46	2.57	2.95	37641	9309			30112	75A0		
114	169.7	1.43	2.52	2.90	37960	9448			30368	76A0		
115	172.9	1.41	2.48	2.84	38296	9598			30637	77AD		
116	176.2	1.38	2.44	2.79	38649	96F9	24	0.15 <= Z < 0.20	30919	78C7	24	-0.08 <= Z < -0.04
117	179.5	1.35	2.40	2.74	38985	9849			31188	79D4		
118	183.0	1.33	2.35	2.69	39321	9999			31457	7AE1		
119	186.4	1.30	2.31	2.64	39640	9AD8			31712	7BE0		
120	190.0	1.28	2.26	2.59	39976	9C28			31981	7CED		
121	193.6	1.26	2.22	2.54	40329	9D89	25	0.20 <= Z < 0.25	32263	7E07	25	-0.04 <= Z < 0.00
122	197.3	1.24	2.18	2.49	40665	9ED9			32532	7F14		
123	201.1	1.21	2.14	2.45	41001	A029			32801	8021		
124	205.0	1.19	2.10	2.40	41321	A169			33057	8121		
125	208.9	1.17	2.06	2.36	41657	A2B9			33325	822D		
126	212.9	1.14	2.02	2.32	42010	A41A	26	0.25 <= Z < 0.30	33608	8348	26	0.00 <= Z < 0.04
127	217.0	1.12	1.99	2.27	42346	A56A			33877	8455		
128	221.1	1.10	1.95	2.23	42682	A6BA			34145	8561		
129	225.3	1.08	1.91	2.18	43001	A7F9			34401	8661		
130	229.6	1.06	1.87	2.14	43337	A949			34670	876E		
131	234.0	1.04	1.84	2.11	43690	AAAA	27	0.30 <= Z < 0.35	34952	8888	27	0.04 <= Z < 0.08
132	238.5	1.02	1.81	2.07	44026	ABFA			35221	8995		
133	243.0	1.00	1.78	2.03	44362	AD4A			35490	8AA2		
134	247.7	0.98	1.74	1.99	44681	AE89			35745	8BA1		
135	252.4	0.96	1.70	1.95	45018	AFDA			36014	8CAE		
136	257.2	0.95	1.68	1.92	45370	B13A	28	0.35 <= Z < 0.40	36296	8DC8	28	0.08 <= Z < 0.12
137	262.1	0.93	1.65	1.89	45706	B28A			36565	8ED5		
138	267.1	0.91	1.62	1.85	46043	B3DB			36834	8FE2		
139	272.2	0.89	1.59	1.81	46362	B51A			37089	90E1		
140	277.4	0.88	1.55	1.78	46698	B66A			37358	91EE		
141	282.7	0.86	1.53	1.74	47051	B7CB	29	0.40 <= Z < 0.45	37641	9309	29	0.12 <= Z < 0.16
142	288.1	0.85	1.50	1.71	47387	B91B			37909	9415		
143	293.6	0.83	1.47	1.68	47723	BA6B			38178	9522		
144	299.2	0.81	1.44	1.65	48042	BBAA			38434	9622		
145	304.9	0.80	1.41	1.63	48378	BCFA			38703	972F		
146	310.7	0.79	1.39	1.60	48731	BE5B	30	0.45 <= Z < 0.50	38985	9849	30	0.16 <= Z < 0.20
147	316.6	0.77	1.36	1.57	49067	BFAB			39254	9956		
148	322.7	0.75	1.34	1.54	49403	C0FB			39523	9A63		
149	328.8	0.74	1.32	1.51	49723	C23B			39778	9B62		
150	335.1	0.73	1.29	1.48	50059	C38B			40047	9C6F		
151	341.5	0.72	1.27	1.45	50412	C4EC	31	0.50 <= Z < 0.55	40329	9D89	31	0.20 <= Z < 0.24
152	348.0	0.70	1.25	1.43	50748	C63C			40598	9E96		
153	354.7	0.69	1.22	1.40	51084	C78C			40867	9FA3		
154	361.4	0.68	1.20	1.37	51403	C8CB			41122	AOA2		
155	368.4	0.66	1.17	1.35	51739	CA1B			41391	A1AF		
156	375.4	0.65	1.15	1.32	52092	CB7C	32	0.55 <= Z < 0.60	41674	A2CA	32	0.24 <= Z < 0.28
157	382.6	0.64	1.13	1.29	52428	CCCC			41942	A3D6		
158	389.9	0.63	1.11	1.27	52764	CE1C			42211	A4E3		
159	397.4	0.61	1.09	1.25	53083	CF5B			42467	A5E3		
160	405.0	0.60	1.07	1.22	53419	D0AB			42736	A6F0		
161	412.7	0.60	1.05	1.20	53772	D20C	33	0.60 <= Z < 0.65	43018	A80A	33	0.28 <= Z < 0.32
162	420.6	0.58	1.03	1.18	54108	D35C			43287	A917		
163	428.6	0.57	1.01	1.15	54444	D4AC			43556	AA24		
164	436.8	0.56	1.00	1.14	54764	D5EC			43811	AB23		
165	445.1	0.55	0.97	1.11	55100	D73C			44080	AC30		
166	453.6	0.54	0.95	1.09	55453	D89D	34	0.65 <= Z < 0.70	44362	AD4A	34	0.32 <= Z < 0.36
167	462.3	0.53	0.94	1.08	55789	D9ED			44631	AE57		
168	471.1	0.52	0.92	1.06	56125	DB3D			44900	AF64		
169	480.1	0.51	0.90	1.04	56444	DC7C			45155	B063		
170	489.3	0.50	0.89	1.01	56780	DDCC			45424	B170		
171	498.6	0.49	0.87	0.99	57133	DF2D	35	0.70 <= Z < 0.75	45706	B28A	35	0.36 <= Z < 0.40
172	508.1	0.48	0.85	0.98	57469	E07D			45975	B397		
173	517.8	0.47	0.84	0.96	57805	E1CD			46244	B4A4		
174	527.7	0.46	0.83	0.94	58125	E30D			46500	B5A4		
175	537.7	0.45	0.80	0.92	58461	E45D			46768	B6B0		



176	548.0	0.45	0.79	0.90	58813	E5BD	36	0.75 <= Z < 0.80	47051	B7CB	36	0.40 <= Z < 0.44
177	558.5	0.44	0.78	0.89	59150	E70E			47320	B8D8		
178	569.1	0.43	0.76	0.87	59486	E85E			47588	B9E4		
179	580.0	0.42	0.75	0.86	59805	E99D			47844	BAE4		
180	591.1	0.42	0.74	0.84	60141	EAED			48113	BBF1		
181	602.4	0.41	0.73	0.83	60494	EC4E	37	0.80 <= Z < 0.85	48395	BD0B	37	0.44 <= Z < 0.48
182	613.9	0.40	0.71	0.81	60830	ED9E			48664	BE18		
183	625.6	0.40	0.69	0.79	61166	EEEE			48933	BF25		
184	637.6	0.38	0.68	0.78	61485	F02D			49188	C024		
185	649.7	0.38	0.67	0.77	61821	F17D			49457	C131		
186	662.1	0.37	0.66	0.76	62174	F2DE	38	0.85 <= Z < 0.90	49739	C24B	38	0.48 <= Z < 0.52
187	674.7	0.37	0.65	0.73	62510	F42E			50008	C358		
188	687.6	0.36	0.63	0.72	62846	F57E			50277	C465		
189	700.7	0.35	0.62	0.71	63166	F6BE			50533	C565		
190	714.1	0.35	0.61	0.70	63502	F80E			50801	C671		
191	727.8	0.34	0.60	0.68	63855	F96F	39	0.90 <= Z < 0.95	51084	C78C	39	0.52 <= Z < 0.56
192	741.8	0.33	0.59	0.67	64191	FABF			51353	C899		
193	756.1	0.32	0.57	0.66	64527	FC0F			51621	C9A5		
194	770.7	0.32	0.57	0.65	64846	FD4E			51877	CAA5		
195	785.3	0.31	0.55	0.63	65182	FE9E			52146	CBB2		
196	800.0	0.31	0.55	0.62	65535	FFFF	40	0.95 <= Z	52428	CCCC	40	0.56 <= Z < 0.60
197	808.0	0.30	0.54	0.62					52933	CEC5		
198	816.0	0.30	0.53	0.61					53437	D0BD		
199	824.0	0.30	0.53	0.61					53941	D2B5	41	0.60 <= Z < 0.64
200	832.0	0.30	0.53	0.60					54445	D4AD		
201	840.0	0.29	0.52	0.60					54949	D6A5	42	0.64 <= Z < 0.68
202	848.0	0.29	0.51	0.59					55453	D89D		
203	856.0	0.29	0.51	0.58					55957	DA95		
204	864.0	0.29	0.51	0.58					56461	DC8D	43	0.68 <= Z < 0.72
205	872.0	0.28	0.50	0.58					56966	DE86		
206	880.0	0.28	0.50	0.57					57470	E07E	44	0.72 <= Z < 0.76
207	888.0	0.28	0.49	0.56					57974	E276		
208	896.0	0.27	0.49	0.56					58478	E46E		
209	904.0	0.27	0.49	0.56					58982	E666	45	0.76 <= Z < 0.80
210	912.0	0.27	0.48	0.55					59486	E85E		
211	920.0	0.27	0.47	0.54					59990	EA56	46	0.80 <= Z < 0.84
212	928.0	0.26	0.47	0.54					60494	EC4E		
213	936.0	0.26	0.46	0.53					60998	EE46		
214	944.0	0.26	0.46	0.53					61503	F03F	47	0.84 <= Z < 0.88
215	952.0	0.26	0.46	0.53					62007	F237		
216	960.0	0.26	0.46	0.52					62511	F42F	48	0.88 <= Z < 0.92
217	968.0	0.25	0.45	0.52					63015	F627		
218	976.0	0.25	0.45	0.51					63519	F81F		
219	984.0	0.25	0.45	0.51					64023	FA17	49	0.92 <= Z < 0.96
220	992.0	0.25	0.44	0.51					64527	FC0F		
221	1,000.0	0.25	0.44	0.50					65031	FE07		
222	1,000.0	0.25	0.44	0.50					65535	FFFF	50	0.96 <= Z

\* Note In FW version 1.4, the ONVIF control value is from -1 to +1, but originally, the ONVIF standard specifies that it should be 0 to +1. Therefore, from next FW version, ONVIF control value will be changed to 0 to +1 according to ONVIF standard.

## Appendix 2. Table of FOCUS Position vs Subject distance for SX801C FW Ver.1.40 and later

### 1. Precision Control Commands

Corresponding commands	SX801	Commands
	Pelco	Set Zoom Position (0x00,0x4F) Query Zoom Position (0x00,0x83)
	SDK	FF_NET_SetAbsoluteZoomPosition FF_Net_GetAbsoluteZoomPosition

#### FL=800mm

Focal Length	mm	20	32	51	82	132	212	341	548	800
Zoom Position	HEX	0000	20D2	41A4	6276	8348	A41A	C4EC	E5BD	FFFF
Control Resolution *	Pulse	14	35	87	219	550	1378	3458	6605	9571
		Focus Position [HEX]								
Subject Distance	10m	7DD4	7943	6FE6	5FC5	4A47	3611	2837		
	12	7F46	7BF5	7501	6932	592C	49B7	3F10		
	14	803D	7E34	78EE	7168	667A	5BF4	5439	273E	
	17	8134	7FFF	7D40	79EB	74FA	6EF4	6ADE	460F	
	20	81AF	8158	80C9	7FFF	7E82	7CF5	7B42	5B4E	2B0E
	24	822B	82B1	83ED	85C6	880B	89C5	8AA1	7024	43E6
	28	82A6	8397	85E3	8A08	8E98	92FF	95A5	7EC9	578B
	33	8322	847D	87DA	8DAE	94C0	9B77	9FAF	8C65	6A01
	40		8563	89D0	9154	9AE9	A3D3	A9AC	99D6	7C49
	47	839D	8649	8AFE	93C3	9F47	A9CC	B0B1	A346	8924
	56		86BC	8C2B	9631	A30D	AF39	B726	ABF2	950A
	67	8419	872F	8D59	9852	A66D	B3E4	BCBB	B380	9F50
	79			8E22	99D7	A935	B77A	C116	B95D	A740
	94		87A2	8E87	9B5C	AB64	BABB	C4EE	BE92	AE61
	110		8815	8F50	9C46	AD2E	BD3B	C7E6	C295	B3D7
	130	8494		8FB4	9D2F	AEC5	BF66	CA90	C635	B8CB
	160			9019	9E67	B08E	C1AE	CD54	C9F2	BDEB
	190		8888	907D	9F02	B18D	C34F	CF47	CC89	C170
	220			90E2	9F9E	B28B	C481	D0A9	CE64	C401
	270			9146	A03A	B389	C5CE	D24D	D099	C702
	320				A088	B421	C6C8	D37A	D227	C914
	380				A0D5	B4BA	C7A7	D466	D37D	CAD8
	450			91AB	A123	B520	C84D	D538	D495	CC5E
	530				A171	B585	C8D8	D5E3	D57B	CD9F
	630					B5EB	C963	D680	D64C	CEBC
	750				A1BF	B651	C9B7	D6F6	D6FB	CFAC
	890			920F		B684	CA26	D76C	D78D	D078
	1,100				A20D	B6B6	CA79	D7D5	D820	D148
	1,300					B6E9	CAB1	D817	D882	D1CB
	1,500						B71C	CACD	D84B	D22F
	1,800				A25B			CB04	D87F	D914
	2,100						B74F	CB20	D8B4	D94C
	2,500							CB3C	D8CE	D97D
	3,000							CB58	D8F5	D9AE
	3,500						B782	CB73	D910	D9D1
	4,200							CB8F	D92A	D9ED
5,000								D937	DA09	
6,000							CBAB	D944	DA1E	
7,100								D951	DA33	
8,400								D95E	DA41	
∞	850F	896E	9274	A2A8	B7B5	CBC7	D96C	DA4F	D44E	

\* Control resolution means the number of drive steps between MOD and INF.

Note) This table is a guide under normal temperature and visible light conditions.

The relationship between Focus Position and Subject Distance changes with temperature and wavelength.

#### SX801C (1000mm)用

Focal Length	mm	20	32	51	82	132	212	341	548	800	1000
Zoom Position	HEX	0000	1A42	3483	4EC5	6906	8348	9D89	B7CB	CCCC	FFFF
Control Resolution *	Pulse	14	35	87	219	550	1378	3458	6605	9571	9571
		Focus Position [HEX]									
Subject Distance	10m	7DD4	7943	6FE6	5FC5	4A47	3611	2837			
	12	7F46	7BF5	7501	6932	592C	49B7	3F10			
	14	803D	7E34	78EE	7168	667A	5BF4	5439	273E		
	17	8134	7FFF	7D40	79EB	74FA	6EF4	6ADE	460F		
	20	81AF	8158	80C9	7FFF	7E82	7CF5	7B42	5B4E	2B0E	2B0E
	24	822B	82B1	83ED	85C6	880B	89C5	8AA1	7024	43E6	43E6
	28	82A6	8397	85E3	8A08	8E98	92FF	95A5	7EC9	578B	578B
	33	8322	847D	87DA	8DAE	94C0	9B77	9FAF	8C65	6A01	6A01
	40		8563	89D0	9154	9AE9	A3D3	A9AC	99D6	7C49	7C49
	47	839D	8649	8AFE	93C3	9F47	A9CC	B0B1	A346	8924	8924
	56		86BC	8C2B	9631	A30D	AF39	B726	ABF2	950A	950A
	67	8419	872F	8D59	9852	A66D	B3E4	BCBB	B380	9F50	9F50
	79			8E22	99D7	A935	B77A	C116	B95D	A740	A740
	94		87A2	8E87	9B5C	AB64	BABB	C4EE	BE92	AE61	AE61
	110		8815	8F50	9C46	AD2E	BD3B	C7E6	C295	B3D7	B3D7
	130	8494		8FB4	9D2F	AEC5	BF66	CA90	C635	B8CB	B8CB
	160			9019	9E67	B08E	C1AE	CD54	C9F2	BDEB	BDEB
	190		8888	907D	9F02	B18D	C34F	CF47	CC89	C170	C170
	220			90E2	9F9E	B28B	C481	D0A9	CE64	C401	C401
	270			9146	A03A	B389	C5CE	D24D	D099	C702	C702
	320				A088	B421	C6C8	D37A	D227	C914	C914
	380				A0D5	B4BA	C7A7	D466	D37D	CAD8	CAD8
	450			91AB	A123	B520	C84D	D538	D495	CC5E	CC5E
	530				A171	B585	C8D8	D5E3	D57B	CD9F	CD9F
	630					B5EB	C963	D680	D64C	CEBC	CEBC
	750				A1BF	B651	C9B7	D6F6	D6FB	CFAC	CFAC
	890			920F		B684	CA26	D76C	D78D	D078	D078
	1,100				A20D	B6B6	CA79	D7D5	D820	D148	D148
	1,300					B6E9	CAB1	D817	D882	D1CB	D1CB
	1,500						B71C	CACD	D84B	D22F	D22F
	1,800				A25B			CB04	D87F	D914	D29B
	2,100						B74F	CB20	D8B4	D94C	D2E4
	2,500							CB3C	D8CE	D97D	D32C
	3,000							CB58	D8F5	D9AE	D370

	3,500					B782	CB73	D910	D9D1	D39D	D39D
	4,200						CB8F	D92A	D9ED	D3CB	D3CB
	5,000							D937	DA09	D3EF	D3EF
	6,000						CBAB	D944	DA1E	D40F	D40F
	7,100							D951	DA33	D425	D425
	8,400							D95E	DA41	D43C	D43C
	∞	850F	896E	9274	A2A8	B7B5	CBC7	D96C	DA4F	D44E	D44E

\* Control resolution means the number of drive steps between MOD and INF.  
Note: This table is a guide under normal temperature and visible light conditions.  
The relationship between Focus Position and Subject Distance changes with temperature and wavelength.

**SX801C (1200mm)用**

Focal Length	mm	20	32	51	82	132	212	341	548	800	1000	1200
Zoom Position	HEX	0000	15E1	2BC3	41A4	5785	6D66	8348	9929	AAAA	D47F	FFFF
Control Resolution *	Pulse	14	35	87	219	550	1378	3458	6605	9571	9571	9571
		Focus Position [HEX]										
Subject Distance	10m	7DD4	7943	6FE6	5FC5	4A47	3611	2837				
	12	7F46	7BF5	7501	6932	592C	49B7	3F10				
	14	803D	7E34	78EE	7168	667A	5BF4	5439	273E			
	17	8134	7FFF	7D40	79EB	74FA	6EF4	6ADE	460F			
	20	81AF	8158	80C9	7FFF	7E82	7CF5	7B42	5B4E	2B0E	2B0E	2B0E
	24	822B	82B1	83ED	85C6	880B	89C5	8AA1	7024	43E6	43E6	43E6
	28	82A6	8397	85E3	8A08	8E98	92FF	95A5	7EC9	578B	578B	578B
	33	8322	847D	87DA	8DAE	94C0	9B77	9FAF	8C65	6A01	6A01	6A01
	40		8563	89D0	9154	9AE9	A3D3	A9AC	99D6	7C49	7C49	7C49
	47	839D	8649	8AFE	93C3	9F47	A9CC	B0B1	A346	8924	8924	8924
	56		86BC	8C2B	9631	A30D	AF39	B726	ABF2	950A	950A	950A
	67	8419	872F	8D59	9852	A66D	B3E4	BCBB	B380	9F50	9F50	9F50
	79			8E22	99D7	A935	B77A	C116	B95D	A740	A740	A740
	94		87A2	8E87	9B5C	AB64	BABB	C4EE	BE92	AE61	AE61	AE61
	110		8815	8F50	9C46	AD2E	BD3B	C7E6	C295	B3D7	B3D7	B3D7
	130	8494		8FB4	9D2F	AEC5	BF66	CA90	C635	B8CB	B8CB	B8CB
	160			9019	9E67	B08E	C1AE	CD54	C9F2	BDEB	BDEB	BDEB
	190		8888	907D	9F02	B18D	C34F	CF47	CC89	C170	C170	C170
	220			90E2	9F9E	B28B	C481	D0A9	CE64	C401	C401	C401
	270			9146	A03A	B389	C5CE	D24D	D099	C702	C702	C702
	320				A088	B421	C6C8	D37A	D227	C914	C914	C914
	380				A0D5	B4BA	C7A7	D466	D37D	CAD8	CAD8	CAD8
	450			91AB	A123	B520	C84D	D538	D495	CC5E	CC5E	CC5E
	530				A171	B585	C8D8	D5E3	D57B	CD9F	CD9F	CD9F
	630					B5EB	C963	D680	D64C	CEBC	CEBC	CEBC
	750				A1BF	B651	C9B7	D6F6	D6FB	CFAC	CFAC	CFAC
	890			920F		B684	CA26	D76C	D78D	D078	D078	D078
	1,100				A20D	B6B6	CA79	D7D5	D820	D148	D148	D148
	1,300					B6E9	CAB1	D817	D882	D1CB	D1CB	D1CB
	1,500					B71C	CACD	D84B	D8C8	D22F	D22F	D22F
	1,800				A25B		CB04	D87F	D914	D29B	D29B	D29B
	2,100					B74F	CB20	D8B4	D94C	D2E4	D2E4	D2E4
	2,500						CB3C	D8CE	D97D	D32C	D32C	D32C
	3,000						CB58	D8F5	D9AE	D370	D370	D370
3,500					B782	CB73	D910	D9D1	D39D	D39D	D39D	
4,200						CB8F	D92A	D9ED	D3CB	D3CB	D3CB	
5,000							D937	DA09	D3EF	D3EF	D3EF	
6,000						CBAB	D944	DA1E	D40F	D40F	D40F	
7,100							D951	DA33	D425	D425	D425	
8,400							D95E	DA41	D43C	D43C	D43C	
∞	850F	896E	9274	A2A8	B7B5	CBC7	D96C	DA4F	D44E	D44E	D44E	

\* Control resolution means the number of drive steps between MOD and INF.  
Note: This table is a guide under normal temperature and visible light conditions.  
The relationship between Focus Position and Subject Distance changes with temperature and wavelength.

## 2. Rough Control Commands

Corresponding commands	SX801	Commands
	OnVIF Preset	Function ID 5,6 ; 1 or 8 step(s) move for near side Function ID 7,8 ; 1 or 8 step(s) move for far side
	SDK	FF_NET_SetFocus (1 step move with MOD1 or INF1) FF_NET_GetFocus

### FL=800, 1000, 1200mm

Argument	Focus Position	
	[DEC]	[HEX]
1	0	0000
2	3449	0D79
3	6898	1AF2
4	10348	286C
5	13797	35E5
6	17246	435E
7	20695	50D7
8	24144	5E50
9	27594	6BCA
10	31043	7943
11	34492	86BC
12	37941	9435
13	41391	A1AF
14	44840	AF28
15	48289	BCA1
16	51738	CA1A
17	55187	D793
18	58637	E50D
19	62086	F286
20	65535	FFFF